

DALLAS-FORT WORTH, TEXAS



GEEKY TRANSITION (GEEKY.BOOVE7)
GUTTZ TRANSITION (GUTZZ.BOOVE7)
KIILLO TRANSITION (KIILLO.BOOVE7)
SNGGGL TRANSITION (SNGGGL.BOOVE7)

NOTE: Jet aircraft only.

NOTE: For use when DFW is operating in south flow. When DFW is in north flow, file and expect the SOCK (RNAV) STAR.

NOTE: SNGGL Transition: For ABI terminal area departures only.

NOTE: KIILLO Transition: For ACT and GRK terminal area departures only.

NOTE: Chart not to scale.