

DALLAS-FORT WORTH, TEXAS



NOTE: Chart not to scale.

GEEKY TRANSITION (GEEKY.BOOVE7)
GUTTZ TRANSITION (GUTZZ.BOOVE7)
KIILLO TRANSITION (KIILLO.BOOVE7)
SNGGGL TRANSITION (SNGGGL.BOOVE7)

NOTE: Jet aircraft only.
NOTE: For use when DFW is operating in south flow. When DFW is in north flow, file and expect the SOCK (RNAV) STAR.
NOTE: SNGGL Transition: For ABI terminal area departures only.
NOTE: KIILLO Transition: For ACT and GRK terminal area departures only.

NOTE: Chart not to scale.