AIRPORT DIAGRAM
26134

AIRPORT DIAGRAM
26134

DANIEL K INOUYE INTL (HNL) (PHNL)
HONOLULU, HAWAII

DANIEL K INOUYE INTL (HNL) (PHNL)
HONOLULU, HAWAII

AL-754 (FAA)

D-ATIS
127.9 251.15
HONOLULU TOWER
118.1 257.8
123.9 273.575 (RWY 08R-26L)
GND CON
121.9 348.6
GND (RAMP CON)
121.8
CLNC DEL
121.4 281.4
PDC
D

157°57'W
157°56'W
157°55'W
21°20'N
21°19'N

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all surfaces.

VAR 11° E
JANUARY 1990
ANNUAL RATE OF CHANGE
0.1° W

JOINT BASE PEARL HARBOR-HICKAM
BASE OPS
FIRE STATION
TERMINAL
HICKAM RAMP ADVISORY
AIR FREIGHT
TRAN ALERT
HAWAII ANG
FIELD ELEV 14
HAZARDOUS CARGO PAD
ATC NON-VISIBILITY AREA
FIRE STATION
BCN
LAHSO
TWR
BAK-14
GENERAL AVIATION CARGO
FIRE STATION
CALIBRATION PAD

HS 1
HS 2
HS 3
HS 4

078°
12360 X 200
079°
12000 X 200
042°
9002 X 150
695 X 150 m
040°
5090 X 300
080°
260°
259°
220°
3000 X 150
ELEV 8
ELEV 9
ELEV 10
ELEV 0

RWY 04L-22R
PCR 740 F/B/X/T
S-120, D-250, 2D-550,
2D/2D2-1100
RWY 04R-22L
PCR 852 F/A/X/T
S-120, D-250, 2D-550,
2D/2D2-1120
RWY 08L-26R, 08R-26L
PCR 852 F/A/X/T
S-120, D-250, 2D-550,
2D/2D2-1120
RWY 08R-26L
PCR 852 F/A/X/T
S-120, D-250, 2D-550,
2D/2D2-1120

HIRL Rwys 8L-26R, 4R-22L and 8R-26L
MIRL Rwy 4L-22R
REIL Rwys 26R, 22L, 8R, 4L and 22R