AIRPORT DIAGRAM
26134

NEW YORK, NEW YORK
NEW YORK STEWART INTL (SWF)

ATIS
124.575
STEWART TOWER
121.0 254.4
GND CON
121.9

D

74°08'W
74°07'W
74°06'W
74°05'W
41°31'N
41°30'N

VAR 14° W

JANUARY 1995
ANNUAL RATE OF CHANGE
0.0° W

CARGO AREA

COMPASS CALIBRATION PAD

HS 2

HS 1

FIELD ELEV 491

ELEV 471

ELEV 467

ELEV 437

TWR

FIRE STATION

ANG RESTRICTED AREA

MC HANGAR

PASSENGER TERMINAL AND U.S. CUSTOMS

GENERAL AVIATION RAMP

AIRPORT OPERATIONS

ARMY

11817 X 150

6004 X 150

092°

272°

163°

343°

0.4% DOWN

0.6% UP

RWY 09-27
PCR 733 F/B/X/T
S-85, D-175, 2D-350, 2D/2D2-775
RWY 16-34
PCR 733 F/B/X/T
S-120, D-190, 2D-350, 2D/2D2-800

HIRL Rwys 9-27 and 16-34
REIL Rwys 27, 16 and 34
TDZL/RCLS Rwy 9

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

NEW YORK STEWART INTL (SWF)
NEW YORK, NEW YORK

AL-450 (FAA)