

HI-ILS Y or LOC Y RWY 13

LOC/DME I-PVO 109.1 Chan 28	APCH CRS 128°	Rwy Idg 10,001 TDZE 75 Arprt Elev 75
---	-------------------------	---

[USAF]

ATLANTIC CITY INTL (KACY)


DME or RADAR required

When ALS inop, increase RVR to 40 and vis to 3/4 mile.
When ALS inop, increase vis to 1 3/8 miles.



MISSED APPROACH: Climb to 600 then climbing left turn to 2000 on ACY R-090 to SMITS/ACY 11 DME and hold.

ATIS 125.725 316.15	APP CON 124.6 327.125 (130° - 309°) 134.25 292.2 (310° - 129°)	TOWER 120.3 239.0	GND CON 121.9 284.6	CLNC DEL 127.85 353.775
-------------------------------	--	-----------------------------	-------------------------------	-----------------------------------



Use I-PVO DME when on the LOC course. VGSI and ILS glidepath not coincident (VGSI Angle 3.00/TCH 71).		ELEV 75 D TDZE 75	
WEROL ACY 13 MAYBN I-PVO 4.4 RADAR JOGR I-PVO 12 ACI 34 SMITS ACY 11		ACI 34 SMITS ACY 11	
GS 3.00° TCH 58		REIL Rwy 31 HRL Rwy 4-22 and 13-31 TDZL/CL Rwy 13	
CATEGORY C D E		FAF to MAP 4.6 NM	
S-ILS 13 * 275/18 200 (200-1/2)		Knots 120 140 160 180 200	
S-LOC 13 ** 520/45 445 (500-7/8)		Min:Sec 2:18 1:58 1:43 1:32 1:23	
CIRCLING 620-1 1/2 545 (600-1 1/2) 640-2 565 (600-2) 760-2 1/2 685 (700-2 1/2)			

HI-ILS Y or LOC Y RWY 13