

VOR/DME GEE	APP CRS	Rwy Idg	N/A
108.2	085°	TDZE	N/A
Chan 19		Apt Elev	814

VOR-A


CANANDAIGUA (IUA)

DME or RADAR required.

When local altimeter setting not received, use Rochester altimeter setting and increase all MDAs 100 feet and Circling visibility all Cals ¼ SM, increase WIVRI Fix Circling minimums visibility Cat C ½ SM.

MISSED APPROACH: Climb to 2000 then climbing right turn to 3500 direct GEE VOR/DME and hold.

AWOS-3P	ROCHESTER APP CON	UNICOM
118.675	119.55 269.6	122.8 (CTAF) 0



One Minute Holding Pattern				2000	3500	GEE
3000 ← 263° → 083° → 085° → 2800				SECKY GEE 13.5 RADAR	WIVRI GEE 17	ZUDUT GEE 18.5
1580				13.5 NM	3.5 NM	1.5 NM
CATEGORY	A	B	C	D	ELEV 814	
CIRCLING	1580-1	766 (800-1)	1580-2 ¼ 766 (800-2 ¼)	NA	13 0.4% UP 3500 X 100 085°	
WIVRI FIX MINIMUMS						MIRL Rwy 13-31 0 REIL Rws 13 and 31 0
CIRCLING	1500-1	686 (700-1)	1540-2 726 (800-2)	NA	FAF to MAP 5 NM	
				Knots	60	90 120 150 180
				Min:Sec	5:00	3:20 2:30 2:00 1:40

NE-2, 17 APR 2025 to 15 MAY 2025

NE-2, 17 APR 2025 to 15 MAY 2025