


ATIS 317.6	TACAN required	Rwy	Knots	60	120	180	240	300	360
CLNC DEL		23L	⊙ V/V(fpm)	805	1610	2415	3220	4025	4830
254.4		23R	⊙ V/V(fpm)	683	1366	2049	2732	3415	4098
GND CON		32L/R	⊙ V/V(fpm)	280	560	840	1120	1400	1680
119.6 336.4									
TOWER									
127.075 360.2									
OCEANA APP/DEP CON									
123.9 266.8									

CAUTION: Departures from Rwy 32 must avoid Norfolk airspace 3.5 NM West.

ATC Climb Rate

- ⓐ to 3000
- ⓑ to 460



NOTE: Chart not to scale

▼

DEPARTURE ROUTE DESCRIPTION

TAKEOFF RWY 5L/R: Climbing right turn to intercept NTU TACAN R-080 to HHOB.

TAKEOFF RWY 14L/R: Climbing right turn to intercept NTU TACAN R-175 no later than 4 DME to WAPLS.

TAKEOFF RWY 23L/R: Climb via heading 322°, crossing NTU TACAN 3.2 DME turn left to intercept NTU R-175 no later than 7 DME to WAPLS. Cross NTU 5 DME Arc at or above 3000.

TAKEOFF RWY 32L/R: Climbing right turn heading 100° within NTU TACAN 2 DME, intercept NTU R-080 to HHOB. Do not exceed 270 KIAS on initial turn.

...Thence maintain 4000 or ATC assigned altitude.