

	DEPARTURE ROUTE DESCRIPTION
JETS:	<u>TAKEOFF RUNWAYS 13L/R:</u> Climb on heading 133°, cross CVE 13 DME at or below 6000, then maintain 8000 for RADAR vectors to appropriate route and expect filed altitude 10 minutes after departure. <u>TAKEOFF RUNWAYS 31L/R:</u> Climb on heading 313° until the I-LVF 5.5 DME or I-OVW 5.5 DME, then right turn heading 013° for RADAR vectors to the appropriate route, maintain ATC assigned altitude and expect filed altitude 10 minutes after departure. <u>BELCHER TRANSITION (DALL4.EIC):</u> From over TTT VOR/DME on TTT R-094 to POTEN, then on EIC R-259 to EIC VORTAC. <u>LITTLE ROCK TRANSITION (DALL4.LIT):</u> From over TTT VOR/DME on TTT R-064 to ORTRO, then on LIT R-237 to LIT VORTAC. <u>SOLDO TRANSITION (DALL4.SOLDO):</u> From over TTT VOR/DME on TTT R-084 to SOLDO. <u>TEXARKANA TRANSITION (DALL4.TXK):</u> From over TTT VOR/DME on TTT R-074 to SHERO, then on TXK R-244 to TXK VORTAC.