CENTERPOINT THREE ARRIVAL

SAN ANTONIO, TEXAS



ARRIVAL ROUTE DESCRIPTION

FORT STOCKTON TRANSITION (FST.CSI3): From over FST VORTAC on FST R-096 and CSI R-280 to CSI VORTAC. Thence . . . .

JUNCTION TRANSITION (JCT.CSI3): From over JCT VORTAC on JCT R-134 and CSI R-314 to CSI VORTAC. Thence . . . .

LANDING SAT RUNWAY 13R: From CSI VORTAC on CSI R-106 to cross LLITE at 10000, then on CSI R-106 to cross RBNSN at 6000 and 210K. Expect ILS or LOC RWY 13R approach.

LANDING SAT RUNWAYS 4, 22, 31L/R: From CSI VORTAC on CSI R-106 to cross LLITE at 10000, then on heading 130°. Expect RADAR vectors to final approach course.

LANDING SKF/SSF/RND: From CSI VORTAC on CSI R-106 to cross LLITE at 10000, then on heading 130°. Expect RADAR vectors to final approach course.

CENTERPOINT THREE ARRIVAL SAN ANTONIO, TEXAS