VOR RWY 23

ROSS COUNTY (RZT)

VOR XUB	APP CRS	Rwy Idg	5405
112.5	204°	TDZE	716
		Apt Elev	725

NA — When local altimeter setting not received, use Rickenbacker Intl altimeter setting. When VGSI is inop, Straight-in and Circling Rwy 23 procedures NA at night.

MISSED APPROACH: Climb to 3000 then right turn direct XUB VOR and hold.

AWOS-3	COLUMBUS APP CON	UNICOM	123.0 L
119.225	134.0 279.6	122.8 (CTAF)	



ELEV 725 TDZE 716



REIL Rwys 5 and 23 L
MIRL Rwy 5-23 L

FAF to MAP 5.2 NM

Knots	60	90	120	150	180
Min:Sec	5:12	3:28	2:36	2:05	1:44



CATEGORY	A	B	C	D
S-23	1220-1 504 (500-1)		1220-1½ 504 (500-1½)	
CIRCLING	1340-1 615 (700-1)	1360-1 635 (700-1)	1500-2¼ 775 (800-2¼)	1540-2¾ 815 (900-2¾)
RICKENBACKER INTL ALTIMETER SETTING MINIMUMS				
S-23	1280-1 564 (600-1)		1280-1⅝ 564 (600-1⅝)	
CIRCLING	1400-1 675 (700-1)	1420-1 695 (700-1)	1560-2½ 835 (900-2½)	1600-2¾ 875 (900-2¾)

EC-2, 01 OCT 2026 to 29 OCT 2026
EC-2, 01 OCT 2026 to 29 OCT 2026