

HOT SPOTS

An "Airport surface hot spot" is a location on an aerodrome movement area with a history or potential risk of collision or runway incursion, and where heightened attention by pilots/drivers is necessary.

A "hot spot" is a runway safety related problem area on an airport that presents increased risk during surface operations. Typically it is a complex or confusing taxiway/taxiway or taxiway/runway intersection. The area of increased risk has either a history of or potential for runway incursions or surface incidents, due to a variety of causes, such as but not limited to: airport layout, traffic flow, airport marking, signage and lighting, situational awareness, and training. Hot spots are depicted on airport diagrams as open circles or ellipses designated as "HS 1", "HS 2", etc. and tabulated in the list below with a brief description of each hot spot. Hot spots will remain charted on airport diagrams until such time the increased risk has been reduced or eliminated.

CITY/AIRPORT	HOT SPOT	DESCRIPTION
IDAHO		
BOISE		
BOISE AIR TRML/GOWEN FLD (BOI)	HS 1	Pilots departing Rwy 10L often miss the left turn on Twy W and continue taxi on Twy J. Do not mistake Rwy 10L apch sign for Rwy 10L entrance.
HAILEY		
FRIEDMAN MEML (SUN)	HS 1	Possible confusion b/n ramp and Twy B due to large paved areas. ATC clnc is needed to enter movement area.
	HS 2	Possible confusion b/n ramp and Twy B due to large paved areas. ATC clnc is needed to enter movement area.
	HS 3	Possible confusion b/n ramp and Twy B due to large paved areas. ATC clnc is needed to enter movement area.
IDAHO FALLS		
IDAHO FALLS RGNL (IDA)	HS 1	Pilots should use caution and look carefully for rwy hold line when using Twy C. Rwy 17-35 does not have rwy edge markings and can be mistaken for a twy.
TWIN FALLS		
JOSLIN FLD/MAGIC VALLEY RGNL (TWF)	HS 1	Confusing ramp and twy configuration. Pilots taxiing from FBO ramp sometimes enter Rwy 12-30 w/o apvl.
	HS 2	Twy A at Twy A3, confusing geometry and painted lines. ATCT clnc required to cross the painted movement – non-movement bdy marking. Pilots sometimes enter Rwy 08-26 w/o apvl.
MONTANA		
BILLINGS		
BILLINGS LOGAN INTL (BIL)	HS 1	Complex intersection of Twy A, Twy C, ramp, and Rwy 10L-28R. Large non-movement area south of Twy A.
BOZEMAN		
BOZEMAN YELLOWSTONE INTL (BZN)	HS 1	Pilots taxiing via Twy A to Rwy 30 for departure sometimes fail to hold short of Rwy 03-21.
BUTTE		
BERT MOONEY (BTM)	HS 1	Rstd visibility between Rwy 33 and Rwy 30. Acft departing/lgng may not see t/c on intersecting rwy.

CITY/AIRPORT	HOT SPOT	DESCRIPTION
OREGON		
AURORA		
AURORA STATE (UAO)	HS 1	Rwy hold line close to Twy A. No sign identifying Twy A when exiting the ramp.
	HS 2	Rwy hold line close to Twy A. No sign identifying Twy A when exiting the ramp.
NORTH BEND		
SOUTHWEST OREGON RGNL (OTH)	HS 1	Twy A crosses the north end of Rwy 13–31. Pilots have mistaken the rwy as part of the twy and taxied onto Rwy 13–31 without clearance.
PORTLAND		
PORTLAND INTL (PDX)	HS 1	Limited wing-tip clearance at twy convergence point. Pilots taxiing eastbound on Twy B should hold at the twy holding position marking when directed by ATC.
	HS 2	Hold line for Rwy 03–21 is on Twy K. Pilots should be prepared to hold short of Rwy 21 on Twy K unless an authorization to cross has been issued by ATC.
	HS 3	Pilots taxiing outbd from the GA ramp via Twy A3 sometimes miss the turn onto Twy A and enter Rwy 10L–28R w/o authorization.
PORTLAND		
PORTLAND–HILLSBORO (HIO)	HS 1	Acft exiting Rwy 13R–31L at Twy A6 have only 90' of clnc between Twy A cntrln and holding posn markings.
	HS 2	Pilots taxiing from the Rwy 31L run-up area via Twy A8 to Rwy 31L for dep sometimes fail to hold short of Rwy 13R–31L.
REDMOND		
ROBERTS FLD/REDMOND MUNI (RDM)	HS 1	Pilots eastbound on Twy B sometimes miss the turn onto Twy A and cross the Rwy 05–23 hold line.
	HS 2	Pilots eastbound on Twy C sometimes miss the turn onto Twy A and cross the Rwy 05–23 hold line.
WASHINGTON		
BELLINGHAM		
BELLINGHAM INTL (BLI)	HS 1	Confusing twy int for pilots exiting/taxiing Rwy 16–34 via Twy D.
EVERETT		
SEATTLE PAINE FLD INTL (PAE)	HS 1	Twy A between Twy A9 and Twy A10 not visible from ATCT.
JOINT BASE LEWIS–MCCHORD		
GRAY AAF (JOINT BASE LEWIS–MCCHORD) (GRF)	HS 1	Congested int of Twy E, Twy F and Twy G.
MOSES LAKE		
GRANT CO INTL (MWH)	HS 1	Unusual hold line location on Twy C, 1568' short of Rwy 18 Thld.
	HS 2	Rwy 09–27 clsd except mil ops. Rwy 09–27 has no rwy markings and nstd rwy lgts.
PASCO		
TRI-CITIES (PSC)	HS 1	Pilots Idg Rwy 30 should listen carefully to ATCT instructions and be prepared to exit onto Rwy 03R–21L or Rwy 03L–21R. Pilots often exit at the wrong rwy as directions signs are not avbl.
	HS 2	Pilots sometimes cross Rwy 21L without authorization. When twr is opr, ATC clearance is required to enter or cross rwy.
SEATTLE		
BOEING FLD/KING CO INTL (BFI)	HS 1	Twy Z restricted access area.
	HS 2	Rwy 14R–32L and Twy A7. Wrong rwy departure risk.
	HS 3	Extv copter ops in the vcnty of Twy B5.
SEATTLE		
SEATTLE–TACOMA INTL (SEA)	HS 1	Acft crossing/exiting Rwy 16C–34C at Twy J sometimes cros Rwy 16L–34R hold line on Twy H w/o authorization. Hold line immediately after joining Twy H.

CITY/AIRPORT	HOT SPOT	DESCRIPTION
YAKIMA		
YAKIMA AIR TRML/MCALLISTER FLD (YKM)	HS 1	Twy C, Twy B, and Rwy 22 complex intersection. Rwy hold lines are at an unusual distance from rwy edge, rwy markings not easily visible from hold line.
WYOMING		
CASPER		
CASPER/NATRONA CO INTL (CPR)	HS 1	Pilots sometimes taxi past Twy A onto Rwy 03–21 without authorization. Twy A on edge of ramp with no signage, and Twy A5 has direct access to Rwy from ramp.
CHEYENNE		
CHEYENNE RGNL/JERRY OLSON FLD (CYS)	HS 1	Confusing twy configuration. Twy A transitions to Twy B and back to Twy A when taxiing to and from Rwy 13–31.
JACKSON		
JACKSON HOLE (JAC)	HS 1	Acft sometimes miss Twy A1 and enter the blast pad.