


ILS Z or LOC Z RWY 16R
SEATTLE PAINE FLD INTL (PAE)

MALSR

MISSED APPROACH: Climb to 1100 then climbing right turn to 3000 on heading 280° and PAE VOR/DME R-236 to ECEPO/PAE 9 DME and hold, continue climb-in-hold to 3000.

1100 ↑	3000 hdg 280°	PAE R-236	ECEPO PAE 9
-----------	---------------------	--------------	----------------



TDZ/CL Rwy 16R
HIRL Rwy 16R-34L **L**
REIL Rws 16L and 34R
MIRL Rwy 16L-34R