


# CURLO SIX DEPARTURE (RNAV)

**TOP ALTITUDE:**  
**RWYS 13L/R: 8000**  
**RWYS 31L/R: 6000**

RNAV 1 - DME/DME/IRU  
 or GPS required.

RADAR required.


LONE STAR DEP CON  
 125.125 353.95  
 D-ATIS  
 120.15  
 CLNC DEL  
 127.9  
 CPDLC  
 GND CON  
 121.75 348.6  
 LOVE TOWER  
 123.7 239.3



- NOTE: For use by turbojet aircraft only.
- NOTE: Props file and expect JOE POOL DEPARTURE.
- NOTE: WACO Transition for aircraft inbound to Waco or Gray terminal area airports.
- NOTE: SAN ANTONIO Transition for aircraft overflying Centex and San Antonio.
- NOTE: WINDU Transition for aircraft inbound to Austin or San Antonio terminal area airports.
- NOTE: COLLEGE STATION Transition for piston and turboprop aircraft inbound to HOU, EFD, GLS, or LBX. Also, for all other aircraft types destined to all other Houston terminal area airports except IAH, CXO, DWH, T78, or 6R3.
- NOTE: ELLVR Transition for turbojet aircraft inbound to HOU, EFD, GLS, or LBX.
- NOTE: TORNN Transition for aircraft landing IAH, CXO, DWH, T78, or 6R3.
- NOTE: Use the JOE POOL DEPARTURE during the period 2100-0600 local time in lieu of the CURLO DEPARTURE.

### TAKEOFF MINIMUMS

Rwys 13L: Standard with minimum climb of 262'/NM to 1600.  
 Rwys 13R: Standard with minimum climb of 315'/NM to 1700.  
 Rwys 31L/R: Standard with minimum climb of 500'/NM to 1000.



SAN ANTONIO  
 SAT

(CONTINUED ON FOLLOWING PAGE)

NOTE: Chart not to scale.

SC-2, 19 MAR 2026 to 16 APR 2026

SC-2, 19 MAR 2026 to 16 APR 2026

# CURLO SIX DEPARTURE (RNAV)