


VOR/DME	MLB	Rwy Ldg	9482
115.85	APP CRS	TDZE	26
Chan 105 (Y)	288°	Apt Elev	33

VOR RWY 27L
MELBOURNE ORLANDO INTL (MLB)

▼
▲

MISSED APPROACH: Climb to 1000 then climbing left turn to 2100 direct MLB VOR/DME and hold.

ATIS 132.55	ORLANDO APP CON 126.025 281.425	MELBOURNE TOWER ★ 118.2 (CTAF) 257.8	GND CON 121.9	UNICOM 122.95
----------------	------------------------------------	---	------------------	------------------



ELEV 33	D	TDZE 26
---------	----------	---------

