



Advisory Circular

Subject: Standards for Airport Markings

Date:

AC No: 150/5340-1M

Initiated By: AAS-100

Change:

1 1 **Purpose.**

2 This advisory circular (AC) contains the Federal Aviation Administration (FAA)
3 standards for markings used on airport runways, taxiways, and aprons.

4 2 **Cancellation.**

5 This AC cancels AC 150/5340-1L, *Standards for Airport Markings*, dated September
6 27, 2013.

7 3 **Application.**

8 The FAA recommends the guidelines and standards contained herein for the marking of
9 airport runways, taxiways, and aprons. The use of these standards is the only method of
10 compliance with the marking of runways, taxiways, and aprons for airports certificated
11 under Title 14 Code of Federal Regulations Part 139, Certification of Airports (Part
12 139). These standards are to be used on all new airport projects that are under
13 development and are to be implemented at all Part 139 certificated airports. Further, use
14 of this AC is mandatory for all projects funded with federal grant monies through the
15 Airport Improvement Program (AIP) and/or with revenue from the Passenger Facility
16 Charge (PFC) Program. (See Grant Assurance No. 34, Policies, Standards, and
17 Specifications, and PFC Assurance No. 9, Standards and Specifications.)

18 4 **Principal Changes.**

19 The AC incorporates the following principal changes:

- 20 1. New criterion for centering runway landing designators (common industry practice).
21 Airports certificated under Title 14 of the Code of Federal Regulations, Part 139,
22 Certification of Airports, can meet the requirements upon the next repainting
23 project.

- 24 2. Paragraph 1.2, no-taxi islands definition. Added new definition to define no-taxi
25 islands applicable to this advisory circular.
- 26 3. Paragraph 1.3.2. Added new red safety box informing airport operators not to apply
27 preformed thermoplastic markings on the runway due to their significant reduction
28 in pavement friction as compared to bare pavement. In the case of existing
29 preformed thermoplastic markings on a runway, such applications are to be rectified
30 within one year of issuance of this change.
- 31 4. Paragraph 1.3.8. Added new paragraph to clarify that all surface markings painted
32 by the use of stencils are not to leave stencil gaps. In the case of existing surface
33 markings with stencil gaps, such stencil gaps are to be rectified during the next
34 painting project.
- 35 5. Paragraph 1.4. Added new notes to Table 1-2 that clarifies the relationship of Table
36 1-2 with Table 1-1 when dealing with the requirements for black borders.
- 37 6. Paragraph 1.5. Added new paragraph explaining the functions and applications of
38 no-taxi islands to mitigate runway incursions and taxiing excursions. Deleted
39 previous no-taxi island criteria from paragraph 4.4.5.2 and paragraph 4.10.4.
40 Revised the red safety box in paragraph 4.4.5.2 to reference new paragraph 1.5
41 criteria.
- 42 7. Paragraph 4.3.4. Revised text to align FAA criterion with International Civil
43 Aviation Organization (ICAO) Annex 14, Volume I criterion for enhanced taxiway
44 centerline surface markings that are collinear with on-centered surface painted
45 holding position signs. Revised Figure D-6 to reflect new criterion. Airports
46 certificated under Title 14 of the Code of Federal Regulations, Part 139,
47 Certification of Airports, must meet these requirements within two years from the
48 effective date of this AC.
- 49 8. Paragraph 4.3.4. Added an instructional green box with guidance on how to
50 relocate surface painted holding position signs between the two taxiway width
51 categories (off-taxiway centerline placement and on-taxiway centerline placement).
- 52 9. Paragraph 4.11.3.1. Replace 600 RVR with 500 RVR to agree with FAA ORDER |
53 7110.65, *Air Traffic Control* (latest edition).
- 54 10. Paragraphs 2.1.1. Added “*Engineered Materials Arresting Systems (EMAS)*” to the
55 end of the paragraph as another example of paved areas prior to the runway end
56 (start of runway). Clarified that Table 2-1 applies to runways that lack stopways,
57 blast pads, displaced thresholds, or aligned taxiways.
- 58 11. Paragraph 2.9. Revised text in subparagraphs (a) and (b) to clarify the functions of a
59 displaced threshold, the location where a displaced threshold begins as compared to
60 a non-displaced threshold, and the use of arrow shafts.
- 61 12. Paragraphs 3.1, 3.2.2.2, 3.2.2.2.1, and 3.5. Changed the marking standard from a
62 Pattern A to a Pattern B to protect runway approach/departure areas. This
63 interchange is a direct result from the FAA Technical Center R&D report
64 DOT/FAA/TC-16/26, *Evaluation of Enhanced Visual Cues for Runway Approach*
65 *and Runway Safety Areas*, published in April 2016. Airports certificated under Title

- 66 14 of the Code of Federal Regulations, Part 139, Certification of Airports, must
67 meet this requirement within 2 years from the effective date of this AC.
- 68 13. Paragraph 4.4.5.5.2. Replaced criterion for the case not outlined in black when a
69 taxiway edge marking is located at a runway holding position to read – a 6-inch (12
70 cm) gap is left between the holding position marking and the taxiway edge marking.
- 71 14. Paragraph 5.3.5, Item 4. Replaced the word “*interior*” with “*exterior*.”
- 72 15. Paragraph 5.6.1. Added more guidance regarding when to remove existing runway
73 markings when a runway is closed or from an intersecting runway that has been
74 closed.
- 75 16. Figures as follow:
- 76 a. Figure A-10 and Figure A-11 added the word “*Displaced*” to the phrase
77 “*Runway Threshold Bar (white)*”;
- 78 b. Figure A-12 added the word “*Yellow*” to Note 2;
- 79 c. Figure A-13 added the word “*each*” to the phrase “*2 Lines and 1 Space are each*
80 *12” [30 cm] Wide*”;
- 81 d. Figure A-15 revised reference in note 2 revised from paragraph 1.4 to paragraph
82 1.3k;
- 83 e. Figure A-16 added to Note 3 the reference to paragraph 3.3;
- 84 f. Figure A-18 clarified the design criterion to build taxiway/taxiway intersections
85 with cockpit-over centerline fillets and marking criterion to use curved taxiway
86 centerline markings by added the phrase “*until such substandard fillets are*
87 *widened to full standard design criteria*” to the end of the existing phrase
88 “*Taxiway centerline markings at intersection having less than standard fillets*
89 *and requiring judgmental over steering*”;
- 90 g. Figure A-19 redrawn to emphasize the design criteria for standard width of
91 taxiway entrances with a No-Taxi Island between entrance taxiways to a runway
92 and for the elimination of paved areas within a POFZ;
- 93 h. Figure A-23 added the pictorial symbol for a vertical sign to reinforce
94 placement of a vertical sign at runway holding position locations;
- 95 i. Figure D-5, Figure D-7, and Figure D-8 added the phrase “*The SPHPS to the*
96 *right of the taxiway centerline is not always required in most cases.*” to the table
97 within the first row.
- 98 j. Figure D-6 revised to show new marking pattern per ICAO Annex 14.
99 Introduced new dimension “D” and removed taxiway centerline marking
100 between the SPHPS and the runway holding position marking (Pattern A).

101 5 **How to use this AC.**

- 102 1. This AC includes color-coded text boxes to emphasize safety initiatives, solutions to
103 painting difficulties, and general remarks.

- 104 a. Green (Painting) – explains painting precautions and solutions, such as when
105 proportioning is permissible for runway surface markings.
- 106 b. Red (Safety) – emphasizes safety initiatives.
- 107 c. Gray (General) – contains general remarks.
- 108 2. All references to other FAA ACs and Orders are interpreted as the current version.
- 109 3. Most figures in this AC are full scale AutoCAD drawings saved as MS Word
110 versions. For some figures, certain details may appear to be missing (missing or
111 broken lines) when either printed or viewed on a computer monitor. To view all the
112 details in these figures, use the appropriate ZOOM function. In some instances,
113 where there is a large surface area, a ZOOM value of over 250% may be necessary
114 to view all details. Both this AC and the original AutoCAD files for all figures are
115 available for download at the FAA web site:

116 http://www.faa.gov/airports/resources/advisory_circulars/index.cfm/go/document.list/pa
117 [rentTopicID/85](http://www.faa.gov/airports/resources/advisory_circulars/index.cfm/go/document.list/pa).

118 **6 Measurements in this AC.**

119 This AC uses U.S. customary units followed with “soft” (rounded) conversion to metric
120 units. The U.S. customary units govern.

121 **7 Copies of this AC and Other FAA Publications.**

122 You can view a list of all ACs at
123 http://www.faa.gov/regulations_policies/advisory_circulars/. You can view the Federal
124 Aviation Regulations at http://www.faa.gov/regulations_policies/faq_regulations/.

125 **8 Feedback on this AC.**

126 If you have suggestions for improving this AC, you may use the Advisory Circular
127 Feedback form at the end of this AC.

128 John R. Dermody
129 Director of Airport Safety and Standard

CONTENTS

| | Number | | Page |
|-----|--|---|-------------|
| 130 | Chapter 1. Surface Markings for Airfield Pavements and Paved Airfield Roadways. | | 1-1 |
| 131 | 1.1 | General..... | 1-1 |
| 132 | 1.2 | Definitions..... | 1-1 |
| 133 | 1.3 | Surface Marking Practices. | 1-2 |
| 134 | 1.4 | Requirements and Recommendations for Enhanced Conspicuity of Surface | |
| 135 | | Markings on Concrete Pavements and Light Colored Pavements..... | 1-9 |
| 136 | 1.5 | No-Taxi Islands..... | 1-12 |
| 137 | Chapter 2. Surface Markings for Runways | | 2-1 |
| 138 | 2.1 | Application..... | 2-1 |
| 139 | 2.2 | Interruption of Runway Surface Markings. | 2-2 |
| 140 | 2.3 | Runway Landing Designator Marking..... | 2-5 |
| 141 | 2.4 | Runway Centerline Marking..... | 2-8 |
| 142 | 2.5 | Runway Threshold Marking. | 2-9 |
| 143 | 2.6 | Runway Aiming Point Marking. | 2-11 |
| 144 | 2.7 | Runway Touchdown Zone Marking. | 2-13 |
| 145 | 2.8 | Runway Edge Marking. | 2-17 |
| 146 | 2.9 | Runway Threshold Bar Marking and Runway Displaced Threshold Marking. | 2-18 |
| 147 | 2.10 | Chevron Markings for Blast Pads, Stopways, and EMAS..... | 2-21 |
| 148 | 2.11 | Runway Shoulder Marking..... | 2-21 |
| 149 | Chapter 3. Holding Position Markings | | 3-1 |
| 150 | 3.1 | Applications of Holding Position Markings. | 3-1 |
| 151 | 3.2 | Case 1 and Case 2 – Applications of Pattern A for the runway holding position | |
| 152 | | marking on runways..... | 3-1 |
| 153 | 3.3 | Case 3 – Applications of Pattern A for the runway holding position marking on | |
| 154 | | taxiways. | 3-4 |
| 155 | 3.4 | Case 4 – Applications of Pattern B for the ILS/MLS Holding Position Marking. | 3-7 |
| 156 | 3.5 | Case 5 – Applications of Pattern B for Precision Obstacle Free Zone (POFZ) | |
| 157 | | holding position marking. | 3-9 |
| 158 | 3.6 | Case 6 – Applications for Pattern C for the Taxiway/Taxiway Intersection | |
| 159 | | Intermediate Holding Position Marking. | 3-11 |

CONTENTS

| | Number | | Page |
|-----|--|--|-------------|
| 160 | Chapter 4. Surface Markings for Taxiways | | A-1 |
| 161 | 4.1 Application..... | | A-1 |
| 162 | 4.2 Taxiway Centerline Markings..... | | A-1 |
| 163 | 4.3 Enhanced Taxiway Centerline Marking. | | A-4 |
| 164 | 4.4 Taxiway Edge Marking..... | | A-9 |
| 165 | 4.5 Surface Painted Holding Position Signs. | | 4-1 |
| 166 | 4.6 Surface Painted Taxiway Direction Signs. | | 4-8 |
| 167 | 4.7 Surface Painted Taxiway Location Signs. | | 4-9 |
| 168 | 4.8 Surface Painted Gate Destination Signs. | | 4-10 |
| 169 | 4.9 Surface Painted Apron Entrance Point Signs..... | | 4-11 |
| 170 | 4.10 Taxiway Shoulder Markings..... | | 4-13 |
| 171 | 4.11 Geographic Position Markings. | | 4-14 |
| 172 | 4.12 Ramp Control Markings. | | 4-16 |
| 173 | Chapter 5. Other Surface Markings..... | | 5-1 |
| 174 | 5.1 Application..... | | 5-1 |
| 175 | 5.2 Vehicle Roadway Markings..... | | 5-1 |
| 176 | 5.3 Very High Frequency Omnidirectional Range (VOR) Receiver Checkpoint | | |
| 177 | Marking..... | | 5-2 |
| 178 | 5.4 Non-Movement Area Boundary Marking..... | | 5-3 |
| 179 | 5.5 Markings for Thresholds Temporarily Relocated During Construction..... | | 5-6 |
| 180 | 5.6 Marking and Lighting of Permanently Closed Runways and Taxiways. | | 5-6 |
| 181 | 5.7 Temporarily Closed Runways and Taxiways. | | 5-7 |
| 182 | 5.8 Converting a Runway to a Taxiway..... | | 5-8 |
| 183 | 5.9 Intermittent Use of a Taxiway as a Runway..... | | 5-9 |
| 184 | 5.10 Closed or Abandoned Airports. | | 5-10 |
| 185 | 5.11 Heliport Markings..... | | 5-10 |
| 186 | 5.12 Marking for Arresting Gear. | | 5-10 |
| 187 | 5.13 Hazardous Construction Areas. | | 5-10 |
| 188 | 5.14 Aircraft Deicing Facility Markings..... | | 5-10 |
| 189 | 5.15 Interim Surface Markings for Taxiways Mistaken as Runways..... | | 5-10 |

CONTENTS

| | Number | Page |
|-----|--|-------------|
| 190 | Appendix A. Pavement Markings | A-1 |
| 191 | Appendix B. Inscriptions for Signs and Geographic Position Markings | B-1 |
| 192 | Appendix C. Examples of Markings Outlined in Black..... | C-1 |
| 193 | Appendix D. Enhanced Markings for Runway Holding Position..... | D-1 |

194 **FIGURES**

| | Number | Page |
|-----|--|-------------|
| 195 | | |
| 196 | Figure 1-1. Example of marking removal patterns | 1-4 |
| 197 | Figure 1-2. Example of marking removal patterns | 1-5 |
| 198 | Figure 1-3. Example of marking removal patterns | 1-6 |
| 199 | Figure 1-4. Example of marking removal patterns | 1-7 |
| 200 | Figure 1-5. Example of painted numbering system for surface painted markings | 1-8 |
| 201 | Figure 1-6. Case 1 | 1-17 |
| 202 | Figure 1-7. Case 3 | 1-18 |
| 203 | Figure 1-8. Case 4..... | 1-19 |
| 204 | Figure 1-9. Case 2..... | 1-20 |
| 205 | Figure 2-1. Closed V geometry..... | 2-4 |
| 206 | Figure 4-1. Sequential circular-shaped Ramp Control Markings 3, 4, and 5 between two | |
| 207 | terminals..... | 4-18 |
| 208 | Figure 4-2. Circular-shaped Ramp Control Marking 16 on elongated terminal apron..... | 4-19 |
| 209 | Figure 4-3. Circular-shaped Ramp Control Markings 9S and 9N between terminals | 4-20 |
| 210 | Figure 4-4. Triangular-shaped ramp control marking between terminals | 4-22 |
| 211 | Figure 4-5. Circular and triangular-shaped ramp control marking dimensions..... | 4-23 |
| 212 | Figure 5-1. Precautionary placement of the non-movement boundary marking | 5-5 |
| 213 | Figure 5-2. TAXI marking location facing runway approach end..... | 5-11 |
| 214 | Figure 5-3. TAXI marking dimensions..... | 5-12 |
| 215 | Figure 5-4. Aviation grade artificial turf installation..... | 5-13 |
| 216 | Figure A-1. Precision runway markings | A-1 |
| 217 | Figure A-2. Non-precision runway | A-3 |
| 218 | Figure A-3. Visual runway markings..... | A-4 |

| Number | Page |
|---------------|--|
| 219 | Figure A-4. Example of conflicting markings on crossing runways A-5 |
| 220 | Figure A-5. Details of markings for intersecting runways A-6 |
| 221 | Figure A-6. Runway designation numerals and letters A-7 |
| 222 | Figure A-8. Marking for aligned taxiway with runway without a displaced threshold A-10 |
| 223 | Figure A-9. Markings for blast pads and stopways A-11 |
| 224 | Figure A-10. Markings for aligned taxiway preceding a displaced threshold A-12 |
| 225 | Figure A-11. Markings for blast pad preceding a displaced threshold A-13 |
| 226 | Figure A-12. Runway shoulder markings A-14 |
| 227 | Figure A-13. Holding position marking details A-15 |
| 228 | Figure A-14. Holding position marking details A-16 |
| 229 | Figure A-15. Taxiway markings A-17 |
| 230 | Figure A-16. Taxiway markings A-18 |
| 231 | Figure A-17. Taxiway markings A-19 |
| 232 | Figure A-18. Methods for taxiway centerline marking A-20 |
| 233 | Figure A-19. Surface painted signs A-21 |
| 234 | Figure A-20. Surface painted gate identification signs A-22 |
| 235 | Figure A-21. Multiple gate signs A-23 |
| 236 | Figure A-22. Surface painted apron entrance point signs A-24 |
| 237 | Figure A-23. Taxiway shoulder markings A-25 |
| 238 | Figure A-24. Geographic position markings A-26 |
| 239 | Figure A-25. Vehicle roadway markings A-27 |
| 240 | Figure A-26. VOR receiver checkpoint markings A-28 |
| 241 | Figure A-27. Closed runway and taxiway markings A-29 |
| 242 | Figure B-1. Pavement markings ABCDEFGH B-1 |
| 243 | Figure B-2. Pavement markings IJKLMNOP B-2 |
| 244 | Figure B-3. Pavement markings QRSTUVWX B-3 |
| 245 | Figure B-4. Pavement markings YZ123456 B-4 |
| 246 | Figure B- 5. Pavement markings 7890-, ↑ B-5 |
| 247 | Figure C-1. Runway holding position marking C-1 |
| 248 | Figure C-2. ILS/MLS holding position marking C-1 |
| 249 | Figure C-3. Continuous taxiway edge line marking C-2 |
| 250 | Figure C-4. Dashed taxiway edge line marking C-2 |

| | Number | Page |
|-----|---|-------------|
| 251 | Figure C-5. Alternate outlining method for dashed taxiway edge line marking | C-1 |
| 252 | Figure C-6. Taxiway centerline marking | C-1 |
| 253 | Figure C-7. Intermediate holding position markings | C-2 |
| 254 | Figure C-8. Non-movement area boundary marking | C-2 |
| 255 | Figure D-1. Enhanced taxiway centerline markings | D-2 |
| 256 | Figure D-2. Dashed lines at converging taxiway centerlines | D-3 |
| 257 | Figure D-3. Converging, straight, and curved enhanced taxiway centerlines intersecting with | |
| 258 | holding position marking | D-4 |
| 259 | Figure D-4. Enhanced runway holding position markings on taxiways | D-5 |
| 260 | Figure D-5. Surface painted holding position signs for taxiway widths greater than 35 feet | |
| 261 | (10.5 m)..... | D-6 |
| 262 | Figure D-6. Surface painted holding position sign for taxiway widths equal to or less than 35 | |
| 263 | feet (10.5 m)..... | D-7 |
| 264 | Figure D-7. Surface painted holding position signs when taxiway centerline is not | |
| 265 | perpendicular to runway holding position marking | D-8 |
| 266 | Figure D-8. Surface painted holding position signs co-located with geographic position | |
| 267 | marking | D-9 |
| 268 | Figure D-9. Two taxiway centerlines converging at a runway holding position marking | D-11 |
| 269 | Figure D-10. Intersection of two taxiways at runway end..... | D-12 |
| 270 | Figure D-11. Intersection of three converging taxiway centerlines..... | D-13 |
| 271 | Figure D-12. Intersection of multi-taxiway centerlines with less than 150 feet (45.7 m) | |
| 272 | between taxiways | D-14 |
| 273 | Figure D-13. Two taxiway centerlines intersecting a runway holding position marking..... | D-15 |
| 274 | Figure D-14. Intersection of stub taxiway and runway..... | D-16 |
| 275 | Figure D-15. Narrow taxiway stacked surface painted holding position sign | D-17 |
| 276 | Figure D-16. Enhanced taxiway centerlines when a taxiway connects closely spaced runways..... | D-18 |

277

TABLES

| | Number | Page |
|-----|--|-------------|
| 279 | Table 1-1. General guidelines for determining light-colored pavements - Painting a Black | |
| 280 | Border | 1-9 |
| 281 | Table 1-2. Requirements and recommendations for black borders and glass beads | 1-10 |
| 282 | Table 2-1. Minimum required runway surface marking schemes for paved runways..... | 2-1 |
| 283 | Table 2-2. Number of runway threshold stripes for standard runway widths | 2-10 |

| Number | | Page |
|---------------|---|-------------|
| 284 | Table 2-3. Groupings of touchdown zone markings required when installed from one | |
| 285 | threshold..... | 2-14 |
| 286 | Table 2-4. Groupings of touchdown zone markings required when installed from both | |
| 287 | thresholds | 2-15 |
| 288 | Table 4-1. Placement of repetitive surface painted holding position signs and no-taxi islands | |
| 289 | on taxiway entrances of over 200 feet (61 m) in width | 4-5 |
| 290 | Table D-1. Notes for Figure D-5..... | D-6 |
| 291 | Table D-2. Notes for Figure D-6..... | D-7 |
| 292 | Table D-3. Notes for Figure D-7..... | D-8 |
| 293 | Table D-4. Notes for Figure D-8..... | D-9 |
| 294 | | |

295 **CHAPTER 1. SURFACE MARKINGS FOR AIRFIELD PAVEMENTS AND PAVED AIRFIELD**
296 **ROADWAYS.**

297 **1.1 General.**

298 This chapter provides the standards for surface markings used on airfield pavements
299 (runways, taxiways, aprons, and paved airfield roadways). The standards for the surface
300 markings assume that runways, taxiways, and aprons are built in accordance to the
301 standard dimensions and layouts (e.g., clearances, fillets) in Advisory Circular (AC)
302 150/5300-13, Airport Design. The airport operator should expect difficulties when
303 painting surface markings on non-standard infrastructure, such as a runway with a non-
304 standard width. To assist airport operators, this AC offers a few workable solutions for
305 existing non-standard situations. Surface markings for large airplane parking positions
306 and surface markings for unpaved airfield runways will be addressed at a future date in
307 additional chapters.

308 **Note:** Use the zoom feature to view detail in any figure.

309 **1.2 Definitions.**

310 The following definitions apply to terms used in this AC.

- 311 1. **Certificated Airport.** An airport that has been issued an Airport Operating Certificate
312 by the FAA under the authority of 14 CFR Part 139, Certification of Airports.
- 313 2. **Commercial Service Airports and Passenger Enplanements.** Defined in FAA Order
314 5100.38, Airport Improvement Program Handbook.
- 315 3. **Displaced Threshold.** A threshold that is located at a point on the runway other than
316 the designated beginning of the runway.
- 317 4. **Island.** An unused paved or grassy area along a taxiway, between taxiways, between
318 runways, or between a taxiway and a runway. Paved islands are clearly marked as
319 unusable, either by painting or the use of artificial turf. For the purposes of this AC,
320 certain islands are referred to as “No-taxi” islands.
- 321 5. **Movement Area.** The runways, taxiways, and other areas of an airport that are used
322 for taxiing, takeoff, and landing of aircraft, exclusive of loading ramps and aircraft
323 parking areas (reference 14 CFR Part 139).
- 324 6. **No-taxi Island.** An island that requires safety enhancements, i.e., the use of specific
325 surface markings and/or taxiway design features to mitigate excursions from a
326 taxiway or mitigate runway incursions. Vertical signage and/or lighting may also be
327 required or used.
- 328 7. **Non-precision Runway.** For the purposes of this AC, a runway end having an
329 instrument approach procedure that provides course guidance without vertical path
330 guidance. See AC 150/5300-13 for additional information.
- 331 8. **Precision Runway.** For the purposes of this AC, a runway end having an instrument
332 approach procedure that provides course and vertical path guidance conforming to
333 Instrument Landing System (ILS) or Microwave Landing System (MLS) precision

334 approach standards in International Civil Aviation Organization (ICAO) Annex 10,
335 Compliance Statement, Aeronautical Telecommunications. See AC 150/5300-13 for
336 additional information about precision approaches.

337 9. Threshold. The beginning of that portion of the runway that is available for landing.
338 In some instances, the landing threshold may not coincide with the end of the
339 opposite direction runway (see paragraph 1.2).

340 10. Visual Runway. A runway end without an existing or planned (on the Airport
341 Layout Plan) straight-in instrument approach procedure.

342 **1.3 Surface Marking Practices.**

343 The following subparagraphs address common practices used in airport markings.

344 1.3.1 In some situations, these standards may call for markings with different meanings to be
345 installed close together. Ensure that sufficient space is left between such markings such
346 that an observer will not be confused. Note: The taxiway edge marking and non-
347 movement area boundary marking never coincide or run side-by-side. See paragraph
348 5.4.

349 1.3.2 Increasing the Friction Coefficient of Surface Markings.

350 AC 150/5370-10, Standards for Specifying Construction of Airports, Item P-620,
351 Runway and Taxiway Marking, provides airport operators information to increase the
352 friction coefficient of surface markings. Common practices include the spreading of
353 silica sand on the marked surface immediately after painting and the use of glass beads
354 in the marking materials. Glass beads or silica sand are required when durable markings
355 (epoxy and methyl acrylate based paints) are used. These paints are usually applied at
356 18 to 30 mils in dry thickness.

Safety Alert – Reduced Runway Surface Friction

Prohibition of Preformed Thermoplastic Surface Markings on Runways

Until further notice, preformed thermoplastic surface markings are not to be used on runways because of the significantly lower friction readings recorded on such markings as compared to dry unmarked pavement (see FAA Technical Report DOT/FAA/AR-TN08/22, Evaluation of Thermoplastic Marking Materials).

357 1.3.3 Paint Color Specifications, Requirements for Surface Preparation, Paint Application 358 Rates and Methods, and Requirements for Preformed Thermal Plastic Markings.

359 AC 150/5370-10 provides the paint color specifications, requirements for surface
360 preparation, paint application rates, the various methods for applying paint, and the
361 performance requirements for using only preformed thermoplastic markings.

362 Precaution: Reflective tapes such as those commonly used for highways and city street
363 applications are not to be used on the airside because of the potential for foreign object
364 damage caused by loosened painted tape.

365 1.3.4 Striated Markings.

366 Striated markings, which may be used in areas subject to frost heave, consist of painted
367 stripes 4 inches (10 cm) to 8 inches (20 cm) in width that are separated by unpainted
368 stripes. The width of the unpainted stripe may not exceed the width of the painted
369 stripe. The width of the painted and unpainted stripes must be the same throughout the
370 specific marking. Each edge of the marking must be a painted stripe. That is, a painted
371 stripe is to begin and end within the width of the markings. Precaution: Because striated
372 markings offer reduced visibility compared to non-striated markings, more frequent
373 maintenance is required to maintain an acceptable level of visibility. Hence, striated
374 markings are never used on Category II and Category III runways. The mixing of
375 striated and non-striated markings is not permitted within a surface marking scheme.
376 For example, in a 2-digit landing designator, one digit cannot be striated while the other
377 is not. It is permitted to mix different marking schemes. For example, the landing
378 designator is striated and the aiming point is not.

379 1.3.5 Temporary Markings.


380 When selecting a material for temporary markings, consider the difficulty of removing
381 the temporary marking when it is no longer needed. Some airports have had some
382 success using water-based paint. Striated markings may also be used for temporary
383 markings, but they are never used to denote a closed runway or other closed pavement
384 or for Category II or Category III runways.

385 1.3.6 Removal of Markings.

386 Pavement markings that are no longer needed are not to be painted over but instead are
387 to be physically removed. The FAA does not endorse painting over the old markings
388 because this inadequate practice merely preserves the old marking which, in some
389 cases, has misled pilots and required extra maintenance. Physical removal of markings
390 is achieved by water blasting, shot blasting, sand blasting, chemical removal, or other
391 acceptable means that do not harm the pavement. The physical removal of any old
392 marking(s) must include a predetermined larger size and shape of a removal area that
393 encompasses the old marking(s) and by grouping adjacent markings together into a
394 larger rectangular removal area. The rationale behind this practice is to eliminate the
395 continued visual appearance of the removed marking(s). When a runway end or
396 threshold is being moved, all of the markings that are being removed must be strikingly
397 larger in size, grouped together with adjacent markings, and be rectangular in shape. For
398 example, use a single, larger rectangular removal area to encompass the entire runway
399 designator 7 or 14L and provide a separate large rectangular area comprising all of the
400 runway threshold markings along with a separate large rectangular area for the
401 touchdown zone markings on the same side of the runway centerline. Also, the size and
402 shape for the removal area for (1) Patterns A, B, and C holding position markings and
403 (2) yellow arrow heads having a runway threshold bar or a runway demarcation bar
404 must be much larger than the marking(s) being removed. For example, use a single,
405 larger rectangular removal area to encompass all yellow arrow heads and the adjacent
406 white runway threshold bar marking. See [Figure 1-1](#), [Figure 1-2](#), [Figure 1-3](#), and [Figure](#)
407 [1-4](#) for examples of marking removal patterns.

408

Figure 1-1. Example of marking removal patterns




409

410

Note: For further details, see paragraph 1.3.6.

411

Figure 1-2. Example of marking removal patterns




412

413

Note: For further details, see paragraph [1.3.6](#).

414

Figure 1-3. Example of marking removal patterns




415

416

Note: For further details, see paragraph [1.3.6](#).

417

Figure 1-4. Example of marking removal patterns



418


419

Note: For further details, see paragraph [1.3.6](#).

420 1.3.7 Painted Numbering System for Record Keeping of Surface Painted Markings.

421 To facilitate the daily inspection, scheduled maintenance, necessary repairs, etc., for
422 surface markings, the airport operator may use a numbering system or alphanumeric
423 system that is located in a corner of the surface marking. Figure 1-5 shows a numbering
424 system adopted by one airport for identifying each surface marking listed in their Sign
425 Plan. If employed, the height of the inscription should be small and inconspicuous to all
426 viewers except an individual standing next to the surface marking.

427 **Figure 1-5. Example of painted numbering system for surface painted markings**



428

429 1.3.8 Use of Stencil Templates.

430 All gaps created when painting surface markings using a stencil template must be filled
431 in. For example, the surface painted holding position sign shown in Figure D-5 contains
432 no stencil gaps.

433 **1.4 Requirements and Recommendations for Enhanced Conspicuity of Surface**
 434 **Markings on Concrete Pavements and Light Colored Pavements.**

435 Surface markings that cannot be seen by pilots and other individuals operating on paved
 436 airfield surfaces are ineffective. Two proven techniques that help airport operators
 437 enhance the degree of contrast (conspicuity) of surface markings are (1) outlining
 438 surface markings with black borders on concrete pavements and light-colored
 439 pavements and (2) placing glass beads in paint. However, glass beads are not to be used
 440 in black paint, including numerals and inscriptions found in Appendix B, Table 1-1
 441 serves as a general guide for determining when existing asphalt concrete surfaces or
 442 asphalt treated surfaces may be classified as a light-colored pavement, i.e., when to
 443 outline a required surface marking with a black border.

444 **Table 1-1. General guidelines for determining light-colored pavements - Painting a Black**
 445 **Border**

| Pavement Surface Type | Age of Pavement Surface ¹ | | |
|--------------------------|--------------------------------------|-------------------|------------------|
| | New | Up to 2 years old | Over 2 years old |
| Portland Cement Concrete | Yes | Yes | Yes |
| Asphalt Concrete | No | No | Yes |
| Asphalt Treated | No | No | Yes |

446 **Note 1:** This table serves only as a general guide since an existing asphalt pavement at one airport
 447 location may not experience the same rate of surface color deterioration as at another airport location.

448 **1.4.1 Technique 1 – Outlining Surface Markings with Black Borders on Concrete Pavements**
 449 **and Light-Colored Pavements.**

450 The degree of contrast (conspicuity) between surface markings on light-colored
 451 pavements, in particular on concrete pavements and older asphalt pavements, can be
 452 increased by outlining all edges of the surface marking with a black border. Appendix B
 453 provides illustrations of recommended patterns for various surface markings outlined in
 454 black. Black borders, except for enhanced taxiway centerline applications, are 6 inches
 455 (15 cm) or greater in width to enhance the conspicuity of certain painted surface
 456 markings on concrete pavements and light-colored pavements. The borders for the
 457 outside dashes of the enhanced taxiway centerline marking can range from 3 to 6 inches
 458 (7.5 to 15 cm). See Table 1-2 for surface markings that are required or recommended to
 459 have black borders.

460 **1.4.1.1 Surface Markings that Require Black Borders.**

- 461 1. Runway centerline marking (per paragraph 2.4).
- 462 2. Runway threshold marking (per paragraph 2.5).
- 463 3. Runway displaced threshold marking (per paragraph 2.9).

- 464 4. Runway threshold bar marking (per paragraph 2.9.1).
- 465 5. Runway aiming point marking (per paragraph 2.6).
- 466 6. Runway landing designator marking (per paragraph 2.3).
- 467 7. Runway touchdown zone markings (per paragraph 2.7).
- 468 8. All holding position markings (per paragraphs 3.2, 3.3, 3.4, and 3.5) |
469 and the non-movement area boundary marking (per paragraph 5.4).
- 470 9. Intermediate holding position marking for taxiway/taxiway
471 intersections (per paragraph 3.6).
- 472 10. All taxiway centerline markings on taxi routes designated as surface
473 movement guidance and control system (SMGCS) routes (per
474 paragraph 4.2).
- 475 11. Enhanced taxiway centerline marking (per paragraph 4.3).
- 476 12. Surface painted holding position sign marking (per paragraph 4.5).
- 477 13. Geographic position marking (per paragraph 4.11).
- 478 14. Non-movement area boundary marking (per paragraph 5.4).

479 1.4.1.2 **Surface Markings Recommended for Black Borders.**

480 This AC strongly recommends outlining all other markings not listed
481 paragraph 1.4.1.1, particularly taxiway centerlines per paragraph 4.2.

482 **Table 1-2. Requirements and recommendations for black borders and glass beads**

| Marking | Black Border | Glass Beads |
|---|--------------|-------------|
| Runway centerline marking (per paragraph <u>2.4</u>). | Required | Required |
| Runway threshold marking (per paragraph <u>2.5</u>). | Required | Required |
| Runway displaced threshold marking (per paragraph <u>2.9</u>). | Required | Required |
| Runway threshold bar marking (per paragraph <u>2.9.1</u>). | Required | Required |
| Runway aiming point marking (per paragraph <u>2.6</u>). | Required | Required |
| Runway landing designator marking (per paragraph <u>2.3</u>). | Required | Required |
| Runway touchdown zone markings (per paragraph <u>2.7</u>). | Required | Required |
| Runway edge marking (per paragraph <u>2.8</u>). | | Recommended |
| Runway demarcation bar marking (per paragraph <u>2.9.3</u>). | | Recommended |
| All holding position markings used on runways, taxiways, and holding bays and used to indicate ILS/MLS or precision obstacle free zone (POFZ) critical areas (per paragraphs <u>3.2</u> , <u>3.3</u> , <u>3.4</u> , and <u>3.5</u>). | Required | Required |
| Intermediate holding position marking for taxiway/taxiway intersections (per paragraph <u>3.6</u>). | Required | |
| Taxiway centerline markings (per paragraph <u>4.2</u>). | Recommended | Required |

| Marking | Black Border | Glass Beads |
|--|--------------|-------------|
| All taxiway centerline markings on taxi routes designated as surface movement guidance and control system (SMGCS) routes (per paragraph 4.2). | Required | Required |
| Enhanced taxiway centerline markings per paragraph 4.3. | Required | Required |
| Taxiway edge marking (per paragraph 4.4). | | Recommended |
| Geographic position marking (per paragraph 4.11). | Required | Required |
| Surface painted signs for holding position signs (paragraph 4.5), taxiway direction signs (paragraph 4.6), taxiway location signs (paragraph 4.7), gate destination signs (paragraph 4.8), and apron entrance point signs (paragraph 4.9). | Required | Required |
| Non-movement area boundary marking (per paragraph 5.4). | Required | Required |
| All other markings not listed paragraph 1.4.1.1. | Recommended | |
| <p>Note 1: Table 1-1 and Table 2-1 are interrelated. Surface markings per Table 1-2 that require black borders may initially be deferred for the case of new, dark-colored asphalt concrete/new asphalt treated pavement surfaces for up to 2 years as per Table 1-1. This case applies to dark, newly constructed asphalt concrete/newly asphalt treated pavements. New light-colored asphalt projects require the black borders upon completion.</p> <p>Note 2: Surface markings identified per Note 1 that sufficiently fade before 2 years, shall receive black borders.</p> | | |

483 1.4.2 Technique 2 – Use of Glass Beads on Permanent Pavement Markings.

484 Glass beads identified in Item P-620 of AC 150/5370-10 are an effective means of
485 enhancing the conspicuity of surface markings when aircraft and vehicles operate at
486 night, during low-visibility conditions, or when the pavement surface is wet. The glass
487 beads used in the below applications should meet the specifications found in AC
488 150/5370-10, Item P-620. Due to the additional increase in marking conspicuity caused
489 by certain glass beads, the FAA recommends that runway holding position markings
490 contain either Type III or Type IV glass beads as determined by the airport operator. If
491 Type IV glass beads that have a larger diameter are used, then they should only be
492 applied in higher-built materials, such as TT-P-1952E-Type III waterborne paint,
493 epoxy, methyl methacrylate, or preformed thermoplastic. Precaution: Glass beads
494 should never be used in black paint, including numerals and inscriptions found in
495 Appendix B. See Table 1-2 for surface markings that are required or recommended to
496 have glass beads.

| Glass Bead Requirement Per AC 150/5370-10, Paragraph 620-3.5, Application (General) |
|--|
| “Glass beads shall be distributed upon the marked areas at the locations shown on the plans to receive glass beads immediately after application of the paint. A dispenser shall be furnished that is properly designed for attachment to the marking machine and suitable for dispensing glass beads. Glass beads shall be applied at the rate(s) shown in Item P-620, Table 1 of AC 150/5370-10. Glass beads shall not be applied to black paint or green paint, including numerals and inscriptions found in <u>Appendix B</u> . Type III beads |

Glass Bead Requirement

**Per AC 150/5370-10, Paragraph 620-3.5, Application
(General)**

shall not be applied to red or pink paint. Glass beads shall adhere to the cured paint or all marking operations shall cease until corrections are made. Different bead types shall not be mixed. Regular monitoring of glass bead embedment should be performed.”

497 **1.5 No-Taxi Islands.**

498 1.5.1 Safety Enhancements.

499 For this advisory circular, the term “No-Taxi Island” is a category of island having
500 safety enhancements. The safety enhancements mentioned by this paragraph are found
501 along a section of a taxiway. The safety enhancements are achieved by painting specific
502 surface markings and, depending on the taxiway’s location, complying with standard
503 taxiway design features under AC 150/5300-13 and complying with standard vertical
504 signage under AC 150/5340-18. The following applications of no-taxi islands serve to
505 mitigate taxiway excursions, runway incursions, or certain types of wrong runway
506 takeoffs. Explanations of the most common applications are listed below along with
507 subparagraph 1.5.2 which provides sequential practices for applying surface markings,
508 types of physical reconstruction of a taxiway section, and figures for visual clarification
509 of their applications.

510 1.5.1.1 **Case 1:** This application involves taxiway excursions into unpaved areas
511 or onto a paved area not intended for aircraft operations. Documented
512 examples are (a) compound taxiing turns along consecutive taxiway-
513 taxiway intersections as shown in Figure 1-6 and (b) an extra-long section
514 of a taxiway that borders a large paved area(s). The objective for this
515 application is to provide clearer, visual cues along such sections of a
516 taxiway so that pilots can recognize the edges of usable full-strength
517 taxiway from non-maneuvering areas. Under this application the safety
518 enhancement is generally achieved through surface painted markings
519 alone.

520 1.5.1.2 **Case 2:** This application involves runway incursions caused by terminals
521 or ramps whose taxiways offer direct access to a runway; in some cases
522 pilots have more immediate access to the runway. The most common
523 documented examples are illustrated in Figure 1-7 (runway lacks a full-
524 length parallel taxiway) and Figure 4-3 of AC 150/5300-13A, (runway has
525 a full-length parallel taxiway). In both cases, a taxi route beyond the ramp
526 offers direct taxi access to a runway. The objective for this application is
527 to create turning maneuvers for pilots along a reconfigured taxi route
528 while on the ramp or just beyond the ramp prior to entering the runway.
529 Under this application the safety enhancement is achieved by either (1)
530 creating no-taxi islands on ramps which are generally accomplished

531 through surface painted marking(s), namely, continuous taxiway edge
532 markings, taxiway shoulder markings, and greenish no-taxi island(s), and
533 possibly installing vertical signage or (2)
534 removing/reconfiguring/constructing a taxiway beyond the ramp.

535 1.5.1.3 **Case 3:** This application involves runway incursions and certain types of
536 wrong-runway takeoffs caused by an oversized entrance taxiway. A
537 documented example is a single entrance taxiway with excessive width
538 located on a sizable paved area that abuts the runway entrance as shown in
539 Figure 1-7 (figure shows new taxiway fillet design methodology from
540 AC 150/5300-13A). The objective for this application is to downsize this
541 oversized entrance taxiway to the standard taxiway width plus having
542 specific taxiway surface marking(s) and relocation of vertical signage
543 closer to the taxiway centerline. Excess pavement usually provides enough
544 surface area to obtain the standard taxiway shoulder width. This action
545 enhances the recognition of the location of the runway holding position by
546 creating a more distinguishable, *channeled entrance* to the assigned
547 runway. Regarding wrong-runway takeoffs, this application may mitigate
548 wrong runway takeoffs when an excessively wide taxiway entrance serves
549 two runway ends that are in very close proximity to each other. Under
550 these applications the safety enhancement is achieved by creating greenish
551 no-taxi islands (a design standard for entrance taxiways) after downsizing
552 excessive taxiway width and by the relocation of standard surface painted
553 markings and placement of vertical signage. Physical reconstruction of the
554 entrance taxiway or the removal of excessive pavement may not be
555 necessary.

556 1.5.1.4 **Case 4:** This application involves runway incursions caused by certain
557 multi-entrance taxiways located on a single, expansive paved area that
558 abuts the runway; usually located at the runway end. A documented
559 example is an excessive paved area with multi-parallel entrance taxiways
560 that lack greenish no-taxi islands as shown in Figure 1-8 (figure shows
561 new taxiway fillet design methodology from AC 150/5300-13A). As
562 illustrated in the “before” example, the continuous pavement lacks (1)
563 standard entrance taxiway widths, (2) greenish no-taxi islands (a design
564 standard for entrance taxiways), (3) standard vertical signage for each
565 taxiway entrance, and (4) standard dual-continuous taxiway edge surface
566 markings on both sides of each taxiway entrance. The objective for this
567 application is to obtain standard width entrance taxiways by the insertion
568 of greenish no-taxi islands which in turn, allow each reconfigured entrance
569 taxiway to have its own, unique taxiway identifier, surface markings, and
570 vertical signage; thus creating a unique tunnel effect. This action enhances
571 the recognition of each runway holding position and allows for the proper
572 placement of their vertical signage and other surface markings. Under this
573 application the safety enhancement is achieved by creating no-taxi islands
574 through the placement of standard surface painted markings and standard

575 vertical signage with or without the physical reconstruction of the entrance
576 taxiway(s).

577 1.5.2 Sequential Process for Safety Enhancements.

578 The following descriptions provide sequential practices for applying surface markings
579 and provide illustrations to achieve the applications explained in subparagraph 1.5.1.

580 1.5.2.1 **Case 1A.**

581 Taxiway section has stabilized/paved taxiway shoulders with or without
582 paved areas beyond the taxiway shoulders, see Figure 1-6.

- 583 1. First, paint the dual-continuous taxiway edge marking per paragraph
584 4.4 of this advisory circular.
- 585 2. If excursions continue, then paint yellow taxiway shoulder markings
586 according to paragraph 4.10.4 of this advisory circular.
- 587 3. If excursions persist, then, for the taxiway section suffering continued
588 excursions, apply a green border that starts beyond the end point of the
589 yellow taxiway shoulder markings to create a visually green no-taxi
590 island(s). The depth of the green no-taxi island must be at least equal
591 to the width of standard taxiway shoulder for the largest taxiway
592 design group using this taxiway. This action may require adding
593 stabilized pavement. If pavement exists, apply green paint in
594 accordance to Federal Standard 595, Color Number #34110. For
595 locations lacking paved areas beyond the taxiway shoulder(s), the
596 green border may be achieved by planting grass, installing green
597 artificial turf, or, for desert locations, placement of an earthen material
598 that provides a more definitive, visual distinction between the
599 shoulders and the ground areas. Note: Because of the variability in the
600 shape of existing taxiway geometries, these sequential marking steps
601 may not be fully achieved. For example, there is insufficient area
602 between the non-parallel taxiways to obtain the standard width of a
603 green border beyond the end point of standard taxiway shoulder
604 markings. Common examples are taxiways in such close proximity to
605 each other that they create small unusable odd-shape/circular areas. In
606 such situations, paint yellow taxiway shoulder markings with a green
607 border onto the available taxiway shoulder(s) such that all or some of
608 the green border is painted between the yellow taxiway shoulder
609 markings. For severe situations, the depth of the green border should,
610 to the extent possible, equal the width of the standard yellow taxiway
611 shoulder markings for the largest taxiway design group using the site.

612 1.5.2.2 **Case 1B.**

613 Taxiway section lacks stabilized/paved taxiway shoulders, see Figure 1-6.

- 614 1. First paint the dual- continuous taxiway edge marking per paragraph
615 4.4 of this advisory circular.

- 616 2. If excursions continue, then plant grass or install green artificial turf
617 beyond the edges of the taxiway for a distance equal to at least the
618 width of standard taxiway shoulder for the largest taxiway design
619 group using this taxiway.
- 620 3. If excursions persist, then construct a stabilized/paved standard
621 taxiway shoulder width per AC 150/5300-13 that is painted with
622 yellow taxiway shoulder markings per paragraph 4.10.4 of this
623 advisory circular, plus create (with or without stabilized pavement) the
624 green border per Case1A (3).

625 1.5.2.3 **Case 2A.**

626 Ramps with a taxiway having direct access to a runway which lacks a
627 parallel taxiway, see Figure 1-7.

- 628 1. First, reconfigure taxiway route(s) located on the ramp to create a no-
629 taxi island in front of the existing taxiway serving the runway. This
630 action produces multi-turning operations for pilots. In some cases,
631 such as ramps that lack sufficient space to create the no-taxi island
632 affect, construct a taxiway(s) off the sides of the ramp running parallel
633 to the runway to create the desired turning maneuver for pilots.
- 634 2. For no-taxi islands located on the ramp, paint the dual-continuous
635 taxiway edge marking per paragraph 4.4 of this advisory circular.
- 636 3. If runway incursions continue or taxing through the no-taxi island
637 occurs, then paint yellow taxiway shoulder markings according to
638 paragraph 4.10.4 of this advisory circular.
- 639 4. If runway incursions or taxing through the no-taxi island persist, then
640 apply a green border starting from the end point of yellow taxiway
641 shoulder markings to create a visually green no-taxi island(s). The
642 depth of the green no-taxi island must be at least equal to the width of
643 standard taxiway shoulder for the largest taxiway design group using
644 this taxiway. The border is green paint per Federal Standard 595,
645 Color Number #34110.
- 646 5. For both (ii) and (iii), install any required or deemed necessary vertical
647 taxiway signage in accordance with AC 150/5340-18 and,
- 648 6. Paint any required or deemed necessary surface markings per this
649 advisory circular.

650 1.5.2.4 **Case 2B.**

651 Ramps with direct access taxiways to runways that have a parallel
652 taxiway, see Figure 4-3 of AC 150/5300-13A.

- 653 1. As illustrated in Figure 4-4 of AC 150/5300-13A, relocate the existing
654 taxiway between the ramp and the parallel taxiway to a new location.
655 This action produces the multi-turning operations for pilots prior to
656 entering the runway.

- 657 2. Install required or deemed necessary surface markings and vertical
658 signage for the new taxiway connector.
- 659 3. Paint the abandoned taxiway to produce a green no-taxi island or
660 remove the abandon taxiway pavement.

661 1.5.2.5

Case 3.

662 Single Entrance Taxiways with Excessive-Width, **Error! Reference**
663 **source not found..**

- 664 1. Reduce the excessive width of the entrance taxiway by painting dual-
665 continuous taxiway edge markings (paragraph 4.4) that indicate the
666 edges of the prescribed standard taxiway width per AC 150/5300-13
667 for the largest taxiway design group using the taxiway entrance; plus
- 668 2. Convert excessive pavement into, if possible, standard taxiway
669 shoulder widths having painted standard yellow taxiway shoulder
670 markings per paragraph 4.10.4 of this advisory circular; plus
- 671 3. Create green no-taxi islands for the reconfigured entrance taxiway
672 starting from the end of the end point of the yellow taxiway shoulder
673 marking. The depth of the green border must be at least equal to the
674 width of the standard taxiway shoulder required for the largest taxiway
675 design group using the taxiway entrance. The border is green paint per
676 Federal Standard 595, Color Number #34110; plus
- 677 4. Relocate/install all missing vertical signage in accordance with
678 AC 150/5340-18.

679 1.5.2.6


Case 4.

680 Multi-Entrance Taxiways located on single, expansive pavement abutting
681 the runway, see **Error! Reference source not found..**

- 682 1. If the width of any entrance taxiway exceeds the standard taxiway
683 width, then follow instructions in Case 3.
- 684 2. If none of the entrance taxiways exceed the standard width, then paint
685 standard yellow taxiway shoulder markings per paragraph 4.10.4 of
686 this advisory circular; plus
- 687 3. Create green no-taxi islands for each taxiway entrance starting from
688 the end of the yellow taxiway shoulder markings. The depth of the
689 green border must be at least equal to the width of the standard
690 taxiway shoulder required for the largest taxiway design group using
691 the taxiway entrance. The border is green paint per Federal Standard
692 595, Color Number #34110; plus
- 693 4. Relocate/install all missing vertical signage for each entrance taxiway
694 in accordance with AC 150/5340-18.

695


Figure 1-6. Case 1



696

697


Figure 1-7. Case 3



698

699

Figure 1-8. Case 4




700

701

702

Figure 1-9. Case 2



703

704

CHAPTER 2. SURFACE MARKINGS FOR RUNWAYS**2.1 Application.**

706 The minimum requirements for surface marking schemes used for runways are a direct
 707 function of the approach category for each runway threshold and the existence of
 708 displaced thresholds, stopways, blast pads, or extra-wide shoulders. Runways having
 709 the same approach category off both runway thresholds will show the same surface
 710 marking scheme from threshold to threshold (with some exceptions, such as the runway
 711 designator). In comparison, runways with different approach categories will show two
 712 different surface marking schemes. The complete runway surface marking schemes
 713 required by a runway combine Table 2-1 requirements with the physical structure, such
 714 as blast pads or stopways, and usage of the runway.

715 2.1.1 Table 2-1 identifies the minimum required surface marking schemes for paved runways
 716 that lack stopways, blast pads, displaced thresholds, or aligned taxiways according to
 717 their threshold approach category. Figure A-1, Figure A-2, Figure A-3, and Figure A-6
 718 provide the dimensional standards for the surface marking schemes. An airport operator
 719 may paint a runway with additional surface marking schemes beyond those required,
 720 such as a visual runway with runway edge markings or the aiming point marking, if
 721 deemed necessary by the FAA. Furthermore, surface markings beyond those described
 722 in Table 2-1 are required to support particular operations, such as a displaced threshold,
 723 or to identify runway related features, such as blast pads, stopways, or Engineered
 724 Materials Arresting Systems (EMAS).

725 **Table 2-1. Minimum required runway surface marking schemes for paved runways**

| Runway Surface Marking Scheme | Threshold Approach Category | | |
|---------------------------------------|-----------------------------|---|---|
| | Visual Approach | Non-precision Approach (and approaches with vertical guidance not lower than $\frac{3}{4}$ -statute mile visibility) | Precision Approach (Approaches with lower than $\frac{3}{4}$ -statute mile visibility) |
| Landing Designator (par. <u>2.3</u>) | X | X | X |
| Centerline (par. <u>2.4</u>) | X | X | X |
| Threshold Markings (par. <u>2.5</u>) | Note 1 | X | X |
| Aiming Point (par. <u>2.6</u>) | Note 2 | Note 3 | X |
| Touchdown Zone (par. <u>2.7</u>) | | | X |
| Edge Markings (par. <u>2.8</u>) | Note 4 | Note 4 | X |

726 **Note 1:** Required on runways serving approach categories C and D airplanes and for runways
 727 used, or intended to be used, by international commercial air transport.

728 **Note 2:** Required on 4,200-foot (1,280 m) or longer runways serving approach categories C and D airplanes.

729 **Note 3:** Required on 4,200-foot (1,280 m) or longer instrumented runways.

730 **Note 4:** Used when the full runway pavement width may not be available for use as a runway.

731 2.1.2 Runways with a displaced threshold, blast pad, stopway, or extra-wide shoulders require
 732 additional marking schemes not identified in [Table 2-1](#). These surface marking schemes
 733 and others not in [Table 2-1](#) are discussed separately in this AC. See [AC 150/5300-13](#)
 734 for detailed information about the location of displaced thresholds, blast pads, and
 735 stopways.

736

**Application of Proportioning Runway Markings
 for Non-Standard Runway Widths
 (Painting)**

The dimensional size for the runway surface marking promulgated by this AC is based on the assumption that the runway has a standard runway width as prescribed by [AC 150/5300-13](#). For convenience, the standard widths are shown in [Table 2-2](#). below.

Airport operators with non-standard runway widths may, for specified surface markings, proportionally adjust the marking's width to be less than the standard scheme. Under substandard conditions, the width of marking is in direct proportion to the available runway width. However, the corresponding length for the marking is never reduced.

Subsequent paragraphs in this AC will specify, via a green-shaded solution box, those runway surface markings that may be proportioned. The absence of a green-shaded solution box in a subsequent paragraph implies that that runway surface marking, such as the runway centerline, is not to be decreased in width even if other nearby runway surface markings are proportionally adjusted.

737 **2.2 Interruption of Runway Surface Markings.**

738 At the intersection of two runways, the surface markings of one runway are, with the
 739 possible exception of runway edge markings (such as closed V-shaped runways), fully
 740 displayed through the intersection while the surface markings of the other runway are
 741 completely interrupted. This process of removing runway surface markings from one
 742 runway establishes an order of precedence among the different runways.

743 **2.2.1 Order of Precedence.**

744 2.2.1.1 The order of precedence for displaying the runway surface marking
 745 schemes of one runway over the other runway at the intersection of these
 746 runways should follow this order:

- 747 1. Precision approach runway, Category III.
- 748 2. Precision approach runway, Category II.
- 749 3. Precision approach runway, Category I.

750 4. Non-precision approach runway.

751 5. Visual runway.

752 2.2.1.2 For an intersection of runways of the same precedence, the preferred
753 higher precedence runway is the one having the lowest approach minima
754 or the runway end most often used.

755 2.2.2 Lesser Precedence Runways.

756 The manner in which a lesser precedence runway intersects a higher precedence runway
757 may require the shifting or complete removal of certain surface markings that fall
758 within the intersection. As shown in Figure A-5, the most affected surface markings are
759 the runway centerline, runway edge markings, aiming point markings, and runway
760 touchdown zone markings. The latter two runway markings may have implications
761 when shifted or removed. See paragraphs 2.2.3 and 2.6 for shifting an aiming point
762 marking, and see paragraph 2.7 for removing touchdown zone markings.

763 2.2.3 Consequences When Shifting the Aiming Point Markings.

764 Figure A-4 shows one possible conflict that could occur when the aiming point
765 markings are relocated.

766 2.2.3.1 When the aiming point markings of a given runway that are in the
767 intersection of two runways need to be moved more than 200 feet (61 m)
768 away from the existing threshold, the airport operator will have to displace
769 the existing threshold or designate a new runway end (threshold) in order
770 to retain the distance between the threshold and the aiming point marking
771 as illustrated in the bottom illustration of Figure A-4. The preferred
772 distance to be maintained between the newly designated threshold and the
773 shifted aiming point marking is 1,020 feet (311 m); see paragraph 2.6.

774 2.2.3.2 Runways with an approach landing aid, such as Precision Approach Path
775 Indicators (PAPIs) or Visual Approach Slope Indicators (VASIs), which
776 are co-located with the aiming point markings, can be negatively affected
777 when an excessive shifting of the aiming point marking occurs. The
778 consequence could be a non-compatible threshold crossing height for
779 landing airplanes. When the aiming point markings are shifted more than
780 60 feet (18.3 m), the co-located PAPI or VASI should be evaluated for
781 relocation to provide a correct vertical guidance to pilots. See AC
782 150/5340-30, Design and Installation Details for Airport Visual Aids, to
783 determine if the impact of shifted aiming point markings warrants a
784 relocation of the co-located PAPI or other runway approach aids.


785 2.2.3.3 For landing safety, the FAA requires that whenever the distance between
786 the threshold and aiming point markings is 1,220 feet (372 m) or more, the
787 airport operators place a note in the Airport/Facility Directory (A/FD) to
788 inform pilots about the increased distance existing between the threshold
789 and the aiming point markings.

790 2.2.4 Closed V-Shaped Runway Ends Configuration.

791 The closed V-shaped runway ends configuration is a pavement geometry where two
 792 runway ends commence from the same location but proceed in different directions (see
 793 Figure 1-2). This undesirable geometry requires a special shifting procedure of the
 794 runway landing designator marking of the lesser precedence runway farther down the
 795 runway than prescribed by paragraph 2.3. The special procedure is as follows. On the
 796 lesser order runway, locate the point on its runway centerline that is perpendicular to the
 797 inside common corner of the two intersecting runways. Once this base point is located,
 798 move this base point 20 feet (6.5 m) down the runway centerline to relocate the bottom
 799 of the letter or number(s) used for the runway landing designator. For an intersection of
 800 runways of the same precedence, the preferred higher precedence runway is the one
 801 having the lowest approach minimums or the runway end most often used.

802

Figure 2-1. Closed V geometry



803

Wrong-Runway Takeoffs Mitigation

(Safety)

In an effort to eliminate the possibility of a “wrong-runway” takeoff operation by pilots, the airport operator should reconstruct closed V-shaped runway geometries to a different geometry, possibly an X-shaped geometry.

804 **2.3 Runway Landing Designator Marking.**

805 2.3.1 Purpose.

806 The runway landing designator marking identifies a runway end.

807 2.3.2 Requirement.

808 See Table 2-1.

809 2.3.3 Location.

810 Runway landing designator marking(s) must be located from the runway threshold per
811 Figure A-1, Figure A-2, Figure A-3, or from the displaced threshold per Figure A-8. All
812 these figures show the start location for both types of thresholds.

813 2.3.4 Color.

814 Runway landing designator markings are white. See paragraph 1.4 and Table 1-1 for
815 required techniques to enhance this marking.

816 2.3.5 Characteristics.

- 817 1. A runway landing designator marking consists of a number comprising one or two
818 digits. When parallel runways exist, the number is further supplemented with a
819 letter.
- 820 2. A single-digit runway landing designation number is never preceded by a zero.
821 Runway landing designators are centered in accordance with the green box entitled
822 “Centering of Runway Landing Designators - Width of Rectangular Boxes.”
- 823 3. For single runways, dual parallel runways, and triple parallel runways, the
824 designator number is the whole number nearest the one-tenth of the magnetic
825 azimuth along the runway centerline when viewed from the direction of approach.
826 For example, where the magnetic azimuth along the runway centerline is 183
827 degrees, the runway designator marking would be 18; for a magnetic azimuth of 87
828 degrees, the runway designation marking would be 9. For a magnetic azimuth
829 ending in the number “5” such as 185 degrees, the runway designator marking may
830 be either 18 or 19.
- 831 4. On four or more parallel runways, one set of adjacent runways is numbered to the
832 nearest one-tenth of the magnetic azimuth and the other set of adjacent runways is
833 numbered to the next nearest one-tenth of the magnetic azimuth.
- 834 5. For parallel runways, each runway landing designator number must be
835 supplemented by a letter, in the order shown from left to right when viewed from
836 the direction of approach as prescribed by the following marking criteria. Different
837 labeling patterns than those prescribed below are permissible under certain
838 circumstances as identified in paragraph 2.3.5.
- 839 a. Two parallel runways having a magnetic azimuth of 182 degrees are designated
840 “18L” and “18R.”

- 841 b. Three parallel runways having a magnetic azimuth of 87 degrees are designated
842 “9L,” “9C,” and “9R.”
- 843 c. Four parallel runways having a magnetic azimuth of 324 degrees are designated
844 “32L,” “32R,” “33L,” and “33R.”
- 845 d. Five parallel runways having a magnetic azimuth of 138 degrees are designated
846 “13L,” “13R,” “14L,” “14C,” and “14R” or “14L,” “14R,” “13L,” “13C,” and
847 “13R.” Other combinations exist for this case. See paragraph 2.3.5.
- 848 e. Six parallel runways having a magnetic azimuth of 83 degrees are designated
849 “8L,” “8C,” “8R,” “9L,” “9C,” and “9R. See paragraph 2.3.5.
- 850 f. Seven parallel runways having a magnetic azimuth of 85 degrees – the runways
851 would be designated “8L,” “8C,” “8R,” “9L,” “9C,” “9R,” and “10.” Other
852 combinations exist for this case. See paragraph 2.3.5.
- 853 6. There are certain runway placements where the surface marking schemes for
854 parallel runways provided in paragraph 5 may not be appropriate because their
855 orientation may lead to pilot confusion. For example, the marking scheme
856 recommended for parallel runways on the same side of a terminal is to follow
857 paragraph 2.3.5. However, when two parallel runways are separated by a large
858 distance, as by a central terminal or several terminals, it is preferable to designate
859 the runways as non-parallel runways to avoid pilot confusion. Another case that
860 may cause pilot confusion is a turf runway that is parallel to a paved visual runway
861 but at a great distance from a higher precedence paved runway. In general, the
862 airport operator should carefully choose how to mark parallel runways to eliminate
863 pilot confusion.
- 864 2.3.6 The appearance of the letters and numbers used for runway landing designator markings
865 are in the form and proportion shown in Figure A-6. The spacing between numbers and
866 letters are as shown in Figure A-1, Figure A-2, Figure A-3, and Figure A-6. However,
867 with the exception of the numerals 6 and 9, all numerals and the letters L, C, and R are
868 60 feet (18.3 m) in height. Numerals 6 and 9, which are 63 feet (18.9 m) in height,
869 follow the Rule of 69. That is, although the numerals 6 and 9 are taller, the 3-foot tips
870 of the numerals are ignored so that their separations from the threshold markings, the
871 letters L-C-R, the first runway centerline, and the start of the runway threshold remain
872 as shown in Figure A-1, Figure A-2, and Figure A-3.

Centering of Runway Landing Designators
Width of Rectangular Boxes
(Painting)

Runway landing designators are centered along the runway centerline in accordance with the width of the numeral(s) and the width of the letter.

A rectangular box contains the numeric runway landing designator whose height equals tallest numeral and whose width equals either (1) the width of a single numeral or (2) the total width of two numerals plus the required spacing between the numerals. A runway that requires the letters L, C, or R, will create a second rectangular box in the same fashion. See [Figure A-6](#) for widths of numerals and letters and horizontal spacing between numerals. See [Figure A-1](#), [Figure A-2](#), and [Figure A-3](#) for vertical spacing of rectangular boxes.

Example 1 - Runway 7R will consists of two rectangular boxes. The width of the rectangular box for the numeral 7 equals 23 feet (6.9 m) while the letter R has a width equal to 20 feet (6 m). Therefore, 23 feet (6.9 m) and 20 feet (6 m) are divided equally along the runway centerline.

Example 2 - Runway 14 will consist of a single rectangular box. The total width equals 47 feet (7 + 25 + 15) 14.3 m (2.1 + 7.6 + 4.6). Therefore 47 feet (14.3 m) is divided equally along the runway centerline.

Note: Although the majority of 2-digit designators are centered equally along the runway centerline, example 2 results in the numeral 4 overlapping the runway centerline (unpainted). Other similar combinations, such as Runway 13, Runway 18, place the wider numeral along the unpainted runway centerline.

**Application of Proportioning Runway Markings
for Airplane Design Group (ADG) I Runway Width
(Painting)**

Due to the space limitations on very narrow runways, the size and spacing of the numbers and letters are reduced only when necessary such that the painted runway landing designator is no closer than 2 feet (0.6 m) from the runway edge or runway edge markings. For example, this problem may occur when painting certain dual-numbered runway landing designators spaced 15 feet (4.5 m) apart on an ADG I runway width of 60 feet (18.3 m). In such cases, first reduce the 15-foot (4.5-m) spacing to 10 feet (3.1 m) and retain the size of numerals and letter per [Figure A-6](#). Second, reduce the 15-foot (4.5-m) spacing to 10 feet (3.1 m) and reduce the size of numerals and letter proportionally to maintain the 2-foot (0.6-m) edge or runway edge markings clearance.

874 **2.4 Runway Centerline Marking.**

875 2.4.1 Purpose.

876 The runway centerline marking identifies the physical center of the runway width and
877 provides alignment guidance to pilots during takeoff and landing operations. For
878 lighting provisions, see [AC 150/5340-30](#).

879 2.4.2 Requirement.

880 See [Table 2-1](#).

881 2.4.3 Location.

882 A runway centerline marking is located along the physical center of the runway width
883 and spaced between the runway landing designation markings as shown in [Figure A-1](#),
884 [Figure A-2](#), and [Figure A-3](#).

885 2.4.4 Color.

886 The runway centerline marking is white. See paragraph [1.1](#) and [Table 1-1](#) for required
887 techniques to enhance this marking.

888 2.4.5 Characteristics.

889 A runway centerline marking consists of a line of uniformly spaced stripes and gaps and
890 of uniform width.

891 1. The stripes are 120 feet (36.5 m) in length and the gaps are 80 feet (24.3 m) in
892 length.

893 2. The minimum width of the stripes is:

894 a. 36 inches (90 cm) for precision runways.

895 b. 18 inches (45 cm) for non-precision runways.

- 896 c. 12 inches (30 cm) for visual runways.
- 897 3. To accommodate varying runway lengths, all adjustments to the uniform pattern of
- 898 runway centerline stripes and gaps are made near the runway midpoint (defined as
- 899 the distance between the two thresholds or displaced thresholds). Under such cases,
- 900 reduce the lengths of both the stripes and gaps starting from midpoint and proceed
- 901 toward the runway thresholds. Reduced stripes must be at least 80 feet (24 m) in
- 902 length, and the reduced gaps must be at least 40 feet (12.3 m) in length. The affected
- 903 stripes and gaps within the section should show a uniform pattern.

904 **2.5 Runway Threshold Marking.**

905 2.5.1 Purpose.

906 A runway threshold marking, commencing 20 feet (6 m) from the actual start point of

907 runway threshold, closely identifies the actual beginning point of the runway threshold

908 used for landings. For lighting provisions, see AC 150/5340-30.

909 2.5.2 Requirement.

910 See Table 2-1.

911 2.5.3 Location.

912 The runway threshold marking starts 20 feet (6 m) from the actual start point of the

913 runway threshold as shown in Figure A-1 and Figure A-2. This value remains the same

914 even though a 10-foot (3-m) white threshold bar is introduced, such as for displaced

915 thresholds or the addition of a blast pad or stopway, as shown in Figure A-9. Previously,

916 when a displaced threshold was painted or a blast pad or stopway added, the 20-foot (6-

917 m) dimension was increased to 30 feet (9 m) to accommodate the requirement for

918 painting the runway threshold bar. When any runway threshold or displaced threshold is

919 re-marked with threshold bar markings, or when a blast pad or stopway is added, the

920 separation is 10 feet (3 m) as shown in Figure A-8.

921 2.5.4 Color.

922 The components of a runway threshold marking are white. See paragraph 1.4 and Table

923 1-1 for required techniques to enhance this marking.

924 2.5.5 Characteristics.

925 The runway threshold marking consists of a pattern of longitudinal stripes of uniform

926 dimensions spaced symmetrically about the runway centerline. The number of

927 longitudinal stripes and their spacing is determined by the runway width.

- 928 1. Table 2-2 provides the number of longitudinal stripes for runways having standard
- 929 runway widths as defined by AC 150/5300-13. Figure A-1 illustrates the pattern for
- 930 a 150-foot (45-m) wide runway. See paragraph 2.5.5 for painting guidance
- 931 applicable to non-standard runway widths.

932

Table 2-2. Number of runway threshold stripes for standard runway widths

| Standard runway widths | Number of symmetrical stripes |
|------------------------|-------------------------------|
| 60 feet (18.3 m) | 4 |
| 75 feet (22.9 m) | 6 |
| 100 feet (30.5 m) | 8 |
| 150 feet (45.7 m) | 12 |
| 200 feet (61 m) | 16 |

933

934

935

936

937

938

939

940

2. For standard runway widths, the longitudinal stripes are 150 feet (45.7 m) long and 5.75 feet (1.75 m) wide with the outer edges spaced (stripe-gap) 5.75 feet (1.75 m) apart. However, the two longitudinal stripes nearest the runway centerline are doubled spaced, i.e., outer edges of the near-most pair are 11.5 feet (3.5 m) apart. Figure A-1 illustrates the stripe-gap pattern for 150-foot (46-m) wide runways. The stripe-gap pattern allows sufficient room to paint runway edge markings without interfering with the outermost longitudinal stripes.

**Application of Proportioning Runway Markings
for Non-Standard Runway Widths
(Painting)**

For standard 75-foot (23-m) wide runways that use 36-inch (90-cm) wide runway edge markings, the stripe-gap pattern of 5.75 feet (1.75 m) is reduced to 5.50 feet (1.68 m).

941

942

943

944

945

946

947

948

949

950

951

952

953

954

955

956

957

3. For non-standard runway widths, the same stripe-gap pattern is continued from the runway centerline until the outermost longitudinal stripe is not closer than 4 feet (1.2 m) from the runway edge. For example, for a non-standard 125-foot (38-m) wide runway, the stripe-gap pattern yields a total of 10 longitudinal stripes symmetrical about the runway centerline. In no case should the stripe-gap pattern exceed 92 feet (27 m) on either side of the runway centerline. The value of 92 feet (27 m) is the width for the pattern used on the standard 200-foot (61-m) wide runways.
4. When there is pavement in excess of 5 feet (1.5 m) prior to the actual start of the runway threshold and (a) pilots may confuse the pavement as part of the actual runway or (b) the pavement does not have the same load bearing capacity as the runway, then painting of a runway threshold bar per paragraph 2.9 is required. In contrast, if the installation of landing threshold lights requires pavement to support the light fixtures and the supportive pavement abuts the start point of the runway threshold, then the supportive pavement is not considered a part of the runway. In this instance, the painting of a runway threshold bar is not required.

958 **2.6 Runway Aiming Point Marking.**

959 2.6.1 Purpose.

960 A runway aiming point marking provides a visual aiming point for landing operations.

961 2.6.2 Requirement.

962 See Table 2-1.

963 2.6.3 Location.

964 The preferred beginning of the aiming point marking starts 1,020 feet (311 m) from the
965 runway threshold as shown in Figure A-1, Figure A-2, and Figure A-3. However, this
966 preferred separation is not adequate for all cases as partially discussed below.

Note: The term “preferred” assumes the following conditions: standard visual glide slope of 3 degrees; no obstacle in the approach area affecting the obstacle clearance surface of the PAPI; standard threshold crossing heights per AC 150/5340-30; sufficient runway length so not to force the placement of the aiming point marking; no rapid terrain drop off near the approach threshold that encounters severe turbulence; no elevation differences between the threshold and the installation zone of the PAPI.

967

968 2.6.3.1 **Intersecting Runways.**

969 A separation tolerance of plus or minus 200 feet (61 m) is allowed when it
970 is necessary to shift the aiming point marking to avoid overlapping aiming
971 point markings at dual runway intersection as shown in Figure A-4 and
972 Figure A-5, and discussed in paragraph 2.2.3. However, depending on the
973 threshold crossing heights and the available runway approach aids, the
974 shifting of the aiming point markings may negatively impact the threshold
975 crossing heights for approaching airplanes. One potential impact of the
976 shift is to the co-located runway approach aids, such as the PAPI, in which
977 the previous vertical guidance offered by the aiming point marking to
978 pilots is now incompatible with the threshold crossing height associated
979 with the runway approach aid. Under such conditions, adjustment in the
980 location of the affected runway approach aid may be necessary after an
981 evaluation so that the co-located relationship between the PAPI (and other
982 approach aids) and the shifted aiming point marking permits an acceptable
983 landing operation for both landing aids.

984 2.6.3.2 **Compatible Threshold Crossing Heights.**

985 See AC 150/5340-30 to determine if the impact of a relocated aiming
986 point marking warrants relocating the co-located PAPI (or other runway
987 approach aids).

988 2.6.4 Color.

989 The runway aiming point marking is white. See paragraph 1.4 and Table 1-1 for
990 required techniques to enhance this marking.

991 2.6.5 Characteristics.

- 992 1. The runway aiming point marking consists of two conspicuous rectangular
993 markings, 150 feet (45.7 m) in length for runways of at least 4,200 feet (1280 m) in
994 length between the thresholds (or a displaced threshold(s)), and 100 feet (30.5 m) in
995 length for lesser lengths between the thresholds (or a displaced threshold(s)). The
996 runway aiming point marking is located symmetrically on each side of the runway
997 centerline as shown in Figure A-1, Figure A-2, and Figure A-3. See Table 2-2. for
998 the dimensions of standard runway widths per AC 150/5300-13.
- 999 2. The width of each rectangular marking is as follows:
- 1000 a. 30 feet (9.1 m) for standard runway widths of 150 feet (45.7 m) or greater.
- 1001 b. 20 feet (6 m) for standard runway widths of 100 feet (30.5 m).
- 1002 c. 15 feet (5 m) for standard runway widths of 75 feet (22.9 m).
- 1003 d. 12 feet (3.7 m) for a standard runway width of 60 feet (18.3 m).
- 1004 3. The lateral spacing between the inner sides of the runway aiming point markings is
1005 as follows:
- 1006 a. For runways of 150 feet (45.7 m) or more in width, the lateral spacing between
1007 the inner sides of the rectangular bars centered on the runway centerline is 72
1008 feet (21.9 m).
- 1009 b. For runways of 100 feet (30.5 m) in width, the lateral spacing between the inner
1010 sides of the rectangular bars centered on the runway centerline is 48 feet (14.6
1011 m).
- 1012 c. For runways of 75 feet (22.9 m) in width, the lateral spacing between the inner
1013 sides of the rectangular bars centered on the runway centerline is 36 feet (11.0
1014 m).
- 1015 d. For runways of 60 feet (18.3 m) in width, the lateral spacing between the inner
1016 sides of the rectangular bars centered on the runway centerline is 28.8 feet (8.8
1017 m).

**Application of Proportioning Runway Markings
for Non-Standard Runway Widths
and for Standard Runway Widths less than 150 feet (45.7 m)
(Painting)**

For runways with widths below 150 feet (45.7 m), the width of the rectangular bars and their lateral spacing between the inner sides of the rectangular bars are adjusted in proportion to the available runway width by using the 150-foot (45.7-m) width runway parameters to determine the percentage decrease in lateral spacing and width of each marking. For example, a non-standard 70-foot wide runway would apply $70/150 = 0.467$ to obtain a lateral spacing of $72 \times 0.467 = 33.6$ feet (10.25 m) between the pair and an individual width of $30 \times 0.467 = 14$ feet (4.27 m).

If runway edge markings are also painted, which are not reduced, then the adjustment should add the width of the corresponding runway edge markings plus a minimum 1-foot (0.3-m) clearance between the outer edge of the aiming point marking and the runway edge marking.

Lateral spacing – in no case is the lateral spacing less than 30 feet (9.1 m) except for runways less than 75 feet (22.9 m).

Lengths – in all cases, the length of the aiming point marking remains unchanged.

1018 **2.7 Runway Touchdown Zone Marking.**

1019 2.7.1 Purpose.

1020 For landing operations, the touchdown zone marking identifies the touchdown zone
1021 along a precision runway in 500-foot (152-m) increments. For lighting provisions, see
1022 AC 150/5340-30.

1023 2.7.2 Requirement.

1024 See Table 2-1.

1025 2.7.3 Location.

1026 The touchdown zone marking consists of symmetrically arranged pairs of rectangular
1027 bars in groups of one, two, and three along the runway centerline as shown in Figure A-
1028 1. As shown, there are five groupings with the aiming point marking serving as an
1029 independent, sixth pair.

1030 2.7.3.1 The touchdown zone marking scheme maintains a 900-foot (275-m)
1031 “no-marking zone” from the midpoint of the runway back toward the
1032 threshold. That is, those pairs of surface markings that extend within 900
1033 feet (275 m) of the runway midpoint are eliminated. The intent of this
1034 painting practice is to preserve a 1,800-foot (550-m) unmarked area so
1035 pilots do not confuse the surface markings during a landing with the

1036 surface markings for the other approach procedure. The same practice
 1037 applies equally to a displaced threshold, i.e., the midpoint is located
 1038 between the thresholds or displaced thresholds and not the runway ends.
 1039 Taking this into consideration, the painted pattern for the runway
 1040 touchdown zone marking depends on the (a) authorized approach off each
 1041 runway and (b) the available length between the runway thresholds or
 1042 displaced threshold, i.e., the midpoint. The surface marking patterns for
 1043 the two possible cases are provided in Table 2-3 (case #1) and Table 2-4
 1044 (case #2).

1045 2.7.3.1.1 **Case #1** – Only one runway end requires the runway touchdown zone
 1046 marking scheme. Apply Table 2-3 criteria, which take into account the
 1047 “no-marking zone” of 900 feet (275 m) from the midpoint back toward the
 1048 threshold.

1049 **Table 2-3. Groupings of touchdown zone markings required when installed from one**
 1050 **threshold**

| Distance Between Thresholds (or displaced thresholds) | Markings for Precision Approach End (includes displaced threshold) | Other Runway End Visual or Non-precision |
|--|--|---|
| 6,065 ft (1849 m) or greater ¹ | Full set of markings | Aiming point marking |
| 5,565 ft (1697 m) to 6,064 ft (1848 m) | Less one grouping of rectangular bar markings ² | Aiming point marking |
| 5,065 ft (1544 m) to 5,564 ft (1696 m) | Less two groupings of rectangular bar markings | Aiming point marking |
| 4,565 ft (1391 m) to 5,064 ft (1543 m) | Less three groupings of rectangular bar markings | Aiming point marking |

Note 1: The value of 6,065 feet is derived as follows. For the non-precision or visual runway end, the table assumes the 900-foot “no-marking zone” criterion plus the length of a preferred aiming point marking, which starts 1,020 feet from the start of the threshold to obtain a length of 1,920 feet. Add to this the length of the aiming point marking. Per paragraph 2.6.5, the length of the aiming point marking is either 150 feet or 100 feet. This table uses a length of 150 feet because all the entries in column #1 are greater than 4,200 feet. Therefore, adding 150 feet to 1,920 feet obtains a length of 2,070 feet. For the precision end, which equals 3,995 feet, it assumes the 900-foot “no-marking zone” followed by the standard 75-foot-long rectangular bar for a total length of 975 feet. Add to this value the full 3,000-foot touchdown zone marking scheme and the 20-foot separation between the actual starting point of the runway threshold (or displaced threshold) and the bottom edge of threshold marking to obtain 3,995 feet. Summing the values 3,995 and 2,070 yields 6,065 feet.

Note 2: Each reduction in a pair of rectangular bar markings from the precision end equates to a 500-foot (152-m) reduction between the thresholds.

The painting rationale for this table is to ignore the midpoint between the thresholds so the precision instrumented landing is favored over non-precision or visual landings. That is, the length of the non-precision/visual side of the runways always remains at 2,070 feet in length to promote the painting of a full set of touchdown zone markings.

1051

1052 2.7.3.1.2 **Case #2** – Both runway ends require runway touchdown zone markings.
 1053 Apply Table 2-4 criteria, which take into account the “no-marking zones”
 1054 of 1,800 feet (550 m) from the threshold-to-threshold midpoint.

1055 **Table 2-4. Groupings of touchdown zone markings required when installed from both**
 1056 **thresholds**

| Distance Between Thresholds (or displaced thresholds) | Markings for Each Threshold (or displaced threshold) |
|--|---|
| 7,990 ft (2436 m) or greater ¹ | Full set of markings |
| 6,990 ft (2130 m) to 7,989 ft (2435 m) | Less one grouping of rectangular bars from each side nearest to the runway midpoint ² |
| 5,990 ft (1826 m) to 6,989 ft (2129 m) | Less two groupings of rectangular bars from each side nearest to the runway midpoint ² |
| 4,990 ft (1521 m) to 5,989 ft (1825 m) | Less three groupings of rectangular bars from each side nearest to the runway midpoint ² |
| <p>Note 1: The value of 7,990 feet is derived as follows. Proceed from the runway midpoint in one direction, and you will have the 900-foot “no-marking zone” criterion followed by the standard 75-foot long rectangular bar for a total length of 975 feet. Add to this value the full 3,000-foot touchdown zone marking scheme plus the 20-foot separation between the actual starting point of the runway threshold (or displaced threshold) and the edge of threshold marking to obtain 3,995 feet. Double this value for both directions to obtain 7,990 feet.</p> <p>Note 2: Each reduction in a grouping of rectangular bar markings from both sides equates to a 1,000-foot (305-m) reduction between the thresholds.</p> <p>The painting rationale for this table is to preserve the midpoint between the thresholds, thereby promoting an equal treatment of painting groupings of rectangular bar markings for both sides.</p> | |

1057 2.7.3.2 Because the location of the aiming point marking may be adjusted from
 1058 the threshold to accommodate different approach slopes and/or heights
 1059 over the threshold, and to possibly take into account non-zero runway
 1060 gradients, the location of an adjusted aiming point marking will vary.
 1061 Please see AC 150/5340-30. Under such conditions, an adjusted aiming
 1062 point will, in most cases, continue to be located between the first and the
 1063 second touchdown zone markings. However, when the accumulative effect
 1064 of the adjustments is severe (defined as when a touchdown zone marking
 1065 coincides with or is within 160 feet (48.8 m) of the adjusted aiming point
 1066 marking), that touchdown zone marking must not be painted. For the pilot
 1067 community, this practice permits the aiming point marking to retain its
 1068 prominent visual landing aid as compared to a touchdown zone marking.

1069 2.7.4 Color.

1070 All rectangular bars are white. See paragraph 1.4 and Table 1-1 for required techniques
 1071 to enhance this marking.

1072 2.7.5 Characteristics.

- 1073 1. For runway widths of 150 feet (45.7 m) or greater, each rectangular bar is 75 feet
1074 (22.9 m) long and 6 feet (1.8 m) wide. The lateral spacing between the inner sides of
1075 the rectangular bars on the same side of the runway centerline is 5 feet (1.5 m).
- 1076 2. For runway widths less than 150 feet (45.7 m), the length of the marking remains
1077 unchanged, but the width and the lateral spacing between the markings are reduced
1078 proportionally to the decrease in runway width by using 150-foot (45.7 m)
1079 parameters to determine the percentage decrease.
- 1080 3. The lateral spacing between the inner sides of the rectangular bars centered along
1081 the runway centerline is equal to that of the aiming point marking (criteria repeated
1082 below from paragraph 2.6.5). In all cases, the length of the rectangular bars (and the
1083 aiming point markings) remains unchanged. See Table 2-2 for the dimensions of
1084 standard runway widths.
- 1085 a. For runways of 150 feet (45.7 m) or more in width, the lateral spacing between
1086 the inner sides of the rectangular bars centered on the runway centerline is 72
1087 feet (21.6 m).
- 1088 b. For runways of 100 feet (30.5 m) in width, the lateral spacing between the inner
1089 sides of the rectangular bars centered on the runway centerline is 48 feet (14.6
1090 m).
- 1091 c. For runways of 75 feet (22.9 m) in width, the lateral spacing between the inner
1092 sides of the rectangular bars centered on the runway centerline is 36 feet (11.0
1093 m).
- 1094 d. For runways of 60 feet (18.3 m) in width, the lateral spacing between the inner
1095 sides of the rectangular bars centered on the runway centerline is 28.8 feet (8.8
1096 m).

**Application of Proportioning Runway Markings
for Non-Standard Runway Widths
(Painting)**

For runways with widths below 150 feet (45.7 m), the width of the rectangular bars and their lateral spacing between the inner sides of the rectangular bars are adjusted in proportion to the available runway width by using the 150-foot (45.7 m) width runway parameters to determine the percentage decrease in lateral spacing and width of the marking. For example, a nonstandard 70-foot wide runway would apply $70/150 = 0.467$ to obtain a lateral spacing for the centered pair of $72 \times 0.467 = 33.6$ feet (10.25 m), a lateral spacing for other pairs of $5 \times 0.467 = 2.3$ feet (0.7 m), and a width of $6 \text{ feet} \times 0.467 = 2.8$ feet (0.85 m). This adjustment must be such that the inner sides of the innermost rectangular bars to the runway centerline align themselves with the inner side of the aiming point marking. Given that the runway edge markings are painted, the adjustment should be such that the clearance between the runway side strip and the outer edge of the three-bar grouping is a minimum of 1-foot (0.3-m). In no case should the three-bar group be painted farther out from the runway centerline than the aiming point marking.

1097 **2.8 Runway Edge Marking.**

1098 2.8.1 Purpose.

1099 The runway edge marking provides enhanced visual contrast between the runway edge
1100 and the surrounding terrain or runway shoulders, and delineates the width of suitable
1101 paved area for runway operations. For lighting provisions, see AC 150/5340-30.

1102 2.8.2 Requirement.

1103 See Table 2-1.

1104 2.8.3 Location.

1105 The runway edge marking consists of two parallel stripes, one placed along each edge
1106 of the usable runway with the outer edge of each stripe approximately on the edge of the
1107 paved useable runway. For extra wide runways, such as military runways converted for
1108 public use, the maximum distance between the outer edges of the parallel stripes is 200
1109 feet (61 m). Figure A-1 illustrates the runway edge marking.

1110 2.8.4 Color.

1111 The stripes of the runway edge marking are white. See paragraph 1.4 for recommended
1112 techniques to enhance this marking.

1113 2.8.5 Characteristics.

1114 The runway edge marking has a minimum width of 36 inches (90 cm) for runways of
1115 100 feet (30.5 m) or wider in width and at least 18 inches (45 cm) on smaller width
1116 runways (see Table 2-2 for standard runway widths).

- 1117 1. For runways with a displaced threshold, the edge markings continue through the
 1118 paved area prior to the displaced threshold as shown Figure A-8. This continuation
 1119 of the edge markings is required because this paved area is used for takeoffs and for
 1120 landing rollouts from the other direction.
- 1121 2. Where an aligned taxiway, as shown in Figure A-8 and Figure A-10, precedes a
 1122 runway threshold, both edge markings will terminate. The point of termination of
 1123 the edge markings is determined by the taxiway geometry. **Prohibited:** The
 1124 conversion of a runway section into an aligned taxiway or the construction of a new
 1125 aligned taxiway is prohibited. See AC 150/5300-13. The FAA further recommends
 1126 that existing aligned taxiways, for example, as shown in Figure A-8 and Figure A-
 1127 10, be removed or be reconfigured into usable runways as shown in Figure A-7 or
 1128 Figure A-11. When a taxiway connects to a runway or the runway has turn pads or
 1129 turnarounds, the runway edge marking remains continuous between the runway and
 1130 these adjoining infrastructures.
- 1131 3. For intersecting runways, see guidance in paragraph 2.2.

1132 2.9 Runway Threshold Bar Marking and Runway Displaced Threshold Marking.

1133 The complete marking scheme for a runway with a displaced threshold, when required
 1134 by paragraph 2.1, includes a runway threshold bar and arrowheads with and without
 1135 arrow shafts. Figure A-7, Figure A-10, and Figure A-11 illustrate the various
 1136 applications of displaced thresholds and the requirement for additional marking
 1137 components. For lighting provisions, see AC 150/5340-30.

1138 2.9.1 Runway Threshold Bar Marking.

1139 2.9.1.1 **Purpose.**

1140 The runway threshold bar marking ~~delineates~~ serves two functions by
 1141 delineating the start of the (i) displaced threshold by indicating the
 1142 beginning section of the runway available for landing from the unusable
 1143 section on the approach side of the displaced threshold as shown in Figure
 1144 A-7 and Figure A-11 and (ii) regular threshold from prepared surfaces
 1145 before the runway that are used for a blast pad, stopway, EMAS or end of
 1146 an aligned taxiway as shown in Figure A-8 and Figure A-9.

1147 2.9.1.2 **Requirement.**

1148 Install a runway threshold bar marking when there is a displaced
 1149 threshold, blast pad, stopway, EMAS, or aligned taxiway on the approach
 1150 side of the threshold.

1151 2.9.1.3 **Location.**

1152 The runway threshold bar marking is an elongated rectangular bar that is
 1153 located perpendicular to the runway centerline and on the landing portion
 1154 of the runway. The outboard edge of the marking is aligned with the

1155 location labeled “start of runway displaced threshold” as shown in Figure
 1156 A-8 or “start of runway threshold” as shown in Figure A-9.

1157 2.9.1.4 **Color.**

1158 The runway threshold bar marking is white. See paragraph 1.4 for required
 1159 techniques to enhance this marking.

1160 2.9.1.5 **Characteristics.**

1161 The runway threshold bar marking is 10 feet (3.1 m) in width and extends
 1162 between the runway edges or between the runway edge markings.

1163 2.9.2 **Arrow Marking.**

1164 The arrow marking (arrowheads with and without arrow shafts; depending on the length
 1165 of the displacement) performs three possible functions, that is, two cases for displaced
 1166 thresholds and one case for a runway threshold with an aligned taxiway.

1167 2.9.2.1 **Purposes.**

- 1168 1. Figure A-7 illustrates the predominant case in which the threshold is
 1169 displaced from the runway end. In this case white arrowheads with and
 1170 without arrow shafts are required to identify the portion of the runway
 1171 before the displaced threshold to provide centerline guidance for pilots
 1172 during approaches, takeoffs, and landing rollouts from the opposite
 1173 direction.
- 1174 2. Figure A-10 illustrates the rare case in which a displaced threshold is
 1175 preceded by an aligned taxiway. In this case white arrowheads with
 1176 and without arrow shafts and yellow arrowheads without arrow shafts
 1177 are required to identify the runway portion from the aligned taxiway
 1178 portion. Furthermore, a yellow runway demarcation bar is required to
 1179 identify the start of the runway. See paragraph 2.9.3 for runway
 1180 demarcation bar criteria and figures.
- 1181 3. Figure A-8 illustrates the rare case in which a runway threshold (not
 1182 displaced) is preceded by an aligned taxiway. In this case yellow
 1183 arrowheads without arrow shafts are required to identify the runway
 1184 portion from the aligned taxiway portion.

1185

| General Comment |
|--|
| The conversion of a runway section into an aligned taxiway or the construction of a new aligned taxiway is prohibited. See <u>AC 150/5300-13</u> . |

1186 2.9.2.2 **Requirement.**

1187 Install this marking when the threshold is displaced or preceded by an
 1188 aligned taxiway.

- 1189 2.9.2.3 **Locations.**
- 1190 1. For the predominant case, arrowheads with or without arrow shafts
1191 (depending on the length of displacement) are located on the portion of
1192 the runway before the displaced threshold.
- 1193 2. For the rare cases, only arrowheads are used on the portion of the
1194 aligned taxiway before the threshold bar marking or before the
1195 demarcation bar marking as described in paragraph 2.9.3.
- 1196 2.9.2.4 **Colors.**
- 1197 1. For the predominant case, the arrow shaft and arrowhead are white.
1198 See paragraph 1.4 for required techniques to enhance these markings
1199 which are part of a displaced threshold.
- 1200 2. For the rare cases, the arrowhead is yellow which is not part of a
1201 displaced threshold.
- 1202 2.9.2.5 **Characteristics.**
- 1203 The dimensions and spacing requirements for arrow shafts and arrowheads
1204 are as shown in Figure A-7 (function one), Figure A-8 (function two), and
1205 Figure A-10 (function three).
- 1206 2.9.3 Runway Demarcation Bar Marking.
- 1207 2.9.3.1 **Purpose.**
- 1208 A demarcation bar delineates a runway with a displaced threshold from a
1209 blast pad, stopway, or an aligned taxiway that precedes the runway.
- 1210 2.9.3.2 **Requirement.**
- 1211 Install a demarcation bar marking only when the threshold is displaced
1212 and the runway is preceded by a blast pad, stopway, or aligned taxiway.
- 1213 2.9.3.3 **Location.**
- 1214 The demarcation bar is an elongated rectangular bar on a blast pad,
1215 stopway, or an aligned taxiway that is perpendicular to the runway
1216 centerline at the point of intersection with the start of the runway as shown
1217 in Figure A-10 and Figure A-11. As shown in Figure A-10, the portion of
1218 aligned taxiway before the demarcation bar is not part of the usable
1219 runway for takeoff or for landing from the opposite direction.
- 1220 2.9.3.4 **Color.**
- 1221 The demarcation bar marking is yellow. See paragraph 1.4 for
1222 recommended techniques to enhance this marking.

- 1223 2.9.3.5 **Characteristics.**
- 1224 The demarcation bar marking is 3 feet (0.9 m) wide and extends across the
- 1225 entire width of the blast pad, stopway, or aligned taxiway.
- 1226 **2.10 Chevron Markings for Blast Pads, Stopways, and EMAS.**
- 1227 2.10.1 Purposes.
- 1228 The chevron marking identifies paved blast pads, stopways, and EMAS (engineered
- 1229 materials arresting systems) in relation to the end of the runway. For lighting
- 1230 provisions, see AC 150/5340-30, and for EMAS design, see AC 150/5220-22,
- 1231 Engineered Materials Arresting Systems (EMAS) for Aircraft Overruns.
- 1232 2.10.2 Requirement.
- 1233 Install chevron markings on blast pads, stopways, and EMAS.
- 1234 2.10.3 Location.
- 1235 The chevron marking is located on the blast pad and stopway that are aligned with and
- 1236 contiguous to the runway end as shown in Figure A-9 and Figure A-11. The chevron
- 1237 scheme for an EMAS installation is also centered along the extended runway centerline
- 1238 (not shown in Figure A-9 and Figure A-11).
- 1239 2.10.4 Color.
- 1240 Chevron markings are yellow. See paragraph 1.4 for a recommended technique to
- 1241 enhance this marking.
- 1242 2.10.5 Characteristics.
- 1243 Dimensionally, stopways equal the width of the runway while blast pads equal the
- 1244 runway width plus the standard shoulder widths (see AC 150/5300-13). The dimensions
- 1245 and spacing requirements for chevron markings are shown in Figure A-9. The
- 1246 recommended minimum length for a stopway is 150 feet (45.7 m) to allow for at least
- 1247 two chevron stripes. For cases where (1) standard length blast pads, per AC 150/5300-
- 1248 13, are installed off runway ends designed exclusively for small airplanes (Airplane
- 1249 Design Groups I and II– small) or (2) existing stopways are less than 150 feet (45.7 m)
- 1250 in length on runway widths of 75 feet (22.9 m) or less, the width of the chevrons and the
- 1251 spacing between the chevrons shown in Figure A-9 can be reduced by two-thirds. The
- 1252 intent of the reduction in dimensions is to provide pilots with at least two visible
- 1253 chevrons.
- 1254 **2.11 Runway Shoulder Marking.**
- 1255 2.11.1 Purpose.
- 1256 The runway shoulder marking is used, when needed, as a supplement to further
- 1257 delineate a paved runway shoulder that pilots have mistaken or are likely to mistake as

- 1258 usable runway. This marking is used only in conjunction with the runway edge
1259 marking.
- 1260 2.11.2 Requirement.
1261 Runway shoulder markings are optional.
- 1262 2.11.3 Location.
1263 The runway shoulder marking is located between the runway edge marking and the
1264 outer edge of the paved shoulder as shown in Figure A-12.
- 1265 2.11.4 Color.
1266 Runway shoulder markings are yellow. See paragraph 1.4 for a recommended technique
1267 to enhance this marking.
- 1268 2.11.5 Characteristics.
1269 The runway shoulder marking consists of stripes 3 feet (0.9 m) in width and spaced 100
1270 feet (30.5 m) apart along the edge of the runway. The stripes start at the runway
1271 midpoint, are slanted at an angle of 45 degrees to the runway centerline, and are
1272 oriented as shown in Figure A-12.

1273

CHAPTER 3. HOLDING POSITION MARKINGS**1274 3.1 Applications of Holding Position Markings.**

1275 The purposes for the different holding position markings are to prevent aircraft and
1276 vehicles from entering into critical areas associated with a runway and navigational
1277 aids, or to control traffic at the intersection of taxiways. This AC describes six
1278 operational situations (cases) using three different holding position marking schemes.
1279 Cases 1, 2, and 3 employ the same marking scheme referred to as Pattern A – runway
1280 holding position marking. Cases 4 and 5 employ a different marking scheme referred to
1281 as Pattern B – ILS/MLS, POFZ holding position marking or the Runway
1282 Approach/Departure Areas of a runway. For certain POFZ operational situations, Case
1283 5 uses Pattern B in which it usually appears as an L-shaped ladder. Case 6 uses a
1284 different marking scheme referred to as Pattern C – intermediate holding position
1285 marking for taxiway/taxiway intersections. Figure A-13 and Figure A-14 show the four
1286 different marking patterns and figure 3 of AC 150/5340-1G shows the application for
1287 the Runway Approach/Departure Areas of a runway.

- 1288 • **Case 1:** In terms of taxiing on a runway, an aircraft will need to hold short of an
1289 intersecting runway (see paragraph 3.2).
- 1290 • **Case 2:** In terms of landing on a runway used for land and hold short operations
1291 (LAHSO), the aircraft will need to hold short of an intersecting runway or, in some
1292 rare cases, at a specified hold spot on the landing runway (see paragraph 3.2).
- 1293 • **Case 3** (most common application for Cases 1, 2, and 3): In terms of taxiing on a
1294 taxiway, an aircraft will need to hold short prior to entering an active runway (see
1295 paragraph 3.3).
- 1296 • **Case 4:** In terms of taxiing on a taxiway, an aircraft will need to hold short before
1297 entering the critical area of an Instrument Landing System (ILS)/Microwave
1298 Landing System (MLS) (see paragraph 3.4).
- 1299 • **Case 5:** In terms of taxiing on a taxiway, an aircraft will need to hold short before
1300 entering the critical area of a Precision Obstacle Free Zone (POFZ) or Runway
1301 Approach/Departure Areas of a runway (see paragraph 3.5). Although the surface
1302 marking pattern is the same as Case 4, the pattern in many POFZ applications is L-
1303 shaped instead of only linear in shape.
- 1304 • **Case 6:** In terms of taxiing on a taxiway, an aircraft will need to hold short of a
1305 taxiway/taxiway intersection (see paragraph 3.6).

**1306 3.2 Case 1 and Case 2 – Applications of Pattern A for the runway holding position
1307 marking on runways.****1308 3.2.1 Purpose.**

1309 Pattern A, when painted on a runway as shown in Figure A-13, identifies the location
1310 where a pilot (or vehicle driver) is to stop and hold when (1) the runway is operationally
1311 closed for an interval of time so that ATCT can control taxiing operations through a

1312 runway/runway intersection or (2) the runway is used for land and hold short operations
 1313 (LAHSO). For necessary corresponding signage and lighting provisions, see
 1314 AC 150/5340-18, and AC 150/5340-30.

1315

Safety Initiatives

(Safety)

Note 1: Land and hold short operations (LAHSO) require a letter of agreement between the airport operator and the airport traffic control tower (ATCT).

Note 2: Since the design standard for a full-length parallel taxiway reduces both wrong-runway takeoffs and runway incursions, we do not recommend the use of an operationally closed runway as a taxiway, especially when a parallel taxiway exists. Such an operation can potentially confuse pilots because this taxiing operation introduces yellow-colored taxiway surface markings onto the runway itself. Hence, to avoid the potential for operational errors by pilots, the airport operator should take measures to meet the full-length parallel taxiway design standard. In some cases, the operational capacity for a given runway could indicate the need for dual parallel taxiways to avoid this type of taxiing operation.

Note 3: To avoid a runway incursion event at runway/runway intersections when an operationally closed runway is used as a taxiway, the intersection must have the runway holding position marking and corresponding signs whether or not pilots taxi through the runway/runway intersection. Additionally, this marking should only be used in those instances where documentation supports the need for the operational use of the runway as a taxiway. The operational use of a runway as a taxiway must be described in a Letter of Agreement with the ATCT.

1316 3.2.2 Location.

1317 In all Case 1 and Case 2 applications, the criteria given below assume that the
 1318 centerlines of the intersecting runways are perpendicular. Hence, for runway/runway
 1319 intersections that are non-perpendicular, additional distance may be required to ensure
 1320 that all airplane features, such as wingtips, remain outside the protected area of the
 1321 intersecting runway.

1322 3.2.2.1 **Operationally Closed Runways Used for Taxiing Operations.**

1323 The location of the runway holding position marking on operationally
 1324 closed runway is in accordance with the holding position criteria per
 1325 AC 150/5300-13 for the intersecting runway's runway design code.

1326 3.2.2.2 **Runways Used for LAHSO.**

1327 3.2.2.2.1 The location of the runway holding position marking on the runway used
 1328 for LAHSO is in accordance with the holding position criteria per
 1329 AC 150/5300-13 for the intersecting runway's runway design code. On

1330 rare cases the location of the runway holding position marking for
1331 LAHSO is based on a predetermined hold-short point along the landing
1332 runway to protect an approach/departure flight path or to overcome
1333 painting difficulties as described below in paragraph 3.2.2.2.2. In no case
1334 should the location of the predetermined hold-short point be within the
1335 holding position criteria per AC 150/5300-13 for the intersecting runway's
1336 runway design code.

1337 3.2.2.2.2 Certain airfield geometries for runways that are used for taxiing or
1338 LAHSO operations have intersecting taxiway(s) that hamper the painting
1339 of the runway holding position marking (and installation of accompanying
1340 necessary signage) in accordance with the applicable holding position
1341 criterion. One such geometry occurs when a crossing taxiway or its fillet
1342 intersects the runway where the marking or sign is to be placed. One
1343 solution is to move the hold-short point farther away from the
1344 runway/runway intersection so that both the marking and the installed
1345 signage clear the common crossing area. Under this solution:

- 1346 1. the marking is always painted at a greater distance than the holding
1347 position criteria in AC 150/5300-13, and
- 1348 2. the required corresponding signage retains only the runway
1349 designations, i.e., never uses a taxiway designation.

1350 3.2.3 Color.

1351 The Pattern A marking scheme, as shown in Figure A-13, is yellow and, when painted
1352 on light-colored pavements, is outlined in black. See paragraph 1.4 and Table 1-1 for
1353 required techniques to enhance this surface marking on light-colored pavements.

1354 3.2.4 Characteristics.

1355 3.2.4.1 The marking is identical to the runway holding position marking installed
1356 on a taxiway as described in paragraph 3.3 and shown in Figure A-13. The
1357 solid lines, as compared to the dashed lines, are always on the side where
1358 the aircraft is to hold.

1359 3.2.4.2 The marking is installed perpendicular to the runway centerline and
1360 interrupts all runway markings except for the runway designation marking.
1361 If the runway holding position marking should interrupt the mentioned
1362 exceptions, then paint the runway holding position marking farther away
1363 than specified by AC 150/5300-13 to avoid any interruption of these
1364 specified markings. The painting practice is to avoid "over striping"
1365 existing runway surface markings.

1366 3.2.4.3 The runway holding position marking extends across the full width of the
1367 runway but not onto the runway shoulders or onto any intersecting
1368 taxiway fillet.

1369 **3.3 Case 3 – Applications of Pattern A for the runway holding position marking on**
1370 **taxiways.**

1371 3.3.1 Purposes.

1372 Pattern A, when painted on a taxiway as shown in Figure A-14, serves several roles. For
1373 a taxiway that intersects a runway at an airport with an operating airport traffic control
1374 tower (ATCT), the Pattern A marking scheme identifies the location on a taxiway where
1375 pilots and vehicle drivers are to stop until they receive a clearance from ATCT to
1376 proceed onto the runway. Under this role, Pattern A may be supplemented with the
1377 Geographic Position Marking as part of the airport's Surface Movement Guidance
1378 Control System (SMGCS) Plan as described in paragraph 4.11 and as shown in **Error!**
1379 **Reference source not found.** For a taxiway that intersects a runway at an airport
1380 without an operating airport traffic control tower, Pattern A identifies the location
1381 where pilots and vehicle drivers are to stop to ensure that they have adequate separation
1382 with other aircraft before proceeding onto the runway. For a taxiway that does not
1383 intersect a runway but crosses through a runway approach area or the runway safety
1384 area, the Pattern A marking scheme identifies the location on a taxiway where pilots
1385 and vehicle drivers are to stop to receive clearance from the airport traffic control tower
1386 before proceeding through the protected area. This application serves to stop a taxiing
1387 aircraft from penetrating the runway safety area (a runway incursion) or any of several
1388 airspace surfaces, for example, those used to define the runway threshold, runway inner
1389 approach obstacle free zone, or the runway inner transitional obstacle free zone. If the
1390 marking is located closer than prescribed by AC 150/5300-13, such as when the taxiing
1391 aircraft penetrates a Terminal Instrument Procedures (TERPS) surface, then the airport
1392 operator can expect higher approach minimums to the impacted runway end. AC
1393 150/5300-13 includes a discussion of these airspace surfaces. Except as specified in
1394 paragraph 3.2, the runway holding position marking must not be used for any other
1395 situations than the roles described in this paragraph. For signage and lighting
1396 provisions, see AC 150/5340-18 and AC 150/5340-30.

1397 3.3.2 Location.

1398 Pattern A for the runway holding position marking is located as follows:

1399 3.3.2.1 For a taxiway that intersects a runway, the Pattern A runway holding
1400 position markings must be located on all such taxiways in accordance with
1401 the holding position criteria per AC 150/5300-13 for the runway's runway
1402 design code. This measurement is taken to the edge of the holding position
1403 marking farthest from the runway, at the taxiway centerline (see Figure A-
1404 16). Because the location is based on the approach visibility minimums,
1405 approach category, and airplane design group, the airport operator should
1406 use the lowest approach visibility minima and critical aircraft intended to
1407 use the runway. Pattern A is used also on turnarounds and holding bays as
1408 shown in AC 150/5300-13, especially for airports with an airport traffic
1409 control tower or for any runways used at night and in low-visibility
1410 conditions. Locating a runway holding position marking other than what is
1411 required by this paragraph must be approved by the FAA.

1412 3.3.2.2 For a taxiway not intersecting a runway but crossing through a runway
 1413 safety area, the Pattern A or/and a Pattern B runway holding position
 1414 markings must be located on all such taxiways in accordance with the
 1415 more protective area obtained by either the holding position criteria per
 1416 AC 150/5300-13 for the runway's runway design code or the boundary of
 1417 the approach surface's critical area or for the Runway Approach/Departure
 1418 Areas of a runway. Locating a Pattern A or a Pattern B runway holding
 1419 position marking other than what is required by this and other paragraphs
 1420 must be approved by the FAA Airports Regional Office or Airports
 1421 District Office.

1422

14 Code of Federal Regulation (CFR) Part 139 Certificated Airports
Runway Incursion Mitigation Requirement
(Safety)

The extended runway holding position marking, as illustrated in [Figure D-4](#), is mandatory and is the only acceptable means of compliance for 14 CFR Part 139 certificated airports serving ADGs V and VI airplanes. The enhanced runway holding position marking applies only to those taxiway entrances for a given runway that serve these airplane design groups. This surface painted marking is part of the taxiway centerline marking standard under 14 CFR Section 139.311(a)(2).

1423 3.3.3 Color.

1424 The Pattern A marking scheme, as shown in [Figure A-13](#), is yellow and, when painted
 1425 on light-colored pavements, outlined in black. See paragraph [1.4](#) and [Table 1-1](#) for
 1426 required techniques to enhance this surface marking.

1427 3.3.4 Characteristics.

1428 3.3.4.1 Pattern A for the runway holding position marking consists of a set of two
 1429 continuous lines, two dashed lines, and three spaces that are all parallel,
 1430 extend across the entire width of the taxiway, measure 12 inches (30 cm)
 1431 in width, and are separated as shown in [Figure A-13](#). It is located laterally
 1432 such that a dash is centered on the taxiway centerline. Where the marking
 1433 extends unbroken over more than one taxiway centerline, locate the
 1434 marking such that a dash is centered on one taxiway centerline. At airports
 1435 that do not have an operating ATCT and are not certificated under 14 CFR
 1436 Part 139, the width and separation measurement may be reduced from 12
 1437 inches (30 cm) to 6 inches (15 cm). For clarification, all airports
 1438 certificated under 14 CFR Part 139, whether or not there is an operating
 1439 ATCT, are required to use the 12-inch measurement.

1440 3.3.4.2 The taxiway centerline marking is interrupted by the runway holding
 1441 position marking as shown in [Figure A-13](#).

- 1442 3.3.4.3 For taxiways having taxiway edge markings, interrupt the taxiway edge
1443 marking as shown in [Figure A-23](#) so that the Pattern A marking continues
1444 to the edge of the defined taxiway width. For taxiways that connect to
1445 runways that serve Airplane Design Groups (ADGs) V or VI airplanes as
1446 defined by [AC 150/5300-13](#), the marking is further extended onto both
1447 paved shoulders as shown in [Figure D-4](#). For both airplane design groups,
1448 the length of the marking from the taxiway centerline onto the paved
1449 shoulder measures 62.5 feet (19 m). The 62.5-foot (19-m) measurement
1450 takes into account the downward viewing angle from the cockpit while the
1451 pilots are seated in the normal position as well as other safety factors, such
1452 as aircraft wander from the taxiway centerline. For taxiways with widths
1453 greater than 75 feet (22.9 m), the runway holding position marking is
1454 extended 25 feet (7.5 m) [62.5 viewing angle minus (1/2)(75) standard
1455 taxiway width equals 25 feet] onto the paved taxiway shoulders. Only
1456 those taxiway entrances to runways that serve ADGs V or VI are to be
1457 further enhanced. Typical airplane models within ADGs V and VI include
1458 the Airbus 330-200/-300, A-340-200/-300/-500/-600, A-380, Boeing-747-
1459 100/-200/-400, B-777-200/-300, and B-787-8/-9.
- 1460 3.3.4.3.1 If the runway holding position marking is outlined in black, then the
1461 taxiway edge markings abut the black outline on both sides of this
1462 marking. That is, it abuts the black border of the solid yellow line on one
1463 side and abuts the black border of the dashed yellow line on the other side
1464 (see [Figure A-13](#)).
- 1465 3.3.4.3.2 If the runway holding position marking is not outlined in black, then the
1466 taxiway edge markings abut the holding position marking on both sides.
1467 That is, the taxiway edge markings abut the solid yellow line on one side
1468 and abut the dashed yellow line on the other side (see [Figure A-13](#)).
- 1469 3.3.4.4 The orientation of Pattern A is for the solid continuous lines to be painted
1470 on the side where the aircraft and vehicles will hold before proceeding to
1471 the runway. That is, dashed lines are painted closer to the runway.
- 1472 3.3.4.5 Pattern A is painted perpendicular to the taxiway centerline but may be
1473 canted from the perpendicular in unusual situations, such as an extremely
1474 acute, angled taxiway. For such unusual situations, it may be necessary to
1475 install additional runway holding position signs, runway guard lights, or
1476 stop bars to emphasize the location of the surface painted runway holding
1477 position marking.
- 1478 3.3.4.6 Pattern A on converging taxiways, as shown in [Figure D-13](#), meet at an
1479 angle when two or more taxiways intersect the same runway holding
1480 position marking. On any angled taxiway to the runway, consideration
1481 must be given to locate the painted marking so no portion of an aircraft,
1482 e.g., wing tip or tail, penetrates the runway safety area or any protected

1483 surface. See AC 150/5300-13 for detailed requirements and information
1484 about clearance requirements by aircraft on taxi routes.

1485 3.3.4.7 For taxiways connecting to runways serving ADGs V and VI, having a
1486 light fixture or a sign located on the taxiway shoulder that aligns with the
1487 extended runway holding position marking, as shown in Figure D-4, the
1488 extended runway holding position marking should extend no closer than 5
1489 feet (1.5 m) to the edge of the light fixture or sign.

1490 3.3.4.8 For taxiways connecting to runways serving ADGs V and VI whose
1491 taxiway shoulder markings interfere with or are within 10 feet (3.1 m)
1492 from the extended runway holding position marking, as shown in Figure
1493 D-4, the taxiway shoulder markings are to be removed (omitted) from that
1494 location.

1495 **3.4 Case 4 – Applications of Pattern B for the ILS/MLS Holding Position Marking.**

1496 3.4.1 Purposes.

1497 Pattern B for the ILS/MLS holding position marking as shown in Figure A-13 identifies
1498 the location on a taxiway or holding bay where a pilot or vehicle driver is to stop when
1499 they have received instructions from the airport traffic control tower (ATCT) to hold
1500 before entering an ILS/MLS critical area. The intent of the marking is to protect the
1501 signal of the ILS/MLS navigational aid by identifying the holding position for CAT I
1502 operations and protecting the approved TERPS for CAT II/III operations. For signage
1503 and lighting provisions, see AC 150/5340-18 and AC 150/5340-30.

1504 3.4.2 Location.

1505 Pattern B for the ILS/MLS holding position marking is located on the taxiway or
1506 holding bay at the boundary of the ILS/MLS critical area and, as appropriate, at the
1507 holding position for CAT I and CAT II/III operations. The entire marking is located
1508 inside the boundary of the protected area.

1509 3.4.2.1 Where the distance between the runway holding position marking (Pattern
1510 A) on a taxiway and the holding position marking (Pattern B) for an ILS
1511 (or MLS) critical area is 50 feet (15 m) or less, one holding position may
1512 be established, provided it will not affect capacity. In this case, the runway
1513 holding position (Pattern A) is moved back to the ILS/MLS holding
1514 position (Pattern B) and only the runway holding position markings
1515 (Pattern A) are installed.

1516 3.4.2.2 If a taxiway or holding bay penetrates both an ILS/MLS critical area and
1517 the Precision Obstacle Free Zone (POFZ) critical area (see Pattern B,
1518 Figure A-13), such as when the threshold is displaced, paint only one
1519 pattern instead of two patterns, but only if the single pattern can protect
1520 both critical areas. The pattern to be painted is the one whose location

- 1521 offers the most conservative, protective boundary (for example, farthest
1522 from the runway).
- 1523 3.4.2.3 The FAA will designate the ILS/MLS critical area and POFZ boundaries
1524 and, as appropriate, determine the correct holding position location for
1525 CAT II/III operations for the airport operator. See AC 150/5300-13 for
1526 general information about the ILS/MLS and POFZ critical areas.
- 1527 3.4.3 Color.
1528 The Pattern B marking scheme as shown in Figure A-13 is yellow and, when used on
1529 light-colored pavements, outlined in black. See paragraph 1.4 and Table 1-1 for
1530 required techniques to enhance this surface marking.
- 1531 3.4.4 Characteristics.
- 1532 3.4.4.1 Pattern B for the ILS/MLS holding position marking consists of a set of
1533 two parallel lines that are 2 feet (0.6 m) wide and spaced 4 feet (1.2 m)
1534 apart. These parallel lines are connected by perpendicular sets of two lines
1535 that are 1 foot (0.3 m) wide and spaced 1 foot (0.3 m) apart and repeat
1536 every 10 feet (3 m). The Pattern B marking for ILS/MLS applications
1537 must extend across the entire width of the taxiway or holding bay (see
1538 Figure A-13). It is located laterally such that a set of perpendicular lines
1539 (parallel to the taxiway centerline) are equidistant from the taxiway
1540 centerline. Where the marking extends unbroken over more than one
1541 taxiway centerline, locate the marking such that one set of perpendicular
1542 lines is equidistant from one taxiway centerline. At airports that do not
1543 have an ATCT and are not certificated under 14 CFR Part 139, the airport
1544 operator may reduce the dimension for the width of the parallel yellow
1545 lines and spaces from 2 feet (0.6 m) to 1 foot (0.3 m) and from 4 feet (1.2
1546 m) to 2 feet (0.6 m). For clarification, all airports certificated under 14
1547 CFR Part 139, whether or not there is an operating ATCT, are required to
1548 use the larger measurements.
- 1549 3.4.4.2 The taxiway centerline marking is interrupted by the ILS/MLS holding
1550 position marking as shown in Figure A-13.
- 1551 3.4.4.3 For taxiways having taxiway edge markings, interrupt the taxiway edge
1552 marking so that the Pattern B marking continues to the edge of the defined
1553 taxiway width as shown in Figure A-13. For taxiways that connect to
1554 runways that serve Airplane Design Groups (ADGs) V or VI airplanes as
1555 defined by AC 150/5300-13, the marking is further extended onto both
1556 paved shoulders (similar to Pattern A as shown in Figure D-4) only when
1557 the Pattern A marking is omitted per paragraph 3.4.2.1. In that case, for
1558 both airplane design groups, the length of the marking from the taxiway
1559 centerline onto the paved shoulder measures 62.5 feet (19 m). The 62.5-
1560 foot (19-m) measurement takes into account the downward viewing angle
1561 from the cockpit while the pilots are seated in the normal position as well

1562 as other safety factors, such as aircraft wandering from the taxiway
 1563 centerline. For taxiways with widths greater than 75 feet (22.9 m), the
 1564 ILS/MLS holding position marking is extended 25 feet (7.5 m) [62.5
 1565 viewing angle minus (1/2)(75) standard taxiway width equals 25 feet] onto
 1566 the paved taxiway shoulders. Typical airplane models within ADGs V and
 1567 VI include the Airbus 330-200/-300, A-340-200/-300/-500/-600, A-380,
 1568 Boeing-747-100/-200/-400, B-777-200/-300, and B-787-8/-9.

1569 3.4.4.3.1 If the ILS/MLS holding position marking is outlined in black, then the
 1570 taxiway edge markings about the black outline on both sides of this
 1571 marking (see [Figure A-13](#)).

1572 3.4.4.3.2 If the ILS/MLS holding position marking is not outlined in black, a 6-inch
 1573 gap is left between the holding position marking and the taxiway edge
 1574 marking (see [Figure A-13](#)).

1575 3.4.4.4 Pattern B is painted perpendicular to the taxiway centerline but may be
 1576 canted from the perpendicular in unusual situations, such as an extremely
 1577 acute, angled taxiway. For such unusual situations, it may be necessary to
 1578 install additional runway holding position signs, runway guard lights, or
 1579 stop bars to emphasize the location of the surface painted runway holding
 1580 position marking.

1581 3.4.4.5 Pattern B on converging taxiways meet at an angle when two or more
 1582 taxiways intersect the same ILS/MLS holding position marking. On any
 1583 angled taxiway to the runway, consideration must be given to locate the
 1584 painted marking so no portion of an aircraft, e.g., wing tip or tail,
 1585 penetrates the protected surface. See AC 150/5300-13 for detailed
 1586 requirements and information about clearance requirements by aircraft on
 1587 taxi routes.

1588 3.4.4.6 For taxiways connecting to runways serving ADGs V and VI whose
 1589 taxiway shoulder markings interfere with or are within 10 feet (3.1 m)
 1590 from the extended ILS/MLS holding position marking (see paragraph
 1591 [3.4.4.3](#)), the taxiway shoulder markings are to be removed (omitted) from
 1592 that location.

1593 **3.5 Case 5 – Applications of Pattern B for Precision Obstacle Free Zone (POFZ)** 1594 **holding position marking.**

1595 3.5.1 Purposes. Pattern B for the POFZ holding position marking as shown in [Figure A-13](#)
 1596 and for the Runway Approach/Departure Areas of a runway as shown in AC 150/5340-
 1597 18G, figure 3, identify the locations on a taxiway or holding bay where a pilot or
 1598 vehicle driver is to stop when they have received instructions from the airport traffic
 1599 control tower (ATCT) to hold before entering these critical areas. The marking is used
 1600 also at non-towered airport where the runway end has an approved vertical guidance of

1601 ¾-statute mile approach visibility minimum or less. The intent of the marking is to
1602 protect the authorized landing minima (TERPS) for a given runway end and the
1603 Runway Approach/Departure Areas of a runway. See AC 150/5300-13 for detailed
1604 information about these critical areas. For signage and lighting provisions, see AC
1605 150/5340-18 and AC 150/5340-30. Install this marking when a POFZ or the Runway
1606 Approach/Departure Areas of a runway exists.

1607 3.5.2 Location.

1608 Pattern B position marking is located on the taxiway or holding bay at the boundary of
1609 the POFZ critical area or the Runway Approach/Departure Areas of a runway as
1610 defined by AC 150/5300-13 and, when appropriate, at the holding position for CAT I
1611 and CAT II/III operations. Figure A-17 shows the most common POFZ application for
1612 this marking, which is L-shaped. Because of the variety of taxiway entrance/holding
1613 bay geometries, the Pattern B marking for the POFZ must not be painted over a surface
1614 painted holding position sign.

1615 3.5.2.1 Certain airfield geometries may cause a taxiway or holding bay to
1616 penetrate both an ILS/MLS critical area and the Precision Obstacle Free
1617 Zone (POFZ) critical area, such as when the threshold is displaced. Under
1618 such situations, paint only one pattern instead of two patterns, but only if
1619 the single pattern can protect both critical areas. The pattern to be painted
1620 is the one whose location offers the most conservative, protective
1621 boundary (for example, farthest from the runway). Under this application
1622 the ILS/MLS holding position (Pattern B) marking or POFZ holding
1623 position (Pattern B) marking, which now serves a dual function, cannot be
1624 replaced with, or used in lieu of, a runway holding position (Pattern A)
1625 marking.

1626 3.5.2.2 The FAA Airports Regional Office or Airports District Office will
1627 designate the ILS/MLS critical area, the Runway Approach/Departure
1628 Areas of a runway, and POFZ boundaries and, as appropriate, determine
1629 the correct holding position location for CAT II/III operations for the
1630 airport operator.

1631 3.5.2.3 The Pattern B marking must extend across only those portions of a
1632 taxiway or holding bays that run along the boundary of the POFZ as
1633 shown in Figure A-14 and Figure A-17 or for the Runway
1634 Approach/Departure Areas of a runway.

1635 3.5.3 Color.

1636 The Pattern B marking scheme is yellow and, when used on light-colored pavements,
1637 outlined in black. See paragraph 1.4 and Table 1-1 for required techniques to enhance
1638 this surface marking.

1639 3.5.4 Characteristics.

1640 Pattern B holding position marking consists of a set of two parallel lines that are 2 feet
1641 (0.6 m) wide and spaced 4 feet (1.2 m) apart. These parallel lines are connected by

1642 perpendicular sets of two lines that are 1 foot (0.3 m) wide and spaced 1-foot (0.3 m)
1643 apart and repeated every 10 feet (3 m). It is located laterally such that a set of
1644 perpendicular lines (parallel to the taxiway centerline) are equidistant from the taxiway
1645 centerline. Where the marking extends unbroken over more than one taxiway centerline,
1646 locate the marking such that one set of perpendicular lines is equidistant from one
1647 taxiway centerline. For example, [Figure A-13](#) provides the discontinuation (separation)
1648 of a POFZ holding position marking, which follows the same criteria as the ILS/MLS
1649 holding position marking, with an intersecting taxiway centerline or taxiway edge
1650 markings. In addition, [Figure A-17](#) illustrates the general separation of a Pattern B
1651 marking for a POFZ from an entrance taxiway serving a runway. At airports that do not
1652 have an ATCT and are not certificated under 14 CFR Part 139, the airport operator may
1653 reduce the dimension for the width of the parallel yellow lines and spaces from 2 feet
1654 (0.6 m) to 1 foot (0.3 m) and from 4 feet (1.2 m) to 2 feet (0.6 m). For clarification, all
1655 airports certificated under 14 CFR Part 139, whether or not there is an operating ATCT,
1656 are required to use the larger measurements.

1657 **3.6 Case 6 – Applications for Pattern C for the Taxiway/Taxiway Intersection** 1658 **Intermediate Holding Position Marking.**

1659 3.6.1 Purpose.

1660 Pattern C for the intermediate holding position marking, as shown in [Figure A-14](#) for
1661 taxiway/taxiway intersections, is used to support the operational need by the airport
1662 traffic control tower to manage taxiing aircraft through a congested intersection or for
1663 other reasons deemed necessary by the FAA. For example, [Figure A-15](#) shows the
1664 intersection between a taxiway and a holding pad used for deicing aircraft. Pilots when
1665 instructed by the airport traffic control tower to “hold short of (taxiway designation)”
1666 must stop so no part of the aircraft extends beyond the boundary of the intermediate
1667 holding position marking. For signage and lighting provisions, see [AC 150/5340-18](#) and
1668 [AC 150/5340-30](#).

1669 3.6.2 Location.

1670 For the taxiway being marked, the intermediate holding position marking for
1671 taxiway/taxiway intersection is located according to the taxiway centerline to fixed or
1672 movable object criteria in [AC 150/5300-13](#) for the most demanding airplane design
1673 group serving the airport (per the definition in [AC 150/5300-13](#)).

1674 3.6.3 Color.

1675 The intermediate holding position marking is yellow and, when used on light-colored
1676 pavements, outlined in black. See paragraph [1.4](#) and [Table 1-1](#) for a required technique
1677 to enhance this surface marking.

1678 3.6.4 Characteristics.

1679 The intermediate holding position marking for taxiway/taxiway intersections consists of
1680 a single dashed line extending across the width of the taxiway per [Figure A-14](#) and
1681 [Figure C-8](#). The single dashed lines are 1 foot (0.3 m) wide, 3 feet (0.9 m) long, and

1682 spaced 3 feet (0.9 m) apart. The marking is located laterally such that a dash is centered |
1683 on the taxiway centerline. Where the marking extends unbroken over more than one |
1684 taxiway centerline, locate the marking such that a dash is centered on one taxiway |
1685 centerline. As shown in Figure A-14, all intersecting taxiway centerlines are spaced 6 to |
1686 12 inches (15 cm to 30 cm) on either side of this marking. When the taxiway has
1687 taxiway edge markings, the taxiway edge markings are interrupted.

1688

CHAPTER 4. SURFACE MARKINGS FOR TAXIWAYS**4.1 Application.**

1690 All taxiways regardless of their width have a centerline marking, and whenever a
1691 taxiway intersects a runway, the taxiway should have a surface painted runway holding
1692 position marking. For 14 CFR Part 139 certificated airports, all taxiways that intersect a
1693 runway must have a surface painted runway holding position sign and an enhanced
1694 taxiway centerline marking. Taxiway edge markings are installed wherever there is a
1695 need to separate the taxiway from a pavement that is not intended for aircraft use or to
1696 delineate the edge of the taxiway that is not otherwise clearly visible. Examples of other
1697 taxiway surface markings that should be installed when appropriate and deemed
1698 necessary by the FAA (in some cases, with input from the tower manager of the airport
1699 traffic control tower (ATCT) include the Pattern A, B, and C holding position markings
1700 discussed in Chapter 3, the intermediate holding position markings for taxiway/taxiway
1701 intersections, geographic position marking, and the taxiway shoulder marking.

4.2 Taxiway Centerline Markings.**4.2.1 Purpose.**

1704 The taxiway centerline marking provides pilots with continuous visual guidance to
1705 permit taxiing along a designated path. See AC 150/5300-13 for standard fillet design,
1706 AC 150/5340-30 for lighting provisions, and AC 150/5340-18 for signage provisions.

4.2.2 Requirement.

1708 All taxiways, regardless of their width, have a surface painted taxiway centerline.

4.2.3 Location.

1710 On a straight section of a taxiway, the taxiway centerline marking is located along the
1711 physical centerline of the paved taxiway. This statement assumes the taxiway was built
1712 to standard, i.e., symmetrical with a taxiway centerline. On curved sections of a
1713 taxiway, the taxiway centerline marking continues from the centerline marking of the
1714 straight portion of the taxiway along a curved centerline defined in AC 150/5300-13.

1715 4.2.3.1 For taxiways that intersect other taxiways, the adequacy of the fillet design
1716 determines the centerline painting scheme as shown in Figure A-19. The
1717 standard design is cockpit-over-centerline steering, which reduces the
1718 number of airplane main gear excursions from the taxiway.

1719 4.2.3.1.1 At taxiway intersections with fillets that do not meet the fillet design
1720 standards of AC 150/5300-13 for the Taxiway Design Group (TDG) of the
1721 taxiway—that is, judgmental over-steering is performed by pilots—the
1722 centerline marking continues straight through the intersection as shown at
1723 the top Figure A-19. This practice applies to intersecting taxiways that are
1724 or are not of the same TDG.

1725 4.2.3.1.2 Where fillets are designed to the TDG of the taxiway, the taxiway
 1726 centerline marking follows the taxiway curve as shown on the bottom of
 1727 Figure A-19 to permit cockpit-over-centerline steering operations. This
 1728 practice applies to intersecting taxiways that are of the same TDG.

Note: AC 150/5300-13 states that cockpit-over-centerline steering is the standard methodology for painting taxiway centerlines in taxiway intersections. To reduce taxiway excursions on turns, airport operators should (1) construct standard fillets and (2) paint taxiway centerlines according to cockpit-over-centerline design.

1729 4.2.3.2 For taxiways that intersect runways, different painting requirements or
 1730 restrictions apply.

1731 4.2.3.2.1 For a taxiway that intersects a runway at a runway end, as shown in Figure
 1732 A-16 and Figure A-17, the taxiway centerline is terminated either at the
 1733 runway edge or at the outer edge of the runway edge marking. However,
 1734 the taxiway centerline (lead-on and lead-off) will continue onto the
 1735 runway under the following conditions:

- 1736 1. Where there is a displaced threshold, as shown in Figure A-8 and
 1737 Figure A-12, the taxiway centerline marking continues onto the
 1738 displaced area of the runway and extends parallel to the displaced
 1739 threshold markings (arrow heads and arrow shafts) for a distance of
 1740 200 feet (61 m) beyond the point of tangency or terminates at the point
 1741 of contact with the displaced threshold bar, whichever is less. As
 1742 shown in Figure A-9, the lead-on and lead-off taxiway centerlines are
 1743 3 feet (1 m) from the runway arrow markings as measured near-edge
 1744 to near-edge. This lead-on or lead-off taxiway centerline line is
 1745 interrupted for all runway markings with some exceptions (see
 1746 paragraph 4.2.3.2.1).
- 1747 2. For low-visibility taxiing operations, when the runway visual range
 1748 (RVR) is below 1,200 feet (366 m), the taxiway centerline marking
 1749 continues across all runway markings with the exception of the runway
 1750 designation marking and, unless required by a SMGCS Plan, the
 1751 runway threshold marking (longitudinal stripes). The painted taxiway
 1752 centerline marking must follow the path of the in-pavement lighting
 1753 criteria of AC 150/5340-30. That is, if the in-pavement lighting is
 1754 curved, the painted taxiway centerline is curved. In this situation, the
 1755 taxiway centerline marking continues onto the runway and extends
 1756 parallel to the runway centerline marking for a distance of 200 feet (61
 1757 m) beyond the point of tangency and is 3 feet (1 m) from the runway
 1758 centerline as measured near-edge to near-edge. For some airfield
 1759 geometries, such as an airfield with parallel runways with several
 1760 parallel taxiways, the painted taxiway centerline at the runway end is
 1761 painted straight through the runway end and curved onto the runway.
 1762 See AC 150/5340-30 for the different RVR in-pavement lighting

1763 requirements and recommendations associated with various airfield
1764 configurations.

1765 4.2.3.3 For taxiways that intersect a runway at any other locations than at the
1766 runway end, as shown in Figure A-16, the taxiway centerline marking
1767 curves onto the runway and extends parallel to the runway centerline
1768 marking for a distance of 200 feet (61 m) beyond the point of tangency
1769 with the runway centerline or terminates at the point of contact with the
1770 displaced threshold bar, whichever is less. As shown in Figure A-16 and
1771 Figure A-17, these lead-on and lead-off taxiway centerlines are 3 feet (1
1772 m) from the runway centerline when measured near-edge to near-edge.

1773 1. For taxiways that cross a runway, which are either perpendicular to or
1774 non-perpendicular to the runway centerline, and are normally used as
1775 crossing taxi routes, the taxiway centerline marking may continue
1776 across the runway but is interrupted for all runway markings with
1777 some exceptions (see paragraph 4.2.3.2.1).

1778 2. For low-visibility taxiing operations, when the RVR is below 1,200
1779 feet (366 m), the taxiway centerline marking continues across all
1780 runway markings with the exception of the runway designation
1781 marking and, unless required by the SMGCS Plan, the runway
1782 threshold marking (longitudinal stripes), aiming point marking, and the
1783 touchdown zone markings.

1784 4.2.4 Color.

1785 The taxiway centerline marking is yellow. See paragraph 1.4 and Table 1-1 for required
1786 and recommended techniques to enhance this marking.

1787

Painting Notice: Over the years, some airport operators have installed other colors to denote various taxiing routes on the movement areas. These surface markings are non-standard. In an attempt to circumvent the yellow color standard, these different colored centerline markings have sometimes been referred to as supplemental markings or some other ambiguous term. Regardless of what they are called, these surface markings are non-standard and require specific approval by the FAA Director of Airport Safety and Standards. Regarding aircraft deicing facilities that are located in a non-movement area, taxiway/taxilane centerlines are painted in accordance with AC 150/5300-14, Design of Aircraft Deicing Facilities.

1788 4.2.5 Characteristics.

1789 4.2.5.1 **Width.**

1790 The taxiway centerline marking width, which is either 6 inches (15 cm) or
1791 12 inches (30 cm), is based on the type of taxiing operation as described

- 1792 below. Uniform width must be maintained for the entire length of the
1793 taxiway except under the following conditions.
- 1794 4.2.5.1.1 The taxiway or part of the taxiway is designated as a SMGCS taxi route.
1795 Under this designation, the width of the taxiway centerline must be 12
1796 inches (30 cm) wide and, on light-colored pavement, further outlined in
1797 black. The taxiway centerline width of any remaining section of the
1798 taxiway that is not part of the designated SMGCS taxi route may change
1799 abruptly at that point or at the intersection with other taxiway centerline
1800 markings, for example, reduced from 12 inches (30 cm) to 6 inches (15
1801 cm).
- 1802 4.2.5.1.2 A confusing intersection of taxiways is better served by the designation of
1803 a preferred taxi route through the confused intersection by painting a
1804 wider centerline width. The FAA recommends that airport operators take
1805 measures to realign or reconstruct confusing taxiway intersections.
- 1806 4.2.5.1.3 If deemed necessary by the airport operator to provide pilots a better
1807 visual clue of the location of troublesome taxiway exits from the runway,
1808 the airport operator may increase 6-inch (15-cm) wide taxiway centerline
1809 markings before the aircraft hold side at the runway holding position
1810 location to 12-inch (30-cm) wide lead-off taxiway centerline markings on
1811 the runway side.
- 1812 4.2.5.2 **Discontinuity of the Taxiway Centerline Marking Along the Taxiway.**
1813 The taxiway centerline marking of a taxiway remains continuous except
1814 when it intersects (1) a runway holding position marking, (2) an
1815 intermediate holding position marking (intersection of taxiways), (3) an
1816 ILS/MLS or POFZ holding position marking, or (4) non-movement area
1817 boundary marking (paragraph 5.4). Figure A-13 and Figure A-14 illustrate
1818 the marking details for most of these conditions.
- 1819 **4.3 Enhanced Taxiway Centerline Marking.**
- 1820 4.3.1 Purposes.
1821 The enhanced taxiway centerline marking provides supplemental visual cues to alert
1822 pilots of an upcoming runway holding position marking (Pattern A) in order to
1823 minimize the potential for runway incursions. To reinforce situational awareness before
1824 entering a runway, this safety enhancement is only used on those taxiways that directly
1825 enter a runway. For example, this safety enhancement would not be painted on a
1826 runway or used at all Pattern A applications, such as case 1 or case 2 (paragraph 3.2),
1827 situations as shown in Figure D-16, or a taxiway that goes through the runway safety
1828 area but not onto the runway itself. The same restriction is valid for case 4 Pattern B
1829 applications.

1830

14 Code of Federal Regulation (CFR) Part 139 Certificated Airports
Runway Incursion Mitigation Requirement
(Safety)

The enhanced taxiway centerline marking, as illustrated in [Figure D-1](#), is mandatory and the only acceptable means of compliance for all 14 CFR Part 139 certificated airports. All taxiways leading ONLY to a runway holding position marking are to have the enhanced taxiway centerline marking.

This surface painted marking is part of the taxiway centerline marking standard under 14 CFR Section 139.311(a)(2).

- 1831 4.3.2 Location.
- 1832 Taxiway centerlines are enhanced for 150 feet (45.7 m) prior to a Pattern A – runway
- 1833 holding position marking, as shown in [Figure D-1](#), except for the situations described in
- 1834 paragraph [4.3.4](#). The portion of the taxiway centerline between the runway holding
- 1835 position marking and the runway itself is not enhanced. If the location of taxiway
- 1836 centerline lights and their housings interfere with the painting of the enhanced taxiway
- 1837 centerline, then lights and their housing can be covered up temporarily during the
- 1838 painting process, i.e., lights need not be relocated or housing painted to accommodate
- 1839 this requirement.
- 1840 4.3.3 Color.
- 1841 The enhanced taxiway centerline marking is yellow and must use glass beads. See
- 1842 paragraph [1.4](#) and [Table 1-1](#) for required techniques to enhance this marking. If a black
- 1843 border is required, the border on the outside of the dashes can be 3 to 6 inches (7.5 to 15
- 1844 cm) in width. All black borders never use glass beads.
- 1845 4.3.4 Characteristics.
- 1846 The standard painted enhanced taxiway centerline marking consists of two parallel lines
- 1847 of yellow dashes one on each side of the existing 6-inch (15-cm) or 12-inch (30-cm)
- 1848 taxiway centerline as shown in [Figure D-2](#) and [Figure D-6](#). For both off-centered [Figure](#)
- 1849 [D-1](#) applications, the first dashes start 6 to 12 inches (15 to 30 cm) from the runway
- 1850 holding position marking. For [Figure D-1](#) applications, the marking The standard
- 1851 pattern runs for a length of 9 feet (2.7 m) with a 6-inch (15-cm) width, and are followed
- 1852 with a gap of 3 feet (0.9 m) between the next set of dashes. For off-centered [Figure D-1](#)
- 1853 applications, the standard pattern consists of 12 sets of 9-foot (2.75-m) dashes plus 3-
- 1854 foot (0.9-m) spaces and ends with a 6-foot (1.8-m) dash for a total length of 150 feet
- 1855 (45.7 m). For on-centered [Figure D-6](#) applications, the first and second set of dashes
- 1856 are 6 to 12 inches (15 to 30 cm) from the runway holding position marking and the
- 1857 surface painted holding position sign the same standard pattern is basically followed but
- 1858 has a fewer set of dashes because of the space taken by the surface painted holding
- 1859 position sign (SPHPS) over the taxiway centerline. In all on-centered [Figure D-6](#)
- 1860 applications, the first set of dashes starts 3 feet (0.91 m) from the bottom of the Surface
- 1861 Painted Holding Position Signs (SPHPS). For this application the total dimension

1862 (includes missing set(s) of dashes and the centered-placed SPHPS) is 150 feet (45.7 m)
 1863 as measured from the runway holding position marking to the bottom of the last set of
 1864 dashes. For both cases, the standard painted pattern has a total length of 150 feet (45.7
 1865 m). However, because of the varieties of existing taxiway geometries, configurations,
 1866 layouts, etc., and the placement of a runway holding position marking, the standard
 1867 painted pattern under both applications is not always painted. The painting patterns for
 1868 the most common taxiway geometries are described in this section below.
 1869

Transition Period for SPHPS when the Taxiway Width Changes Category between “more than 35 feet” and “35 feet or less”

When a taxiway width is increased from the category “35 feet (10.5 m) or less” to the category “more than 35 feet (10.5 m),” physically remove the on-centered SPHPS and apply a new SPHPS to the left of the taxiway centerline. In some cases an additional SPHPS is required to the right of the taxiway centerline.

Physically remove the on-centered SPHPS and, mostly likely, the entire set of dashes of the enhanced taxiway centerline marking. Insert a new Figure D-5 standard surface pattern.

When a taxiway width is reduced from the category “more than 35 feet (10.5 m)” to the category “35 feet or less,” physically remove the off-center SPHPS and apply an on-centered SPHPS.

Physically remove the off-centered SPHPS and, most likely, the entire first set of dashes of the existing enhanced taxiway centerline marking. Insert a new Figure D-6 standard surface pattern.

Compliance: Although a single marking project should correct both the enhanced taxiway centerline markings and the SPHPS marking, the existing enhanced taxiway centerline marking may be corrected during the next painting project.

- 1870 4.3.4.1 **Taxiway Serving Two Closely Spaced Runways.**
 1871 Figure D-16 illustrates how to paint enhanced taxiway centerline markings
 1872 for a taxiway that connects two closely spaced runways. Each
 1873 enhancement terminates at the runway edge unless the full 150-foot (46-
 1874 m) length can be painted. Figure D-16 illustrates situations in which one
 1875 enhancement is fully painted, one enhancement terminates at the outer
 1876 edge of the runway edge marking, and the other enhancements terminate
 1877 at the edge of the runway (Figure D-16 uses an unpainted reference line to
 1878 terminate the enhancements to Runway 1/19).
- 1879 4.3.4.2 **Taxiway/Taxiway Intersections and Merging Intersections.**
 1880 Figure D-11 (Note 2), Figure D-12 (Note 1), and Figure D-14 illustrate
 1881 that if the taxiway centerline to be enhanced intersects another taxiway

1882 that is located within 150 feet (45.7 m) of a runway holding position
1883 marking and leads to a point other than onto the runway (another enhanced
1884 taxiway centerline), the enhancement must terminate 5 feet (1.5 m) prior
1885 to the point where the other taxiway centerline crosses the taxiway
1886 centerline that is being enhanced. In comparison, on a taxiway, as shown
1887 in Figure D-11 (Note 1) and Figure D-13, where the enhancement is 150
1888 feet (45.7 m) or less and merges with a straight or curved taxiway
1889 centerline, the enhancement terminates at the last set of full dashes prior to
1890 the point of tangency with the other taxiway centerline.

1891 4.3.4.3 **Single, Straight-In, Enhanced Taxiway Centerline Marking**
1892 **Intersecting a Runway Holding Position Marking at Angles of 90**
1893 **Degrees.**

1894 Figure D-10 and Figure D-12 (Note 3) show the standard painted patterns,
1895 i.e., the enhanced taxiway centerline measures 150 feet (45.7 m) in length.
1896 In comparison, Figure D-13 shows a painted pattern for Runway 16/34 in
1897 which an enhancement terminates at the last set of full dashes prior to the
1898 point of tangency with the other taxiway centerline marking.

1899 4.3.4.4 **Straight-In, Enhanced Taxiway Centerline Markings Intersecting a**
1900 **Runway Holding Position Marking at Angles Other than 90 Degrees.**

1901 Figure D-3 (details A – D) and Figure D-7 show standard painted patterns.
1902 When a straight-in enhancement intersects the runway holding position
1903 marking at an angle other than 90 degrees, the first dashes of the
1904 enhancement on either side of the taxiway centerline will start and stop at
1905 different locations. In this case, use the taxiway centerline as a guide to
1906 paint the enhancements as shown in details A – D of Figure D-3. This
1907 painting pattern will show both dashes starting 6 to 12 inches (15 to 30
1908 cm) from the first solid bar of the runway holding position marking and
1909 ending at the same location. The finished pattern will show for the first set
1910 of dashes, one dash longer than 9 feet (2.7 m) and the other dash shorter
1911 than 9 feet (2.7 m).

1912 4.3.4.5 **Single Taxiway Centerline Serving Two Runway Holding Position**
1913 **Markings.**

1914 If a taxiway centerline intersects two runway holding position markings as
1915 shown in Figure D-12 (Note 2) and measures less than 150 feet (45.7 m)
1916 in length, then the entire taxiway centerline is enhanced only between the
1917 two runway holding position markings. In no case will the lacking length
1918 of the enhancement be painted between the runway itself and the runway
1919 holding position markings. To paint this enhancement, start with the 9-foot
1920 (2.75-m) dashes from each runway holding position marking (see
1921 paragraph 4.3.4.7.2 for painting practice). Next, continue painting the
1922 pattern from each starting point until both enhancements meet at the
1923 midpoint of the curved taxiway centerline. It is okay if the dashes or the
1924 spaces at the midpoint are less than the length specified in the standard.

1925 The intent here is to maintain the pattern of long dashes and shorter spaces
1926 on each side of the centerline.

1927 4.3.4.6 **Dual Holding Position Markings.**

1928 If an ILS/MLS or a POFZ (Pattern B) holding position marking is within
1929 150 feet (45.7 m) of a runway holding position marking (Pattern A), the
1930 enhanced taxiway centerline remains within the confines of the two
1931 holding position markings, i.e., the enhancement does not proceed beyond
1932 the ILS/MLS or the POFZ holding position marking. Under this situation,
1933 the enhanced taxiway centerline terminates 3 feet (0.9 m) before the
1934 ILS/MLS and the POFZ holding position markings.

1935 4.3.4.7 **Curved and Multiple Taxiway Centerlines Converging Prior to or**
1936 **Intersecting a Runway Holding Position Marking.**

1937 Various geometries exist such as those shown in [Figure D-9](#), [Figure D-10](#),
1938 [Figure D-11](#), and [Figure D-12](#). Below are the most common geometries
1939 and the recommended painting patterns.

1940 4.3.4.7.1 Intersecting and Convergent Taxiway Centerlines.

1941 As shown in [Figure D-2](#) and [Figure D-3](#) (Detail B), where two taxiway
1942 centerlines intersect or converge before or at the runway holding position
1943 marking, the outside dashes continue, with the possible exception of the
1944 first set of dashes, to maintain the 9-foot (2.75-m) pattern along the point
1945 of convergence. Depending on the geometry, the first inside dashes may
1946 be less than 9 feet (2.7 m) but must be aligned with the outside dashes, i.e.,
1947 the inside dashes stop with and possibly start with the outside dashes. As
1948 noted in [Figure D-3](#) (Detail B), it is permissible to omit inside dashes that
1949 measure less than 5 feet (1.5 m). Detail B also illustrates that the inside
1950 dashes can overlap each other.

1951 4.3.4.7.2 Curved Taxiway Centerlines Intersecting a Runway Holding Position
1952 Marking.

1953 As shown in [Figure D-3](#) (Detail D), when a taxiway centerline is curved,
1954 the dashes on either side of the taxiway centerline would start and stop at
1955 different locations when maintaining the 9-foot (2.75-m) length.

1956 Therefore, in order to correct this mismatch, apply the following painting
1957 practice, which takes all measurements from the taxiway centerline:

- 1958 1. Each dash in the first set of dashes along with the taxiway centerline
1959 will start at the same distance, 6 to 12 inches (15 to 30 cm) from the
1960 first solid bar of the runway holding position marking.
- 1961 2. To locate the end point of the first set of dashes, first measure 9 feet
1962 (2.7 m) along the taxiway centerline. Next, draw an imaginary line that
1963 is perpendicular to the tangent of the taxiway centerline and mark the
1964 ends of the first dashes on each side of the taxiway centerline.

- 1965 3. Measure an additional 3 feet (0.9 m) along the curved taxiway
 1966 centerline. Next, draw an imaginary line perpendicular to the tangent
 1967 of the curve and mark the starting point for the second set of dashes.
 1968 The ending point for this set is found by measuring 9 feet (2.7 m)
 1969 along the center of the curved taxiway centerline. An imaginary line
 1970 perpendicular to the tangent at this point will mark the end of the
 1971 second set of dashes.
- 1972 4. Repeat the procedure for the remaining curved portion of the taxiway
 1973 centerline, remembering that the last set of dashes only measures 6 feet
 1974 (1.8 m).

1975 4.4 Taxiway Edge Marking.

1976 Where the term “taxiway edge marking” is used throughout this AC, it is understood to
 1977 apply equally to taxilanes.

1978 4.4.1 Purposes.

1979 The taxiway edge marking, a dual continuous or dashed marking, is used along a taxi
 1980 route to (1) alert pilots where the demarcation line exists between usable pavement for
 1981 taxi operations and unusable pavement and (2) identify the edge(s) of a taxi route
 1982 located on sizeable paved areas that can be crossed over by the pilot. Two marking
 1983 schemes for the taxiway edge marking are available to the airport operator to indicate
 1984 whether the pilot is allowed to cross the taxiway edge. Figure A-16, Figure C-3, and
 1985 Figure C-4**Error! Reference source not found.** illustrate these marking variations. For
 1986 lighting provisions, see AC 150/5340-30.

1987 4.4.1.1 Continuous Taxiway Edge Marking.

1988 The continuous taxiway edge marking is used to delineate the taxiway
 1989 edge from the shoulder or some other contiguous paved surface that is not
 1990 intended for use by pilots. Continuous taxiway edge markings are never
 1991 used in any operational situation where pilots are permitted to cross this
 1992 surface marking, for example, a taxilane on a terminal used for gate
 1993 access. See paragraph 1.5 for additional usage of this surface marking.

1994 4.4.1.2 Dashed Taxiway Edge Marking.

1995 The dashed taxiway edge marking is used where there is an operational
 1996 need to define the edge(s) of a taxi route on or contiguous to a sizeable
 1997 paved area that permits pilots to cross over this surface marking. A
 1998 common application for this surface marking is a taxi route along the outer
 1999 edge of a terminal apron. To achieve safety objectives, dashed taxiway
 2000 edge markings are never used on entrance taxiways/bypass taxiways that
 2001 directly enter a runway, such as shown in Figure 5-1 and Figure A-19 (see
 2002 red safety box below, Runway Incursion Mitigation Requirement).
 2003 Furthermore, airports having dual or more parallel taxiways at a runway
 2004 end, as shown in Figure 5-1 with “paved islands,” must use continuous
 2005 taxiway edge markings around all paved no-taxi islands. This safety

2006 measure is taken to ensure standard wingtip-to-wingtip clearances.
 2007 Regardless of the taxi route's site, the location for painting the dashed taxi
 2008 edge marking must be per AC 150/5300-13 using standard taxiway widths
 2009 after obtaining standard taxiway/taxilane object free area widths for
 2010 locating the taxiway centerline. In other words, these dashed taxiway edge
 2011 markings (the stripe pattern) are never used to provide wing tip clearances
 2012 for other moving or parked airplanes found, for example, operating on
 2013 aprons. For this separation situation the airport operator may use the non-
 2014 movement area boundary marking to indicate adequate clearance
 2015 (taxiway/taxilane object free area).

2016 4.4.2 Requirement.

2017 Taxiway edge markings are used when deemed necessary by the airport operator or the
 2018 FAA.

2019 4.4.3 Location.

2020 The taxiway edge marking is located such that the outer edge of the continuous line or
 2021 dashed line defines the edge of the usable pavement.

2022 4.4.4 Color.

2023 Both taxiway edge marking schemes are yellow. If black borders are necessary, the
 2024 black borders on the outside of the marking can be 6 inches (15 cm) in width and never
 2025 use glass beads. See paragraph 1.4 and Table 1-1 for recommended techniques to
 2026 enhance this marking.

2027 4.4.5 Characteristics.

2028 4.4.5.1 The outermost edge of both dual dashed or dual continuous marking
 2029 schemes must be painted along the edge of the usable pavement.

2030 4.4.5.2 The continuous taxiway edge marking consists of dual, continuous lines
 2031 with each line being at least 6 inches (15 cm) in width and spaced 6 inches
 2032 (15 cm) apart (edge to edge) as shown in Figure C-3. This continuous
 2033 marking must be used to designate no-taxi islands as shown in Figure A-
 2034 19. Although it is preferable for the inner portion of NO-TAXI islands to
 2035 be unpaved, for example, grass covered, the inner area may be painted
 2036 green or painted with striated yellow markings per paragraph 1.3.4.
 2037 Placement of the striated yellow stripes is perpendicular to and abuts the
 2038 continuous taxiway edge marking. The length, which may be governed by
 2039 the shape of the NO-TAXI island, should be 5 feet (1.5 m) for TDG-1A
 2040 and TDG-1B; 15 feet (4.5 m) for TDG-2; 20 feet (6 m) for TDG-3 and
 2041 TDG-4; and 25 feet (7.6 m) for TDG-5, TDG-6, and TDG-7. Width and
 2042 separation between striated yellow stripes follow paragraph 1.3.4 criteria.
 2043 One other option to enhance NO-TAXI islands is to apply artificial turf for
 2044 the portion of the area between the standard taxiway shoulder widths as
 2045 prescribed by AC 150/5300-13.

2049 4.4.5.4 Figure C-5. The dashed lines are 15 feet (4.5 m) in length with 25-foot
 2050 (7.5-m) gaps as shown in Figure A-15. This marking is never used to
 2051 designate no-taxi islands.

2052

**Runway Incursion Mitigation Requirement
(Safety)**

Recorded runway incursion data associated with multi-taxiway entrance designs to a runway without “no-taxi islands” between the adjacent taxiway entrances have experienced a higher rate of runway incursions as compared to entrances with no-taxi islands. To reduce the possibility of runway incursions, all designs for a direct entrance to a runway that use two or more taxiway entrances must use “no-taxi islands” that are outlined with the dual continuous taxiway edge marking. In most cases, a green border to create the no-taxi island is required (see paragraph 1.5). AC 150/5300-13 prescribes and illustrates only bypass taxiway entrance designs that have unpaved no-taxi islands as part of the design.

2053 4.4.5.5 For the cases where the taxiway edge marking intersects a holding
 2054 position marking (Pattern A) which is:

2055 4.4.5.5.1 Outlined in black – the taxiway edge markings should abut the black
 2056 outlines on both sides of the runway holding position marking, i.e., the
 2057 borders for the yellow dashed and yellow solid line.

2058 4.4.5.5.2 Not outlined in black – a 6-inch (12 cm) gap is left between the holding
 2059 position marking and the taxiway edge marking as shown in Figure A-17.

2060 **4.5 Surface Painted Holding Position Signs.**

2061 4.5.1 Purposes.

2062 This surface painted sign provides supplemental visual cues that alert pilots and vehicle
 2063 drivers of an upcoming holding position location and the associated runway
 2064 designator(s) as another method to minimize the potential for a runway incursion and,
 2065 for certain airport geometries, wrong runway takeoffs. Several applications of this
 2066 surface painted sign for taxiways are shown in **Error! Reference source not found.**
 2067 (non-centered), Figure D-6 (centered) and Figure D-15 (stacked). The surface painted
 2068 holding position sign is used only on taxiways (not runways) that connect a runway and
 2069 have a Pattern A holding position marking. Taxiways that do not lead directly onto the
 2070 runway, such as a taxiway that crosses through an approach area, are not to have this
 2071 surface painted sign. In regards to Pattern B under specific landing operations, certain
 2072 taxiway/runway geometries, for example Figure A-17, do occur in which this surface
 2073 painted sign is necessary to protect both the runway entrance environment and the
 2074 ILS/MLS or the POFZ critical area. Figure A-17 shows the POFZ critical area
 2075 overlapping the holding bay at the entrance to the runway.

2076

14 Code of Federal Regulation (CFR) Part 139 Certificated Airports
Runway Incursion Mitigation
(Safety)

The surface painted holding position sign (SPHPS), as illustrated in [Figure D-5](#) or [Figure D-6](#) for existing taxiway widths, is mandatory and the only means of compliance for all 14 CFR Part 139 certificated airports regardless of the number of runways at the airport. The intent of this requirement is to eliminate the various practices among 14 CFR Part 139 certificated airports in which pilots would (1) see the surface painted holding position sign at all taxiway entrances to a runway, (2) only see the marking on extra wide taxiway entrances over 200 feet (61 m) in width, or (3) see none at all at single runway airports. In turn, this all-inclusive application will reduce human confusion among pilots and drivers that may contribute to runway incursions.

This surface painted sign is mandatory on the left side of the taxiway centerline for TDGs 3-7 and centered over the taxiway centerline for TDG-1A, TDG-1B, and TDG-2 even if a vertical runway holding position sign exists. For TDGs 3-7, the surface painted sign for the right side of the taxiway centerline, which is highly recommended for taxiway entrances serving airplane operations that require two person crews, may be eliminated when a taxiway centerline is closer than 45 feet (13.7 m) from the edge of the taxiway and a mandatory vertical runway holding position sign is in clear view (either left or right of the taxiway centerline).

2077 4.5.2 Location.

2078 The location (and number) of the SPHPS is determined by the width of the taxiway
 2079 entrance and the number of taxiway centerlines that intersect the same holding position
 2080 marking. Although the design of all taxiway entrances to a runway should have been
 2081 based on a single taxiway design group, i.e., all taxiway entrances have the same
 2082 standard width, some existing runways have varied taxiway widths serving more than
 2083 one taxiway design group. In such cases, the taxiway design group for that taxiway
 2084 entrance will determine the location (and number) of the surface painted marking. For
 2085 example, a runway with a runway design code of C-III-5000 has one taxiway entrance
 2086 built to TDG-2 standards and others built to TDG-3 standards. For the TDG-2 entrance,
 2087 a single, centered surface painted marking as shown in [Figure D-6](#) is painted while the
 2088 TDG-3 taxiway entrances are painted differently.

2089 4.5.2.1 The SPHPS must not be painted on a runway, including runways that are
 2090 temporarily used by ATCT as a taxiway.

2091 4.5.2.2 In all cases, the SPHPS is never painted onto the taxiway shoulders.

2092 4.5.2.3 In reference to the holding position marking (Pattern A), the surface
 2093 painted holding position sign is always painted prior to and runs parallel to
 2094 the holding position marking at a distance of 2 to 4 feet (0.6 to 1.2 m) as

2095 shown in [Figure D-5](#), [Figure D-6](#), and [Figure D-7](#). The location takes into
2096 account the direction of taxiing and should allow sufficient clearance for
2097 in-pavement runway guard lights and/or stop bars.

2098 4.5.2.4 When a single taxiway centerline intersects the holding position marking
2099 (Pattern A), the surface painted holding position sign is located as follows:

2100 4.5.2.4.1 For taxiway widths that are greater than 35 feet (10.5 m) (TDG-3 - TDG-
2101 7), one or two surface markings are placed 3 to 10 feet (0.9 to 3.1 m) from
2102 the center of the taxiway centerline. With a few exceptions, one surface
2103 marking must be painted on the left side of the taxiway centerline. The left
2104 side rather than the right side is used because not all aircraft that may use
2105 this entrance require two-person crews. The surface painted sign for the
2106 right side of the taxiway centerline, which is highly recommended for
2107 taxiway entrances serving airplane operations that require two-person
2108 crews, may be eliminated when a taxiway centerline is closer than 45 feet
2109 (13.7 m) from the edge of the taxiway and a mandatory vertical runway
2110 holding position sign is in clear view (from either left or right of the
2111 taxiway centerline.) Any airport with a taxiway entrance to a runway with
2112 insufficient lead-on length (see safety box under Condition 2 of paragraph
2113 [4.5.2.5](#) for definition) to the runway holding position marking, such as
2114 [Figure D-11](#), must have two surface painted holding position signs, one on
2115 each side of the taxiway centerline marking. Because of the variety in
2116 taxiway geometries, such as shown in [Figure D-9](#), [Figure D-10](#), [Figure D-
2117 11](#), [Figure D-12](#), and [Figure D-14](#), the taxiway centerline may or may not
2118 be perpendicular to the holding position marking. If the taxiway centerline
2119 is perpendicular, then placement of the surface painted holding position
2120 sign is in accordance with [Figure D-5](#). If the taxiway centerline is not
2121 perpendicular, then placement is in accordance with [Figure D-7](#).

2122 4.5.2.4.2 For taxiways widths of 35 feet (10.5 m) or less (TDG-1A, TDG-1B, and
2123 TDG-2), one surface marking is centered directly over the taxiway center.
2124 If the taxiway centerline is perpendicular to the holding position marking
2125 (Pattern A), then placement of the surface painted holding position sign is
2126 as shown in [Figure D-6](#). If the taxiway centerline is not perpendicular,
2127 then placement is still centered over the taxiway centerline, but oriented to
2128 run parallel to the holding position marking. That is, its placement would
2129 appear in like fashion when two such markings are painted as shown in
2130 [Figure D-7](#).

2131 4.5.2.5 When two or more taxiway centerlines intersect or converge within 15 feet
2132 (4.5 m) of the holding position marking (Pattern A), there might not be
2133 enough space for two or more surface painted holding position signs.
2134 [Figure D-3](#), [Figure D-12](#), and [Figure D-16](#) are examples of layouts where
2135 it is not possible to paint all the required surface painted holding position
2136 signs for each converging taxiway centerline. In these cases, a surface
2137 painted holding position sign may be omitted on one side of the taxiway

2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156

centerline as shown in Figure D-9 and Figure D-12 for TDGs 3-7 standard taxiway widths. In the cases of TDG-1A, TDG-1B, and TDG-2 standard taxiway widths, a single surface painted holding position sign must be centered over the two converging taxiways where separate surface markings would have overlapped each other. These and other types of geometries will require individual site assessment by the airport operator to determine the number of surface painted holding position signs that are required by this AC fit properly into the available space. In terms of proper spacing between two taxiway centerlines, a surface painted holding position sign should be approximately equidistant from both taxiway centerlines at a distance of no less than 3 feet (0.9 m) or more than 10 feet (3.1 m) from either taxiway centerline as measured from the center of the taxiway centerlines to the nearest border of the surface painted holding position sign. For difficult taxiway geometries, the airport operator should consult their FAA Regional Airports Division Office or the Airports District Office (ADO) before painting any markings. For such requests, the airport operator should provide information about the rate of usage by each taxiway centerline, aircraft types, and the available space for painting.

2157 4.5.2.6

Wrong-Runway Takeoff Mitigation
(Safety)

If an airport has a taxiway entrance that simultaneously serves two or more runways, the surface painted holding position sign must show all runway designators plus directional arrows. The directional arrows must approximate the orientation of the runways.

The surface painted holding position sign is part of the standard signage requirements under 14 CFR Part 139.311(b)(1)(ii).

2158

Runway Incursion Mitigation
Extra-Wide Taxiway Entrances
(Safety)

Condition 1.

Any airport with a taxiway entrance to a runway having a width greater than 200 feet (61 m) as measured along its runway holding position marking requires the following surface markings. First, a surface painted holding position sign must be painted on the left side of the taxiway centerline (or centered over the taxiway centerline for TDG-1A, TDG-1B, and TDG-2 standard taxiway widths). Second, depending on how excessive the width, a “repetitive pattern” of additional surface painted holding position signs must be painted in

Runway Incursion Mitigation
Extra-Wide Taxiway Entrances
(Safety)

accordance with [Table 4-1](#) below. This second requirement is in direct response to documented runway incursions associated with extra-wide taxiway entrances to a runway. Note the spacing requirement is based on the Airplane Design Group component of the Runway Design Code, not the Taxiway Design Group.

The repetitive pattern of [Table 4-1](#) relates the spacing of the additional markings to the viewing angles of pilots and to the painting of future parallel taxiway entrances according to [AC 150/5300-13](#). In other words, when the airport operator decides to paint additional parallel taxiway entrances, the criterion in [Table 4-1](#) would already have in place the required surface painted holding position sign within the proper distance of the newly painted taxiway centerlines (or centered over the taxiway centerline for TDG-1A, TDG-1B, and TDG-2).

When the airport operator paints additional parallel taxiway entrances, then the repetitive pattern is completed by painting a no-taxi island per paragraph [1.5](#).

Table 4-1. Placement of repetitive surface painted holding position signs and no-taxi islands on taxiway entrances of over 200 feet (61 m) in width

| Airplane Design Group (ADG) Category ¹ | Distance between adjacent surface painted holding position signs ² as measured from the same outer edge ³ Feet (meters) | Midpoint distance for a no-taxi island between parallel taxiway centerlines ⁴ as measured from either taxiway centerline Feet (meters) |
|---|--|--|
| ADG I | 69 (21) | 34.5 (10.5) |
| ADG II | 105 (32) | 52.5 (16) |
| ADG III | 152 (46.5) | 76 (23.25) |
| ADG IV | 215 (65.5) | 107.5 (32.75) |
| ADG V | 267 (81) | 133.5 (40.5) |
| ADG VI | 324 (99) | 162 (49.5) |

Note 1: The terms Airplane Design Group and Taxiway Design Group are defined in [AC 150/5300-13](#).

Note 2: Each entry equals the taxiway centerline to parallel taxiway centerline value based on ADGs listed in [AC 150/5300-13](#).

Note 3: The listed value assumes that the existing surface painted holding position sign is used as the starting point to measure and paint additional surface markings either on the left side of the taxiway centerline ([Figure D-5](#)) or directly centered over the taxiway centerline ([Figure D-6](#)). For taxiways with dual surface markings, such as shown in [Figure D-5](#), the measurement should still be from the left-side surface marking. If there is no left-side surface marking, use the center of the taxiway centerline and add 3

Runway Incursion Mitigation
Extra-Wide Taxiway Entrances
(Safety)

to 10 feet (0.9 to 3.1 m) to the listed value in [Table 4-1](#). This numeric range is the dimension letter B used in [Figure D-5](#).

Note 4: Each entry is half of the taxiway centerline to parallel taxiway centerline value based on ADG listed in [AC 150/5300-13](#).

Condition 2.

Any ADG III–VI runway with a taxiway entrance to a runway with insufficient lead-on length to the runway holding position marking must have two surface painted holding position signs, one on each side of the taxiway centerline marking.

The term “insufficient lead-on-length” is defined as follows:

1. For the case of a perpendicular taxiway centerline intersecting the holding position marking, such as shown in [Figure D-5](#), [Figure D-12](#) curve #3, and [Figure D-14](#), the design airplane for that runway is unable to line up its entire fuselage perpendicular to the runway holding position marking.
2. For the case of a non-perpendicular taxiway centerline intersecting the holding position marking, such as shown in [Figure D-7](#) and [Figure D-9](#), the design airplane for that runway is unable to line up its entire fuselage on a straight section of the entrance taxiway centerline while holding at the runway holding position marking.

Three quick, visual indications of this undesirable design condition are (1) taxiway centerlines, such as shown in [Figure D-9](#), that only curve into the runway holding position marking; (2) holding position markings, such as shown in [Figure D-14](#), that are painted in or near the region where taxiway fillets are constructed; and (3) an enhanced taxiway centerline that measures far less than 150 feet (45.7 m) in length.

[Figure D-9](#), [Figure D-10](#), [Figure D-11](#), and [Figure D-12](#) provide some examples on how to paint left-of-centerline and right-of-centerline surface painted holding position signs.

The surface painted holding position sign is part of the standard signage requirements under 14 CFR Part 139.311(b)(1)(ii).

2159 4.5.3 Color.

2160 The surface painted holding position sign has a red background with a white inscription
 2161 and, on light-colored pavements, is outlined in black. Although this marking
 2162 supplements the mandatory runway holding position sign, the black outline that
 2163 surrounds the white alphanumeric inscription on the signs is not required for the surface
 2164 painted holding position sign. See paragraph [1.4](#) and [Table 1-1](#) for required techniques
 2165 to enhance this marking.

2166 4.5.4 Characteristics.

2167 4.5.4.1 The standard height of the inscription and its location are as follows:

2168 4.5.4.1.1 For taxiway widths that are greater than 35 feet (10.5 m) (TDGs 3-7), the
 2169 inscription is 12 feet (3.7 m), but may be reduced in accordance with the
 2170 criteria in Figure D-5.

2171 4.5.4.1.2 For taxiways widths of 35 feet (10.5 m) or less (TDG-1A, TDG-1B, and
 2172 TDG-2), the inscription is in accordance with the criteria in Figure D-6.

2173

Solutions for Difficult Placements
Stacked Surface Painted Holding Position Signs
(Painting)

For taxiway entrances or a taxiway entrance with a complex geometry that requires a lengthy inscription (a single surface marking) for two or more runways and that will not fit properly between the existing taxiway centerline and the taxiway edge, the airport operator should reduce the inscription height. Under this solution, the lowest allowable height for the inscription for TDGs 3-7 standard taxiway widths is 6 feet (1.8 m), and for TDG-1A, TDG-1B, and TDG-2 standard taxiway widths the lowest allowable height is 3 feet (0.9 m). This painting solution may be necessary for smaller standard taxiway widths whose entrance taxiways support two runway ends. If this solution fails, the single marking may then be broken into two separate markings, one marking per runway, but stacked one above the other as shown in Figure D-15. Under this solution, the airport operator should fit the stacked markings such that (1) the height of the inscription is increased toward the standard height and (2) the separation between the stacked inscriptions is 2 to 4 feet (0.6 to 1.2 m). For taxiways less than or equal to 35 feet (10.7 m) wide, the stacked surface painted holding position signs are located centered on the taxiway in accordance with criteria in Figure D-6. See Figure D-15 for the recommended order of appearance for stacked surface painted holding position signs.

Note: All other unaffected runway holding positions that do not require a reduced inscription height must use the standard inscription height. The intent of this note is to maintain uniformity in visual cues across the United States.

2174 4.5.4.2 The inscription must be identical to the runway holding position sign by
 2175 using the same numbers, letters, and arrows. The appearance of the letters,
 2176 numbers, and arrows must be per Appendix B.

2177 4.5.4.3 The background is rectangular and extends horizontally and vertically
 2178 beyond the extremities of the inscription by 7.5 inches (19 cm) for TDG-
 2179 1A, TDG-1B, and TDG-2 standard taxiway widths, and by 15 inches (38
 2180 cm) for TDGs 3-7 standard taxiway widths.

2181 4.5.4.4 The surface painted holding position sign is at least 2 feet (0.6 m) from the
 2182 edge of the inside taxiway edge marking or from the edge of the paved
 2183 taxiway when there are no taxiway edge markings. See Figure D-4.

2184 **4.6 Surface Painted Taxiway Direction Signs.**

2185 4.6.1 Purpose.

2186 The surface painted taxiway direction sign is used with an arrow to provide directional
2187 guidance at an intersection.

2188 4.6.2 Requirement.

2189 This marking is required where it is not possible to provide a taxiway direction sign in
2190 accordance with AC 150/5340-18. Optionally, it may be installed where operational
2191 experience has indicated that its presence at a troublesome taxiway intersection can
2192 assist flight crews in better ground navigation. For signage provisions, see AC
2193 150/5340-18.

2194 4.6.3 Location.

2195 The edge of the surface painted taxiway direction sign (excluding the black border if
2196 used) is 3 feet (0.9 m) from the edge of the taxiway centerline and is located on the side
2197 of the taxiway centerline that the aircraft travels as shown in Figure A-19. That is,
2198 markings that indicate left turns are located on the left-hand side of the taxiway
2199 centerline while markings indicating right turns are located on the right-hand side of the
2200 taxiway centerline.

2201 4.6.3.1 The surface painted taxiway direction sign is not painted on runways,
2202 including runways that are operationally used as a taxiway, or painted
2203 between the runway holding position marking (Pattern A) and the runway.

2204 4.6.3.2 For crisscrossing taxiways, such as two taxiways crisscrossing at 90
2205 degrees to each other, a surface painted taxiway direction sign is combined
2206 with arrows to indicate the different travelling directions at the
2207 intersection. Under this application, the single marking is located on the
2208 left side of the taxiway centerline.

2209 4.6.3.2.1 When it is not practicable to install a taxiway direction sign along the side
2210 of the taxiway, paint a surface painted taxiway direction sign and locate it
2211 at the same distance from the intersection per AC 150/5300-13 standards
2212 for fixed/moveable objects.

2213 4.6.3.2.2 When a surface painted taxiway direction sign supplements a taxiway
2214 direction sign installed along the side of the taxiway, the surface painted
2215 direction sign may be located at or within the distances per AC 150/5300-
2216 13 standards for fixed/moveable objects, and the point of divergence of the
2217 painted taxiway centerlines.

2218 4.6.3.3 A surface painted taxiway direction sign is not co-located with a surface
2219 painted holding position sign.

2220 4.6.3.4 The surface painted taxiway direction sign is not painted on runways,
2221 including runways that are operationally used as a taxiway.

- 2222 4.6.4 Color.
2223 The surface painted taxiway direction sign has a yellow background with a black
2224 inscription that includes an arrow(s). See paragraph 1.4 and Table 1-1 for required
2225 techniques to enhance this marking. On light-colored pavements, a 6-inch (15-cm)
2226 black border completely surrounds its perimeter.
- 2227 4.6.5 Characteristics.
- 2228 4.6.5.1 The black inscription is 12 feet (3.7 m) in height. However, the height may
2229 be reduced if necessary to the minimum height of 9 feet (2.7 m).
- 2230 4.6.5.2 Each black inscription must be accompanied by an arrow oriented to show
2231 the approximate direction of a turn.
- 2232 4.6.5.3 The black inscription with the arrow(s) must conform in appearance to the
2233 letters, numbers, and symbols in Appendix B.
- 2234 4.6.5.4 The yellow background is rectangular and extends a minimum of 15
2235 inches (38 cm) horizontally and vertically beyond the extremities of the
2236 black inscription, which includes the arrow head(s).
- 2237 4.6.5.5 A 6-inch (15-cm) wide vertical black stripe separates two black
2238 inscriptions when more than one inscription is included on the same side
2239 of the taxiway centerline.
- 2240 4.6.5.6 See paragraph 4.7.5.4 when collocating a surface painted taxiway
2241 direction sign with a surface painted taxiway location sign.
- 2242 **4.7 Surface Painted Taxiway Location Signs.**
- 2243 4.7.1 Purposes.
2244 The surface painted taxiway location sign identifies the taxiway upon which the aircraft
2245 is located. This marking is used to supplement other signs located along the taxiway
2246 system.
- 2247 4.7.2 Requirement.
2248 This marking is required when deemed necessary by the airport operator or FAA.
2249 Optionally, it may be installed where operational experience has indicated that its
2250 presence can assist flight crews in better ground navigation. For signage provisions, see
2251 AC 150/5340-18.
- 2252 4.7.3 Location.
2253 The surface painted taxiway location sign is located normally on the right side of the
2254 taxiway centerline in the direction of travel as shown in Figure A-19. The edge
2255 (excluding the black border if used) of the surface painted taxiway location sign should
2256 be 3 feet (0.9 m) from the edge of the taxiway centerline.

- 2257 4.7.3.1 When adequate pavement width exists, a surface painted taxiway location
2258 sign may be located on the left side of the taxiway centerline if it is co-
2259 located to the left of a surface painted holding position sign (paragraph
2260 4.5). In this case, the two surface painted signs will mimic the mandatory
2261 holding position signs. Under this application, if the co-located surface
2262 painted taxiway location sign and the mandatory holding position sign
2263 serve two converging taxiways, then the surface painted taxiway location
2264 sign should be located to the left of the surface painted holding position
2265 sign (in the direction of taxiing).
- 2266 4.7.3.2 The surface painted taxiway location sign is not painted on runways,
2267 including runways that are operationally used as a taxiway, or painted
2268 between the runway holding position marking (Pattern A) and the runway.
- 2269 4.7.4 Color.
2270 The surface painted taxiway location sign has a black background with a yellow
2271 inscription, and a yellow border around its perimeter for all pavement surfaces. See
2272 paragraph 1.4 and Table 1-1 for required techniques to enhance this marking.
- 2273 4.7.5 Characteristics.
- 2274 4.7.5.1 The yellow inscription is 12 feet (3.7 m) in height. However, the height
2275 may be reduced if necessary to the minimum height of 9 feet (2.7 m).
- 2276 4.7.5.2 The yellow inscription never contains an arrow and must conform in
2277 appearance to the letters, numbers, and symbols in Appendix B.
- 2278 4.7.5.3 The background is rectangular and extends a minimum of 15 inches (38
2279 cm), which includes the 6-inch (15-cm) yellow border, horizontally and
2280 vertically beyond the extremities of the yellow inscription.
- 2281 4.7.5.4 When a surface painted taxiway location sign is collocated with a surface
2282 painted taxiway direction sign on any pavement surface, paint the
2283 inscriptions for both markings of equal height.
- 2284 **4.8 Surface Painted Gate Destination Signs.**
- 2285 4.8.1 Purpose.
2286 The surface painted gate destination sign is used to assist pilots in locating their
2287 assigned terminal gate. The marking is especially useful for low-visibility operations.
- 2288 4.8.2 Requirement.
2289 This marking is optional.

2290 4.8.3 Location.

2291 The surface painted gate destination sign may be installed in non-movement areas or
2292 movement areas that are in the proximity of terminal building(s) per the examples in
2293 Figure A-21 and Figure A-22. The markings are located adjacent to taxiway centerlines
2294 on the same side in which a turn will be made while traveling toward the assigned gate.

2295 4.8.4 Color.

2296 The surface painted gate destination sign has a solid yellow background with a black
2297 inscription. On light-colored pavements, a 6-inch (15-cm) black border may be used.
2298 See paragraph 1.4 and Table 1-1 for required techniques to enhance this marking.

2299 4.8.5 Characteristics.

2300 4.8.5.1 For surface painted gate destination signs containing only a single row of
2301 several gate designations as shown in Figure A-21, the black inscriptions
2302 must have a maximum height of 4 feet (1.2 m).

2303 4.8.5.2 For surface painted gate destination signs containing more than one row of
2304 gate designations, shown as an option in Figure A-22, the inscriptions
2305 must have a minimum height of 3 feet (0.9 m). There is no maximum
2306 height size for a surface painted gate destination sign containing more than
2307 one row of inscriptions.

2308 4.8.5.3 The background of the marking is rectangular and extends a minimum of
2309 15 inches (38 cm) horizontally and vertically beyond the extremities of the
2310 inscriptions.

2311 4.8.5.4 The black inscription must conform in appearance to the letters, numbers,
2312 and other symbols in Appendix B.

2313 4.8.5.5 A range of gates that are sequential should be indicated with a single dash.
2314 For example, a series of gates A1 through A4 are indicated as “A1 - A4”.

2315 4.8.5.6 A range of gates that are non-sequential should be separated by commas.
2316 For example, the gates B1, B3, and B6 are indicated as “B1, B3, B6.”

2317 **4.9 Surface Painted Apron Entrance Point Signs.**2318 4.9.1 Purpose.

2319 The surface painted apron entrance point sign is used to assist pilots in locating their
2320 position along the edges of a large, continuous apron serving the terminal gates. The
2321 marking is especially useful for identifying both the entrances and exits in and along the
2322 terminal complex. To facilitate shorter, less confusing verbal communication and to
2323 enhance the movement of ground traffic, the surface painted apron entrance point sign
2324 is sometimes referred to as the “ramp spot” at some airports.

- 2325 4.9.2 Requirement.
2326 This marking is optional.
- 2327 4.9.3 Location.
2328 The surface painted apron entrance point sign may be painted in non-movement areas or
2329 movement areas that are in the proximity of an apron leading to the concourses or
2330 terminal buildings as shown in Figure A-22. The marking, located 7 feet (2.1 m) from
2331 taxiway centerline(s), is on the same side of the centerline to which a turn will be made
2332 to travel toward the assigned gate.
- 2333 4.9.4 Color.
2334 The surface painted apron entrance point sign has a yellow background with a black
2335 inscription. The color of the border depends on the pavement color. Concrete or light-
2336 colored pavement should use a black border, while dark pavements should use a white
2337 border. See paragraph 1.4 and Table 1-1 for required techniques to enhance this
2338 marking.
- 2339 4.9.5 Characteristics.
- 2340 4.9.5.1 The surface painted apron entrance point sign consists of three 9-foot (2.7-
2341 m) diameter circles each located 7 feet (2.1 m) from the associated
2342 taxiway/apron centerline. As shown in Figure A-22, two circles are
2343 located on either side of the entrance taxiway centerline(s) that continues
2344 toward the gate and ends with the third circle.
- 2345 4.9.5.2 For taxiways that do not turn but continue forward, only the third circle is
2346 painted. For complex taxiways where two converging taxiway centerlines
2347 cross the non-movement boundary marking in very close proximity to
2348 each other, the airport operator may paint a single marking near the non-
2349 movement boundary marking that is between the two converging taxiway
2350 centerlines. That is, the single marking is not overlapping the taxiway
2351 centerlines. For a single taxiway centerline that diverges into two separate
2352 taxiway centerlines just prior to the non-movement boundary marking,
2353 paint a single marking on the taxiway centerline prior to its splitting into
2354 different taxiway centerlines.
- 2355 4.9.5.3 Each circle is comprised of an inner 8-foot (2.7-m) diameter yellow circle
2356 with a 6-inch (15-cm) outer ring that is black in color for concrete and
2357 light-colored pavements and is white in color for asphalt pavements.
- 2358 4.9.5.4 The inscription is either numeric or alpha-numeric. For the situation that
2359 consists of three circles, the inscription for gate designation within each of
2360 the three circles should match.
- 2361 4.9.5.5 The black inscription inside each circle should only be a number, black in
2362 color and 4 feet (1.2 m) in height.

2363 4.9.5.6 The appearance of the inscription numbers must conform to the scale of
2364 letters, numbers, and other symbols in Appendix B.

2365 **4.10 Taxiway Shoulder Markings.**

2366 4.10.1 Purpose.

2367 Aprons, holding bays, and taxiways are sometimes provided with paved shoulders or
2368 stabilization per AC 150/5300-13 to prevent ground erosion attributed to jet blast or
2369 water runoff or to minimize engine damage caused by foreign object debris. Although
2370 these shoulders are not intended for use by aircraft, conditions may exist along a taxi
2371 route that confuse pilots and cause them to use the shoulders. For example, a particular
2372 taxiway curve with an extra-wide paved shoulder may confuse pilots as to which side of
2373 the painted taxiway edge marking stripe is intended for their use. Where such conditions
2374 exist, the airport operator should paint taxiway shoulder markings to indicate the non-
2375 usable (deceptive) area to pilots. Figure A-23 illustrates this surface marking.

2376 4.10.2 Requirement.

2377 This marking is optional.

2378 4.10.3 Location.

2379 The taxiway shoulder marking is painted using a perpendicular reference line draw from
2380 the taxiway centerline. The start and stop points, and separation gaps, for painting the
2381 marking are described below.

2382 4.10.3.1 Referring to Figure A-23 on straight sections, the taxiway shoulder
2383 markings will be placed perpendicular at each point of intersection with
2384 the defined edge of paved taxiway or the taxiway edge marking with
2385 additional markings being uniformly placed between the two start and
2386 finish markings. The spacing of the markings, centerline-to-centerline,
2387 will not exceed 100 feet (30.5 m) between two adjacent markings as
2388 shown in Figure A-23.

2389 4.10.3.2 Referring to Figure A-23 on curved sections, the taxiway shoulder
2390 markings will be uniformly spaced along the curve. The first and last
2391 markings are placed perpendicular at the point of curvature and point of
2392 tangency of the curve or, in the case of a runway/taxiway intersection, at
2393 the point of intersection of the runway and taxiway edges. The spacing of
2394 the markings, centerline-to-centerline, will not exceed 50 feet (15 m)
2395 between two adjacent markings measured at the largest gap of the radially-
2396 spaced markings. Two cases exist for the largest gap of the radially-spaced
2397 markings.

2398 4.10.3.2.1 Case 1 - For a taxiway that intersects a paved area as shown in Figure A-
2399 23, both curved shoulders are referred to as “inboard” shoulders. Under
2400 this case use a 50-foot (15-m) centerline-to-centerline separation
2401 (maximum separation) as measured along the inner edge of the curved

2402 shoulder that abuts the paved taxiway. Notice that in case 1 both curved
2403 shoulders are categorized as inboard shoulders.

2404 4.10.3.2.2 Case 2 - For a taxiway that makes a turn prior to connecting another paved
2405 area, as shown in Figure A-10, one curved shoulder is referred to as an
2406 “inboard” shoulder and the other as an “outboard” shoulder. Placement of
2407 the taxiway shoulder marking along the inboard shoulder is measured as
2408 described above. For the outboard shoulder use the same maximum 50-
2409 foot (15-m) centerline-to-centerline placement of the taxiway shoulder
2410 marking but as measured along the outer edge of the curved shoulder that
2411 abuts the ground.

2412 4.10.4 Color.

2413 The taxiway shoulder marking is yellow. For NO-TAXI islands with a paved interior, it
2414 is acceptable to paint the paved interior green in color instead of painting yellow
2415 taxiway shoulder markings. If this option is used, it is acceptable to paint both the
2416 interior area and the shoulder area green.

2417 4.10.5 Characteristics.

2418 The area is marked with 3-foot (1-m) wide yellow stripes that start with the edge of the
2419 paved taxiway or the edge of the taxiway edge marking (paint over the black border if
2420 present) and extended to within 5 feet (1.5 m) of the edge of the paved/stabilized
2421 shoulder area or 25 feet (7.5 m) in length, whichever length is less.

2422 **4.11 Geographic Position Markings.**

2423 4.11.1 Purpose.

2424 The geographic position marking (GPM), as shown in Figure A-24, is used repeatedly
2425 along a designated taxi route to serve as an indicator of a location (a spot) so that pilots
2426 can confirm holding points or report their location while taxiing during periods of low-
2427 visibility operations. Low-visibility operations are those taxiing operations prior to
2428 takeoff or after landings that occur when the runway visual range (RVR is below 1,200
2429 feet (366 m). Operationally, these sequentially numbered holding points differ from a
2430 reporting point. For example, one of the GPM (the spot) may be used only as a
2431 reporting point when ATCT is sequencing airplanes along the Surface Movement
2432 Guidance and Control System (SMGCS) route—when the first airplane reports to
2433 ATCT it is passing spot #3, ATCT would then clear the next airplane up to the next
2434 open spot.

2435 **Note:** See AC 120-57, Surface Movement Guidance and Control System, and AC
2436 150/5340-18 for signage and lighting provisions.

2437 4.11.2 Requirement.

2438 This marking is required as noted in the airport’s SMGCS plan.

2439 4.11.3 Location.

2440 The repeated marking is located along a low-visibility taxi route identified by the
2441 airport's SMGCS Plan. Each marking is positioned to the left of the taxiway centerline
2442 in the direction of taxi.

2443 4.11.3.1 All geographic position markings used operationally by the airport traffic
2444 control tower to designate a specific hold point along the low-visibility
2445 taxi route are co-located with the intermediate holding position marking
2446 (Pattern C) for taxiway/taxiway intersections as shown in Figure A-24.
2447 For a taxi route designated for use in visibilities below 500 RVR, the
2448 geographic position marking must be collocated with the intermediate
2449 holding position marking as well as a clearance bar consisting of three
2450 yellow lights. When the GPM is not used operationally for hold points,
2451 i.e., when the spot is always used as a reporting point for sequencing
2452 operations, the painting of an intermediate holding position marking and
2453 the installation of the clearance bar are optional. To avoid operational
2454 confusion, GPM must not be collocated with Pattern A or Pattern B
2455 surface markings.

2456 4.11.3.2 The geographic position marking is never located at a runway holding
2457 position marking (Pattern A) location that immediately enters the runway
2458 used for the departure. However, the GPM may be located at a runway
2459 holding position for other runway(s) that the designated low-visibility taxi
2460 route happens to cross prior to arriving at the departure runway.

2461 4.11.3.3 A taxiway/taxiway intermediate holding position marking should be used
2462 with the geographic position marking, except for a GPM that is located at
2463 a runway holding position for the runway that will not be used for takeoff.

2464 4.11.3.4 The airport operator, in coordination with the FAA Regional Airports
2465 Division Office or the Airports District Office, will determine where the
2466 geographic position markings are deemed necessary. Generally, the
2467 geographic position markings are sequentially numbered holding points
2468 along a designated taxi route. To offer airport operators greater flexibility
2469 in developing a labeling scheme benefitting ATCT, the inscription scheme
2470 may, if approved by the FAA, take into account the specific taxiway
2471 intersections. For example, a geographic position marking that is located
2472 near Taxiway B2 may be labeled "2B" while another geographic position
2473 marking associated with Taxiway E4 is labeled "4E."

2474 4.11.4 Color.

2475 The geographic position marking, as shown in Figure A-24, is a 7-foot (2-m) diameter
2476 pink circle with a black inscription surrounded by two 6-inch (15-cm) wide rings, one
2477 white and one black. When the geographic position marking is painted on concrete or
2478 other light-colored pavements, the white ring is inside the black outer ring. When the
2479 geographic position marking is installed on asphalt or other dark-colored pavements, the
2480 white ring becomes the outer ring and the black ring becomes the inner ring. See
2481 paragraph 1.4 and Table 1-1 for required techniques to enhance this marking.

2482 4.11.5 Characteristics.

2483 The GPM is designated with a black inscription that may be a single number or a
2484 number-letter combination. Since the basic marking reappears along the designated
2485 low-visibility SMGCS taxi route, each inscription must correspond to the sequential
2486 position identified by the SMGCS Plan. The sequential process for inscriptions is as
2487 follows.

2488 4.11.5.1 The number used for the inscription must correspond to its sequential
2489 position along the SMGCS taxi route, i.e., 1, 2, 3, etc.

2490 4.11.5.2 When a number plus a letter combination is used for the inscription, the
2491 letter indicates the taxiway's letter designation on which the marking is
2492 located. For example, the inscription "2B" implies the second marking
2493 along Taxiway B. Additionally, the number always precedes the letter for
2494 all inscriptions.

2495 4.11.5.3 If a GPM is located on a taxiway with an alphanumeric designation, only
2496 the letter portion of the taxiway designation is used for all the inscriptions.
2497 For example, if the fourth location on the SMGCS taxi route is located on
2498 Taxiway A7, the inscription for this location would read "4A".

2499 4.11.5.4 The inscription inside the GPM is centered within the circle.

2500 4.11.5.5 The inscription has a height of 4 feet (1.2 m).

2501 4.11.5.6 The numbers and letters used in the inscription are scaled to those in
2502 Appendix B.

2503 **4.12 Ramp Control Markings.**2504 4.12.1 Purpose.

2505 The ramp control marking is used to facilitate the local ramp tower or the FAA airport
2506 traffic control tower in the movement of aircraft and vehicles to designated areas of
2507 ramps, aprons, and other paved areas between non-movement areas and the movement
2508 area. In terms of controller workload, the surface marking simplifies verbal
2509 communications between controllers, pilots, and vehicle drivers during this transition
2510 process.

2511 4.12.2 Requirement.

2512 This marking is optional.

2513 4.12.3 Location.

2514 The ramp control marking is predominantly located on terminal aprons and cargo ramps
2515 within the non-movement area but may be painted within the movement area.

2516 4.12.4 Color.

2517 The ramp control marking has a black inscription on a yellow background with a black
2518 border when painted on light-colored pavements. See Table 1-1 for general guidelines
2519 for determining light-colored pavements. The black inscription, determined by the
2520 airport operator, may be numeric, letters, or alphanumeric with or without special
2521 characters such as an arrow. Flexibility is acknowledged for the black inscription as a
2522 means for the airport operator to address the varied operational applications conducted
2523 on diverse apron and ramp layouts. The black inscription is centered within the surface
2524 marking with a height of at least 4 feet (1.2 m). The numbers, letters, and other
2525 characters used in the inscription are scaled to those in Appendix B.

2526 4.12.5 Characteristics.

2527 Two recommended shapes for ramp markings are as follows. Note: Existing ramp
2528 marking schemes that differ from the two recommended shapes may remain until
2529 repainting is necessary for a major section or to replace the existing marking scheme to
2530 one of the recommended shapes.


2531 4.12.5.1 **Circular-shaped.**

2532 Circular ramp markings—illustrated in Figure 4-1, Figure 4-2 and Figure
2533 4-3—should have a diameter of at least 9 feet (2.7 m), which excludes the
2534 black border. The diameter of the circular marking must be increased so
2535 the width and height of the black inscription is at least 1 foot (30 cm) from
2536 the edges of the yellow circumference. Place the marking directly over the
2537 taxiway centerline or so the outer edge of the circular marking, excluding
2538 the black border, is within 7 feet (2.1 m) of the taxiway centerline.

2539

2540
2541


Figure 4-1. Sequential circular-shaped Ramp Control Markings 3, 4, and 5 between two terminals



2542

2543
2544


Figure 4-2. Circular-shaped Ramp Control Marking 16 on elongated terminal apron



2545

2546
2547

Figure 4-3. Circular-shaped Ramp Control Markings 9S and 9N between terminals




2548

2549 4.12.5.2 Triangular-shaped.
2550 Triangular-shaped ramp markings, as illustrated in Figure 4-5, offer pilots
2551 and drivers the additional function of reinforcing a specific direction of
2552 travel. Triangular-shaped ramp markings are equiangular triangles of at
2553 least 9 feet (3 m) in height. The base and height of the triangular marking
2554 must be increased so that the width and height of the black inscription is at
2555 least 1 foot (30 cm) from the edges of the yellow triangle. Place the
2556 marking directly over the taxiway centerline.

2557


Figure 4-4. Triangular-shaped ramp control marking between terminals




2558

2559

Figure 4-5. Circular and triangular-shaped ramp control marking dimensions



(a) Circular Shaped Ramp Control Marking Details



(b) Triangular Shaped Ramp Control Marking Details

2560

2561

Page intentionally left blank

2562

CHAPTER 5. OTHER SURFACE MARKINGS.2563 **5.1 Application.**

2564 The surface markings in this section are used, as appropriate, on airports.

2565 **5.2 Vehicle Roadway Markings.**2566 5.2.1 Purpose.

2567 The three distinct vehicle roadway markings contained in this chapter are used to
2568 delineate roadways located on or that cross paved areas used by aircraft (aircraft
2569 maneuvering areas) so that collisions and other mishaps are averted. Markings for
2570 roadways not located on aircraft maneuvering areas, such as airport service roads,
2571 should conform, whenever possible, to the U.S. Department of Transportation's Manual
2572 on Uniform Traffic Control Devices. Do not use surface painted markings intended for
2573 aircraft, such as holding position markings, enhanced taxiway centerline markings, or
2574 non-movement area boundary markings for roadways used exclusively by vehicles.
2575 Misuse of such markings may mislead pilots into identifying the roadway as a taxiway.
2576 For roadway signage provisions for either case, see AC 150/5340-18.

2577 5.2.2 Requirement.

2578 These markings for roadways located on or that cross aircraft maneuvering areas are
2579 applied as necessary to control vehicular traffic on the airport.

2580 5.2.3 Location.

2581 Vehicle roadways are delineated on aircraft maneuvering areas where there is a need to
2582 define a pathway for vehicle operations. A minimum separation of 2 feet (0.6 m) must
2583 be maintained between the roadway edge marking described below and the non-
2584 movement area boundary marking (see paragraph 5.4). All vehicle roadway markings
2585 are interrupted when crossing any taxiway and runway markings.

2586 5.2.4 Color.

2587 Vehicle roadway markings are white.

2588 5.2.5 Characteristics.

2589 5.2.5.1 Vehicle roadway markings consist of (a) roadway edge lines to delineate
2590 each edge of the roadway, (b) a dashed line to separate lanes within the
2591 edges of the roadway, and, where appropriate, (c) a roadway stop line
2592 (bar). The roadway edge lines, which are either solid lines or zipper-style,
2593 and the dashed lines are all 6 inches (15 cm) wide, except that zipper-style
2594 edges are 12 inches (30 cm) wide and 4 feet (1.2 m) long. See Figure A-15
2595 for details of the zipper-style marking. The dashed line for lane separation
2596 is 15 feet (4.5 m) in length and spaced 25 feet (7.5 m) apart. The roadway
2597 stop line (bar) is 2 feet (0.6 m) wide and extends across its appropriate
2598 lane. See Figure A-25 for illustrations and details.

- 2599 5.2.5.2 In lieu of the solid lines for roadway edge lines, zipper-style markings
2600 may be used to delineate the edges of the vehicle roadway wherever the
2601 airport's SMGCS working group or the airport operator determines the
2602 roadway edges need enhanced delineation.
- 2603 5.2.5.3 Every roadway lane that feeds vehicle traffic onto or across a taxi route
2604 must have a solid roadway stop line (bar). The placement of the stop line
2605 (bar) is in accordance with the criteria for taxiway centerline to
2606 fixed/movable object per AC 150/5300-13 for the largest airplane design
2607 group serving the airport. This placement generally ensures adequate
2608 vehicle clearance from taxiing aircraft. However, airport operators should
2609 evaluate if the effects of jet blasts by turning aircraft operations on vehicle
2610 traffic require a larger setback.
- 2611 **5.3 Very High Frequency Omnidirectional Range (VOR) Receiver Checkpoint**
2612 **Marking.**
- 2613 5.3.1 Purpose.
2614 The VOR receiver checkpoint marking is used by pilots to check their aircraft
2615 instruments with navigational aid signals. It consists of a painted circle with a painted
2616 directional arrow that is aligned toward the azimuth of the VOR facility. The location of
2617 the marking indicates a point on the airport where sufficient signal strength from a VOR
2618 facility exists so a pilot can check the aircraft VOR equipment against the radial
2619 azimuth indicated by the painted directional arrow. For the accompanying signage
2620 provisions, see AC 150/5340-18.
- 2621 5.3.2 Requirement.
2622 This marking is required as directed by FAA Flight Inspection Services.
- 2623 5.3.3 Location.
2624 FAA Flight Inspection personnel determine the location for the VOR receiver
2625 checkpoint marking(s) and issue information for checkpoint descriptions in flight
2626 publications. In general, the VOR receiver checkpoint marking preferably is located on
2627 an airport apron but could be on a taxiway; but it is never on a runway. The location(s)
2628 should also allow easy access to align the aircraft with the marking without unduly
2629 obstructing other airport traffic. VOR receiver checkpoint markings should not be
2630 established at distances less than one-half mile (0.8 km) from the facility, nor on
2631 unpaved areas.
- 2632 5.3.4 Color.
2633 The VOR receiver checkpoint marking is a painted circle of the size and colors shown
2634 in Figure A-26.

2635 5.3.5 Characteristics.

2636 The VOR receiver checkpoint marking is a painted circle with an arrow that is
2637 accompanied with an associated information sign.

- 2638 1. The VOR receiver checkpoint is a circle 10 feet (3.1 m) in diameter with a yellow
2639 arrow aligned toward the azimuth of the VOR facility.
- 2640 2. The arrow should extend to the full width of the inner circle.
- 2641 3. The black interior of the circle is surrounded by a 6-inch (15-cm) wide yellow ring
2642 contiguous to a 6-inch (15-cm) wide white outer ring per Figure A-26.
- 2643 4. When installed on concrete or other light-colored pavements, the exterior of the
2644 circle is painted black.

2645 **5.4 Non-Movement Area Boundary Marking.**2646 5.4.1 Purpose.

2647 The non-movement area boundary marking is used to delineate the movement areas
2648 under direct control by the airport traffic control tower from the non-movement areas
2649 that are not under their control. Secondary purpose: The primary users of this marking
2650 are airport operators having an airport traffic control tower. However, some airport
2651 operators without an airport traffic control tower have effectively used this surface
2652 marking on terminals and other aprons to separate vehicle traffic, equipment traffic, etc.
2653 from the areas where aircraft taxi, such as, when aircraft enter/exit an aircraft parking
2654 area located off the terminal. No part of a parked aircraft may overhang this marking. If
2655 aircraft taxi parallel to this marking, paint a taxiway or taxilane centerline marking such
2656 that the taxiway/taxilane object free area criteria are met.

2657 5.4.2 Requirement.

2658 This marking is used when there is a need to delineate the movement areas under direct
2659 control by the airport traffic control tower from the non-movement areas that are not
2660 under their control, and only where aircraft may cross the marking. Airports without an
2661 airport traffic control tower may use the surface marking to help delineate aircraft traffic
2662 routes, aircraft parking limits, etc.

2663 5.4.3 Location.

2664 A non-movement area boundary marking is located on the boundary between the
2665 movement and non-movement area as shown in Figure A-15. Prior to its
2666 implementation, a letter of agreement should be formalized between the airport operator
2667 and airport traffic control tower that specifies the location(s) of the boundaries. To
2668 provide adequate clearance for the wings of taxiing aircraft, the marking should never
2669 coincide with the edge of a taxiway. In this regard, the non-movement area boundary
2670 marking is set back in accordance with the taxiway or taxilane centerline to
2671 fixed/movable object criteria (taxiway/taxilane object free area) of AC 150/5300-13.
2672 However, the airport operator should evaluate if the effects of jet blasts by turning
2673 aircraft operations on equipment, personnel, or vehicle traffic require a larger setback.

2674 Taxilane instead of taxiway clearance criteria are usually used because this marking is
2675 painted in nearly all cases on terminal aprons, cargo areas, and aircraft parking areas
2676 where aircraft taxi at lower speeds.


2677

Mitigation of Wrong Runway Takeoffs

(Safety)

Precaution should be taken not to paint a non-movement area boundary marking on the outer edges of an apron that is transitioning into a taxiway that leads directly to a runway. Under certain runway/taxiway geometries, such as shown in [Figure 5-1](#), placement of this surface marking where dual parallel taxiways support a runway have resulted in pilots taking off on a parallel taxiway. The concern of such usage is that pilots who expect a nearby runway holding position marking after leaving an apron will confuse these two markings because of their visual similarities, i.e., single dash/single line versus dual dashes/dual lines. It is recommended that the non-movement boundary marking not be located on or just prior to a taxiway that leads directly to a runway.

2678

Figure 5-1. Precautionary placement of the non-movement boundary marking

2679

2680 5.4.4 Color.

2681 The non-movement area boundary marking is yellow and will be outlined in black on
 2682 light-colored pavements. See paragraph 1.4 and Table 1-1 for required techniques to
 2683 enhance this marking.

2684 5.4.5 Characteristics.

2685 5.4.5.1 The non-movement area boundary marking consists of two yellow lines,
 2686 one solid and one dashed as shown in Figure A-15. The solid line is
 2687 located on the side of the non-movement area while the dashed line is
 2688 located on the side of the movement area.

2689 5.4.5.2 Each line is 6 inches (15 cm) in width with 6-inch (15-cm) spacing
 2690 between lines. In the event of circumstances where pilots may have
 2691 difficulty discerning the edge of a movement area, the width of the lines
 2692 and spaces may be doubled to 12 inches (30 cm). In both applications, the
 2693 dashes are 3 feet (0.9 m) in length with 3-foot (0.9-m) spacing between
 2694 dashes.

- 2695 5.4.5.3 If a taxiway centerline intersects a non-movement area boundary marking,
2696 then the taxiway centerline is interrupted so that it is 6 to 12 inches (15 to
2697 30 cm) from both sides of the non-movement area boundary marking.
- 2698 5.4.5.4 If the non-movement area boundary marking that includes a black border
2699 intersects a taxiway edge marking, then the taxiway edge marking is
2700 interrupted such that the taxiway edge marking abuts the black border of
2701 the non-movement area boundary marking.
- 2702 5.4.5.5 If the non-movement area boundary marking that does not include a black
2703 border intersects a taxiway edge marking, then the taxiway edge marking
2704 is interrupted such that a 6-inch gap is left between the taxiway edge
2705 marking and the non-movement area boundary marking.
- 2706 **5.5 Markings for Thresholds Temporarily Relocated During Construction.**
2707 See AC 150/5370-2, Operational Safety on Airports During Construction, for provisions
2708 for marking and lighting a threshold temporarily relocated during construction.
- 2709 **5.6 Marking and Lighting of Permanently Closed Runways and Taxiways.**
2710 Permanently closed paved areas are indicated by the use of an “X”. Figure A-27
2711 provides detailed criteria for the “X” marking.
- 2712 5.6.1 For runways and taxiways that are permanently closed, the lighting circuits are
2713 disconnected. For closed runways, all markings for runway thresholds, runway
2714 designations, touchdown aiming points, and touchdown zones are obliterated. Removal
2715 of other existing runway markings, such as the centerline, edge markings, shoulder
2716 markings, stopway markings, and blast pad markings is recommended but not required.
2717 For closed runways that intersect another open runway, the runway centerline that abuts
2718 the open runway is obliterated for the 200 feet (61 m) adjacent to the open runway.
- 2719 5.6.2 For closed runways, only solid yellow “X” markings are painted (never striated “X”
2720 markings) at each end of the runway and at 1,000-foot (305-m) intervals.
- 2721 5.6.3 For a closed runway that intersects an active runway, a solid yellow “X” marking
2722 should be placed on the closed runway near the sides of the open intersecting runway.
2723 In most cases, two “X” markings are required, i.e., one “X” per each side of the open
2724 intersecting runway.
- 2725 5.6.4 For closed taxiways, a yellow “X” marking is placed at each entrance of the closed
2726 taxiway.
- 2727 5.6.5 In terms of pattern selection from Figure A-27, the larger alternate pattern is preferable
2728 over the smaller pattern for closed runways because this pattern is seen more readily
2729 from aircraft on final approach. For closed taxiways, the smaller pattern is preferable
2730 over the larger alternative pattern unless taxiing pilots have difficulty seeing the

- 2731 marking and are entering the closed taxiway or have reported near landings on the
2732 closed taxiway.
- 2733 **5.7 Temporarily Closed Runways and Taxiways.**
- 2734 The following procedures are to be followed when it is necessary to temporarily close a
2735 runway or a taxiway. See AC 150/5370-2 for requirements and guidelines.
- 2736 5.7.1 For temporarily closed runways, the airport operator has two options when it is
2737 necessary to provide a visual indication that a runway is temporarily closed.
- 2738 5.7.1.1 **Option 1 (preferred).**
- 2739 The airport operator uses a raised-lighted “X” on each runway end to
2740 indicate the runway is temporarily closed. See AC 150/ 5370-2,
2741 Operational Safety on Airports During Construction, for guidance on the
2742 use of this visual aid.
- 2743 5.7.1.2 **Option 2.**
- 2744 The airport operator places an “X” only at each end of the runway over the
2745 runway designation markings or, when required by construction activity,
2746 just off the runway end. The “X” is yellow in color and conforms to the
2747 dimensions specified in Figure A-27. Since the “X” is used temporarily,
2748 they are usually made of some easily removable material, such as plywood
2749 or fabric, rather than painted on the pavement surface. Any materials used
2750 for a temporary “X” should provide a solid appearance, for example, not
2751 by being prevented from flapping in the wind, say by using a ground
2752 anchor device. Anchoring devices should be designed to minimize damage
2753 to pavement, and any damage should be repaired before the runway is
2754 opened to aircraft traffic. Since the “X” will usually be placed over white
2755 runway markings, their visibility can be enhanced by a 6-inch (15-cm)
2756 black border.
- 2757 5.7.2 For temporarily closed taxiways, the airport operator has two options when it is
2758 necessary to provide a visual indication that a taxiway is temporarily closed.
- 2759 5.7.2.1 **Option 1.**
- 2760 Usually this type of closure is treated as a hazardous area so the guidance
2761 in paragraph 5.13 applies.
- 2762 5.7.2.2 **Option 2.**
- 2763 As an alternative, the airport operator may install the same yellow “X”
2764 shown in Figure A-27 for those entrances leading into the temporarily
2765 closed taxiway.
- 2766 5.7.3 If the runway or taxiway will be closed during the nighttime, the runway and taxiway
2767 lights will normally be disconnected so they cannot be illuminated unless such

2768 illumination is needed to perform maintenance operations on or adjacent to the runway,
2769 e.g., snow removal.

2770

| General Comment |
|-----------------|
|-----------------|

| |
|--|
| <p>Note: The airport operator is responsible for determining (1) the need for a visual indication that a runway or taxiway is temporarily closed and (2) the safest place to put the “X” or “X”s or other indicators per paragraph 5.13. In making these determinations, the airport operator should consider such things as the reason for the closure, duration of the closure, airfield configuration, and the existence and hours of operation of the airport traffic control tower and construction crews.</p> |
|--|

2771 **5.8 Converting a Runway to a Taxiway.**

2772 The following actions are necessary to convert a runway permanently to a taxiway.
2773 Operationally, once this conversion is invoked, aircraft are not permitted to land or take
2774 off from the taxiway.

2775 5.8.1 All runway markings found on the runway are obliterated or replaced with the
2776 appropriate taxiway markings. For example, the runway landing designation numbers
2777 are obliterated, and the white runway centerline is converted to a yellow taxiway
2778 centerline.

2779 5.8.2 All runway related signage and lighting fixtures found on or along the runway must be
2780 removed and/or replaced with the appropriate taxiway signage and lighting to indicate
2781 the existence of the converted taxiway. For example, runway edge lights are converted
2782 to blue edge lights, and runway centerline lighting fixtures are converted to green. (It
2783 may be possible to do both actions by changing the lens color.) See AC 150/5345-46,
2784 Specification for Runway and Taxiway Light Fixtures, for information about taxiway
2785 edge lights; AC 150/5345-39, Specification for L-853 Runway and Taxiway
2786 Retroreflective Markers, for information about Runway and Taxiway Retroreflective
2787 Markers; and AC 150/5340-30 for information about taxiway centerline lighting
2788 requirements.

2789 5.8.3 All markings associated with the converted runway but not painted on the runway, such
2790 as the runway holding position markings found on entrance taxiways, are obliterated
2791 and replaced with the appropriate taxiway markings. Additionally, runway related
2792 signage and lighting fixtures found off the runway must be removed and/or replaced
2793 with the appropriate taxiway signage and lighting to indicate the existence of the
2794 converted taxiway.

2795 5.8.4 In terms of documentation, airport operators must update their Airport Layout Plan as
2796 well as other appropriate documents to indicate the presence of the new taxiway and the
2797 permanent closure of the runway. Both the Airport/Facility Directory (A/FD) and the

2798 Airport Master Record (FAA Form 5010) need to indicate the conversion to a
2799 permanent taxiway.

2800

| General Comment |
|--|
| Note: The “X” closure marking is never used on this type of conversion since the converted pavement is intended to be an active, new taxiway. |

2801 **5.9 Intermittent Use of a Taxiway as a Runway.**

2802 The intermittent use of a taxiway as a runway is a type of conversion where the
2803 converted taxiway is either used only as a runway or used as a runway for a specified
2804 time of the day or night. In both of these applications, the airport operator must properly
2805 re-mark affected pavements (including provisions for signage and lighting). One
2806 required restriction for any conversions is that the converted pavement cannot be
2807 marked simultaneously with a yellow taxiway centerline and a white runway
2808 designation number. Other re-marking actions are listed below. The FAA recommends
2809 a Safety Management System risk assessment to determine if other necessary actions
2810 need to be implemented.

2811

| General Comment |
|--|
| Note: For airports subject to National Environmental Policy Act (NEPA) requirements, any proposal to use a taxiway as a runway should include a review of the potential environmental consequences of such an action. The airport operator should contact the FAA Airports Regional Office or Airports District Office for NEPA guidance. |

2812 5.9.1 Pavement used as a runway during the day should at a minimum be painted with the
2813 visual runway markings identified in Table 2-1, that is, the white landing designation
2814 number(s) and a white centerline. Furthermore, converted pavement used as a runway
2815 at night that is to be lighted should have runway lighting installed per AC 150/5340-30.

2816 5.9.2 If the pavement is to be used ONLY as a taxiway at night, blue edge lights should be
2817 installed per AC 150/5340-30.

2818 5.9.3 In terms of documentation, airport operators must update their Airport Layout Plan as
2819 well as other appropriate documents to indicate the presence of the new runway. If the
2820 runway is to be used ONLY as a taxiway at night and has blue edge lighting, this
2821 runway must be listed as unlighted along with an appropriate annotation in both the
2822 Airport/Facility Directory (A/FD) and the Airport Master Record (FAA Form 5010)
2823 indicating the runway is closed to nighttime operations and that the blue lights are
2824 provided for taxiing aircraft.

2825 5.9.4 Since the pavement is now considered a runway, any taxiways intersecting the
2826 designated runway must have appropriate runway holding position markings (including
2827 provisions for signage and lighting) painted per this AC including criteria from
2828 AC 150/5340-18, and AC 150/5340-30.

2829 **5.10 Closed or Abandoned Airports.**

2830 When all runways are closed temporarily, the airport beacon is turned off and the
2831 runways are marked per paragraph 5.7. When an airport is abandoned and all runways
2832 are closed permanently, the runways are marked per paragraph 5.6, the airport beacon is
2833 disconnected, and an “X” is placed in the segmented circle or at a central location if no
2834 segmented circle exists. For additional details, see AC 150/5370-2.

2835 **5.11 Heliport Markings.**

2836 Information on markings for heliports is in AC 150/5390-2, Heliport Design.

2837 **5.12 Marking for Arresting Gear.**

2838 Information on marking for arresting gear is in AC 150/5220-9, *Aircraft Arresting*
2839 *Systems on Civil Airports*.

2840 **5.13 Hazardous Construction Areas.**

2841 Marking of hazardous areas due to construction, in which no part of an aircraft may
2842 enter, are marked in accordance with AC 150/5370-2.

2843 **5.14 Aircraft Deicing Facility Markings.**

2844 Information on markings for aircraft deicing facilities is in AC 150/5300-14, *Design of*
2845 *Aircraft Deicing Facilities*.


2846 **5.15 Interim Surface Markings for Taxiways Mistaken as Runways.**

2847 This AC recognizes the use of the non-standard surface marking “TAXI” as an interim
2848 measure only for those taxiways that have repeated landing incidents.

2849 **Note:** For new construction, the outer edge of an entrance taxiway must be curved. See
2850 AC 150/5300-13. Figure 5-2 and Figure 5-4 provide location and characteristics for this
2851 application. In practice “TAXI” extends across the entire pavement including any
2852 paved shoulder as shown in the figures. The color is yellow with a 12 inch (30.5 cm)
2853 wide black border along the sides of each letter and a 4-foot (1.2-m) black border on the
2854 tops and bottoms of the letters. Figure 5-4 illustrates the combined application with
2855 aviation grade artificial turf. See FAA Engineering Brief No. 72A, *Positive*
2856 *Identification of Runways for Landing*, which provides guidance for identifying
2857 situations where a taxiway could be mistaken for a runway and provides other
2858 mitigation strategies for dealing with this problem.

2859

Figure 5-2. TAXI marking location facing runway approach end




2860

2861

Note: For new construction, the outer edge of an entrance taxiway must be curved. See AC 150/5300-13.

2867

Figure 5-4. Aviation grade artificial turf installation



2868

2869


Page intentionally left blank

2870

APPENDIX A. PAVEMENT MARKINGS

2871

Figure A-1. Precision runway markings



2872

2873

2874

2875

2876

2877

2878

2879

2880


Notes:

1. Dimensions are expressed in feet (meters).
2. Dimension varies with runway width. See paragraph 2.6.
3. The touchdown zone marking scheme maintains a 900 ft (275m) "no marking zone" from the midpoint of the runway. That is, those pairs of surface markings that extend within 900 ft (275m) of the runway midpoint are eliminated.
4. See paragraph 2.5.
5. See Figure A-6.

2881 6. See paragraph 2.6.
2882

2883

Figure A-2. Non-precision runway



2884

2885

2886

2887


2888

Notes: Dimensions are expressed in feet (meters).

1. See paragraph 2.5 and Table 2-2.
2. See Figure A-6.
3. See paragraph 2.6. See Table 2-1 for when required.

2889

Figure A-3. Visual runway markings



2890

2891

2892


2893

Notes: Dimensions are expressed in feet (meters).

1. See Figure A-6.
2. See paragraph 2.6.

2894

Figure A-4. Example of conflicting markings on crossing runways



2895


2896

2897

Note: In lieu of displaced threshold, the airport operator may place a remark on FAA Form 5010 which provides the distance that exists between the threshold and the aiming point marking.

2898


Figure A-5. Details of markings for intersecting runways



2899

2900

Figure A-6. Runway designation numerals and letters



2901

2902

2903

2904

2905

2906

2907

2908

2909

2910

2911

2912

2913

2914

2915


Notes:

- Dimensions are expressed in feet (meters).
- All characters have these characteristics (unless otherwise specified):
 - 60 [18] high
 - 20 [6] wide
 - vertical stroke of 5 [1.5]
 - horizontal stroke of 10 [30]
 - diagonal stroke of 5 [1.5]
- All numerals except the number eleven as shown are horizontally spaced 15 [4.5] apart.
- Single digits must not be preceded by a zero.
- The numeral "1", when used alone, contains a horizontal stroke, as shown, to differentiate it from the runway centerline marking.
- Single designations are centered on the runway pavement centerline. For double designations, the center of the outer edges of the two numerals is centered on the runway pavement centerline.

2916
2917
2918

- Where the runway designation consists of a number and a letter, the number and letter are located on the runway centerline in a stacked arrangement as shown in Figure A-1.

Figure A-7. Displaced threshold markings



2919
2920
2921
2922

Notes:


- Dimensions are expressed in feet (meters).
- Runway edge markings, when used on the runway, extend into the displaced area.

2923
2924

3. Runway markings (except holding position markings) including those in the displaced threshold are white.

2925
2926

Figure A-8. Marking for aligned taxiway with runway without a displaced threshold




2927

2928

Notes: Dimensions are expressed in feet (meters).

2929

Figure A-9. Markings for blast pads and stopways

2930

2931

2932

2933

2934

2935

2936

2937


2938

Notes:

1. Dimensions are expressed in feet (meters).
2. The widths of the stopways and blast pads are not the same. Stopways equal runway width. Blast pads equal runway width plus runway shoulders. See [AC 150/5300-13](#).
3. 50 ft (15m) spacing may be used when length of area is less than 250 ft (76 m) in which case the first full chevron starts at the index point (intersection of runway centerline and runway threshold).
4. Chevrons are painted yellow and at an angle of 45° to the runway centerline.
5. Chevron spacing may be doubled if length of area exceeds 1000 ft (305m).

2939

Figure A-10. Markings for aligned taxiway preceding a displaced threshold




2940

2941

2942

Figure A-11. Markings for blast pad preceding a displaced threshold



2943

2944

2945


2946

Notes:

1. Stopway width equals runway width.
2. Blast pad width equals runway width plus runway shoulders.

2947

Figure A-12. Runway shoulder markings



2948

2949

2950

2951


2952

Notes:

1. Dimensions are expressed in feet (meters).
2. Yellow runway shoulder markings are used only in conjunction with white runway edge markings.
3. Runway shoulder markings are painted yellow.

2953

Figure A-13. Holding position marking details



2954


2955
 2956
 2957
 2958
 2959
 2960
 2961

Notes:

1. Unless otherwise noted, all lines are yellow.
2. See paragraph 3.3 for reductions.
3. See paragraph 3.4 for reductions.
4. Dimensions shown do not account for outline marking in black paint when on light-colored pavement. See paragraph 1.4 and Appendix C.
5. See Table 1-1 for general guidelines for black borders on light-colored pavements.

2962

Figure A-14. Holding position marking details



2963

2964

2965

2966

2967

2968

Notes:


1. Unless otherwise noted all lines are yellow.
2. Dimensions shown do not account for outline marking in black paint when on light-colored pavement. See paragraph 1.4 and Appendix C.
3. See Table 1-1 for general guidelines for black borders on light-colored pavements.

2969

2970

2971

Figure A-15. Taxiway markings



2972

2973

2974

2975


2976

Notes:

1. Unless otherwise noted all lines are yellow.
2. Dimensions shown do not account for black outline of enhanced taxiway marking. See paragraph 1.3.8 and Appendix C.

2977

Figure A-16. Taxiway markings



2978

2979

2980

2981

2982

2983


2984

Notes:

1. Refer to [Figure A-1](#), [Figure A-13](#) and [Figure A-14](#) for dimensions off the runway and taxiway markings identified in this figure.
2. Refer to [AC 150/5340-18](#) for sign requirements at holding position markings.
3. Refer to [AC 150/5300-13](#), [paragraph 3.3](#).

2985

Figure A-17. Taxiway markings



2986

2987

2988

2989

2990

2991

2992


2993

Notes:

1. Refer to [Figure A-1](#), [Figure A-13](#) and [Figure A-14](#) for dimensions off the runway and taxiway markings identified in this figure.
2. Refer to [AC 150/5340-18](#) for sign requirements at holding position markings.
3. Refer to [AC 150/5300-13](#).
4. Refer to [Figure A-14](#).

2994

Figure A-18. Methods for taxiway centerline marking



2995

2996

2997


2998

Notes:

1. Refer to Figure A-12 and Figure A-13 for dimensions of the taxiway marking identified in this figure.
2. Refer to Figure A-13.

2999


Figure A-19. Surface painted signs



3000
3001

3002


Figure A-20. Surface painted gate identification signs



3003

3004


Figure A-21. Multiple gate signs



3005

3006

Figure A-22. Surface painted apron entrance point signs



3007

3008


3009

3010

Note: Centerline at apron entrance point locations may be marked with a radius marking rather than with a “T” configuration, as shown.

3011

Figure A-23. Taxiway shoulder markings




3012

3013
3014

- Note:** 1. See paragraph 4.10.3.2
2. PC – Point of curvature

3015

Figure A-24. Geographic position markings




3016

3017

3018

Figure A-25. Vehicle roadway markings




3019

3020

Note: Refer to [Figure A-15](#).

3021

Figure A-26. VOR receiver checkpoint markings



3022

3023

3024

3025

3026

3027

3028


Notes:

1. Arrow is to be aligned toward the facility.
2. Interior of circle is to be painted black on concrete surfaces only.
3. Circle may be bordered on inside and outside with a 6 inches (15 cm) black band if necessary for contrast.
4. Refer to AC 150/5340-18.

3029

3030

Figure A-27. Closed runway and taxiway markings



3031

3032 **Note:** Both symbols are always painted yellow.

3033 * For temporary symbol, this dimension may be changed to 8 ft (2.4m).


3034 ** For temporary symbol, this dimension may be changed to 4 ft (1.2m).

3035

APPENDIX B. INSCRIPTIONS FOR SIGNS AND GEOGRAPHIC POSITION MARKINGS

3036


Figure B-1. Pavement markings ABCDEFGH



3037

3038


Figure B-2. Pavement markings IJKLMNOP



3039

3040

Figure B-3. Pavement markings QRSTUVWX




3041

3042

3043


Figure B-4. Pavement markings YZ123456



3044

3045

Figure B- 5. Pavement markings 7890-, ↑



3046

3047

Page intentionally left blank

3048

APPENDIX C. EXAMPLES OF MARKINGS OUTLINED IN BLACK

3049

This appendix illustrates the acceptable layout for various markings outlined in black. The black paint extends at least 6 inches (15 cm) beyond the outside edge of the markings. All spaces between paint lines in markings composed of two or more lines or dashes are painted in black as illustrated in the figures below. An alternate outlining pattern is provided for dashed taxiway edge line markings. These figures are not drawn to scale.

3050

3051


3052

3053

3054

3055


Figure C-1. Runway holding position marking



3056

3057


Figure C-2. ILS/MLS holding position marking



3058

3059


Figure C-3. Continuous taxiway edge line marking



3060

3061


Figure C-4. Dashed taxiway edge line marking



3062

3063


Figure C-5. Alternate outlining method for dashed taxiway edge line marking



3064

3065

Figure C-6. Taxiway centerline marking




3066

3067

3068


Figure C-7. Intermediate holding position markings



3069

3070

Figure C-8. Non-movement area boundary marking



3071

3072 **APPENDIX D. ENHANCED MARKINGS FOR RUNWAY HOLDING POSITION**

3073 **D.1 General.**

3074 D.1.1 Enhanced taxiway markings are intended to provide additional visual cues to taxiing
3075 pilots to help them identify the location of the runway holding position. This appendix
3076 provides standards for these enhanced markings and guidance, including examples, on
3077 where to use the enhanced markings.


3078 D.1.2 The figures included in this appendix are not drawn to scale.

3079 **D.2 Applicability.**

3080 The guidelines and standards for enhanced taxiway markings contained in this appendix
3081 may be used as a runway incursion prevention initiative. They may be used in
3082 combination or separately with existing taxiway markings. However, all intersections at
3083 an airport must use the same combination of markings.

3084 D.3 Enhanced Taxiway Centerline Markings.

3085 Figure D-1. Enhanced taxiway centerline markings




3086

3087 **Notes:**

- 3088 1. Dashed lines for the enhanced taxiway centerline marking are 6 inches (15cm) in width and separated
- 3089 6 inches (15 cm) from the taxiway centerline. This applies to both 6 inches (15 cm) and 12 inches (30
- 3090 cm) taxiway centerline markings.

- 3091 2. The taxiway centerline markings may be shifted left or right to avoid interference with the taxiway
3092 centerline lights.


3093 **Figure D-2. Dashed lines at converging taxiway centerlines**



- 3094
- 3095 **Notes:**
- 3096 1. As shown in this case the V-shaped inner dashes start and stop with the outside 9-foot (3 m) dashes. -
- 3097 However, this may not always be the case for the inner dashes. If the v-shaped are less than 5 feet (1.5
- 3098 m) they may be omitted.
- 3099 2. Measurements are taken along the center of the centerline stripe.

3100
3101

Figure D-3. Converging, straight, and curved enhanced taxiway centerlines intersecting with holding position marking



3102


3103

Note: All measurements are taken along the center of the centerline.

3104 **D.4 Enhanced Runway Holding Position Markings.**

3105 The enhanced runway holding position marking, applicable only to those taxiway
3106 entrances that serve Airplane Design Group (ADG) V or VI airplanes, measures 125
3107 feet (38 m) from one paved shoulder to the other paved shoulder, i.e., 62.5 feet (19 m)
3108 from the main taxiway centerline. Figure D-4 illustrates the enhanced surface marking
3109 on a standard 75-foot (23-m) wide taxiway with a standard 35-foot (10.5-m) wide
3110 taxiway shoulder for TDG-6. For taxiways wider than 75 feet (22.9 m) that connect to
3111 the runways that serve ADG V or VI aircraft, the holding position line is extended so it
3112 is 25 feet (7.5 m) on both paved taxiway shoulders.


3113 **Figure D-4. Enhanced runway holding position markings on taxiways**



3114

3115 **D.5 Surface Painted Holding Position Signs.**

3116 **Figure D-5. Surface painted holding position signs for taxiway widths greater than**
 3117 **35 feet (10.5 m)**




3118

3119

Table D-1. Notes for Figure D-5

| Dimension Letter | Dimension feet (meters) | Notes |
|------------------|-------------------------|--|
| A | 2 – 4 (0.67 – 1.34) | The SPHPS to the right of the taxiway centerline is not always required in most cases. |
| B | 3 – 10 (0.91 – 3.0) | |
| C | 9 – 12 (2.75 – 3.7) | Inscriptions must have a height of 12 feet (3.7 m); however, the height may be reduced, as necessary, to the minimum height of 9 feet (2.75 m). In special situations, the surface painted marking may be reduced to less than 9 feet (2.75 m) in order to fit the marking appropriately. Examples of special situations include taxiways with widths narrower than 75 feet (22.9 m) or taxiways that need to display multiple runway designations with arrows. In all cases, inscriptions follow Appendix B inscription criteria. All other taxiway entrances to the same runway not needing the reduction are to maintain the 12 foot (3.7 m) height dimension. For practicality, the lowest height reduction is 6 feet (1.8 m). In all cases, the dimension D is not reduced. |
| D | 15 inches (38 cm) | |
| E | 9 (2.75) | |
| F | 3 (0.91) | |

3120

3121
3122**Figure D-6. Surface painted holding position sign for taxiway widths equal to or less than 35 feet (10.5 m)**

3123

3124

Table D-2. Notes for Figure D-6


| Dimension Letter | Dimension feet (meters) | Notes |
|------------------|-------------------------|--|
| A | 2 – 3 (0.67 – 0.91) | |
| B | 6 (1.8) | Inscriptions follow Appendix B inscription criteria. The size of the sign inscription is scaled to fit taxiways 35 feet (10.5 m) or less in width for TDG-1A, TDG-1B, and TDG-2. Reference AC 150/5300-13 . In special situations, the surface marking may be reduced to less than 6 feet (1.8 m) in order to fit the marking appropriately. Examples of special situations include taxiways that need to display multiple runway designations with arrows. In all cases, the inscriptions follow Appendix B inscription criteria. All other taxiway entrances to the same runway not needing the reduction are to maintain the 6-foot (1.8-m) height dimension. For practicality, the lowest height reduction is 3 feet (0.91 m). |
| C | 7.5 inches (19 cm) | |
| D | 36 inches (0.91) | The dimension is measured without any black border., i.e., red to yellow. |
| NOTE | | The dimensions for the enhanced taxiway centerline are in Figure D-1 . |

3125

3126

3127

Figure D-7. Surface painted holding position signs when taxiway centerline is not perpendicular to runway holding position marking



3128


3129

Table D-3. NOTES for Figure D-7

| Dimension Letter | Dimension feet (meters) | Notes |
|------------------|-------------------------|--|
| A | 2 – 4 (0.67 – 1.34) | The SPHPS to the right of the taxiway centerline is not always required in most cases. |
| B | 3 – 10 (0.91 – 3.0) | |
| C | 9 – 12 (2.75 – 3.7) | Inscriptions must have a height of 12 feet (3.7 m); however, the height may be reduced, as necessary, to the minimum height of 9 feet (2.75 m). In special situations, the surface painted marking may be reduced to less than 9 feet (2.75 m) in order to fit the marking appropriately. Examples of special situations include taxiways with widths narrower than 75 feet (22.9 m) or taxiways that need to display multiple runway designations with arrows. In all cases, inscriptions follow Appendix B inscription criteria. All other taxiway entrances to the same runway not needing the reduction are to maintain the 12-foot (3.7-m) height dimension. For practicality, the lowest height reduction is 6 feet (1.8 m). In all cases, the dimension D is not reduced. |
| D | 15 inches (38 cm) | |
| E | 9 (2.75) | |
| F | 3 (0.91) | |

3130
3131

Figure D-8. Surface painted holding position signs co-located with geographic position marking



3132
3133

Table D-4. Notes for Figure D-8

| Dimension Letter | Dimension feet (meters) | Notes |
|------------------|-------------------------|--|
| A | 2 – 4 (0.67 – 1.34) | The SPHPS to the right of the taxiway centerline is not always required. |
| B | 3 – 10 (0.91 – 3.0) | |
| C | 9 – 12 (2.75 – 3.7) | Inscriptions must have a height of 12 feet (3.7 m); however, the height may be reduced, as necessary, to the minimum height of 9 feet (2.75 m). In special situations, the surface painted marking may be reduced to less than 9 feet (2.75 m) in order to fit the marking appropriately. Examples include taxiways with widths narrower than 75 feet (22.9 m) or taxiways that need to display multiple runway designations with arrows. In all cases, the inscriptions follow Appendix B inscription criteria. All other taxiway entrances to the same runway not needing the reduction are to maintain the 12-foot (3.7-m) height dimension. For practicality, the lowest height reduction is 6 feet (1.8 m). In all cases, the dimension D is not reduced. |
| D | 15 inches (38 cm) | |
| E | 9 (2.75) | |
| F | 3 (0.91) | |
| G | 4 (1.3) | From edge of red border |
| H | 2 (0.65) | From outermost edge of main yellow taxiway centerline |

3134
3135
3136

Note: Because the geographic position marking cannot be located at a runway holding position for the low-visibility runway (see paragraph 4.11), this figure applies only where the designated taxi route for low-visibility operations crosses a runway that is not itself the low-visibility runway.

3137 D.5.1 Additional Guidelines for Application.


3138 The following illustrations provide examples of various runway holding position
3139 locations using the enhanced markings. The figures included in this appendix are not
3140 drawn to scale.

3141 D.5.2 Two Taxiway Centerlines Converging at a Runway Holding Position Marking.

3142 Where two taxiway centerlines converge at a runway holding position marking, the
3143 surface painted holding position signs must be installed parallel to the runway holding
3144 position marking. As shown in Figure D-9, only one sign on either side of the two
3145 taxiway centerlines is practical.

3146
3147

Figure D-9. Two taxiway centerlines converging at a runway holding position marking




3148

3149 **D.5.3 Intersection of Two Taxiways at Runway End.**

3150 In the case of two converging taxiway centerlines, surface painted holding position
3151 signs containing a single runway designator must be positioned parallel to the runway
3152 holding position marking, as shown in Figure D-10.


3153

Figure D-10. Intersection of two taxiways at runway end

3154

3155 D.5.4 Intersection of Three Converging Taxiway Centerlines.3156 Figure D-11 illustrates taxiway centerline configurations when there are three
3157 converging centerlines.

3158

Figure D-11. Intersection of three converging taxiway centerlines

3159

3160

3161

3162

Notes:

1. Enhancement is tangent to merging curve.
2. Enhancement terminates 5 feet (1.5 m) from intersection.

3163

3164

D.5.5 Intersection of Multi-Taxiway Centerlines with Less than 150 Feet (45.7 m) Between Taxiways.

3165

3166


3167

3168

Figure D-12 illustrates different taxiway centerline configurations when there are three converging centerlines, less than 150 feet (45.7 m) between the runway holding position markings, and potential difficulty in positioning surface painted holding position signs in the available space.

3169
3170

Figure D-12. Intersection of multi-taxiway centerlines with less than 150 feet (45.7 m) between taxiways



3171

3172
3173
3174
3175
3176**Notes:**

1. Illustrates perpendicular taxiway centerlines less than 150 feet (45.7 m) (see paragraph 4.3.4).
2. Illustrates a curved taxiway centerline between two runway holding position markings with less than 150 feet (45.7 m) along the taxiway centerline (see paragraph 4.3.4).
3. Illustrates a converging taxiway centerline curving toward two runway holding positions.


3177
3178
3179

D.5.6 Two Taxiway Centerlines Intersecting a Runway Holding Position Marking.

Figure D-13 illustrates an angled runway holding position marking that is intersected by two taxiway centerlines.

3180
3181

Figure D-13. Two taxiway centerlines intersecting a runway holding position marking




3182

3183 **D.5.7 Intersection of Stub Taxiway and Runway.**

3184 **Figure D-14** illustrates a solution for a stub taxiway that is less than 150 feet (45.7 m)
3185 long, with a 90-degree turn and angled taxiway shoulder areas. Per paragraph 4.3.4, the
3186 enhancement terminates 5 feet (1.5 m) from a taxiway/taxiway intersection.

3187


Figure D-14. Intersection of stub taxiway and runway



3188

3189

3190

Figure D-15. Narrow taxiway stacked surface painted holding position sign

3191

3192

3193

3194

3195

3196

3197

3198

3199

3200

3201

3202

3203

3204


3205

Notes:

1. Stacked surface painted holding position signs for narrow taxiways - only to be used per paragraph 4.5.4.2.
2. The recommended order of appearance follows:
 - a. If the “stacked” surface painted holding position signs are for a taxiway that clearly accesses one runway (for example, RWY 14L-32R) before another runway (RWY 18-36), then the order of appearance is from “bottom up” as shown above.
 - b. If the “stacked” surface painted holding position signs are for a taxiway that equally offers access to two or more runways, then follow a “clockwise” order of appearance as viewed for the holding position. Hence, the bottom surface painted holding position sign is the first runway as viewed from the holding position. This practice follows the signage convention.
3. For taxiways less than or equal to 35’ wide, the stacked surface painted holding position signs are located centered on the taxiway in accordance with Figure D-6.

3206
3207

Figure D-16. Enhanced taxiway centerlines when a taxiway connects closely spaced runways



3208

Advisory Circular Feedback

If you find an error in this AC, have recommendations for improving it, or have suggestions for new items/subjects to be added, you may let us know by (1) mailing this form to Manager, Airport Safety and Operations Division, Federal Aviation Administration ATTN: AAS-100, 800 Independence Avenue SW, Washington DC 20591 or (2) faxing it to the attention of the Office of Airport Safety and Standards at (202) 267-5383.

Subject: AC 150/5340-1M

Date: _____

Please check all appropriate line items:

An error (procedural or typographical) has been noted in paragraph _____ on page _____.

Recommend paragraph _____ on page _____ be changed as follows:

In a future change to this AC, please cover the following subject:
(Briefly describe what you want added.)

Other comments:

I would like to discuss the above. Please contact me at (phone number, email address).

Submitted by: _____

Date: _____