



U.S. Department
of Transportation
**Federal Aviation
Administration**

Advisory Circular

Subject: Design and Installation Details
for Airport Visual Aids

Date: DRAFT

AC No.: 150/5340-30J

Initiated by: AAS-100

Change:

1. **Purpose.**

This advisory circular (AC) provides guidance and recommendations on the installation of airport visual aids.

2. **Cancellation.**

This AC cancels AC 150/5340-30H, *Design and Installation Details for Airport Visual Aids*, dated July 21, 2014.

3. **Application.**

The Federal Aviation Administration (FAA) recommends the guidance and specifications in this AC for Design and Installation Details for Airport Visual Aids. In general, use of this AC is not mandatory. However, use of this AC is mandatory for all projects funded with federal grant monies through the Airport Improvement Program (AIP) and with revenue from the Passenger Facility Charges (PFC) Program. See Grant Assistance No. 34, *Policies, Standards, and Specifications*, and PFC Assurance No. 9, *Standards and Specifications*. All lighting configurations contained in this standard are a means acceptable to the Administrator to meet the lighting requirements of Title 14 CFR Part 139, *Certification of Airports*, Section 139.311, *Marking, Signs and Lighting*. See exception in paragraph 2.3.1.2.

4. **Principal Changes.**

Changes are marked with vertical bars in the margin. The AC incorporates the following principal changes:

1. Paragraph 1.6 is added to prohibit non-certified devices from attachment to the HV series power circuit.
2. Paragraph 6.7.1.5 deletes the note about separate power sources for wind cone obstruction lights.

3. Paragraph 7.4.2 is updated to move installation- specific information for REIL to paragraph 7.7.
4. Paragraph 7.5.4.4.5 adds a note to explain what flight inspection personnel consider when evaluating the Precision Approach Path Indicator (PAPI) Obstacle Clearance Surface (OCS) and objects that are outside the surface. The reader is directed to paragraph 7.7.6.6.4 item 3 for additional information.
5. Paragraph 7.7.6.6.4 item 6 is updated to explain obstacles outside the PAPI OCS that may be evaluated during flight inspections.
6. Paragraph 8.1.3.2.4 item 2 adds a reference to AC 150/5345-51, *Specification for Discharge-Type Flashing Light Equipment*.
7. Paragraph 9.6 is updated for propane fueled generators.
8. Added a note to paragraph 10.2 item 4 to address bolt torque maintenance requirements for in-pavement light fixtures.
9. Paragraph 10.3 is updated to remove reference to the application of silicone rubber between spacers and extensions.
10. Paragraph 11.2.1.11 is updated to remove references to using silicone sealant between the light base upper flange and extensions.
11. Figure A-44 is updated – Detail A inset is updated to show maximum distance.
12. Figure A-45 is updated to make bi-color taxiway centerline light fixtures more recognizable.
13. Figure A-48 is updated to add Note 5 to reference FAA JO 6850.2, *Visual Guidance Lighting Systems*.
14. Figure A-79 notes 5 and 6 are updated to correct errors.
15. Figure A-93 is updated for Runway End Identifier Lights (REIL) installation details.
16. Figure A-115 is added to show taxiway edge light configurations at General Aviation (GA) Airports. The reference paragraph 2.5.2.5.4 is also updated to reference link the new figure.
17. Removed references to Declared Distance from Figure A-6 through Figure A-18.
18. Reoriented Figure A-2 through Figure A-11 to promote ease of review.
19. Engineering Brief (EB) #92 has been incorporated into this document, starting with paragraph 2.5.2.6. It provides new guidance for taxiway edge lighting design for new taxiway construction or rehabilitation.
20. Updated Appendix A figures (A-2 thru A-12 and A-17) to new taxiway edge lighting geometry.
21. Added new figures based on updated guidance in AC 150/5300-13, *Airport Design*:
 - a. Figure A-12, Lighting for Crossover Taxiway
 - b. Figure A-13, Lighting for Runway Entrance, TDG 6, 600 to 150-foot runway

c. Figure A-14, Lighting for Taxiway Intersection.

22. Moved AC 150/5340-30H legacy Figures 2, 3, 5, 6, 7, 8, 9, 10, 11, 12 and 17 to new Appendix H.

23. Deleted AC 150/5340-30H figures with an aligned taxiway (Figures 4, 13, 14, and 15).

24. The AC is updated to remove long paragraphs and divide them into smaller sections to facilitate easier reading and better comprehension of the subject matter.

25. The format of the document has been updated, and minor editorial changes have been made throughout.

Hyperlinks (allowing the reader to access documents located on the internet and to maneuver within this document) are provided throughout this document and are identified with underlined text. When navigating within this document, return to the previously viewed page by pressing the “ALT” and “←” keys simultaneously.

Figures in this document are representations and are not to scale.

5. **Metrics.**

To promote an orderly transition to metric units, this AC contains both English and metric dimensions. The metric conversions may not be exact metric equivalents, and, until there is an official changeover to the metric system, the English dimensions will govern.

6. **Feedback on This AC.**

If you have suggestions for improving this AC, you may use the Advisory Circular Feedback form at the end of this AC.

7. **Copies of This AC.**

All ACs are available online at http://www.faa.gov/regulations_policies/advisory_circulars/.

John R. Dermody

Director of Airport Safety and Standards

CONTENTS

Paragraph	Page
Chapter 1 Introduction.....	1-1
1.1. General.....	1-1
1.2. Scope.....	1-1
1.3. Safety.	1-1
1.4. Mixing of Light Source Technologies.	1-1
1.5. Airports Geographical Information System (GIS) Database.	1-2
1.6. High Voltage Series Circuit Power.....	1-2
Chapter 2 Runway and Taxiway Edge Lighting Systems.	2-1
2.1. General.....	2-1
2.2. Selection Criteria.	2-1
2.3. Runway Edge Light Configurations.	2-1
2.4. Stopway Edge Lights.	2-5
2.5. Taxiway Edge Lights, Taxiway End Indicators, and Runway-Taxiway Intersections.	2-6
2.6. Taxiway Edge Light Installation for Standard Taxiway Turns.	2-8
2.7. System Design.	2-11
2.8. Equipment and Materials.	2-16
Chapter 3 Runway Centerline and Touchdown Lighting Systems.	3-1
3.1. Introduction.....	3-1
3.2. Selection Criteria.	3-1
3.3. Configuration.	3-1
3.1. Design.	3-3
3.4. Equipment and Material.....	3-5
Chapter 4 Taxiway Lighting Systems.	4-9
4.1. Introduction.....	4-9
4.2. Implementation Criteria.	4-10
4.3. Taxiway Centerline.....	4-11
4.4. Runway Guard Lights (RGLs).....	4-15
4.5. Runway Stop Bar.	4-19

CONTENTS

Paragraph	Page
118 4.6. Combination In-Pavement Stop Bar and RGLs.....	4-21
119 4.7. Clearance Bar Configuration.	4-21
120 4.8. Design.	4-23
121 4.9. Equipment and Material.....	4-36
122 4.10. Installation.....	4-37
123 Chapter 5 Land and Hold Short Lighting Systems.....	5-39
124 5.1. Introduction.....	5-39
125 5.2. Background.	5-39
126 5.3. Definitions.....	5-39
127 5.4. Implementation Criteria.	5-39
128 5.5. Configuration.	5-39
129 5.6. Design.	5-40
130 5.7. Equipment and Material.....	5-44
131 5.8. Installation.....	5-45
132 Chapter 6 Airfield Miscellaneous Aids.	6-1
133 6.1. Airport Rotating Beacons.	6-1
134 6.2. System Design.	6-1
135 6.3. Installation.....	6-3
136 6.4. Maintenance.....	6-4
137 6.5. Beacon Towers.....	6-4
138 6.6. Wind Cones.....	6-7
139 6.7. Obstruction Lights.	6-8
140 6.8. Equipment and Materials.	6-10
141 Chapter 7 Economy Approach Aids.	7-1
142 7.1. Introduction.....	7-1
143 7.2. Types of Economy Approach Lighting Aids.	7-1
144 7.3. Selection Considerations.....	7-1
145 7.4. Configurations.....	7-3
146 7.5. Design.	7-5

CONTENTS

Paragraph	Page
147 7.6. Equipment and Material.....	7-18
148 7.7. Installation.....	7-19
149 Chapter 8 Radio Control Equipment.....	8-1
150 8.1. Radio Control Equipment.	8-1
151 Chapter 9 Standby Power – Non-FAA.	9-1
152 9.1. Background.	9-1
153 9.2. Definitions.....	9-1
154 9.3. FAA Policy.	9-1
155 9.4. Electrical Power Configurations.	9-2
156 9.5. Design.	9-3
157 9.6. Equipment and Material.....	9-6
158 9.7. Installation.....	9-9
159 9.8. Inspection.....	9-10
160 9.9. Tests.	9-11
161 9.10. Maintenance.	9-11
162 9.11. Reducing Electrical Power Interruptions.	9-12
163 9.12. Engine Generator Equipment Performance Requirements.	9-12
164 Chapter 10 Pavement Types.	10-1
165 10.1. General.....	10-1
166 10.2. New Pavement – Rigid (Concrete).	10-1
167 10.3. New Pavement – Flexible (Bituminous).....	10-4
168 10.4. Overlay – Rigid.....	10-6
169 10.5. Overlay – Flexible.....	10-8
170 Chapter 11 Fixture Mounting Bases	11-1
171 11.1. General.....	11-1
172 11.2. L-868 Mounting Bases.....	11-1
173 11.3. Direct-Mounted (Inset) Fixtures.	11-4
174 11.4. Field Adjustable L-868 Mounting Bases.	11-7
175 11.5. Installation.....	11-8

CONTENTS

Paragraph	Page
Chapter 12 Equipment and Material.	12-1
12.1. General.	12-1
12.2. Light Bases, Transformer Housings, and Junction Boxes.	12-1
12.3. Duct and Conduit.	12-1
12.4. Cable, Cable Connectors, Plugs, and Receptacles.	12-2
12.5. Counterpoise (Lightning Protection System).....	12-5
12.6. Light Base Ground.	12-8
12.7. Light Fixture Bonding.....	12-9
12.8. Concrete.	12-9
12.9. Steel Reinforcement.	12-9
12.10. Adhesive and Sealants.	12-9
12.11. Load-Bearing Lighting Fixtures.	12-9
12.12. Inspection.	12-11
12.13. Auxiliary Relays.	12-13
12.14. Vault.	12-13
Chapter 13 Power Distribution and Control Systems.	13-1
13.1. Introduction.	13-1
13.2. Power Distribution.	13-1
Appendix A Figures.	A-1
Appendix B Airport Technical Advisory.....	B-1
Appendix C Terms and Acronyms.....	C-1
Appendix D Bibliography.	D-1
Appendix E Typical Installation Drawings for Airport Lighting Equipment.	E-1
Appendix F Application Notes.	F-1
Appendix G Runway Status Light (RWSL) System.	G-1
Appendix H Legacy Figures.	H-1

CONTENTS**Number****Page****FIGURES**

202		
203	Figure A-1. Legend and General Notes for Figures A-1 through A-23.....	A-1
204	Figure A-2. Runway and Threshold Lighting Configuration (LIRL Runways and MIRL Visual	
205	Runways)	A-2
206	Figure A-3. Runway and Threshold Lighting Configuration (HIRL Precision Instrument	
207	Approach - runway centerline not shown for HIRL. Non-Precision Instrument	
208	Approach for MIRL).....	A-3
209	Figure A-4. Runway with Blast Pad (No Traffic).....	A-4
210	Figure A-5. Lighting for Runway with Displaced Threshold.....	A-5
211	Figure A-6. Normal Runway with Taxiway	A-6
212	Figure A-7. Lighting for Runway with Displaced Threshold.....	A-7
213	Figure A-8. Lighting for Runway with Displaced Threshold/Usable Pavement.....	A-8
214	Figure A-9. Lighting for Runway with Displaced Threshold Not Coinciding with Opposite	
215	Runway End.....	A-9
216	Figure A-10. Lighting for Runway with Stopway	A-10
217	Figure A-11. Lighting for Runway with Displaced Threshold and Stopway	A-11
218	Figure A-12. Lighting for Crossover Taxiway	A-12
219	Figure A-13. Lighting for Runway Entrance, TDG 6, 600 to 150 Foot Runway	A-13
220	Figure A-14. Lighting for Taxiway Intersection.....	A-14
221	Figure A-15. Typical Straight Taxiway Sections (Less Than 200 Ft. (61 m))	A-15
222	Figure A-16. Spacing of Lights on Curved Taxiway Edges	A-16
223	Figure A-17. Taxiway Edge Lights for Standard Taxiway Turns	A-17
224	Figure A-18. Taxiway Edge Lights for Runway/Taxiway Intersection	A-18
225	Figure A-19. Typical Single Straight Taxiway Edges (More Than 200 Ft. (61 m))	A-19

CONTENTS

Number	Page
226 Figure A-20. Typical Single Straight Taxiway Edges (Less Than 200 Ft. (61 m)).....	A-20
227 Figure A-21. Typical Taxiway Edge Lighting Configuration	A-21
228 Figure A-22. Typical Taxiway Edge Lighting for Portions of Runways Used as Taxiway (When 229 Taxiway Lights Are “ON”).....	A-22
230 Figure A-23. Typical Edge Lighting for Portions of Runways Used as Taxiway (When Runway 231 Lights Are “ON”).....	A-23
232 Figure A-24. Light Fixture Wiring.	A-24
233 Figure A-25. Typical Wiring Diagram Utilizing L-828 Step-type Regulator with External 234 Remote Primary Oil Switch	A-25
235 Figure A-26. Typical Wiring Diagram Utilizing L-828 Step-type Regulator with Internal 236 Control Power and Primary Oil Switch	A-26
237 Figure A-27. Typical Basic 120-Volt AC Remote Control System	A-27
238 Figure A-28. Alternative 120-Volt AC Remote Control System	A-28
239 Figure A-29. Typical 120-Volt AC Remote Control System with L-847 Circuit Selector Switch 240	A-29
241 Figure A-30. Typical 48 VDC Remote Control System with 5-Step Regulator and L-841 Relay 242 Panel.....	A-30
243 Figure A-31. Typical 48 VDC Remote Control System with 3-Step Regulator and L-841 Relay 244 Panel.....	A-31
245 Figure A-32. Curves for Estimating Loads in High Intensity Series Circuits	A-32
246 Figure A-33. Curves for Estimating Loads in Medium Intensity Series Circuits.....	A-33
247 Figure A-34. Runway Centerline Lighting Layout.....	A-34
248 Figure A-35. Touchdown Zone Lighting Layout	A-35
249 Figure A-36. Section Through Non-adjustable Base and Anchor, Base and Conduit System, 250 Rigid Pavement.....	A-36
251 Figure A-37. Section Through Non-adjustable Base and Anchor, Base and Conduit System, 252 Flexible Pavement.....	A-37
253 Figure A-38. Runway Centerline Light – Shallow Base and Conduit Installation.....	A-38

CONTENTS

Number	Page
254 Figure A-39. Saw Kerf Wireway Details.....	A-39
255 Figure A-40. Saw Kerf Orientation Details – R/W Centerline and TDZ Lights	A-40
256 Figure A-41. Transformer Housing Installation Details Inset Type Lighting Fixtures	A-41
257 Figure A-42. Typical Equipment Layout, Inset Type Lighting Fixtures	A-42
258 Figure A-43. Junction Box for Inset Fixture Installation.....	A-43
259 Figure A-44. Typical Taxiway Centerline Lighting Configuration for Non-Standard Fillets 260 (Centerline light spacing for operations above 1,200 ft. (365 m) RVR)	A-44
261 Figure A-45. Color-Coding of Exit Taxiway Centerline Lights.....	A-45
262 Figure A-46. Taxiway Centerline Lighting Configuration for Acute-Angled Exits	A-46
263 Figure A-47. Controlled Stop Bar Design and Operation – “GO” Configuration.....	A-47
264 Figure A-48. Typical Taxiway Centerline Lighting Configuration for Standard Fillets 265 (Centerline light spacing for operations above 1,200 ft. (365 m) RVR)	A-48
266 Figure A-49. Taxiway Centerline Light Beam Orientation	A-49
267 Figure A-50. In-Pavement Runway Guard Light Configuration	A-50
268 Figure A-51. Elevated RGL and Stop Bar Configuration.....	A-51
269 Figure A-52. Typical Light Beam Orientation for In-Pavement RGLs and Stop Bars	A-52
270 Figure A-53. Clearance Bar Configuration at a Low Visibility Hold Point	A-53
271 Figure A-54. Curves for Estimating Primary Load for Taxiway Centerline Lighting Systems .. A- 272 54	A-54
273 Figure A-55. Typical Elevated RGL Installation Details	A-55
274 Figure A-56. Typical In-Pavement RGL External Wiring Diagram – Power Line Carrier 275 Communication, One Light Per Remote.....	A-56
276 Figure A-57. Typical In-Pavement RGL External Wiring Diagram – Power Line Carrier 277 Communication, Multiple Lights per Remote	A-57
278 Figure A-58. Typical In-Pavement RGL External Wiring Diagram – Dedicated Communication 279 Link	A-58

CONTENTS

Number	Page
280 Figure A-59. In-Pavement RGL Alarm Signal Connection.....	A-59
281 Figure A-60. Controlled Stop Bar Design and Operation – “STOP” Configuration	A-60
282 Figure A-61. Controlled Stop Bar Design and Operation – Intermediate Configuration	A-61
283 Figure A-62. Controlled Stop Bar Design and Operation – “STOP” Configuration for A/C 2 .. A- 284 62	A-62
285 Figure A-63. Typical Layout for Land and Hold Short Lights	A-63
286 Figure A-64. Typical Wireway Installation Details for Land and Hold Short Lights	A-64
287 Figure A-65. Sawing and Drilling Details for In-pavement Land and Hold Short Lights	A-65
288 Figure A-66. Typical Block Diagram for Land and Hold Short Lighting System	A-66
289 Figure A-67. Typical Curve for Determining Maximum Separation Between Vault and Control 290 Panel with 120-Volt AC Control	A-67
291 Figure A-68. Beacon Dimensions and Wiring Diagram.....	A-68
292 Figure A-69. Calculations for Determining Wire Size.	A-69
293 Figure A-70. Typical Automatic Control.....	A-70
294 Figure A-71. 120-Volt AC and 48-Volt DC Remote Control.	A-71
295 Figure A-72. Typical Structural Beacon Tower	A-72
296 Figure A-73. Typical Tubular Steel Beacon Tower.....	A-73
297 Figure A-74. Typical Airport Beacon Tip-Down Pole	A-74
298 Figure A-75. Typical Pre-Fabricated Beacon Tower Structure	A-75
299 Figure A-76. Typical Location of Supplemental Wind Cone.....	A-76
300 Figure A-77. Externally Lighted Wind Cone Assembly (Frangible)	A-77
301 Figure A-78. Typical Layout for MALSF	A-78
302 Figure A-79. Typical Layout for REIL.....	A-79
303 Figure A-80. Typical ODALS Layout	A-80

CONTENTS

Number	Page
304	Figure A-81. PAPI Obstacle Clearance Surface A-81
305	Figure A-82. PAPI Signal Presentation A-82
306	Figure A-83. Correction for Runway Longitudinal Gradient A-83
307	Figure A-84. General Wiring Diagram for MALSF with 120-Volt AC Remote Control A-84
308	Figure A-85. Typical Wiring Diagram for MALSF Controlled from Runway Lighting Circuit A-
309	85
310	Figure A-86. Typical Field Wiring Circuits for MALSF A-86
311	Figure A-87. Typical Installation Details for Frangible MALS Structures – 6-foot (1.8 m)
312	Maximum..... A-87
313	Figure A-88. Typical Wiring for REILs Multiple Operation A-88
314	Figure A-89. Typical Wiring for REIL Series Operation A-89
315	Figure A-90. FAA L-880 Style B (Constant Current) System Wiring Diagram A-90
316	Figure A-91. FAA L-880 Style A (Constant Voltage) System Wiring Diagram A-91
317	Figure A-92. PAPI Light Housing Unit (LHU) Installation Detail A-92
318	Figure A-93. Typical Installation Details for Runway End Identifier Lights (REILs)..... A-93
319	Figure A-94. Configuration “A” Electrical Power A-94
320	Figure A-95. Typical kVA Input Requirements A-95
321	Figure A-96. Typical Wiring Diagram for Configuration “A” Electrical Power A-96
322	Figure A-97. Typical Equipment Layout for Configuration “A” Electrical Power..... A-97
323	Figure A-98. Configuration “B” Electrical Power..... A-98
324	Figure A-99. Typical Wiring Diagram for Configuration “B” Electrical Power A-99
325	Figure A-100. Typical Wiring Diagram for Configuration “C” Power A-100
326	Figure A-101. Flexible Pavement or Overlay Installation..... A-101
327	Figure A-102. Use of Alignment Jig, No Reference Edge Available, Non-adjustable Base and
328	Conduit System..... A-102

CONTENTS

Number	Page
329 Figure A-103. Use of Alignment Jig, Reference Edge Available, Non-adjustable Base and 330 Conduit System	A-103
331 Figure A-104. In-pavement Shallow Base Runway Edge End or Threshold Light.....	A-104
332 Figure A-105. In-pavement Shallow Base Runway Centerline or TDZ Light	A-105
333 Figure A-106. Sawing and Drilling Details for In-Pavement Taxiway Centerline Lights	A-106
334 Figure A-107. Wiring Details for Direct- and Base-Mounted Taxiway Centerline Lights ...	A-107
335 Figure A-108. Typical Transformer Housing and Conduit Installation Details for Taxiway 336 Centerline Lights.....	A-108
337 Figure A-109. Adjustment of Edge Light Elevation for High Snowfall Areas	A-109
338 Figure A-110. Cable and Duct Markers.....	A-110
339 Figure A-111. Counterpoise Installation.....	A-111
340 Figure A-112. Power and Control System Block Diagram	A-112
341 Figure A-113. Typical PLC Control System Block Diagram.....	A-113
342 Figure A-114. PC Control System Block Diagram	A-114
343 Figure A-115. Typical Spacing for GA Airport Edge Lights	A-115
344 Figure E-1. Typical Standard Details for Runway and Taxiway Edge Lights –High Intensity 345 Light – Non-adjustable Base-mounted	E-2
346 Figure E-2. Typical Standard Details for Runway and Taxiway Edge Lights –Medium / High 347 Intensity Light – Non-adjustable Base-mounted	E-3
348 Figure E-3. Typical Standard Details for Runway and Taxiway Edge Lights –Medium Intensity 349 Light – Stake-mounted.....	E-4
350 Figure E-4. Typical Counterpoise and Ground Rod Connections	E-5
351 Figure E-5. Identification (ID) Tag Detail	E-6
352 Figure E-6. Standard Details for Underground Cable Installation – Typical Multiple Bank 353 Layout	E-7
354 Figure E-7. Standard Details for Underground Cable Installation – Type A	E-8

CONTENTS

Number	Page
355	Figure E-8. Standard Details for Underground Cable Installation – Type B.....E-9
356	Figure E-9. Standard Details for Underground Cable Installation – Type C.....E-10
357	Figure E-10. Standard Details for Underground Cable Installation – Plowed CableE-11
358	Figure E-11. Standard Details for Underground Cable Installation – Plowed CableE-12
359	Figure E-12. Standard Details for Taxiway Hold and Guidance Sign – Sign – Single Pedestal..E-
360	13
361	Figure E-13. Standard Details for Taxiway Hold and Guidance Sign – Sign – Multiple Pedestal
362E-14
363	Figure E-14. Standard Details for Taxiway Hold and Guidance Sign – Detail AE-15
364	Figure E-15. Standard Details for Pivoting Rotating Beacon Pole – Rotating Beacon and
365	Mounting Bracket Detail.....E-16
366	Figure E-16. Standard Details for Pivoting Rotating Beacon Pole – Locking Device Detail ..E-17
367	Figure E-17. Standard Details for Pivoting Rotating Beacon Pole – Pivot DetailE-18
368	Figure E-18. Standard Details for Pivoting Rotating Beacon Pole.....E-19
369	Figure E-19. Standard Details for Wind Cone Foundation (L-807)E-20
370	Figure E-20. Standard Details for Wind Cone – 12 ft. (3.7 m) Wind ConeE-21
371	Figure E-21. Standard Details for Precision Approach Path Indicators (PAPIs) – PAPI Light
372	Unit Locations.....E-22
373	Figure E-22. Standard Details for Precision Approach Path Indicators (PAPIs)E-23
374	Figure E-23. Standard Details for Precision Approach Path Indicators (PAPIs) – Section A-A .E-
375	24
376	Figure E-24. Standard Details for Runway End Identifier Light Power and Control Derived from
377	Runway Circuit – Profile View.....E-25
378	Figure E-25. Standard Details for Runway End Identifier Light Power and Control Derived from
379	Runway Circuit – Plan ViewE-26
380	Figure E-26. Location of Entrance-Exit Lights (in lieu of guidance signs).....E-27
381	Figure F-1. Controlled Output Sign Block DiagramF-2

CONTENTS

Number	Page
382 Figure F-2. Typical Power Line Carrier System.....	F-4
383 Figure F-3. Load Example for In Pavement RGL Circuit	F-11
384 Figure F-4. ALCMS Block Diagram from AC 250/5345-56	F-15
385 Figure G-1. REL Configuration for Taxiways at 90 Degrees.....	G-3
386 Figure G-2. Angled Configuration.....	G-4
387 Figure G-3. Takeoff/Hold Lights.....	G-6
388 Figure G-4. Runway Intersection Lights	G-9
389 Figure H-1. Runway and Threshold Lighting Configuration (LIRL Runways and MIRL Visual 390 Runways)	H-2
391 Figure H-2. Runway and Threshold Lighting Configuration (HIRL Precision Instrument 392 Approach - Runway Centerline Not Shown for HIRL; Non-precision Instrument 393 Approach for MIRL).....	H-3
394 Figure H-3. Runway with Blast Pad (No Traffic).....	H-4
395 Figure H-4. Lighting for Runway with Displaced Threshold.....	H-5
396 Figure H-5. Normal Runway with Taxiway	H-6
397 Figure H-6. Lighting for Runway with Displaced Threshold.....	H-7
398 Figure H-7. Lighting for Runway with Displaced Threshold/Usable Pavement.....	H-8
399 Figure H-8. Lighting for Runway with Displaced Threshold Not Coinciding with Opposite 400 Runway End.....	H-9
401 Figure H-9. Lighting for Runway with Stopway	H-10
402 Figure H-10. Lighting for Runway with Displaced Threshold and Stopway	H-11
403 Figure H-11. Spacing of Lights on Curved Taxiway Edges	H-12
404	

TABLES

405	
406 Table 2-1. Straight Taxiway Edge Light Spacing.....	2-7

CONTENTS

Number	Page
407 Table 2-2. Edge Lighting System Design Guide.	2-13
408 Table 2-3. Equipment and Materials.....	2-17
409 Table 4-1. Longitudinal Dimensions.	4-13
410 Table 4-2. Equipment and Material Used for Low Visibility Lighting Systems.....	4-36
411 Table 5-1. Equipment and Material Used for Land and Hold Short Lighting Systems.....	5-44
412 Table 7-1. Threshold Crossing Heights.	7-11
413 Table 7-2. Aiming of Type L-880 (4 Box) PAPI Relative to Pre-Selected Glide Path.....	7-11
414 Table 7-3. Aiming of Type L-881 (2 Box) PAPI Relative to Pre-Selected Glide Path.....	7-12
415 Table 8-1. Interface of Radio Control with Airport Visual Aids.	8-5
416 Table 13-1. AGL Control System Response Times.....	13-6

CHAPTER 1 INTRODUCTION

1.1. General.

Numerous airport visual aids are available to provide information and guidance to pilots maneuvering on airports. These aids may consist of single units or complex systems composed of many parts. Often visual aids have different performance requirements and configurations, but may share common installation procedures. For example, installation procedures for in-pavement lighting systems are essentially the same, yet the lighting systems may perform different functions. This AC provides installation details for all airport visual aids in one document. Performance specifications and configuration details for the various visual aids can be found in the referenced ACs. Drawings in Appendix E depict typical installation methods for various types of airport lighting equipment.

1.2. Scope.

This AC provides installation methods and techniques for airport visual aids. The standards contained herein are standards the FAA requires in all applications involving airport development of this nature. These standards must be met where lighting systems are required for FAA-developed procedures. Installations should conform to the National Electrical Code (NEC) and local codes where applicable. See referenced materials.

1.3. Safety.

Airports present a unique working environment. Airplanes traveling at high speed, multi-directional traffic, noise, and night work are a few of the conditions that may confront a construction worker on an airport. Safety is of paramount concern to all parties. We encourage you to become familiar with FAA guidance contained in AC 150/5370-2, Operational Safety on Airports During Construction.

1.4. Mixing of Light Source Technologies.

The increasing use of airport light emitting diode (LED) light fixtures on the air operations area (AOA) has caused concerns when LED light fixtures are interspersed with their incandescent counterparts. LED light fixtures are essentially monochromatic (aviation white excepted) and may present a difference in perceived color and/or brightness than an equivalent **glass or plastic filtered** incandescent fixture. These differences can potentially distort the visual presentation to a pilot. Therefore, LED light fixtures must not be interspersed with incandescent lights of the same type.

Example: An airport adds an extension to a runway. On the existing runway, the runway centerline light fixtures are incandescent. The airport decides to install LED runway centerline fixtures on the new section of runway and retains the incandescent fixtures on the existing section. This interspersion of dissimilar technology is not approved for installation.

In addition, defective incandescent fixtures must not be replaced with their LED counterparts. When replacing a defective light fixture, make certain that the replacement uses the same light source technology to maintain a uniform appearance.

LED Technology System(s) that are not to be interspersed:

- Runway Guard Lights – each pair of elevated RGLs must be the same technology. For in-pavement lights, do not mix LED with incandescent fixtures in the same bar.
- Touchdown Zone Lights.
- Runway Edge Lights including Threshold, End, and Stopway.
- Signs per location – do not collocate LED signs with incandescent signs. Example: runway holding position signs on both sides of a taxiway, holding position signs on both sides of a runway, separate signs that form a sign array.
- Taxiway curved segments (centerline and edge).
- Taxiway Straight Segments (centerline and edge).
- Approach Light Systems.
- Stop Bars.
- Runway Centerline.
- Lead-on and Lead-off Lights.
- Precision Approach Path Indicator (PAPI).

1.5. **Airports Geographical Information System (GIS) Database.**

When airport visual aids are newly installed or relocated, all relevant information in the Airports GIS database should be updated and verified by National Geodetic Survey (NGS) per AC 150/5300-18, *General Guidance and Specifications for Submission of Aeronautical Surveys to NGS: Field Data Collection and Geographic Information System (GIS) Standards*.

1.6. **High Voltage Series Circuit Power.**

Do not use the high voltage series lighting circuit to power devices that are not certified per AC 150/5345-53, *Airport Lighting Equipment Certification Program*, listed in Appendix 3, Addendum. Using non-certified devices can result in a poor system power factor resulting in unexpected constant current regulator (CCR) shutdowns and lighting circuit start-up problems.

CHAPTER 2 Runway and Taxiway Edge Lighting Systems.

2.1. General.

Edge lighting systems are used to outline usable operational areas of airports during periods of darkness and low visibility weather conditions. These systems are classified according to the intensity or brightness produced by the lighting system.

This chapter covers standards for the design and installation of the following systems (see Figure A-1 for the legend for Figure A-2 through Figure A-21).

2.1.1 Runway Edge Lighting Systems.

Runway edge lights define the edge of the runway. The following standard systems are described in this section:

- Low Intensity Runway Lights (LIRL)
- Medium Intensity Runway Lights (MIRL)
- High Intensity Runway Lights (HIRL)

2.1.2 Taxiway Edge Lighting Systems.

Taxiway edge lights define the edge of the taxiway. The standard taxiway edge lighting system for airports is described in this section:

- Medium Intensity Taxiway Lights (MITL)

2.2. Selection Criteria.

The selection of an edge lighting system is based on the operational needs per the following guidelines:

- LIRL - install on visual runways (for runways at small airports).
- MIRL - install on visual runways or non-precision instrument runways.
- HIRL - install on precision instrument runways.
- MITL - install on taxiways and aprons at airports where runway lighting systems are installed.

The airport surface requirements for specific approach procedures are the determining factor for the runway lighting system selection. See AC 150/5300-13, Airport Design, for more information. Any runway edge lighting system requires that the airport be equipped with a rotating beacon meeting the requirements of AC 150/5345-12, Specification for Airport and Heliport Beacons.

2.3. Runway Edge Light Configurations.

A runway edge lighting system is a configuration of lights that defines the lateral and longitudinal limits of the usable landing area of the runway. Two straight lines of lights installed parallel to and at equal distances from the runway centerline define the lateral

limits. The longitudinal limits of the usable landing area are defined at each end of the area by straight lines of lights called threshold/runway end lights, which are installed perpendicular to the lines of runway edge lights. Table 2-3 provides information on the recommended light fixture for each application.

2.3.1 Edge Lights.

2.3.1.1 **Colors.**

2.3.1.1.1 **LIRL.**

The runway edge lights emit white light per Figure A-2.

2.3.1.1.2 **MIRL and HIRL.**

1. The runway edge lights emit white light except in the caution zone (not applicable to visual runways) which is the last 2,000 ft. (610 m) of runway or one-half the runway length, whichever is less.
2. In the caution zone, yellow lights are substituted for white lights; they emit yellow light in the direction facing the instrument approach threshold and white light in the opposite direction.
3. Instrument approach runways are runway-end-specific, meaning a runway may have an instrument approach on one end and a non-instrument approach on the opposite end.
4. When there is an instrument approach at each runway end, yellow/white lights are installed at each runway end in the directions described above. The yellow lights indicate caution on rollout after landing. An example is shown in Figure A-3.

2.3.1.2 **Location and Spacing.**

2.3.1.2.1 **General.**

1. The runway edge lights are located on a line parallel to the runway centerline at least 2 ft. (0.6 m), but not more than 10 ft. (3 m), from the edge of the full-strength pavement designated for runway use.
2. On runways used by jet aircraft, we recommend 10 ft. (3 m) to avoid possible damage by jet blast. On runways not used by jet aircraft, we recommend 2 ft. (0.6 m).
3. The edge lights are uniformly spaced and symmetrical about the runway centerline, such that a line between light units on opposite sides of the runway is perpendicular to the runway centerline.
4. Longitudinal spacing between light units must not exceed 200 ft. (61 m), except as described in paragraph 2.3.1.2.2 item 1.
5. Use the threshold/runway end lights as the starting reference points for longitudinal spacing calculations during design.

Note: See AC 150/5340-26, *Maintenance of Airport Visual Aid Facilities*, for additional information about the toe-in of runway edge light fixtures.

Follow the manufacturer's instructions for proper light fixture toe-in alignment.

2.3.1.2.2 Intersections.

1. LIRL/MIRL. For runways with MIRL or LIRL installed and where the configuration of the runway intersection does not allow for the matching of the runway edge lights on opposite sides of the runway to be maintained, the distance between light units on the same side of the runway must not exceed 400 ft. (122 m). See Figure A-2, note 3, for maintaining uniform spacing at intersections.
2. MIRL. If the distance between the runway edge lights units is greater than 400 ft. (122 m), install an L-852D, taxiway centerline light fixture (per AC 150/5345-46, *Specification for Runway and Taxiway Light Fixtures*), modified to produce white light (by removing the filters if an incandescent lamp is used) or white/yellow, and maintain the designed spacing per Figure A-3.
3. HIRL. For runways approved for instrument landing system (ILS) CAT III operations with HIRL installed at runway intersections, install L-850C, flush in-pavement light fixtures (described in AC 150/5345-46), to maintain uniform spacing. For other operations on runways with HIRL, the installation of a in-pavement fixture should be based on the following:
 - a. The availability of other visual cues at the intersection, such as guidance signs or centerline lighting.
 - b. The geometric complexity of the intersection, such as crossing runways. When the gap exceeds 400 ft. (122 m) install an in-pavement light fixture to maintain uniform spacing.
 - c. Whether the addition of a in-pavement fixture could confuse ground operations.

2.3.1.2.3 Runway Sections Used as Taxiways.

1. For runway or sections of runways used as taxiways, the runway/taxiway must have the specified runway lights with the designed spacing maintained on the dual-purpose area.
2. It is permissible to install taxiway edge lights on the dual-purpose area. However, taxiway centerline lighting compliant with Chapter 4 is preferred.
3. Design the control systems such that either the taxiway lights or the runway lights are on. Runway and taxiway lights must not be illuminated at the same time.
4. All runway lights must be off when the runway's taxiway lights are illuminated.
5. See Figure A-22 and Figure A-23.

6. In some cases, where a section of the runway is used as a taxiway, it may be desirable to install a controllable stop bar to prevent taxiing aircraft from entering an intersecting runway.
7. The stop bar should be interlocked with the taxiway lights so that it is on when the taxiway lights are on.

2.3.2 Threshold/Runway End Lights.

2.3.2.1 **Color.**

2.3.2.1.1 **Runway Thresholds.**

1. Threshold lights emit green light outward from the runway and emit red light toward the runway to mark the ends of the runway.
2. The green lights indicate the landing threshold to arriving aircraft and the red lights indicate the end of the runway for departing aircraft.
3. The red and green lights are usually combined into one fixture and special lenses or filters are used to emit the desired light in the appropriate direction.
4. The layout details for runway threshold lights are shown in Figure A-2, Figure A-3, and Figure A-4.

2.3.2.1.2 **Centerline Light Operation in Displaced Runway Thresholds.**

1. When the runway threshold is displaced, the lights located in the area before the threshold emit red light toward the approach.
2. The threshold lights located at the displaced threshold emit green light outward from the runway threshold.
3. Examples of threshold lighting when the landing threshold is displaced from the actual runway threshold are per Figure A-5. Refer to AC 150/5300-13, the Declared Distances **paragraph**, for additional information about obstructions with regard to displaced thresholds and declared distances.

2.3.2.1.3 **Light Fixtures.**

1. Light fixtures in each group on both sides of a runway threshold should be either all elevated or all in pavement.
2. Mixing of elevated and in-pavement light fixtures in the same group will result in inconsistent light output.
3. See AC 150/5345-46 for standard elevated light fixture height.

2.3.2.2 **Location and Spacing.**

2.3.2.2.1 **General.**

The threshold and runway end lights are located on a line perpendicular to the extended runway centerline **at least** 2 ft. (0.6 m) **but** not more than 10 ft. (3 m) **before** the designated runway threshold. See Figure A-3.

1. The lights are installed in two groups located symmetrically about the extended runway centerline. The outermost light in each group is located in line with the runway edge lights.
2. The other lights in each group are located on 10 ft. (3 m) centers toward the extended runway centerline. Coordinate locations and spacing of threshold/runway end lights with other plans for future lighting equipment.
3. Approach lighting systems are equipped with a green threshold light bar located 2 ft. (0.6 m) to 10 ft. (3 m) before the runway threshold (see [Figure A-78](#)).
4. If other airport navigational equipment that is installed at the threshold prevents the lights from being properly spaced, each light in a group may be offset not more than 1 ft. (0.3 m) in the same direction.
5. For runways with LIRL/MIRL, threshold/runway end lights installed on visual runways with LIRL or MIRL must have 3 lights in each group per [Figure A-2](#).
6. For runways with MIRL/HIRL, threshold/runway end lights installed on non-precision instrument runways with MIRLs and precision instrument runways with HIRLs must have 4 lights in each light group per [Figure A-3](#).

2.3.2.2.2 Displaced Threshold.

When the threshold is displaced from the end of the runway or paved area, and access by aircraft prior to the threshold is allowed, the threshold lights are located outboard from the runway per [Figure A-5](#).

1. The innermost light of each group is located in line with the line of runway edge lights, and the remaining lights are located outward, away from the runway, on 10 ft. (3 m) centers on a line perpendicular to the runway centerline.
2. When the displaced runway area is usable for takeoff, red runway edge lights are installed to delineate the outline of this area, per [Figure A-5](#).

2.3.2.2.3 Runways Where Declared Distances are Adjusted.

Airport designs for constrained airports may require a reduction to the runway declared distance to meet runway safety area (RSA), runway object free area (ROFA), or the runway protection zone (RPZ) standards.

2.4. Stopway Edge Lights.

Definition of a stopway: A stopway is an area beyond the takeoff runway, centered on the extended runway centerline, and designated by the airport owner for use in decelerating an airplane during an aborted takeoff.

The stopway must be at least as wide as the runway and able to support an airplane during an aborted takeoff without causing structural damage to the airplane. See Figure A-10 and Figure A-11 for illustrations of stopways.

2.4.1 Color.

The stopway edge lights emit unidirectional red light in the takeoff direction of the runway.

2.4.2 Location and Spacing.

Stopway lights are placed along its full length in two parallel rows that are equidistant from the runway centerline and coincident with the rows of runway edge lights.

2.4.2.1 The spacing between the lights and distance from the edge is the same as runway edge lights per paragraph 2.3.

2.4.2.2 Lights must also be placed at the end of the stopway (spaced symmetrically in relation to the extended runway centerline) and no more than 10 ft. (3 m) outboard of the stopway edge per Figure A-10 and Figure A-11.

2.4.2.3 For visual runways with LIRL/MIRL, use two groups of three lights. For non-precision and precision instrumented runways use two groups of 4 lights.

2.5. **Taxiway Edge Lights, Taxiway End Indicators, and Runway-Taxiway Intersections.**

Taxiway edge lighting systems are configurations of lights that define the lateral limits of the taxiway. **Taxiway end indicators are a subset of taxiway edge lights that indicate the approach of the taxiway curve or intersection. Runway-Taxiway intersections require a unique set of signage.**

Note: See paragraph 2.5.2.6 for guidance about taxiway edge light installation. Also see AC 150/5300-13, Chapter 4, for new information for taxiway fillet design using newly formulated Taxiway Design Groups (TDG). The TDG is based upon the aircraft main landing gear width (MGW) and the distance from the cockpit to the main landing gear centroid (CMG).

2.5.1 Color.

The taxiway edge lights emit blue light, and edge reflectors reflect blue.

2.5.2 Location and Spacing.

Fixtures in the edge lighting system are located in a line parallel to the taxiway centerline not more than 10 ft. (3 m) outward from the edge of the full-strength pavement.

2.5.2.1 See Figure A-109 for additional details about light fixture height versus lateral location requirements in areas with high snowfall.

2.5.2.2 Reflectors may be installed per paragraph 2.6.3 of this section in lieu of, or to enhance taxiway edge lights.

2.5.2.3 The spacing for taxiway edge lights is calculated based on the taxiway configuration. The methods of calculating taxiway edge light spacing are described below:

Note: The use of in-pavement taxiway edge lighting fixtures should be restricted to where elevated lights may be damaged by jet blast or where they interfere with aircraft operations.

2.5.2.4 **Straight Taxiway Sections.**

2.5.2.4.1 The edge lights are spaced symmetrically using the criteria outlined in Table 2-1.

2.5.2.4.2 Lights installed on opposite sides of a straight taxiway are aligned such that opposing lights are in a line perpendicular with the taxiway centerline.

2.5.2.4.3 Examples of taxiway lighting for straight taxiway sections are shown in Figure A-15, Figure A-19, and Figure A-20.

Table 2-1. Straight Taxiway Edge Light Spacing

Section Length (L)	Number, Edge Lights (N) (per side) ¹	Maximum Spacing (Max)	Spacing (S)
$L \leq 50$ ft. (15 m)	2	50 ft. (15 m)	L
$L > 50$ ft. (15 m) and $L \leq 100$ ft. (30 m)	3	50 ft. (15 m)	$L/2$
$L > 100$ ft. (30 m) and $L \leq 200$ ft. (61 m)	3 $[(L/\text{max}) + 1]^{2,3}$	100 ft. (30 m) 50 ft. (15 m) (single edges)	$L/2$ $L/(N-1)^3$
$L > 200$ ft. (61 m)	$[(L/\text{max}) + 1]^2$	100 ft. (30 m) (single edges) ³ 200 ft. (61 m)	$L/(N-1)$

1. Number (N) excludes lights required for end and entrance/exit indicators.

2. Round value up to the next whole number, i.e. 1.31 becomes 2.

3. Applies to single straight taxiway only, where only one side exists. See Figure A-19 and Figure A-20.

2.5.2.5 **Curved Sections (Existing Taxiway Edge Lighting System Design)**

2.5.2.5.1 Curved taxiway edges require shorter spacing of edge lights.

2.5.2.5.2 The spacing is determined based on the radius of the curve. The applicable spacing for curves is per Figure A-16.

2.5.2.5.3 The taxiway edge lights are uniformly spaced. Curved edges of more than 30 degrees from point of tangency (PT) of the taxiway section to PT of the intersecting surface must have at least three edge lights.

2.5.2.5.4 For radii not listed in Figure A-16, determine spacing by linear interpolation **method**.

2.5.2.5.5 Taxiway spacing on curved sections at other than 14 CFR Part 139 certificated airports may be reduced per Figure A-115. In such cases, like curves on an airport will have the same spacing.

2.5.2.6 Curved Sections (New Taxiway Construction or Rehabilitation Design).

This section provides guidance on taxiway edge lighting system design for new taxiway construction or rehabilitation. See AC 150/5300-13 for guidance on using TDG instead of Aircraft Design Groups (ADG) for taxiway design.

2.6. Taxiway Edge Light Installation for Standard Taxiway Turns.

See Figure A-17 for an example of a taxiway edge lighting layout.

1. The spacing of the taxiway edge lights along the outer curve of taxiway turns and along curved fillets is shown in Figure A-16.
2. Because L-1 is a gradual taper, light spacing along L-1 must align with the respective outer edge straight segments. The gradual taper is treated as part of the straight segment.
3. The spacing used along the straight section prior to the intersection of the taxiway must continue along the L-1 taper.
4. Install taxiway end indicator lights prior to intersections and curves per Figure A-17 and paragraph 2.5.2.3. The light is installed 50 feet prior to the point of tangency of the outer pavement edge.
5. A light must be placed at the intersection point (IP) of the L-1 and L-2 tapers, and on the opposite edge of the taxiway directly across from this point.
6. The IP indicates where the straight section light spacing requirement originates (see subparagraphs 2 and 3 above).
7. A light must be placed at the intersection of the L-2 taper and any curved fillets. Where there is no curved fillet (R-FILLET=0), a light must be installed at the intersection of the two L-2 tapers.
8. For closely spaced turns where the L-1 tapers intersect, a light must be installed at that intersection.
9. The maximum spacing of the edge lights for L-2 tapers must not exceed 50 feet (15.2 m).

10. Per Figure A-17, use single straight segment spacing requirements for straight sections that are opposite L-2 tapers. Use typical straight taxiway light spacing to establish the spacing for the straight segments opposite of the L-2 tapers. Note that the straight segment is defined as a point aligned with the L-2 Intersection Point and the outside curve's point of tangency.

11. A minimum of three edge lights must be installed on a curved fillet where the angle of the intersection (delta) is more than 30 degrees. This is similar to the guidance in Figure A-16, note 4.

12. See the Spacing Notes within Figure A-17 for additional details.

2.6.1 Taxiway Edge Light Installation for Taxiway Turns (180 degree).

2.6.1.1 **Design Rules.**

Use the design rules described above to place the fillet taxiway edge lights.

2.6.1.2 **Crossover Taxiways.**

W-3 represents the dimension of the narrowest paved segment for a crossover taxiway. Lights are placed opposite one another at the narrowest point. See AC 150/5300-13 (paragraph 411, Figure 4-23 and Figure 4-24) for W-3 dimension. See Figure A-12 and Figure A-14 for additional design guidance.

2.6.1.3 **Entrance Taxiways.**

W-3 represents the dimension of the narrowest paved segment for an entrance taxiway. A light is placed on the inside edge at the narrowest point. The placement of a light on the opposite side of the narrowest paved segment is required unless the opposite side straight segment has a light within 10 feet (3 m) of the opposite location based on a single-sided light layout. See AC 150/5300-13 (paragraph 408, Figure 4-17 and Table 4-12) for W-3 dimension. Install the last taxiway edge light on the inside pavement edge at the point of intersection of the runway edge light line plus a 3-foot (1 m) offset and the taxiway edge light line. Install the last taxiway edge light on the outside pavement edge 10 feet (3 m) from the closest runway end light.

2.6.2 Taxiway Edge Light Installation for Runway and Taxiway Intersections.

2.6.2.1 See Figure A-18 for examples of taxiway edge lighting layouts at runway/taxiway intersections. Also, see Figure A-13 for additional design guidance.

2.6.2.2 The taxiway lighting fillet segment length "L" must start at the taxiway fillet IP and continue to a point on a line parallel to and offset 3 feet (1 m) outboard of the runway edge light line. The taxiway lighting is based on

the point of intersection of the runway edge light line plus a 3-foot (1 m) offset, with the taxiway light line.

2.6.2.3 Taxiway lighting along the taper is spaced based upon the length of the segment “L.” Refer to Table 1 of [Figure A-18](#) for recommended spacing requirements.

2.6.2.4 If the intersection with the taxiway lighting segment is on a curve, the point of intersection is treated as a PT and the taxiway light spacing is per this AC. If the curve has a W-3, a light is placed at W-3 and the light line curve spacing is based on the PT and W-3 point.

2.6.2.5 Note that the TDG directly affects the pavement design, thus the layout of the taxiway edge lights. See the Spacing Notes in [Figure A-18](#) for additional details.

2.6.2.5.1 **Taxiway End indicators.**

1. Install end indicators on straight taxiway sections 200 ft. (61 m) or longer.
2. End indicators are additional taxiway edge lights installed before the intersection spaced 50 ft. (15 m) from the last light on straight taxiway sections.
3. These lights are installed on sections of taxiways that are **at least** 200 ft. (61 m) long, where edge light spacing exceeds 60 ft. (18 m).
4. [Figure A-19](#) and [Figure A-20](#) show typical placement of end indicators.

2.6.2.5.2 **Taxiway Edge Lights in Lieu of Guidance Signs at Runway-Taxiway Intersections.**

1. Taxiway guidance signs are installed at runway-taxiway intersections to define the throat or entrance into the intersecting taxiing route.
2. Where taxiway signs would interfere with aircraft operations, or at small general aviation (GA) airports, dual taxiway lights spaced per [Appendix E, Figure E-26](#), may be installed instead of the sign.
3. The taxiway lights used are L-861T fixtures. Taxiway lights used per the above must be illuminated when the runway edge lights are on.

2.6.3 Use of Reflectors.

Reflectors are permitted to enhance taxiway lighting systems installed on short taxiway sections, curves, and intersections (see [Figure A-15](#) and [Figure A-16](#)).

2.6.3.1 Lights are installed to meet the spacing requirements and reflectors are installed uniformly between the lights.

2.6.3.2 Reflectors are also permitted in lieu of edge lights where a centerline system is installed.

2.6.3.3 Reflectors must be installed using the required spacing for taxiway edge lights as specified in this AC.

2.6.3.4 See AC 120-57, Surface Movement Guidance and Control System, for additional guidance about the use of retroreflective markers.

2.6.3.5 Figure A-109 (which shows elevated light height versus the distance from the defined pavement edge) must also apply to the use of Type II retroreflective markers in areas with high snowfall.

2.6.3.6 Retroreflective markers are described in AC 150/5345-39, Specification for L-853, Runway and Taxiway Retroreflective Markers.

2.7. System Design.

Coordinate the lighting system design with the existing and future airport plans. Airport drawings will show existing system(s) layout and available utilities. Install the conduits and ducts needed for the lighting system prior to paving operations to eliminate the expense of installing these utilities in existing pavement. Airport drainage systems may influence the location of cable ducts and trenches. Develop design drawings showing the dimensional layout of the lighting system prior to construction. Examples of system layouts are per Figure A-21, Figure A-22, and Figure A-23, for high-density traffic airports.

2.7.1 Lighting Fixtures.

The lighting fixtures installed in the edge lighting systems are either base-mounted or stake-mounted.

2.7.1.1 Base mounts are used for either elevated fixtures or in-pavement fixtures.

2.7.1.2 In-pavement light fixtures are not permitted for the full length of the runway. They are typically used in areas where aircraft may roll over the fixture and require load-bearing bases.

2.7.1.3 Stake mounting is typically less expensive than base mounting; however, base mounting provides additional protection for this equipment and makes the equipment more accessible for maintenance. Stake mounting requires the transformers, cables, and connectors be buried in the earth. A typical drawing of light fixture mountings is per Figure A-24.

2.7.1.4 Base-mounted fixtures must be installed using series circuits only and are recommended for HIRL, MIRL, or MITL.

2.7.1.5 Stake-mounted fixtures can be installed with either series or parallel circuits.

2.7.2 Electrical Power (Series vs. Parallel Circuits).

Series powered circuits with isolation transformers are recommended for HIRL, MIRL, and MITL lighting systems.

2.7.2.1 **The advantages of the series circuits are:**

- Uniform lamp brightness.
- Lower installation cost for long runways, generally over 4,000 ft. long.
- Reduced cold-start burnouts and in-rush currents on turn-on.
- Unintentional grounding will not shut the system down.

2.7.2.2 Parallel power circuits are recommended for LIRL, but may also be used for MIRL or MITL. Parallel circuits have a lower installation cost for short runways, 4,000 ft. or less.

2.7.2.3 Parallel circuits should be designed using a 120/240-volt AC, single-phase, 3-wire system with a shared neutral. Interleave the circuits so that each adjacent fixture is on a separate leg.

2.7.2.4 Series circuits may also be interleaved, considering requirements for equipment such as regulators and adjacent lamp monitoring during design of the system.

2.7.2.5 If two or more circuits are used to power the edge lights for one runway, and loss of power to any of those circuits will leave more than 400 ft. of the runway without edge lights, the circuits should be coupled such that if one is energized both are energized, or if one is de-energized both are de-energized.

2.7.2.6 For additional technical information about airport lighting circuit interleaving, see [International Civil Aviation Organization \(ICAO\), Aerodrome Design Manual, Document 9157-AN/901, Part 5, Electrical Systems](#).

2.7.3 Power Source and Monitoring.

Series-powered airport lighting circuits are powered by CCRs. The CCRs and the associated monitoring system are described in [AC 150/5345-10, Specification for Constant Current Regulators and Regulator Monitors](#). The CCRs are designed to provide the desired number of brightness steps.

2.7.3.1 Some CCRs emit electromagnetic interference (EMI) that may degrade the performance of other air navigational equipment, such as computers, radars, instrument landing systems, radio receivers, very high frequency omnidirectional radio ranges, etc.

2.7.3.2 See [Appendix B](#) for more information about potential airport EMI.

2.7.3.3 Runway edge lighting systems that support CAT II or CAT III operations should be remotely monitored and must provide the monitoring information to the Airport Traffic Control Tower (ATCT).

2.7.3.4 See AC 150/5345-56, *Specification for L-890 Airport Lighting Control and Monitoring System (ALCMS)*, for additional information about monitoring systems.

2.7.3.5 See AC 150/5340-26, Appendix A, Standards and Tolerances, for airport lighting operational tolerances.

Table 2-2. Edge Lighting System Design Guide.

Lighting System	Installation		Fixture	Power System	Number of Steps	Associated Threshold	
	Type	Mounting				Design	Fixtures
RUNWAY EDGE LIGHTING							
HIRL	Inset ¹	Base	L-850C	Series	5	8 lights	L-862E
	Elevated	Base or Stake	L-862				
MIRL	Inset ¹	Base	L-852D	Series	3	6 or 8 lights	L-861SE ² L-861E ²
	Elevated	Base or Stake	L-861	Series or Parallel			
LIRL	Elevated	Base or Stake	L-860	Series or Parallel	1	6 lights	L-860E
TAXIWAY EDGE LIGHTING							
MITL	Inset	Base	L-852T	Series	3		
	Elevated	Base or Stake	L-861T	Series or Parallel	3		

¹ Inset fixtures are not permitted for the full length of the runway. They are typically installed in areas where aircraft may roll over the fixture.

² For runways with either a PAPI, runway end identifier lights (REIL), medium approach light system (MALs), or lead-in lighting system (LDIN), L-861E light fixture may be installed in lieu of the L-861SE.

³ An L-861SE light fixture should be used for MIRL if there is no PAPI, REIL, MALs, or LDIN present.

2.7.4 Brightness Steps.

The brightness of the lamps is specified in steps that are defined as a percentage of the full brightness of the lamp. (AC 150/5345-46 contains the specifications for the light fixtures.) The following tables specify the appropriate lamp current or voltage to achieve each brightness step:

2.7.4.1 **HIRL Systems.**

HIRL **systems** have five brightness steps:

	Percent Brightness	Lamp Current
Step 5	100	6.6 A
Step 4	25	5.2 A
Step 3	5	4.1 A
Step 2	1.2	3.4 A
Step 1	0.15	2.8 A

2.7.4.2 **MIRL Systems.**

MIRL and MITL, when installed using a series circuit and powered by an L-828 or L-829 regulator, have three brightness steps:

	Percent Brightness	Lamp Current	
		Series	Parallel
Step 3	100	6.6 A	120 V
Step 2	30	5.5 A	85 V
Step 1	10	4.8 A	60 V

When MITL are installed using a parallel circuit, only one brightness step is required. In some cases, it may be desirable to provide equivalent brightness steps **similar to a 3- step series circuit**. This may be accomplished by use of a variable transformer, autotransformer, or other means.

2.7.4.3 **LIRL Systems.**

LIRL have only one brightness step, 100%.

2.7.5 Control Methods.

2.7.5.1 The edge lighting systems should have provisions for local and/or remote control methods.

2.7.5.2 Remote controls are recommended for **systems at** locations served by an **ATCT**, flight service station, or other manned offices where the system(s) operates. Refer to Chapter 13 for additional information about control systems.

2.7.5.3 Local controls may be designed using direct switching at the site, or automatic controls such as a photoelectric control device or timer switch with provisions for switching from automatic to manual control.

2.7.5.4 Remote controls may be designed using a fixed-wire method, or radio control with L-854 equipment per AC 150/5345-49, *Specification L-854, Radio Control Equipment*. Figure A-25, Figure A-26, Figure A-27, Figure A-28, Figure A-29, Figure A-30, and Figure A-31 show some typical applications for remote controls.

2.7.5.4.1 **120 Volts AC.**

Where the distance between the remote-control panel and the vault is not great enough to cause an excessive voltage drop (5%) in the control leads, the standard control panel switches should be used to operate the control relays directly.

Control relays supplying power to the regulators must have coils rated for the control voltage. Conductor size of the control cable should be of a size that will not cause more than a 5% voltage drop. The voltage rating of the conductor insulation must be rated for the system voltage. Refer to Chapter 13 for additional guidance.

2.7.5.4.2 **120 Volts AC – Auxiliary Relay.**

Special low-burden pilot auxiliary relays, having proper coil resistance to reduce control current, may be used to obtain additional separation distance with 120-volt AC control circuits. It may be advantageous to use these relays to expand existing 120-volt AC control circuits.

2.7.5.4.3 **48 Volts DC.**

Where the distance between control panel and the vault would cause an excessive voltage drop, a low voltage (48-volt DC) control system should be used.

1. In such a system, remote control panel switches activate sensitive pilot relays, such as those specified in AC 150/5345-13, *Specification for L-841 Auxiliary Relay Cabinet Assembly for Pilot Control of Airport Lighting Circuits*, which, in turn, control the regulator relays.
2. Use an appropriately sized cable, of a type listed for use as direct earth burial, to connect the control panel to the pilot relays.
3. The DC control system is adequate for up to 7,900 ft. (2408 m) separation between control point and vault.
4. For typical application details, see Figure A-30, Figure A-31 and AC 150/5345-3, *Specification for L-821 Panels for Control of Airport Lighting*.

2.7.6 Runway Visual Range (RVR) Connections.

2.7.6.1 Where RVR equipment is to be installed, provide two No. 12 AWG wires for 120-volt AC control, or two No. 19 wires if 48-volt control is used, between the control tower and the vault.

2.7.6.2 The wires in the vault connect to an interface unit provided with the RVR equipment. The wires in the tower connect to RVR equipment.

2.7.6.3 All RVR connections must be per instructions provided with the RVR system, and be made by personnel responsible for the RVR or their designee.

2.8. **Equipment and Materials.**

Equipment and material covered by FAA ACs are referred to by item numbers and the associated AC numbers where the equipment is specified - all pertinent ACs and specifications are referenced by number and title in Appendix D. Equipment that is not covered by FAA specifications, such as distribution transformers, circuit breakers, cutouts, relays, and other commercial items of electrical equipment, must conform to the applicable rulings and standards of the electrical industry and local code regulations. Electrical equipment must be tested and certified by an Occupational Safety and Health Administration (OSHA) recognized Nationally Recognized Testing Laboratory (NRTL) and should bear that mark. A current list of NRTLs can be obtained by contacting the OSHA NRTL Program Coordinator. Table 2-3 contains a list of equipment and material used for runway and taxiway edge lighting systems described in this section. See Chapter 12 for additional information:

- Light Bases, Transformer Housings and Junction Boxes. See paragraph 12.2.
- Duct and Conduit. See paragraph 12.3.
- Cable, Cable Connectors, Plugs and Receptacles. See paragraph 12.4.
- Counterpoise (Lightning Protection). See paragraph 12.5.
- Light Base Ground. See paragraph 12.6.
- Light Fixture Bonding. See paragraph 12.7.
- Concrete. See paragraph 12.8.
- Steel Reinforcement. See paragraph 12.9.
- Adhesive and Sealants. See paragraph 12.10.
- Load-bearing Lighting Fixtures. See paragraph 12.11.
- Inspection. See paragraph 12.12.
- Testing. See paragraph 12.12.1.
- Auxiliary Relays. See paragraph 12.13.

- 1033 • Vault. See paragraph 12.14.
- 1034 • Maintenance. See paragraph 12.14.2.

1035 **Table 2-3. Equipment and Materials.**

Item Description	Item No.	ACs
Auxiliary Relay Cabinet	L-841	<u>AC 150/5345-13</u>
Cable	L-824	<u>AC 150/5345-7</u>
Cable Connectors	L-823 series circuits L-108 parallel circuits	<u>AC 150/5345-26</u> <u>AC 150/5370-10</u>
Circuit Selector Switch	L-847	<u>AC 150/5345-5</u>
Control Panel	L-821	<u>AC 150/5345-3</u>
Elevated Edge Light Fixture (HIRL)	L-862, L-850C ¹	<u>AC 150/5345-46</u>
Elevated Edge Light Fixture (LIRL)	L-860	<u>AC 150/5345-46</u>
Elevated Edge Light Fixture (MIRL)	L-861	<u>AC 150/5345-46</u>
Elevated Threshold Light Fixture (HIRL)	L-862	<u>AC 150/5345-46</u>
Elevated Threshold Light Fixture (MIRL)	L-861 SE, L861E ²	<u>AC 150/5345-46</u>
In-pavement Light Fixture	L-852	<u>AC 150/5345-46</u>
In-pavement Light Fixture	L-850 D, E	<u>AC 150/5345-46</u>
Isolation Transformers	L-830	<u>AC 150/5345-47</u>
Junction Box ⁴	L-867/L-868, blank covers	<u>AC 150/5345-42</u>
Light Base and Transformer Housing ³	L-867, L-868	<u>AC 150/5345-42</u>
Regulators	L-828, L-829	<u>AC 150/5345-10</u>
Retroreflective Markers	L-853	<u>AC 150/5345-39</u>
Duct and Conduit	L-110	<u>AC 150/5370-10</u>
Concrete	P-610	<u>AC 150/5370-10</u>
Tape	L-108	<u>AC 150/5370-10</u>
Vaults	L-109	<u>AC 150/5370-10</u>

¹ Install the L-850 C light fixture if in-pavement fixtures are applicable, per paragraph 2.3.

² For runways with either a PAPI, REIL, MALS, or LDIN, L-861E light fixture may be installed in lieu of the L-861SE.

- 1040 ³ Elevated lights are installed with a 12-inch (size B) Type L-867 base or are stake-
1041 mounted, and in-pavement light fixtures are installed with a 15-inch (size C)
1042 base or a 12-inch (size B) L-868 base.
- 1043 ⁴ Use an L-867 light base with blanking cover for a junction box or transformer
1044 housing that must withstand occasional light vehicular loads. Use an L-868 light
1045 base with blanking cover for a junction box or transformer housing that must
1046 withstand heavy loads from vehicles or aircraft.

CHAPTER 3 Runway Centerline and Touchdown Lighting Systems.

3.1. Introduction.

Runway centerline and touchdown zone lighting systems are designed to facilitate landings, rollouts, and takeoffs. The touchdown zone lights are primarily a landing aid while the centerline lights are used for both landing and takeoff operations.

3.2. Selection Criteria.

Runway centerline lights and touchdown zone lights are required for CAT II and CAT III runways, and for CAT I runways used for landing operations below 2,400 ft. (750 m) RVR.

3.2.1 Runway centerline lights are required on runways used for takeoff operations below 1,600 ft. (480 m) RVR unless specifically approved by the FAA in an airline operator's specification for that runway.

3.2.2 See guidance in FAA Order 8900.1, *Flight Standards Information Management Systems (FSIMS)*, Volume 4, Chapter 2, Section 9, "Lower than Standard Takeoff Minima".

3.2.3 Although not operationally required, runway centerline lights are recommended for CAT I runways greater than 170 ft. (50 m) in width or when used by aircraft with approach speeds over 140 knots.

3.3. Configuration.

3.3.1 Runway Centerline Lighting.

3.3.1.1 Location.

The runway centerline lights are located along the runway centerline at 50 ft. (15 m) equally spaced longitudinal intervals.

3.3.1.1.1 The longitudinal tolerance for runway centerline lights is ± 2 ft. (0.6 meter).

3.3.1.1.2 See Figure A-34 for a graphic of the runway centerline lighting layout. The line of runway centerline lights may be uniformly offset laterally to the same side of the physical runway centerline **by** a maximum of 2.5 ft. (0.8 m) (tolerance ± 1 inch (25.4 mm)), **as** measured from the physical runway centerline to the fixture centerline.

3.3.1.1.3 For any new runway, the light base installation must be no closer than 2 ft. (0.6 m) (measured to the edge of the fixture base) to any pavement joints. Runway extensions of existing runways must use the convention already established for that runway.

3.3.1.1.4 See paragraph 4.3 and Figure A-46 for additional information about the taxiway centerline lighting location requirements related to runway

centerline lights for major taxiway turnoffs. See AC 150/5340-1 for additional information about runway centerline marking widths and locations.

3.3.1.2 **Color Coding.**

The last 3,000 ft. (900 m) portion of the runway centerline lighting system is color coded to warn pilots of the impending runway end. Alternating red and white lights are installed, starting with red, as seen from 3,000 ft. (900 m) to 1,000 ft. (300 m) from the runway end, and red lights are installed in the last 1,000 ft. (300 m) portion.

3.3.1.3 **Displaced Threshold.**

On runways with centerline lights, the centerline lights are extended into the displaced threshold area.

3.3.1.3.1 If the displaced area is equal to or less than 700 feet (110 m) in length, the centerline lights are blanked out in the approach direction.

3.3.1.3.2 For displaced threshold areas over 700 ft. (110 m) in length, the centerline lights in the displaced area are circuited separately from the centerline lights in the non-displaced runway area to permit turning “off” the centerline lights in the displaced area during landing operations.

3.3.1.3.3 If the displaced threshold area also contains a medium intensity approach light system, the control of the approach lights and displaced threshold area centerline lights is interlocked to ensure that when the approach lights are “on”, the displaced area centerline lights are “off”, and vice versa.

3.3.1.3.4 If the displaced threshold area contains a high intensity approach lighting system, separate circuited of the centerline lights in the displaced area is not required since the high intensity approach lights will “wash out” the centerline lights.

3.3.2 Touchdown Zone Lighting.

Touchdown zone lights consist of 2 rows of transverse light bars located symmetrically about the runway centerline per Figure A-35.

3.3.2.1 Each light bar consists of 3 unidirectional lights facing the landing threshold.

3.3.2.2 The rows of light bars extend to 3,000 ft. (900 m), or one-half the runway length for runways less than 6,000 ft. (1800 m), from the threshold with the first light bars located 100 ft. (30 m) from the threshold.

3.3.2.3 The light beam of the touchdown zone lights is toed four degrees toward the runway centerline. This is achieved by either installing light fixtures that have had their optical assembly toed four degrees, or by angling the light base four degrees and installing the light fixture.

11183.1. Design.

1119 3.3.3 Sequence of Installation.

1120 3.3.3.1 The installation of in-pavement lights should be done, if possible, while
1121 the runway is under construction or when an overlay is made. This allows
1122 for the installation of L-868 light base and transformer housings with a
1123 conduit system, which is preferred.

1124 3.3.3.2 Though lighting may not be programmed at the time of runway paving or
1125 overlay, installation of bases and a conduit system should be considered
1126 for future installation of in-pavement lighting.

1127 3.3.3.3 Installation of the lighting system after paving is completed is very costly
1128 and requires a lengthy shutdown of the runway.

1129 3.3.4 Layout.

1130 3.3.4.1 Provide a design drawing to the airport authority showing the dimensional
1131 layout of the centerline and touchdown zone lighting systems prior to
1132 construction.

1133 3.3.4.2 Correlate this design with current airport drawings to utilize available
1134 ducts and utilities and to avoid conflict with existing or planned facilities.

1135 3.3.5 Runway Centerline and Touchdown Zone.

1136 3.3.5.1 **Light Fixtures and Wires.**

1137 Design these systems for one of the following conditions:

1138 3.3.5.1.1 In new pavements, provide access to cables and transformers through the
1139 use of conduits and L-868 transformer bases. This type of installation will
1140 reduce downtime and repair costs when the underground circuits require
1141 maintenance. See Figure A-36, Figure A-37, and Figure A-38.

1142 3.3.5.1.2 In pavements **that are** being overlaid, a base and conduit system per Figure
1143 A-36 and Figure A-37 may be used. This provides the advantages listed in
1144 (a) above.

1145 3.3.5.1.3 In existing pavements, provide recesses or holes for the light fixtures and
1146 shallow sawed wireways for electrical conductors. This method does not
1147 require the installation of bases and conduits. See Figure A-39, Figure
1148 A-40, Figure A-41, Figure A-42, and Figure A-43.

1149 3.3.5.1.4 In existing pavements, the directional boring of a raceway under the
1150 pavement along the lighting route is permitted. Core drill a 3 ft. (0.91 m)
1151 diameter hole at the light location. Install L-868 light bases in the cored
1152 hole and connect conduit.

3.3.5.2 **Electric Power.**

3.3.5.2.1 Design each system as a 20-ampere or 6.6-ampere series circuit using a CCR. Provide each light fixture with an isolation transformer sized by the manufacturer to match the lamp.

3.3.5.2.2 To estimate the size (kilowatt (kW) capacity) of the CCR, allow for the total load for each fixture, as calculated in paragraph 3.3.6.1, plus losses in the feed cable from the regulator around the entire loop.

3.3.5.2.3 Use a 6.6-ampere primary circuit if the total load is 30 kW or less, and a 20-ampere primary circuit if the total load is over 30 kW.

3.3.5.3 **Electrical Control.**

3.3.5.3.1 Make the centerline lighting system controls independent of the touchdown zone lighting system and the high intensity runway edge lights.

3.3.5.3.2 A normal control circuit is 120-volt AC; see special considerations in the next paragraph. We recommend including a minimum of 20% spare wires in the control cable for future use.

3.3.5.3.3 Refer to Chapter 13 for additional information on control systems.

3.3.6 Special Considerations.

3.3.6.1 **The total load of a fixture is calculated as follows:**

$$(LampWatts) + [(LampWatts) \times \left[1 - \left(\frac{TransformerEfficiency}{100} \times \frac{TransformerPowerFactor}{100} \right) \right]]$$

Transformer power factor and efficiency is given in percentage, and is specified in AC 150/5345-47, Specification for Series to Series Isolation Transformers for Airport Lighting Systems.

3.3.6.2 **Voltage drop between the ATCT and the CCR must be considered.**

3.3.6.2.1 Control voltage at the regulator must be 100 volts AC (minimum).

3.3.6.2.2 If this voltage cannot be maintained, either an auxiliary low current AC relay must be installed at each regulator or a low voltage DC remote control circuit must be used.

3.3.6.2.3 In some instances, it will be more economical, because of material costs, to install a low voltage DC control circuit though the voltage drop is within acceptable limits with the standard 120-volt AC system.

3.3.6.2.4 Refer to Chapter 13 for additional information on control systems.

- 1184 3.4. **Equipment and Material.**
- 1185 3.4.1 Specifications and Standards.
- 1186 3.4.1.1 Equipment and material covered by specifications are referred to by AC
1187 numbers.
- 1188 3.4.1.2 Distribution transformers, oil switches, cutouts, relays, terminal blocks,
1189 transfer relays, circuit breakers, and all other commercial items of
1190 electrical equipment not in FAA specifications must conform to the
1191 applicable rulings and standards of the applicable National Fire Protection
1192 Association (NFPA) 70, NEC.
- 1193 3.4.2 Light Fixtures.
- 1194 3.4.2.1 Provide runway centerline light fixtures per AC 150/5345-46, using light
1195 fixture Type L-850A (Bidirectional).
- 1196 3.4.2.2 Provide touchdown zone light fixtures per AC 150/5345-46, using light
1197 fixture Type L-850B (Unidirectional).
- 1198 3.4.3 Isolation transformers.
- 1199 3.4.3.1 Provide isolation transformers, L-830 (60 Hz) or L-831 (50 **Hertz (Hz)**),
1200 per AC 150/5345-47.
- 1201 3.4.3.2 The transformers serve as a means of isolating the light unit from the high
1202 voltage of the series circuit.
- 1203 3.4.3.3 When a lamp filament opens, the continuity of the primary series circuit is
1204 maintained by the isolation transformer.
- 1205 3.4.4 Light Base and Transformer Housings.
- 1206 3.4.4.1 Where required, provide L-868 light bases per AC 150/5345-42,
1207 *Specification for Airport Light Bases, Transformer Housings, Junction*
1208 *Boxes, and Accessories.*
- 1209 3.4.4.2 The light bases consist of a cylindrical body with top flange and cable
1210 entrance hubs; the user may specify an internal grounding lug.
- 1211 3.4.4.3 The internal grounding lug is used where bases are interconnected with the
1212 duct and the ground wire is installed through the duct system.
- 1213 3.4.4.4 Certain applications may require additional entrance hubs. Provide
1214 necessary covers per AC 150/5345-42.

- 1215 3.4.5 Constant Current Regulators (CCRs).
- 1216 3.4.5.1 Provide L-828 and L-829 CCRs per AC 150/5345-10.
- 1217 3.4.5.2 The CCR is designed for step brightness control without interrupting load
1218 current.
- 1219 3.4.5.3 The CCR assembly has lightning arresters, open circuit and over current
1220 protective devices, and a local control switch.
- 1221 3.4.5.4 All parts are suitably wired at the factory as a complete assembly. Series
1222 disconnects are required but are not furnished with the CCR; various
1223 ratings are available.
- 1224 3.4.6 Control Panel.
- 1225 3.4.6.1 System controls may be installed in the existing control panel if space is
1226 available. Otherwise, provide an L-821 remote control panel per AC
1227 150/5345-3.
- 1228 3.4.6.2 The panel consists of a top panel plate and housing, toggle switches,
1229 terminal boards, and brightness controls, as required.
- 1230 3.4.6.3 The site of the panel and the number of components to be mounted on the
1231 panel must be specified for each installation.
- 1232 3.4.6.4 In areas where lightning is prevalent, lightning arresters should be
1233 installed at the terminal points of this panel.
- 1234 3.4.7 Auxiliary Relay Cabinet.
- 1235 3.4.7.1 L-841 auxiliary relay cabinet assemblies, manufactured per AC 150/5345-
1236 13 can be obtained for use in 48-volt DC control circuits.
- 1237 3.4.7.2 The assembly consists of an enclosure containing a DC power supply,
1238 control circuit protection, and 20 pilot relays.
- 1239 3.4.7.3 In areas where lightning is prevalent, lightning arresters should be
1240 installed at the terminal points of this cabinet.
- 1241 3.4.7.4 See Chapter 12, Equipment and Material, for additional information.
- 1242 • Light Bases, Transformer Housings and Junction Boxes. See
1243 paragraph 12.2.
- 1244 • Duct and Conduit. See paragraph 12.3.
- 1245 • Cable, Cable Connectors, Plugs and Receptacles. See paragraph 12.4.
- 1246 • Counterpoise (Lightning Protection). See paragraph 12.5.

- 1247 • Light Base Ground. See paragraph 12.6.
- 1248 • Light Fixture Bonding. See paragraph 12.7.
- 1249 • Concrete. See paragraph 12.8.
- 1250 • Steel Reinforcement. See paragraph 12.9.
- 1251 • Adhesive and Sealants. See paragraph 12.10.
- 1252 • Load-bearing Lighting Fixtures. See paragraph 12.11.
- 1253 • Inspection. See paragraph 12.12.
- 1254 • Testing. See paragraph 12.12.1.
- 1255 • Auxiliary Relays. See paragraph 12.13.
- 1256 • Vault. See paragraph 12.14.
- 1257 • Maintenance. See paragraph 12.14.2.

1258

Page Intentionally Blank

CHAPTER 4 Taxiway Lighting Systems.

4.1. Introduction.

Taxiway lighting systems such as taxiway centerline lights, runway guard lights (RGLs), stop bars, and clearance bars are designed to facilitate taxiing and may be required for airport operations during low visibility conditions. Coordinate these systems with Flight Standards and Air Traffic Control (ATC) for all low visibility operations:

4.1.1 Taxiway Centerline lights.

Taxiway centerline lights provide taxi guidance between the runway and apron areas.

4.1.2 Runway Guard Lights.

RGLs provide a visual indication to anyone approaching the runway holding position that they are about to enter an active runway.

4.1.3 Stop Bars.

Stop bars provide a distinctive “stop” signal to anyone approaching a runway.

4.1.3.1 In low visibility conditions, controlled stop bars are used to permit access to the active runway.

4.1.3.1.1 Controlled stop bars are controlled individually via L-821 stop bar control panel(s) or via buttons on a touch screen display panel in the ATCT.

4.1.3.1.2 Uncontrolled stop bars are generally “on” for the duration of operations below 1,200 ft. (365 m) RVR.

4.1.3.2 Uncontrolled stop bars protect the active runway at taxiway/runway intersections that are not part of the low visibility taxi route.

4.1.3.3 Stop bars are required for operations below 600 ft. (183 m) RVR on illuminated taxiways that provide access to the active runway.

4.1.3.4 Stop bars may also be used as a means of preventing runway incursions regardless of visibility conditions. For example, stop bars could be illuminated in certain airfield configurations that would prevent aircraft access from particular taxiways to active, as well as closed runways.

4.1.4 Clearance Bars.

4.1.4.1 In low visibility, clearance bars advise pilots and vehicle drivers that they are approaching a hold point (other than a runway holding position).

4.1.4.2 Clearance bars are installed at designated hold points on the taxiway for operations below 600 ft. (183 m) RVR.

1292 4.1.4.3 At night and in inclement weather, clearance bars advise pilots and vehicle
1293 drivers that they are approaching an intersecting taxiway.

1294 4.1.4.4 They are generally installed at taxiway intersections where the taxiway
1295 centerline lights do not follow the taxiway curve, per Figure A-44, and
1296 where taxiway edge lights are not installed.

1297 4.2. **Implementation Criteria.**

1298 Airports approved for scheduled air carrier operations below 1,200 ft. (365 m) RVR are
1299 required to have some or all of the various lighting systems (taxiway centerline lights,
1300 RGLs, stop bars, and clearance bars) discussed in this chapter per the criteria in AC
1301 120-57, and the FAA-approved SMGCS plan.

1302 In addition, taxiway centerline lights, RGLs, and stop bars may be installed where a
1303 taxiing problem exists. Such problems include, but are not limited to, the following:

1304 4.2.1 Runway Incursions.

1305 4.2.1.1 RGLs provide runway incursion protection regardless of visibility
1306 conditions and are recommended at runway holding positions to enhance
1307 the conspicuity of the hold position at problem intersections or where
1308 recommended by an FAA Runway Safety Action Team (RSAT).

1309 4.2.1.2 Stop bars used for runway incursion prevention will primarily be the
1310 uncontrolled type.

1311 4.2.1.2.1 For example, an uncontrolled stop bar may be installed on a high-speed
1312 exit to a runway that is never used for entering or crossing the runway to
1313 prevent aircraft from inadvertently entering the runway from that exit.

1314 4.2.1.2.2 Controlled and uncontrolled stop bars may also be installed during certain
1315 runway use configurations or runway closures to prevent access to the
1316 runway.

1317 4.2.1.2.3 Stop bars may also be installed on runways that are used as part of a
1318 taxiing route at the intersection with another runway. In this case the stop
1319 bar should be interlocked with any taxiway lighting installed on the
1320 runway so that the stop bar and taxiway lights will not be illuminated
1321 when the runway lights are illuminated. See paragraph 2.3.1.2.3.

1322 4.2.1.3 Color coded (green/yellow) taxiway centerline lights are used to enhance
1323 pilot situational awareness of the runway area to reduce potential runway
1324 incursions

1325 4.2.2 Complex Taxiway Configurations.

1326 Taxiway centerline lights should be installed to improve guidance for complex taxiway
1327 configurations. Edge lights may be installed in addition to centerline lights if warranted
1328 by operational and weather conditions.

- 1329 4.2.3 Apron Areas.
1330 Taxiway centerline lights should be installed in apron areas where other lighting may
1331 cause confusion to taxiing or parking operations.
- 1332 4.3. **Taxiway Centerline.**
- 1333 4.3.1 General.
1334 A taxiway centerline lighting system consists of unidirectional or bidirectional in-
1335 pavement lights installed parallel to the centerline of the taxiway.
- 1336 4.3.2 Color-Coding.
1337 Taxiway centerline lights are green except as provided in the following subparagraphs:
- 1338 4.3.2.1 **Lead-off Lights.**
1339 Taxiway centerline lights which provide visual guidance to persons
1340 exiting the runway (lead-off lights) are color-coded to warn pilots and
1341 vehicle drivers that they are within the runway environment or instrument
1342 landing system/microwave landing system (ILS/MLS) critical area.
- 1343 4.3.2.1.1 Alternate green and yellow lights are installed from the runway centerline
1344 (beginning with a green light) to one centerline light position beyond the
1345 runway hold or ILS/MLS critical area hold position ending with a yellow
1346 light.
- 1347 4.3.2.1.2 The fixture used prior to the runway hold or ILS/MLS critical area
1348 position must always be bidirectional: green when approached from the
1349 taxi direction and yellow when approached from the runway direction.
- 1350 4.3.2.1.3 If the layout of the lights results in an odd number of color-coded lights,
1351 the first two taxiway centerline lights on the runway should be green. See
1352 Figure A-45, Detail A, for an example of a lead-off light configuration.
- 1353 4.3.2.2 **Lead-on Lights.**
1354 Lead-on lights provide visual guidance to pilots entering the runway.
- 1355 4.3.2.2.1 They are also color-coded with the same yellow/green color pattern as
1356 lead-off lights to warn pilots and vehicle drivers that they are within the
1357 runway environment or ILS/MLS critical area.
- 1358 4.3.2.2.2 The color-coding begins with a green light at the runway centerline and
1359 progresses to one light beyond the runway hold or ILS/MLS critical hold
1360 position.
- 1361 4.3.2.2.3 The fixture used prior to the runway hold or ILS/MLS critical area
1362 position must always be bidirectional: green when approached from the
1363 taxi direction and yellow when approached from the runway direction
1364 (bidirectional).

- 4.3.2.3 Taxiway centerline lights that cross a runway are color-coded yellow/green per Figure A-43 Detail B.
- 4.3.2.3.1 Color coded taxiway centerline lights must end with a bidirectional yellow/green light fixture one centerline light position beyond the runway holding position painted marking or ILS/MLS critical area holding position painted marking.
- 4.3.2.3.2 The bidirectional light must be green for traffic on the taxiway approaching the runway and yellow for traffic crossing the runway.
- 4.3.2.3.3 Depending on the number of lights required, it may be necessary to use the same color twice on the runway to achieve the required colors for the bidirectional light fixtures before the runway holding position.

4.3.3 Longitudinal and Lateral Spacing.

The lights are spaced longitudinally per Table 4-1 for minimum authorized operations above and below 1,200 ft. (365 m) RVR.

- 4.3.3.1 **Light** fixtures should be installed so that the nearest edge is approximately 2 ft. (0.6 m) from any rigid pavement joint. Allow a tolerance for individual fixtures of ± 10 percent of the longitudinal spacing specified to avoid undesirable spots.
- 4.3.3.2 A tolerance of ± 2 ft. (0.6 m) is allowed for fixtures spaced at 12.5 ft. (4 m).
- 4.3.3.3 Displace centerline lights laterally a maximum of 2 ft. (0.6 m) to the nearest edge of the fixture, **(2.5 ft. (0.7 m) to the centerline of the light fixture)** to avoid rigid pavement joints and to ease painting the **taxiway** centerline marking.
- 4.3.3.4 Apply this lateral tolerance consistently to avoid abrupt and noticeable changes in guidance; i.e., no “zigzagging” from one side of the centerline to the other.

Note: Taxiway fillets are designed in relation to the centerline of the curve and, therefore, the location of the centerline marking. Displacement of taxiway centerline lights 2.5 ft. (0.8 m) to the inside of a curve does not necessitate enlargement of the fillet.

1396

Table 4-1. Longitudinal Dimensions.

	Maximum Longitudinal Spacing	
	1,200 Ft. (365 m) RVR and Above	Below 1,200 Ft. (365 m) RVR
Radius of Curved Centerlines		
75 ft. (23 m) to 399 ft. (121 m)	25 ft. (7.6 m) ²	12.5 ft. (4 m) 25 ft. (7.6m) ¹
400 ft. (122 m) to 1199 ft. (364 m)	50 ft. (15 m)	25 ft. (7.6 m)
≥1200 ft. (365 m)	100 ft. (30 m)	50 ft. (15 m)
Acute-Angled Exits (See Figure A-46 and AC 150/5300-13)	50 ft. (15 m)	50 ft. (15 m)
Straight Segments	100 ft. (30 m) ³	50 ft. (15 m) ³

1397

1. A L-852K fixture must be used versus an L-852D.

1398

2. A L-852J fixture must be used versus an L-852B.

1399

3. Short straight taxiway segments may require shorter spacing per paragraphs [4.3.8](#).

1400

4.3.4 Acute-Angled Exits.

1401

For acute-angled exits, taxiway centerline lead-off lights begin 200 ft. (61 m) prior to the point of curvature of the designated taxiway path, per [Figure A-46](#).

1402

1403

4.3.4.1 See [Figure A-46](#) for additional details about requirements for light spacing and offsets.

1404

1405

4.3.4.2 If the acute-angled exit is used only as an exit, then install unidirectional centerline light fixtures so that the pilots of an exiting aircraft can only see the lights.

1406

1407

1408

4.3.4.3 On existing systems: if a bidirectional fixture is used, we recommend **that** blanks be installed in the opposite side of the lead-off fixture so that neither lead-on lights nor lights leading from the parallel taxiway to the holding position would be visible.

1409

1410

1411

1412

4.3.5 Taxiway/Runway Intersections Other Than Acute-Angled Exits.

1413

For these exits that lie on low visibility taxi routes, taxiway centerline lead-off lights begin at the point of curvature on the runway if the runway has approach or departure minimums below 600 ft. (183 m) RVR.

1414

1415

1416

4.3.5.1 Lead-off/lead-on lights are recommended below 1,200 ft. (365 m) RVR. (Extra lead-off/lead-on lights should not be installed before the point of curvature on the runway because they would erode the visual distinction between acute-angled exits and other exits.)

1417

1418

1419

1420

4.3.5.2 Taxiway centerline lead-on lights should extend to the PT on the runway, per [Figure A-46](#), if the runway has departure minimums below 600 ft. (183 m) RVR.

1421

1422

- 1423 4.3.5.3 Where operations are not conducted below 1,200 ft. (365 m) RVR, neither
1424 taxiway centerline lead-on nor lead-off lights may be installed within the
1425 confines of the runway.
- 1426 4.3.5.4 If the taxiway is perpendicular to and dead-ends into the runway, the
1427 taxiway centerline light nearest the runway must be installed 150 ft. (46
1428 m) from the centerline of the runway. Otherwise, taxiway centerline lights
1429 must not extend into the confines of the runway per Figure A-44.
- 1430 4.3.6 Taxiways Crossing a Runway.
- 1431 4.3.6.1 At airports where operations less than 600 ft. (183 m) RVR are conducted,
1432 color coded (alternating green/yellow per paragraph 4.3.2.3) taxiway
1433 centerline lights should continue across a runway if they are installed on a
1434 designated low visibility taxi route per the airport's SMGCS plan (see AC
1435 120-57 for additional information).
- 1436 4.3.6.2 **We** also recommend that color coded centerline lights continue across a
1437 runway for operations below 1,200 ft. (365 m) RVR where the taxiway is
1438 an often-used route or there is a jog in the taxiway at the intersection with
1439 the runway. Otherwise, taxiway centerline lights must not extend onto the
1440 runway.
- 1441 4.3.7 Taxiways Crossing Another Taxiway.
- 1442 4.3.7.1 Continue taxiway centerline lighting across the intersection when a
1443 taxiway intersects and crosses another taxiway. If the fillets at a given
1444 taxiway intersection meet the design criteria in AC 150/5300-13, and the
1445 taxiway centerline markings follow the taxiway curves per AC 150/5340-
1446 1, then taxiway centerline lights must be installed per Figure A-48;
1447 otherwise, install them per Figure A-44.
- 1448 4.3.7.2 See paragraph 4.7.1 and 4.7.2 for criteria on the installation of taxiway
1449 intersection centerline lights and clearance bars.
- 1450 4.3.8 Short Straight Taxiway Segments.
1451 There must be a minimum of four taxiway centerline lights installed on short straight
1452 taxiway segments. See Table 4-1.
- 1453 4.3.9 Orientation of Light Beam for Taxiway Centerline Lights.
1454 Taxiway centerline lights must be oriented as follows, with a horizontal tolerance of ± 1
1455 degree.
- 1456 4.3.9.1 **On Straight Portions.**
1457 On all straight portions of taxiway centerlines, the axis of the light beam
1458 must be parallel to the centerline of the taxiing path.

4.3.9.2 **On Curved Portions (Excluding Acute-Angled Exits) with Standard Fillets.**

Orient the axes of the two beams of bidirectional lights parallel to the tangent of the nearest point of the curve designated as the true centerline of the taxiway path. Orient the axis of a unidirectional light beam so that it is “toed-in” to intersect the centerline at a point approximately equal to four times the spacing of lights on the curved portion. Measure this chord spacing along the curve. See Figure A-49.

4.3.9.3 **On Curved Portions (Excluding Acute-Angled Exits) with Non-Standard Fillets.**

See Figure A-44 for orientation and configuration of bidirectional and unidirectional fixtures for taxiway intersections, taxiway crossing a taxiway, or runway and taxiway curves.

4.3.9.4 **Acute-Angled Exits.**

Orient the axis of a unidirectional light beam so that it is “toed-in” to intersect the centerline at a point approximately equal to four times the spacing of lights on the curved portion. Measure this chord spacing along the curve. Orient the axes of the two beams of bidirectional lights parallel to the tangent of the nearest point of the curve designated as the true centerline of the taxiing path.

4.3.10 Supplemental Taxiway Edge Lights and Elevated Edge Reflectors.

Refer to AC 120-57 for criteria about supplementing taxiway centerline lights with taxiway edge lights (L-861T), or elevated edge reflectors (L-853) for low visibility operations.

4.3.10.1 For higher visibilities (>600 RVR), where taxiway edge lights are not installed, taxiway centerline lighting should be supplemented with elevated edge reflectors installed adjacent to the taxiway edge on paved fillets and on curves of radii less than 800 ft. (244 m) (measured to the taxiway centerline).

4.3.10.2 Supplemental edge lights may be installed to aid taxi operations when centerline lights are obscured by snow.

4.3.10.3 Space edge lights and reflectors per the requirements in Chapter 2. Supplemental reflectors may also be used in ramp areas.

4.4. **Runway Guard Lights (RGLs).**

4.4.1 General.

Elevated and in-pavement RGLs serve the same purpose and are generally not both installed at the same runway holding position. However, if snow could obscure in-pavement RGLs, or there is an acute angle between the holding position and the

direction of approach to the holding position, it may be advantageous to supplement in-pavement RGLs with elevated RGLs. Each elevated RGL fixture consists of two alternately illuminated, unidirectional yellow lights. In-pavement RGLs consist of a row of alternately illuminated, unidirectional yellow lights.

4.4.2 Runway Guard Light Selection.

There are two configurations of runway guard lights. The following criteria should be used to determine which configuration should be installed at a specific runway holding position.

4.4.2.1.1 Elevated runway guard lights should be installed at the runway holding position if the taxiway does not have taxiway centerline lights installed and is 150 feet wide or less. However, if the taxiway has a stop bar installed at the runway holding position, elevated runway guard lights should be co-located with the stop bar, regardless of taxiway width or the presence of taxiway centerline lights.

4.4.2.1.2 In-pavement runway guard lights should be installed at the runway holding position if the taxiway has centerline lights installed, or the taxiway is greater than 150 feet wide, or a stop bar is installed at the ILS critical area holding position.

4.4.2.1.3 In-pavement combination stop bar/runway guard light fixtures (dual red/yellow lens) may be installed at the discretion of the airport operator. The yellow in-pavement lights may not be turned on when the stop bar is in operation. If the stop bar is located at an ILS critical area holding position, dual red/yellow fixtures should not be selected. (This would result in the installation of two sets of runway guard lights at different locations which serve the same intersection.)

4.4.3 Location of In-Pavement RGLs.

In-pavement RGLs are centered on an imaginary line that is parallel to, and 2 ft. (0.6 m) from, the holding side of the runway holding position marking, per Figure A-50.

4.4.3.1 The lights may vary from this imaginary line up to ± 2 inches (± 51 mm) in a direction perpendicular to the holding position marking. Holding position marking locations are described in AC 150/5340-1.

4.4.3.2 If a conflict with rigid pavement joints occurs, move both the runway holding position marking and the RGLs away from the runway the minimum distance required to resolve the conflict. If other markings (e.g., geographical position markings) are installed, they must be moved as well.

4.4.3.3 **Lateral Spacing - Preferred Method.**

The lights are spaced across the entire taxiway, including fillets, holding bays, etc., at intervals of 9 ft., 10 inches (3 m), ± 2 inches (± 51 mm), center-to-center, per Figure A-50.

- 1536 4.4.3.3.1 The lights are spaced in relation to a reference fixture that is installed
1537 inline (longitudinally) with existing or planned taxiway centerline lights.
1538 However, it is not intended that the reference fixture replace a taxiway
1539 centerline light.
- 1540 4.4.3.3.2 If a conflict between the reference fixture and a centerline light occurs, the
1541 reference fixture takes the place of an existing centerline light and a new
1542 centerline light is installed per the criteria in paragraph 4.3.3.
- 1543 4.4.3.3.3 If the holding position marking is intersected by multiple taxiway
1544 centerline markings, the reference **light** fixture is set at the centerline that
1545 is used most often.
- 1546 4.4.3.3.4 A **light** fixture whose outboard edge falls at a point less than 2 ft. (0.6 m)
1547 from the defined edge of the taxiway (outboard edge of the taxiway
1548 marking) may be omitted.
- 1549 4.4.3.3.5 Individual **light** fixtures may be moved laterally a maximum of ± 1 foot
1550 (305 mm) to avoid undesirable spots, i.e., conduit and rigid pavement
1551 joints, etc.
- 1552 **Note:** If undesirable spots cannot be avoided in this way, fixtures may be
1553 moved no more than 2 ft. (0.6 m) using the following alternate method.
- 1554 4.4.3.4 **Lateral Spacing - Alternate Method.**
1555 The following alternate method of spacing the lights must be followed if it
1556 is not possible to meet the preferred method specified in paragraph 4.4.3.1.
- 1557 4.4.3.4.1 The lights are spaced across the entire taxiway, including fillets, holding
1558 bays, etc. If it is possible to meet paragraph 4.4.3.1 by allowing the
1559 reference fixture to be moved any amount laterally, then that method
1560 should be used.
- 1561 4.4.3.4.2 Otherwise, the lights must be spaced as uniformly as possible with a
1562 minimum spacing of 8 ft. (2.4 m) and a maximum of 13 ft. (4 m).
- 1563 4.4.4 Light Beam Orientation for In-Pavement RGLs.
1564 The L-868 bases for in-pavement RGLs must be installed such that a line through one
1565 pair of bolt holes on opposite sides of the base is parallel to the runway holding position
1566 marking.
- 1567 4.4.4.1.1 Each **light** fixture is installed so that the light beam faces away from the
1568 runway and is perpendicular to the runway holding position marking
1569 within a tolerance of ± 1 degree.
- 1570 4.4.4.1.2 For some pavement configurations, it may be necessary to orient the lights
1571 at some angle to the marking.
- 1572 4.4.4.1.3 To accomplish **proper light fixture orientation**, install a 12-bolt light base
1573 (see AC 150/5345-42 for additional information) using the above
1574 procedure; this allows the light fixtures to be adjusted 30 degrees left or
1575 right, as required.

- 1576 4.4.4.1.4 See Figure A-52 for typical examples of various orientations.
- 1577 4.4.5 Location of Elevated RGLs.
- 1578 Elevated RGLs are collocated with the runway holding position marking and are
- 1579 normally installed on each side of the taxiway.
- 1580 4.4.5.1 The distance from the defined taxiway edge to the near side of an installed
- 1581 light fixture must be 10 to 17 ft. (3 to 5 m).
- 1582 4.4.5.2 To avoid undesirable spots, the RGL may be moved up to 10 ft. (3 m)
- 1583 farther from the runway, but may not be moved toward the runway (see
- 1584 Figure A-51).
- 1585 4.4.5.3 If a stop bar is installed at the runway holding position, the elevated RGL
- 1586 must be located at least 3 ft., 6 inches (1 m) outboard of the elevated stop
- 1587 bar light.
- 1588 4.4.5.4 The RGL must not interfere with the readability of the runway holding
- 1589 position sign, obscure any taxiway edge lights, or interfere with other
- 1590 airport lighting.
- 1591 4.4.6 Light Beam Orientation for Elevated RGLs.
- 1592 **Orient** RGLs to maximize the visibility of the light to pilots of aircraft approaching the
- 1593 runway holding position.
- 1594 4.4.6.1 Aim the center of the light beam toward the aircraft cockpit when the
- 1595 aircraft is between 150 ft. (45 m) and 200 ft. (60 m) from the holding
- 1596 position, along the predominant taxi path to the holding position.
- 1597 4.4.6.2 **Set** the vertical aiming angle between 5 degrees and 10 degrees above the
- 1598 horizontal.
- 1599 4.4.6.3 Aim of the lights such that the steady-burning intensity at all viewing
- 1600 positions between 150 ft. (45 m) and 200 ft. (60 m) from the holding
- 1601 position is at least 300 candela (cd) for an incandescent lamp when
- 1602 operated at the highest intensity step. (Refer to AC 150/5345-46 for
- 1603 specifications and photometrics of the L-804 RGL fixture.)
- 1604 4.4.6.4 If these criteria cannot be met for all taxi paths to the holding position,
- 1605 consider using multiple fixtures aimed to adequately cover the different
- 1606 taxi paths.
- 1607 4.4.6.4.1 Use in-pavement fixtures to increase the viewing coverage, or aim the
- 1608 single fixtures on each side of the holding position to optimize the
- 1609 illumination of the predominant taxi path.

4.5. Runway Stop Bar.

4.5.1 General.

A stop bar consists of a row of unidirectional in-pavement red lights and an elevated red light on each side of the taxiway.

4.5.2 Location of In-Pavement Stop Bar Lights.

In-pavement stop bar lights are centered on an imaginary line which is parallel to, and 2 ft. (0.6 m) from, the center of the fixture and the holding side of the runway holding position marking, per Figure A-51.

4.5.2.1 The lights may vary from this imaginary line up to ± 2 inches (± 50 mm) in a direction perpendicular to the holding position marking. Holding position marking locations are described in AC 150/5340-1.

4.5.2.2 If a conflict with rigid pavement joints occurs, move both the runway holding position marking and the stop bar lights away from the runway the minimum distance required to resolve the conflict. If other markings (e.g., geographical position markings) are installed, they must be moved as well.

4.5.2.3 Lateral Spacing - Preferred Method.

4.5.2.3.1 The lights are spaced across the entire taxiway, including fillets, holding bays, etc., at intervals of 9 ft., 10 inches (3 m), ± 2 inches (± 50 mm), center-to-center, per Figure A-51.

4.5.2.3.2 The lights are spaced in relation to a reference fixture which is installed inline (longitudinally) with existing or planned taxiway centerline lights. However, it is not intended that the reference fixture replace a taxiway centerline light.

4.5.2.3.3 If a conflict between the reference fixture and a centerline light occurs, the reference fixture takes the place of an existing centerline light and a new centerline light must be installed per the criteria in paragraph 4.3.3.

4.5.2.3.4 If the holding position marking is intersected by multiple taxiway centerline markings, the reference fixture must be set at the centerline that is used most.

4.5.2.3.5 If a fixture's outboard edge falls at a point less than 2 ft. (0.6 m) from the defined edge of the taxiway marking, the outboard edge of the taxiway marking may be omitted.

4.5.2.3.6 Individual fixtures may be moved laterally a maximum of ± 1 foot (305 mm) to avoid undesirable spots, e.g., conduit, etc.

Note: If undesirable spots cannot be avoided in this way, fixtures may be moved no more than 2 ft. (0.6 m) using the following alternate method.

4.5.2.4 **Lateral Spacing - Alternate Method.**

4.5.2.4.1 The **following** alternate method of spacing the lights should be followed if it is not possible to meet the preferred method per paragraph 4.5.2.1.

1. The lights are spaced across the entire taxiway, including fillets, holding bays, etc. If it is possible to meet paragraph 4.5.2.1 by allowing the reference fixture to be moved any amount laterally, then that method should be used.
2. Otherwise, the lights should be spaced as uniformly as possible with a minimum spacing of 8 ft. (2.4 m) and a maximum spacing of 13 ft. (4 m).

4.5.3 Light Beam Orientation for In-Pavement Stop Bar Lights.

The L-868 bases for in-pavement stop bar lights must be installed such that a line through one pair of bolt holes on opposite sides of the base is parallel to the runway holding position marking.

4.5.3.1 Each **light** fixture is installed so that the axis of the light beam faces away from the runway and is perpendicular to the marking with a tolerance of ± 1 degree.

4.5.3.2 In some instances, it may be necessary to aim the lights at some angle to the marking. To accomplish this, install a 12-bolt base using the above procedure.

4.5.3.3 This allows the light fixtures to be adjusted 30 degrees left or right, as required. See Figure A-52 for typical examples.

4.5.4 Location of Elevated Stop Bar Lights.

Elevated stop bar lights are installed in line with the in-pavement stop bar lights on each side of the taxiway.

4.5.4.1 They are located not more than 10 ft. (3 m) from the defined edge of the taxiway.

4.5.4.2 For airports that perform any snow removal operations, if taxiway edge lights are present, the elevated stop bar light should not be installed closer to the taxiway edge than the line of taxiway edge lights. This is to help prevent the elevated stop bar light from being struck by snow removal equipment.

4.5.4.3 To avoid conflicts with taxiway edge lights or undesirable spots, the elevated stop bar lights may be moved up to 10 ft. (3 m) away from the runway, but may not be moved toward the runway. See Figure A-51.

4.5.5 Light Beam Orientation for Elevated Stop Bar Lights.

Elevated stop bar lights should be oriented to enhance conspicuity of the light by pilots of aircraft approaching the runway holding position.

- 1684 4.5.5.1 Aim the lights such that the axis of the light beams intersects the primary
1685 taxiway centerline between 120 ft. (37 m) and 170 ft. (52 m) from the
1686 holding position.
- 1687 4.5.5.2 **Set** the vertical aiming angle between 5 degrees and 10 degrees above the
1688 horizontal. **Specify** the aiming of the lights such that the axis of the light
1689 beams intersects the primary taxiway centerline between 120 ft. (37 m)
1690 and 170 ft. (52 m) from the holding position.
- 1691 4.6. **Combination In-Pavement Stop Bar and RGLs.**
1692 At the **airport's** option, combination in-pavement stop bar and RGL lights may be
1693 installed in lieu of standard in-pavement stop bar fixtures.
- 1694 4.6.1 This option allows for the provision of in-pavement RGLs above 1,200 ft. (365 m) RVR
1695 and a stop bar below 1,200 ft. (365 m) RVR for a given location. (A typical application
1696 includes taxiways >150 ft. (46 m) wide which lie on a designated low visibility taxi
1697 route for operations below 600 ft. (183 m) RVR.)
- 1698 4.6.2 **Design** the circuit so that the yellow and red lights cannot both be “on” at the same time
1699 (applies only to in-pavement fixture L-852G/S).
- 1700 4.6.3 **Install** combination stop bar/RGL fixtures in the same location and with the same light
1701 beam orientation as in-pavement stop bars. See Figure A-51 for additional information.
- 1702 4.6.4 Refer to AC 120-57 for further criteria on the application of combination stop bar/RGLs
1703 below 1,200 ft. (365 m) RVR.
- 1704 **Note:** Elevated RGLs may be operated continuously regardless of RVR condition or
1705 stop bar use to enhance safety and awareness of the runway environment.
- 1706 4.7. **Clearance Bar Configuration.**
- 1707 4.7.1 General.
1708 A clearance bar consists of a row of three in-pavement yellow lights that indicate a low
1709 visibility hold point.
- 1710 4.7.1.1 The light fixtures are normally unidirectional but may be bidirectional **if**
1711 the hold point is intended to be used in **either** one or two directions. Refer
1712 to AC 120-57 for criteria on the application of clearance bars.
- 1713 4.7.1.2 With the following exceptions, **install** clearance bars (without regard to
1714 visibility) at a taxiway intersection with non-standard fillets or where the
1715 taxiway centerline lights do not follow curves at intersections per Figure
1716 A-44. Clearance bars installed for this purpose consist of unidirectional
1717 fixtures.

- 1718 4.7.1.3 Clearance bars may be omitted if taxiway edge lights are installed at the
1719 intersection per paragraph 2.5.2.3.
- 1720 4.7.1.4 Clearance bars at a “T” or “+” shaped taxiway/taxiway intersection may
1721 be replaced or supplemented by an omnidirectional yellow taxiway
1722 intersection light (L-852E or F, as appropriate) installed near the
1723 intersection of the centerline markings, if the angle between the
1724 centerlines of any two adjacent segments of the pavement is 90 degrees \pm
1725 10 degrees.
- 1726 4.7.1.5 The clearance bar located on an exit taxiway may be omitted if it would be
1727 located before, or within 200 ft. (61 m) beyond, a runway holding position
1728 (as viewed while exiting the runway).
- 1729 4.7.2 Location of a Clearance Bar Installed at a Low Visibility Hold Point.
1730 A low visibility hold point consists of an intermediate holding position marking, a
1731 geographic position marking, and a clearance bar.
- 1732 4.7.2.1 Hold points are not necessarily located at taxiway/taxiway intersections.
- 1733 4.7.2.2 **Center** in-pavement clearance bar lights on an imaginary line that is
1734 parallel to, and 2 ft. (0.6 m) from, the holding side of the taxiway/taxiway
1735 holding position marking, per Figure A-53.
- 1736 4.7.2.3 The lights may vary from this imaginary line **by** up to ± 2 inches (± 50 mm)
1737 (perpendicular to the holding position marking).
- 1738 4.7.2.4 If a conflict occurs with rigid pavement joints or other undesirable areas,
1739 move the taxiway/taxiway holding position marking, geographic position
1740 marking, and the clearance bar longitudinally any amount necessary to
1741 resolve the conflict.
- 1742 4.7.2.5 If the hold point is located at a taxiway/taxiway intersection, **move all of**
1743 the aforementioned items away from the intersecting taxiway the
1744 minimum **distance** necessary to resolve the conflict. If a conflict occurs
1745 between the center fixture in the clearance bar and a **taxiway** centerline
1746 light, the center **light** fixture takes the place of an existing **taxiway**
1747 centerline light, and a new centerline light must be installed per the criteria
1748 in paragraph 4.3.3.
- 1749 4.7.3 Location of a Clearance Bar Installed at a Taxiway Intersection.
1750 A clearance bar installed at a taxiway intersection is located per the criteria in paragraph
1751 4.7.2 if that location is established as a hold point and taxiway/taxiway holding position
1752 markings are present. Otherwise, **locate** the clearance bar in the same manner as if the
1753 holding position marking were present. This allows room for the possible future
1754 installation of the marking.

Note: Taxiway/taxiway holding position marking locations are described in AC 150/5340-1.

4.7.3.1 **Lateral Spacing.**

Install the center light of the clearance bar in line with existing or planned taxiway centerline lights. **Install** the two remaining lights outboard of the center fixture on 5 foot (1.5 m) intervals, center-to-center, per Figure A-44, Clearance Bar Detail A. The outboard fixtures may be moved laterally a maximum of ± 1 foot (305 mm) to avoid undesirable spots, e.g., conduit, etc.

4.7.4 Light Beam Orientation for Clearance Bars.

The axis of the light beam for each fixture must be parallel to the centerline of the designated taxiway path with a tolerance of ± 1 degree.

4.8. **Design.**

4.8.1 General.

The installation of in-pavement L-868 light bases and conduit should be done, if possible, while the pavement is under construction or when an overlay is made. Installation of light bases after paving is very costly and requires a lengthy shutdown of the taxiway or runway.

4.8.2 Layout.

Develop a design drawing prior to construction that shows the dimensional layout of each lighting system to be installed. Correlate this design with current airport drawings to utilize available ducts and utilities and to avoid conflict with existing or planned facilities. Do not exceed 40% conduit fill, per the conduit fill tables in NFPA 70, NEC. Also, correlate this design with the type of existing equipment fed by the existing cable system to minimize the effects of EMI.

4.8.3 In-Pavement Light Fixtures and Electrical Cables.

Design each in-pavement lighting system for one of the conditions listed in Chapter 10 and Chapter 11.

4.8.4 General Circuit Design and Control Concept

4.8.4.1 **For Airports That Use RGLs and/or Stop bars to Prevent Runway Incursions in Visibility at or Above 1200 (365 m.) RVR.**

Each of these systems should be on dedicated circuits (see paragraphs 4.8.6.1.1 and 4.8.7.3.1).

4.8.4.2 **For Airports with Operations Below 1,200 ft. (365 m) RVR.**

As the weather deteriorates below 1,200 ft. (365 m) RVR, SMGCS procedures to be in effect will activate the “below 1,200 ft. RVR” system on the airport lighting control panel.

- 1792 4.8.4.2.1 All low visibility lighting systems necessary for below 1,200 ft. (365 m)
1793 RVR operations will be turned on, per AC 120-57.
- 1794 4.8.4.2.2 **Turn** off taxiway centerline lights and edge lights on taxiways that are not
1795 designated as low visibility taxi routes.
- 1796 4.8.4.2.3 For airports with operations below 600 ft. (183 m) RVR, see AC 120-57
1797 paragraph 8b(2)(a), for operations below 600 ft. (183 m) RVR.
- 1798 4.8.5 Taxiway Centerline Lighting and Clearance Bar Systems.
- 1799 4.8.5.1 **Fixture Selection.**
1800 **Install** L-852C (narrow beam), L-852D (wide beam), and L-852F
1801 (omnidirectional) fixtures on taxiways that are designated as low visibility
1802 taxi routes below 1,200 ft. (365 m) RVR per AC 120-57.
- 1803 4.8.5.1.1 Where the RVR \geq 1200 ft., **install** L-852A (narrow beam), L-852B (wide
1804 beam), and L-852E (omnidirectional) taxiway centerline fixtures.
- 1805 4.8.5.1.2 **Install** the appropriate L-852B (RVR \geq 1200 ft.) or L-852D (RVR < 1200
1806 ft.) bidirectional fixture at the intersections of taxiways with taxiways,
1807 taxiways with runways, and/or runways at single taxiway curves, and on
1808 all straight sections of taxiways off runways up to a distance of at least
1809 400 ft. (122 m).
- 1810 4.8.5.1.3 **Install the appropriate L-852B or L-852D unidirectional fixture on**
1811 **curved sections of taxiways.**
1812 Alternatively, an L-852J (RVR \geq 1200 ft.) or L-852K (RVR < 1200 ft.)
1813 fixture may be used for curved sections of taxiways positioned per Table
1814 4-1.
- 1815 4.8.5.1.4 **Install** the appropriate L-852A or L-852C fixture on straight sections of
1816 taxiways (excluding straight sections of taxiways off runways to an
1817 intersection). See Figure A-44, Figure A-46, and Figure A-48 for typical
1818 lighting configurations.
- 1819 4.8.5.1.5 Unidirectional L-852A or L-852C fixtures are normally installed on acute-
1820 angled exits. However, bidirectional fixtures may be installed to provide
1821 guidance for emergency vehicles approaching the runway.
- 1822 4.8.5.2 **Power Supply.**
1823 Series circuits for clearance bars and taxiway centerline lighting systems
1824 should be powered from an appropriately-sized L-828 or L-829, Class 1,
1825 Style 2 (5-step) CCR. Brightness control is achieved by varying the
1826 output current. Determine the appropriate size and number of **CCRs** for a
1827 specific 6.6-ampere series lighting circuit by using the curves per Figure
1828 A-54.
- 1829 **Note:** A 5-step CCR is necessary to control LED high intensity lighting
1830 systems. This is because a 3-step CCR may not adequately reduce LED

intensity at the lowest brightness step. See [EB #67](#) for additional information about LED lighting systems.

4.8.5.3 Secondary Circuit Design for Taxiway Centerline Lights.

Example design calculations for the secondary circuit for taxiway centerline lights are per [Figure A-54](#).

4.8.5.3.1 The example calculations assume four fixtures are installed on the secondary side of each isolation transformer.

4.8.5.3.2 Other designs/configurations require individual analysis. Seek manufacturers' recommendations when sizing components.

4.8.5.4 Circuit Design for Clearance Bars and Low Visibility Taxi Routes.

4.8.5.4.1 Clearance bars.

We recommend that clearance bars installed at low visibility hold points can be switched "off" in visibilities above 1,200 ft. (365 m) RVR. This can be accomplished through the use of local control devices or circuit selector switches. Other clearance bars must be "on" whenever the taxiway centerline lights are "on."

Note: If a clearance bar is installed for both purposes described in paragraph [4.7.1](#), then it must be "on" whenever the taxiway centerline lights are "on."

4.8.5.4.2 Taxiways Designated as Low Visibility Taxi Routes Below 1,200 ft. (365 m) RVR.

We strongly recommend that new taxiway centerline lighting circuits be designed with consideration of the low visibility taxi routes designated in the airport's SMGCS plan for operations below at or 1,200 ft. (365 m) RVR and below 600 ft. (183 m) RVR.

4.8.5.4.3 It is advantageous for lights on a low visibility taxi route to be installed on a separate circuit from those that are not. Further, account for the possibility of different low visibility routes above and below 600 ft. (183 m) RVR.

4.8.5.4.4 For example, an uncontrolled stop bar installed for operations below 600 ft. (183 m) RVR will be turned on below 1,200 ft. (365 m) RVR. This, in effect, eliminates the possibility of that taxiway being considered as part of a low visibility taxi route below 1,200 ft. (365 m) RVR. The alternative is to design the taxiway centerline and edge light circuits so that they may be turned off below 600 ft. (183 m) RVR, thus eliminating the requirement for an uncontrolled stop bar.

4.8.5.5 Taxiway Centerline Lighting and Clearance Bar Control Methods.

Refer to [Chapter 13](#) for control methods.

4.8.5.5.1 **General.**

Where possible, use simple switching to energize and de-energize the circuits or to control lamp brightness.

4.8.5.5.2 **Remote Control.**

Remote control systems are controlled from a panel located in the cab of the ATCT or at some other location **that is accessible by controllers**. Use the control panel recommended in AC 150/5345-3. This panel controls operating relays located in the vault, from which power is supplied to the taxiway centerline lighting CCRs.

There are many methods of providing for the remote control of L-828/L-829 CCRs, L-847 circuit selector switches, etc. **Examples of** such methods include ground-to-ground radio control (see AC 150/5345-49), twisted shielded pair copper, and fiber optic control lines. Control signals may be digital or analog. **Ensure** that the control system is suitable and that EMI does not cause adverse effects in the lighting systems or subsystems.

Two common methods used to control CCRs and other equipment is described below. They may be used as a basis for the design of more complex control systems.

1. 120-Volt AC.

- a. Where the distance between the remote-control panel and the vault is not great enough to cause excessive voltage drop (greater than 5%) in the control leads, use the standard control panel switches to operate the control relays directly.
- b. Operating relays supplying power to the taxiway centerline regulators must have coils rated for 120-volt AC.
- c. **Use** a No. 12 AWG control cable to connect the control panel to the power supply equipment in the vault.
- d. Special pilot low burden auxiliary relays, having proper coil resistance to reduce control current, may be used to obtain additional separation distance with 120-volt AC control circuits.
- e. It may be advantageous to use these relays for expanding existing 120-volt AC control circuits. Figure A-28 and Figure A-29 illustrate typical applications of 120-volt AC control circuits.

2. 48 Volt DC.

- a. Where the distance between the control panel and the vault would cause an excessive control voltage drop, a low voltage (48-volt DC) control system must be used.
- b. In such a system, remote control panel switches activate sensitive pilot relays, such as those specified in AC 150/5345-13 which, in turn, control the CCR relays.

- c. Use an appropriately sized cable, of a type that is listed for direct earth burial, to connect the control panel to the pilot relays.
- d. The DC control system is adequate for up to 7,900 ft. (2408 m) separation between control point and vault.
- e. For typical application details, see Figure A-30, Figure A-31 and AC 150/5345-3.

4.8.5.6 **Partitioning of Circuits for Traffic Control.**

4.8.5.6.1 **General.**

1. The taxiway centerline lighting system may be sectionalized to delineate specific routes for ground movements, and to control traffic where such control is deemed necessary by consultation with the air traffic facility manager and airport sponsor.
2. To control taxiway centerline lighting segments, taxiway centerline lighting systems may either be designed with many small circuits or with fewer circuits covering multiple taxiway segments.
3. If portions of larger circuits need to be switched on and off separately from the remainder of the circuit, local control devices or L-847 circuit selector switches may be used.

Note: Consult CCR manufacturers for information on the recommended minimum load for their regulators.

4.8.5.6.2 **Local Control Devices.**

Segments of the taxiway centerline lighting system may be turned on and off by the transmission of control commands to local control devices via some means, e.g., power line carrier or separate control cable. Individual lights or groups of lights may be installed on each local control device, per the manufacturer's recommendations.

4.8.5.6.3 **Selector Switch.**

1. A circuit selector switch may be used to select short segments of separate taxiway centerline lighting circuits supplied from the same CCR.
2. The selector switch may be remotely controlled from separately installed circuit breakers or an L-821 control panel conforming to AC 150/5345-3.
3. Use the appropriate selector switch per AC 150/5345-5, *Circuit Selector Switch*, for the number of individual loops to be controlled.
4. Combinations of selector switches may be used to control remotely more than four series loops.
5. The **maximum power of the** selector switch described in AC 150/5345-5, is 5000 volts, limiting the maximum connected load on 6.6-ampere

1949 series circuits to approximately 30 kW. For application of the selector
1950 switch, see Figure A-29.

1951 4.8.6 Runway Guard Light (RGL) System.

1952 4.8.6.1 **Power Supply.**

1953 4.8.6.1.1 **General.**

1954 Elevated RGLs are available as constant current fixtures (Mode 1) or
1955 constant voltage fixtures (Mode 2). See AC 150/5345-46 for further
1956 information on the modes.

- 1957 1. If Mode 1 elevated RGLs are selected, install them using separate
1958 **CCRs**. This will allow independent control of the elevated runway
1959 guard lights and in-pavement guard lights. Confirm with the
1960 manufacturer that the CCR is compatible with the loads characteristic
1961 to flashing lights (typically a ferroresonant type of CCR).
- 1962 2. If Mode 2 elevated RGLs are selected, install them on a dedicated 120-
1963 volt AC or 240-volt AC circuit, and install any in-pavement RGLs on
1964 their own series circuit. This provides independent on/off control for
1965 operation during daytime visual meteorological conditions (VMC), if
1966 desired, and allows the RGLs to be turned off when the runway is
1967 closed.
- 1968 3. RGLs often need to be operated at a different intensity setting than that
1969 of runway or taxiway edge lights. Power **the** dedicated series RGL
1970 circuits from an appropriately sized L-828 or L-829, Class 1, Style 1
1971 (3-step) CCR.
- 1972 4. Brightness control for series circuits is achieved by varying the output
1973 current of the CCR.
- 1974 5. Brightness control for Mode 2 elevated RGLs is achieved by an
1975 integrated or remote sensing device (e.g. photocell) for each fixture.

1976 **Note:** Consult with CCR manufacturers to determine the suitability of
1977 specific **CCRs** to power flashing lights.

1978 4.8.6.1.2 **Elevated RGLs.**

- 1979 1. When installing **a** small number of elevated RGLs on an airport, it may
1980 be more economical to tap into a nearby circuit than to install a
1981 dedicated circuit.
- 1982 2. If you intend to operate the RGLs during the day for runway incursion
1983 prevention purposes, we do not recommend tapping into a nearby
1984 circuit because of the increased costs of operating the circuit 24-hours
1985 a day.
- 1986 3. A partial circuit load consisting of either elevated or in-pavement
1987 RGLs may cause unwanted pulsing of the steady-burning lights on the

circuit. This effect, if present, will vary with the actual load and type of CCR.

- 4.8.6.1.3 **Do not install** Mode 1 RGLs on a circuit powered from a 5-step CCR where all 5 steps are available **because** elevated RGLs may appear dim when operated on step 1 or 2. See Figure A-55 for a typical elevated RGL.

4.8.6.2 **Circuit Design.**

4.8.6.2.1 **Constant Voltage Circuits for Elevated RGLs.**

It is important that the voltage provided to elevated RGLs be within the tolerances specified by the light manufacturer. **Therefore**, verify the voltage drop of the circuit and make any special provisions necessary to obtain adequate operating voltage at the RGL.

4.8.6.2.2 **Elevated RGL Electrical Interface.**

If elevated RGLs will be monitored, order them with a two-conductor lead or a five-conductor lead, as required by the L-804 manufacturer.

1. Monitoring with a two conductor lead normally involves the use of power line carrier signals.
2. The five-conductor lead (2 power, 2 monitoring, 1 case ground) terminates with a 5-pin plug.
 - a. The mating 5-socket receptacle is either: 1) purchased separately, or 2) provided with a separately purchased control and monitoring device, i.e., as would be provided in a power line carrier system.
 - b. **Use** a 5-socket receptacle and lead must be used to interface with the 5-pin plug. The method of connecting the two leads is at the discretion of the elevated RGL manufacturer.

4.8.6.2.3 **In-Pavement RGL Control Methods.**

Refer to Chapter 13 for Control Methods. There are two typical methods used to control in-pavement RGL systems:

1. Method 1. In the first method, a power line carrier system is used.
 - a. Two common methods for connecting a power line carrier system are per Figure A-56 and Figure A-57. In Figure A-56, a remote-control device is connected to each in-pavement RGL.
 - b. Communication occurs on the series circuit between each remote-control device and a master control device located in the airfield lighting vault.
 - c. In Figure A-57, a remote-control device is connected to every fourth light fixture to prevent adjacent light fixtures from becoming inoperative in the event of the failure of a single control device.

Note: Consult the manufacturer of the power line carrier system for any equipment or environment limitations, e.g., the condition of the lighting cables, presence of moisture, etc. See [Appendix F](#) for additional information about power line carrier systems.

2. Method 2. In the second method, a separate communication connection (copper wire, fiber-optic cable, etc.) is made to a remote input/output (I/O) control device located adjacent to the in-pavement RGL system per [Figure A-58](#).
 - a. This is typically a programmable logic controller (PLC). The communication link is typically connected to a separate vault computer. Provide control and monitoring terminals in the vault computer.
 - b. The vault computer must have a monitoring link to the CCR to verify that current is present on the output of the CCR.
 - c. As an option, you may locate the control and monitoring terminal blocks (or other interface device, as required) in the remote I/O control device.
 - d. See [Appendix F](#) for additional information about Airfield Lighting Control and Monitoring Systems (ALCMS).
 - e. Provide a terminal block (see [Figure A-59](#)) or other interface device in the master control device or vault computer at which a closed contact is made to activate all in-pavement RGL systems connected to the CCR.
 - f. When the “on” signal is activated, all RGL systems must turn on and automatically begin pulsing.
 - g. If **using** electronic monitoring, **install** a separate “caution” and “fault” terminal block to activate the “caution” and “fault” signals. The “caution” signal will be activated with the failure of at least one in-pavement RGL, a single local control device, or an I/O control module. The “fault” signal will be activated if two adjacent in-pavement RGLs, or a total of three, fail in any RGL row.

4.8.6.2.4 When a “caution” signal occurs, maintenance personnel manually reset the alarm using a dedicated contact closure per [Figure A-59](#).

1. Resetting allows the “caution” signal to be generated again if another non-critical failure occurs.
2. A “fault” signal can only be cleared after the problem is corrected.
3. A “caution” signal is always active when a “fault” signal is active.

4.8.6.2.5 **Mode of Operation for In-Pavement RGLs.**

1. An entire row of in-pavement RGLs must pulse in such a manner that the even-numbered lights in the row pulse simultaneously and, as they extinguish, the odd-numbered lights pulse simultaneously.
2. Power must be applied alternately to each set of fixtures for 50 percent ± 0.5 percent, of the total cycle. Each fixture must produce a pulse at a rate of 30-32 flashes per minute overall brightness settings.

4.8.6.2.6 **Failure Modes of In-Pavement RGLs.**

In the event of a lamp failure, the remaining lights in the RGL row must continue to pulse normally.

1. In the event of a control system communications failure, the lights must continue to pulse in the normal sequence for eight hours, and the lights within each of the even and odd sets must pulse simultaneously, within a tolerance of 0.05 second.
2. The even set of RGLs must pulse exactly opposite to the odd set, within a tolerance of 0.13 second.
3. A failure of a local control device (component failure) must cause the associated lamp(s) to fail to an “off” state.
4. A component failure is considered to be a failure of a lamp, local control device, isolating transformer, or “smart” isolation transformer.
5. A communication failure is considered a loss of communication to the local control device.

4.8.7 Stop Bar System.

4.8.7.1 **General.**

There are two types of stop bars: controlled and uncontrolled.

1. Controlled stop bars are controlled individually via L-821 stop bar control panel(s) or via buttons on a touch screen display panel in the ATCT.
2. Uncontrolled stop bars are generally “on” for the duration of operations below 1,200 ft. (365 m) RVR.
3. If the need arises for an uncontrolled stop bar to be turned off, all stop bars for a given low visibility runway may be temporarily turned off via a master stop bar button for each low visibility runway.
4. See AC 120-57 for additional information about the use and operation of stop bars.

4.8.7.2 **Power Supply.**

1. Power elevated and in-pavement stop bar light circuits from an appropriately sized L-828, Class 1, Style 1 (3-step) CCR.

2. Brightness control is achieved by varying the output current of the CCR **via the current step selected.**
3. Install elevated stop bar fixtures on the same circuit as the associated in-pavement stop bar fixtures.

4.8.7.3 **Circuit Design.**

4.8.7.3.1 **General.**

1. When the stop bar system is activated, all controlled and uncontrolled stop bars must be turned on at the same time and at the same intensity.
2. Subsequent intensity changes must also occur in unison.
3. It is **not** required to install all stop bars for a given runway on a dedicated circuit, although that is the simplest method of meeting the foregoing requirement.

4.8.7.3.2 **Controlled Stop Bars.**

Controlled stop bars operate in conjunction with taxiway centerline lead-on lights (this also applies to taxiway lights crossing a runway), which are grouped into two segments per Figure A-47, Figure A-60, Figure A-61, and Figure A-62.

1. Segment #1 begins at the stop bar and is 155 to 165 ft. (47 to 50 m) long.
2. Segment #2 consists of the remainder of the lead-on lights to the PT at the runway centerline if the total distance from the stop bar to the PT (measured along the curve) is less than 300 ft. (90 m).
3. If the total length exceeds 300 ft. (90 m), segment #2 may consist of all lead-on lights between the end of segment #1 and the PT at the runway centerline, or segment #2 may be such that the total length of segment #1 and segment #2 is at least 300 ft. (90 m) long.
4. Two stop bar sensors are used to re-illuminate the stop bar and to extinguish the lead-on lights.
 - a. Sensor #1 is located approximately at the end of lead-on segment #1.
 - b. Sensor #2 is located approximately at the end of lead-on segment #2.
5. There are many different types of sensors that can be used to control stop bars, and their exact location depends on the type of sensor used. Sensors for stop bar control must be per **RTCA DO-221, *Guidance and Recommended Requirements for Airport Movement Sensors.***

4.8.7.3.3 Normal Operation of Controlled Stop Bars.

1. Depressing the stop bar button on the L-821 stop bar control panel or touch screen display causes two backup timers to start, the red stop bar to be extinguished, and both segments of lead-on lights to illuminate.
 - a. The first timer (approximately 45 seconds) provides a backup to the first sensor. The second timer (approximately 2 minutes) provides a backup to the second sensor.
 - b. In the event of a failure of either sensor, the backup timers will perform the same function as the respective sensor.
2. When the aircraft or vehicle activates sensor #1, the stop bar is re-illuminated and the lead-on segment #1 is extinguished. This protects the runway against inadvertent entry by a trailing aircraft or vehicle.
3. When the aircraft or vehicle activates sensor #2, the lead-on segment #2 is extinguished.
 - a. If a detection on sensor #2 occurs before sensor #1 times out, then the backup timers per paragraph 4.8.7.3.3 item 1 above must automatically reset the stop bar.
 - b. Alternatively, if sensor #1 has failed, and the backup timer for sensor #1 has not ended by the time sensor #2 is activated, then both segments of lead-on lights must be extinguished and the stop bar must be re-illuminated.

4.8.7.3.4 Special Operation of Controlled Stop Bars.

1. From time to time, there is a need for multiple vehicles (i.e., airport rescue and firefighting equipment and snow removal equipment) to be cleared simultaneously onto or across a runway at a location where a controlled stop bar is installed.
2. The stop bar button is depressed while depressing the “Sensor Override” button on the control panel. (See AC 150/5345-3 for information on the control panel.)
3. The control system must be designed so that the foregoing sequence of events will cause inputs from both sensors to be ignored.
4. The stop bar and lead-on lights must be reset to their original state when the backup timer for sensor #2 runs out.

4.8.7.3.5 Failure Modes of Stop Bar Lights.

1. In the event of a lamp failure, the remaining lights in the stop bar must continue to operate normally.
2. The failure of a local control device (component failure) must cause any connected lamps to fail “off.” In the event of a control system failure (inclusive of a communication failure), the failure mode of the local control devices must be selectable depending upon visibility.

3. An entire stop bar must fail “on” (individual lights fail “off”) for visibilities at or below 1,200 ft. (365 m) RVR.
4. The entire stop bar and individual lights must fail “off” for visibilities above 1,200 ft. (365 m) RVR.
5. Selection of the failure mode must be achieved remotely.
6. Following the occurrence of a communications failure, a method must be provided to allow a failed stop bar to be turned off. This may be accomplished through various means:
 - a. Turning off the power to an individual stop bar through an L-847 circuit selector switch,
 - b. Manually changing the failure mode of the local control devices,
 - c. Or having an integral timer within each local control device which automatically shuts off the lights 10 minutes, ± 5 seconds, after the failure.

Note: The indication, on the stop bar control panel, of a failed controlled stop bar must continue to be displayed until the stop bar is returned to service.

4.8.7.4 **Stop Bar Control Methods.**

Refer to Chapter 13 for additional information.

4.8.7.4.1 **General.**

The two control methods described in paragraph 4.8.6.2.3 for the control of in-pavement RGLs may also be used for the control of controlled stop bars and lead-on lights. However, when multiple lights are installed on each local control device, every second, third, or fourth light may be installed on the same local control device.

4.8.7.4.2 **Control and Monitoring System Response Time.**

Within 2 seconds from the time the stop bar button in the ATCT is activated, the stop bar lights switch off and the lead-on lights switch on.

4.8.7.5 **Monitoring Requirements for Controlled Stop Bars.**

1. Controlled stop bars and associated lead-on lights must be electronically monitored.
2. Within 5 seconds of pressing the stop bar button, the actual status of the lights must be displayed on the stop bar control panel in the ATCT.
3. This response time reflects the state-of-the-art for local control devices. Ideally, the lights would be switched and their status returned to the ATCT within 2 seconds of pressing the stop bar button.
4. The monitoring system should have the capability of determining the number of lights that are not functional and whether or not the failed lights are adjacent.

5. A standard L-827 monitor or L-829 CCR with integral monitor may be used if it is accurately calibrated to indicate a fault indication with approximately 2 stop bar or lead-on lights not functioning.

6. Because this monitoring system **cannot** determine adjacency, a visual inspection would have to be made to determine whether or not the failed lights are adjacent.

7. There is individual lamp monitoring technology currently available; **consult** the system manufacturer for the application of this technology – see Appendix F for additional information.

Note: In locations where the circuit resistance to ground varies widely from day to day, it may not be possible to use the L-827 monitor for this level of precision.

4.8.8 Combination In-Pavement Stop Bar and RGLs.

4.8.8.1 **Power Supply.**

Combination in-pavement stop bar/**RGL** fixtures have two lights, one red and one yellow, which are independently controlled. The power supply for the yellow light is as described in paragraph 4.8.6.1. The power supply for the red light is as described in paragraph 4.8.7.2.

4.8.8.2 **Circuit Design.**

4.8.8.2.1 **Mode of Operation.**

Operate the yellow lights down to, but not below, 1,200 ft. (365 m) RVR. **Operate** the red lights at or below 1,200 ft. RVR, and not above.

Note: The yellow lights must not be temporarily turned on during the “GO” Configuration per Figure A-47.

4.8.8.2.2 **Failure Modes of Combination Stop Bars/RGLs.**

1. In the event of a lamp failure, the remaining lights in the stop bar or RGL row must continue to operate normally.

2. In the event of a control system communications failure, the failure mode of the local control device must be selectable depending upon visibility.

a. For visibilities below 1,200 ft. (365 m) RVR, the yellow lights must fail “off” and the red lights must fail “on.”

b. For visibilities at or above 1,200 ft. (365 m) RVR, the yellow lights must pulse normally and the red lights must fail “off.”

c. Selection of the failure mode must be achieved remotely. Following the occurrence of a communications failure, the failure mode must be selectable locally.

d. The failure of a local control device (component failure) must cause both lights to fail “off.”

2257 4.8.8.3 **Control Methods.**
 2258 Control methods for the yellow lights are as described in paragraph
 2259 4.8.6.2.3. Control methods for the red lights are as described in paragraph
 2260 4.8.7.

2261 4.8.8.4 Monitoring requirements for the red lights are as described in paragraph
 2262 4.8.7.5.

2263 4.9. **Equipment and Material.**

2264 General. Equipment and material used in a taxiway centerline lighting system listed
 2265 below conform to the AC and specification specified. All pertinent ACs and
 2266 specifications are referenced by number and title in Appendix D. See Chapter 12 for
 2267 additional information.

- 2268 • Light Bases, Transformer Housings and Junction Boxes. See paragraph 12.2.
- 2269 • Duct and Conduit. See paragraph 12.3.
- 2270 • Cable, Cable Connectors, Plugs and Receptacles. See paragraph 12.4.
- 2271 • Counterpoise (Lightning Protection). See paragraph 12.5.
- 2272 • Light Base Ground. See paragraph 12.6.
- 2273 • Light Fixture Bonding. See paragraph 12.7.
- 2274 • Concrete. See paragraph 12.8.
- 2275 • Steel Reinforcement. See paragraph 12.9.
- 2276 • Adhesive and Sealants. See paragraph 12.10.
- 2277 • Load-bearing Lighting Fixtures. See paragraph 12.11.
- 2278 • Inspection. See paragraph 12.12.
- 2279 • Testing. See paragraph 12.12.1.
- 2280 • Auxiliary Relays. See paragraph 12.13.
- 2281 • Vault. See paragraph 12.14.
- 2282 • Maintenance. See paragraph 12.14.2.

2283 **Table 4-2. Equipment and Material Used for Low Visibility Lighting Systems.**

Equipment and Material	ACs or Items
L-821 Remote Control Panel	<u>AC 150/5345-3</u>
L-847 Circuit Selector Switch	<u>AC 150/5345-5</u>
L-824 No. 8 AWG Cable	<u>AC 150/5345-7</u>

Equipment and Material**ACs or Items**

L-824 No. 10 AWG THWN Cable	<u>AC 150/5345-7</u>
L-824 No. 12 AWG Cable	<u>AC 150/5345-7</u>
L-828 CCR	<u>AC 150/5345-10</u>
L-841 Auxiliary Relay Cabinet Assembly	<u>AC 150/5345-13</u>
L-823 Connectors	<u>AC 150/5345-26</u>
L-853 Retroreflective Markers	<u>AC 150/5345-39</u>
L-867 and L-868 Bases and L-868/L-867 Junction Box, Blank Covers	<u>AC 150/5345-42</u>
L-804, L-852, and L-862S Light Fixtures	<u>AC 150/5345-46</u>
L-830 Isolation Transformer	<u>AC 150/5345-47</u>
L-854 Radio Control Equipment	<u>AC 150/5345-49</u>
Counterpoise Cable	*Item L-108
Airport Transformer Vault	*Item L-109
Conduit and Duct	*Item L-110
Joint Sealer, Type III	*P-605 (See <u>Chapter 12</u>)
Sealer Material (Liquid and Paste)	*P-606 (See <u>Chapter 12</u>)
Concrete Backfill	*P-610

2284 * These items are referenced in AC 150/5370-10, *Standards for Specifying Construction*
 2285 *of Airports*.

2286 4.10. **Installation.**
 2287 See Chapter 10 for various pavement types.

2288

Page Intentionally Blank

2289 CHAPTER 5 Land and Hold Short Lighting Systems.

2290 5.1. Introduction.

2291 Land and hold short lighting systems indicate the location of hold-short points on
2292 runways approved for land and hold short operations (LAHSO).

2293 5.2. Background.

2294 FAA Order 7110.118, *Land and Hold Short Operations (LAHSO)*, provides operational
2295 requirements for lighting systems and other visual navigational aids that are required to
2296 conduct LAHSO.

2297 5.3. Definitions.

2298 5.3.1 Available Landing Distance (ALD)

2299 That portion of a runway available for landing roll-out for aircraft cleared for LAHSO.
2300 This distance is measured from the landing threshold to the hold-short point.

2301 5.3.2 Hold-Short Point

2302 A point on the runway beyond which a landing aircraft with a LAHSO clearance is not
2303 authorized to cross.

2304 5.3.3 LAHSO

2305 These operations include landing and holding short of an intersecting runway, a
2306 taxiway, a predetermined point, or an approach/departure flight path.

2307 5.4. Implementation Criteria.

2308 Install land and hold short lighting systems at locations described in the letter of
2309 agreement between the airport authority and the local ATCT. See FAA Order 7110.118
2310 for information about the letter of agreement.

2311 5.5. Configuration.

2312 A land and hold short lighting system consists of a row of six or seven in-pavement
2313 unidirectional pulsing white lights installed across the runway at the hold-short point. A
2314 6-light bar is standard for new installations. A 7-light bar is standard for airports with
2315 existing 5-light bars. Five-light bars must be upgraded to meet the standard by adding a
2316 light fixture on each end of the existing installation, with the same spacing as the
2317 existing fixtures. Selection of the 6- or 7-light bar is not based on the presence of
2318 runway centerline lights.

2319 5.5.1 Location.

2320 5.5.1.1 Center the light fixtures on an imaginary line that is parallel to, and 2 ft.
2321 (0.6 m) -0 ft. (0 mm) +3 ft. (0.9 m) prior to, the holding side of the runway
2322 holding position marking, per Figure A-63.

2323 5.5.1.2 Individual **light** fixtures may vary from the imaginary line **by** up to 2
2324 inches (51 mm) in a direction parallel to the runway centerline.

2325 5.5.1.3 Install **light** fixtures so that their nearest edge is approximately 2 ft. (0.6
2326 m) from any rigid pavement joint or another fixture.

2327 5.5.1.4 **If** any of the light fixtures **conflict with** undesirable areas, such as rigid
2328 pavement joints, etc., which cannot be resolved through the +3-foot (0.9
2329 m) longitudinal tolerance or by varying the lateral spacing as specified in
2330 the following paragraph, move the holding position marking and the entire
2331 land and hold short lighting system sufficiently toward the landing
2332 threshold (shortening the ALD) to resolve the conflict.

2333 5.5.2 Lateral Spacing of Light Fixtures.

2334 5.5.2.1 The total width of the row of lights (measured between the centers of the
2335 outboard fixtures) should be 50% ($\pm 10\%$) of the defined runway width for
2336 6-light bars per Figure A-63, and 65% ($+5\%$, -15%) for 7-light bars.

2337 5.5.2.2 Space the remaining lights uniformly between the outboard fixtures within
2338 a tolerance of ± 2 inches (51 mm).

2339 5.5.2.3 Arrange the light bar symmetrically about the runway centerline for 6-
2340 light bars, or about the center fixture for 7-light bars. Refer to Chapter 3.

2341 5.6. **Design.**

2342 Land and hold short lighting systems are designed for installation in new or existing
2343 pavements. When possible, install land and hold short lighting systems during
2344 construction of the runway or when the pavement is being overlaid. This allows for the
2345 installation of L-868 light bases interconnected by conduit, which is preferred. In this
2346 system, the isolation transformers are contained within the light bases.

2347 5.6.1 Light Fixtures and Electrical Cables.

2348 You may select one of two types of fixtures for the land and hold short lighting system:
2349 1) L-850F, unidirectional white light, or 2) L-850A unidirectional white light, per AC
2350 150/5345-46. The fixtures are similar except that the L-850F fixture includes a second
2351 lamp which illuminates in the event the first lamp fails. Design the system for the
2352 appropriate pavement condition listed below:

- 2353 5.6.1.1 **New pavements.**
2354 Provide access to electrical cables and isolation transformers through the
2355 use of conduits and L-868 light bases. This type of installation reduces
2356 downtime and repair costs when the underground circuits require
2357 maintenance. Refer to Chapter 11.
- 2358 5.6.1.2 **Pavement overlays.**
2359 You may use a base and conduit system as described in the preceding
2360 paragraph. Two-section bases and spacer rings or an adjustable base to
2361 reach proper elevation may be required. Refer to Chapter 11.
- 2362 5.6.1.3 **Existing pavements.**
2363 Provide recesses or holes for direct-mounted light fixtures or fixtures
2364 installed on bases. Locate isolation transformers at the side of the runway.
2365 Run No. 10 AWG wire between the transformers and the lights through
2366 shallow sawed wire ways (saw kerfs) in the pavement surface. See Figure
2367 A-64 and Figure A-65. Alternatively, you may retrofit L-868 bases and
2368 conduit systems into existing pavements. Locate isolation transformers
2369 within the bases.
- 2370 5.6.2 Electrical System.
- 2371 5.6.2.1 An L-884 Power and Control Unit (PCU), described in AC 150/5345-54,
2372 *Specification for L-884 Power and Control Unit for Land and Hold Short*
2373 *Lighting Systems*, is typically used to power land and hold short lighting
2374 systems.
- 2375 5.6.2.2 The PCU pulses the lights by varying the voltage on the primary side of
2376 the series circuit per Figure A-66.
- 2377 5.6.2.3 **Isolate** light fixtures from the series circuit via 6.6/6.6-ampere isolation
2378 transformers specified in AC 150/5345-47.
- 2379 5.6.3 PCU.
- 2380 5.6.3.1 You may install PCUs either indoors (Style I) in a vault or outdoors (Style
2381 II) near the lighting system, as required.
- 2382 5.6.3.2 The PCUs, when installed outdoors, must be located as far from the
2383 runway as possible to present the minimum possible obstruction to
2384 aircraft.
- 2385 5.6.3.3 **Mount** the PCUs at the minimum possible height, **positioning them** outside
2386 the RSA, taxiway safety area, and taxiway object-free area. The safety
2387 and object free areas are defined in AC 150/5300-13.

2388 5.6.4 Control System.2389 **5.6.4.1 Local and Remote Control.**

2390 The system must have provisions for local and remote control.

2391 5.6.4.1.1 Local control (“on/off” and intensity control) must be provided at the
2392 PCU.

2393 5.6.4.1.2 Remote control (“on/off” exclusively) must be provided in the ATCT.

2394 5.6.4.1.3 If there are two or more land and hold short lighting systems installed on
2395 the airport, install each system on dedicated circuits with its own set of L-
2396 884 PCUs.

2397 5.6.4.1.4 **However**, you may power two lighting systems installed on the same
2398 runway (e.g., installed on opposite sides of an intersecting runway and
2399 facing in opposite directions) from the same set of PCUs through the use
2400 of L-847 circuit selector switches specified in AC 150/5345-5.

2401 5.6.4.2 Configure the L-847 switches so that only one lighting system at a time
2402 may be selected. Figure A-66 shows a typical block diagram of the
2403 LAHSO lighting system.

2404 **5.6.4.3 Automatic Intensity Control.**

2405 5.6.4.3.1 When the PCUs are under remote control, intensity selection is automatic
2406 and is derived from PCU photoelectric control inputs and sensing of the
2407 intensity of the runway edge lights that are installed on the same runway
2408 as the land and hold short lighting system.

2409 5.6.4.3.2 The required intensity levels are described in AC 150/5345-54.

2410 **5.6.4.4 Photocell.**2411 **5.6.4.4.1 Use a photocell to switch the PCU into day or night mode.**

2412 1. The photocell is an integral part of a PCU designed for outdoor
2413 installation.

2414 2. With the PCU installed, face the photocell north.

2415 **5.6.4.4.2 A PCU installed indoors must have a remotely mounted photocell in a
2416 readily accessible outdoor location.**

2417 1. Install the photocell facing north and clearly label it for ease of
2418 maintenance. If surrounding airport lights activate a photocell, then
2419 turn it as necessary to prevent false activation.

2420 2. **Do** not gang multiple PCUs on a single photocell, as it would create a
2421 single point source of failure.

2422 **5.6.5 Remote Control.**

2423 Remote control may be provided in the ATCT through an appropriate L-821 control
2424 panel per AC 150/5345-3. Where possible, you may integrate remote control switches

2425 into existing airfield lighting control panels. Two common methods used to control L-
2426 884 PCUs and other equipment are described below:

2427 5.6.5.1 **120-Volt AC.**

2428 5.6.5.1.1 Where the distance between the remote-control panel and the vault is not
2429 great enough to cause excessive voltage drop (>5%) in the control leads,
2430 use the standard control panel switches to operate the control relays
2431 directly.

2432 5.6.5.1.2 Operating relays supplying power to the L-884 PCUs must have coils
2433 rated for 120-volt AC.

2434 5.6.5.1.3 Use a #12 AWG control cable to connect the control panel to the power
2435 supply equipment in the vault.

2436 5.6.5.1.4 Use the curves in [Figure A-67](#) to determine the maximum permissible
2437 separation between the control panel and the vault for 120-volt AC
2438 control.

2439 5.6.5.1.5 You may use special pilot low burden auxiliary relays, having proper coil
2440 resistance to reduce control current, to obtain additional separation
2441 distance with 120-volt AC control circuits. It may be advantageous to use
2442 these relays for expanding existing 120-volt AC control circuits.

2443 5.6.5.2 **48 Volt DC.**

2444 5.6.5.2.1 Where the distance between the control panel and the vault would cause
2445 excessive control voltage drop, use a low voltage (48-volt DC) control
2446 system.

2447 5.6.5.2.2 In such a system, use remote control panel switches to activate sensitive
2448 pilot relays such as those specified in [AC 150/5345-13](#) which, in turn,
2449 control the L-884 relays.

2450 5.6.5.2.3 Use an appropriately sized cable, of a type that is listed for direct earth
2451 burial, to connect the control panel to the pilot relays.

2452 5.6.5.2.4 The DC control system is adequate for up to 7,900 ft. (2408 m) separation
2453 between control point and vault.

2454 5.6.5.3 **Remote Control Using Other Methods.**

2455 5.6.5.3.1 There are many methods of providing for the remote control of L-884
2456 PCUs, L-847 circuit selector switches, etc.

2457 5.6.5.3.2 Such methods include ground-to-ground radio control (see [AC 150/5345-](#)
2458 49), copper wire, fiber-optic control lines, etc. Control signals may be
2459 digital or analog.

2460 5.6.5.3.3 Whatever the method used, ensure that the control system is reliable and
2461 that EMI does not cause unintended switching of the lighting system.

2462 5.6.6 Monitoring.

2463 The status of each land and hold short lighting system must be indicated on the L-821
 2464 control panel in the ATCT. A monitoring system is a required component of an L-884
 2465 PCU and is described in AC 150/5345-54.

2466 5.7. **Equipment and Material.**

2467 Equipment and material covered by FAA ACs are referred to by AC numbers.
 2468 Equipment not covered by FAA specifications, such as distribution transformers, circuit
 2469 breakers, cutouts, relays, and other commercial items of electrical equipment, must
 2470 conform to the applicable rulings and standards of the electrical industry and local code
 2471 regulations. Electrical equipment must be tested and certified by an OSHA recognized
 2472 NRTL and must bear that mark. A current list of NRTLs can be obtained by contacting
 2473 the OSHA NRTL Program Coordinator at web site
 2474 <https://www.osha.gov/dts/otpca/nrtl/>. Table 5-1 below contains a list of equipment and
 2475 material used for land and hold short lighting systems.

2476 **Table 5-1. Equipment and Material Used for Land and Hold Short Lighting Systems.**

Item No.	Item Description	ACs
L-821	Remote Control Panel	<u>AC 150/5345-3</u>
L-847	Circuit Selector Switch	<u>AC 150/5345-5</u>
L-824 #8 AWG Cable	Electrical Cable	<u>AC 150/5345-7</u>
L-824 #10 AWG THWN Cable	Electrical Cable	<u>AC 150/5345-7</u>
L-824 #12 AWG Cable	Electrical Cable	<u>AC 150/5345-7</u>
L-841	Auxiliary Relay Cabinet Assy.	<u>AC 150/5345-13</u>
L-823	Cable Connectors	<u>AC 150/5345-26</u>
L-867	Transformer Housing	<u>AC 150/5345-42</u>
L-868	Light Base	<u>AC 150/5345-42</u>
L-850F (unidirectional)	Light Fixture	<u>AC 150/5345-46</u>
or L-850A (unidirectional)	Light Fixture	<u>AC 150/5345-46</u>
L-830	Isolation Transformer	<u>AC 150/5345-47</u>
L-854	Radio Control Equipment	<u>AC 150/5345-49</u>
L-884	Power and Control Unit	<u>AC 150/5345-54</u>
Item L-110	Conduit and Duct	<u>AC 150/5370-10</u>
Item P-605	Joint Sealer, Type III	<u>AC 150/5370-10</u>
Item P-606	Sealer Material (Liquid and Paste)	<u>AC 150/5370-10</u>

Item No.	Item Description	ACs
Item P-610	Concrete Backfill	<u>AC 150/5370-10</u>

2477 5.8. **Installation.**

2478 This chapter recommends installation methods and techniques; however, other methods
 2479 and techniques, and variations of those outlined here, may be used provided they are
 2480 approved by the appropriate local FAA Airports Office. The installation must conform
 2481 to the applicable sections of NFPA 70 (NEC) and local codes. See Chapter 12 for
 2482 additional information.

- 2483 • Light Bases, Transformer Housings and Junction Boxes. See paragraph 12.2.
- 2484 • Duct and Conduit. See paragraph 12.3.
- 2485 • Cable, Cable Connectors, Plugs and Receptacles. See paragraph 12.4.
- 2486 • Counterpoise (Lightning Protection). See paragraph 12.5.
- 2487 • Light Base Ground. See paragraph 12.6.
- 2488 • Light Fixture Bonding. See paragraph 12.7.
- 2489 • Concrete. See paragraph 12.8.
- 2490 • Steel Reinforcement. See paragraph 12.9.
- 2491 • Adhesive and Sealants. See paragraph 12.10.
- 2492 • Load-bearing Lighting Fixtures. See paragraph 12.11.
- 2493 • Inspection. See paragraph 12.12.
- 2494 • Testing. See paragraph 12.12.1.
- 2495 • Auxiliary Relays. See paragraph 12.13.
- 2496 • Vault. See paragraph 12.14.
- 2497 • Maintenance. See paragraph 12.14.2.

2498

Page Intentionally Blank

CHAPTER 6 Airfield Miscellaneous Aids.

6.1. Airport Rotating Beacons.

6.1.1 Airport rotating beacons must be per AC 150/5345-12.

6.1.2 All airport rotating beacons project a beam of light in two directions, 180 degrees apart. For civil land fields only, the optical system consists of one green lens and one clear lens.

6.1.3 The rotating mechanism rotates the beacon to produce alternate clear and green flashes of light with a flash rate of 24-30 flashes per minute.

6.1.4 The main purpose of the beacon is to indicate the location of a lighted airport, and a rotating beacon is an integral part of an airfield lighting system.

6.1.4.1 L-802A Beacon.

The L-802A rotating beacon is the standard high intensity rotating beacon and is installed at all airports where high intensity lighting systems are used. See Figure A-68 for a typical beacon.

6.1.4.2 L-801A Beacon.

The L-801A rotating beacon is the standard medium intensity beacon and is installed at airports where only medium intensity lighting systems are used, unless special justification exists requiring the use of a high intensity beacon at the site. Such a justification includes high background brightness caused by neighboring lights, or where the beacon is used as a navigational aid rather than for location and identification.

6.2. System Design.

6.2.1 Power Supply.

6.2.1.1 Primary power supply for airport rotating beacons is either from an existing 120/240-volt AC power supply or from a separately located distribution transformer.

6.2.1.2 Match, as closely as possible, the primary circuit wire size to the lamp's rated voltage. See Figure A-69 for formulae to calculate wire size and voltage drop.

6.2.1.3 Where the separation distance between power supply and the beacon is excessive, booster transformers are recommended to maintain proper voltage at lamp receptacles.

2531 6.2.2 Control Circuits.

2532 6.2.2.1 Airport rotating beacons employ simple switching circuits to energize and
2533 de-energize the power supply. The control system design varies.

2534 6.2.2.2 At a small airport, all control equipment and circuitry is self-contained in
2535 the power supply equipment; at a large airport, a complex control system
2536 is needed. The two types of control systems used are direct control or
2537 remote control:

2538 6.2.2.3 **Direct Control.**

2539 6.2.2.3.1 Direct control systems are controlled at the power supply through a switch
2540 **that** energizes the branch circuit supplying the power to the airport beacon.

2541 6.2.2.3.2 Normally, this type of system is used for the control of rotating beacons at
2542 small airports and for other miscellaneous associated lighting circuits.

2543 6.2.2.3.3 Automatic control of the beacon is obtained through a photoelectric switch
2544 with a built-in method of switching from automatic to manual control.

2545 6.2.2.3.4 See Figure A-70 for a typical automatic control.

2546 6.2.2.4 **Remote Control.**

2547 6.2.2.4.1 Remote control systems are controlled from a remote-control panel that
2548 may be located in the cab of the control tower or at other remote areas,
2549 using a control panel per AC 150/5345-3.

2550 6.2.2.4.2 This panel contains switches and other devices that control operating
2551 relays in the vault from which the power is supplied through the relay
2552 contacts to the lighting visual aid.

2553 6.2.2.4.3 The following control voltages are used for remote control of equipment.
2554 See Figure A-71.

2555 6.2.2.4.4 **120-Volt AC.**

2556 1. Where the distance between the remote-control panel and the vault is
2557 not great enough to cause an excessive voltage drop in the control
2558 leads, use the standard control panel switches to operate the equipment
2559 power supply relays directly.

2560 2. Use No. 12 AWG control cable to connect the control panel to the
2561 power components in the vault.

2562 3. Use the formula in Figure A-69 to calculate the maximum permissible
2563 separation between control point and vault, using the manufacturer's
2564 electrical operating circuit.

2565 4. In many cases, 120-volt AC, special low-burden auxiliary relays, **and**
2566 having the proper coil resistance, may be more advantageous for
2567 expanding the existing 120-volt AC control system than redesigning
2568 the control system to 48-volt DC.

- 2569 6.2.2.4.5 **48 Volt DC.**
- 2570 1. Use a low voltage 48-volt DC control system where the distance
- 2571 between the control panel and the vault would cause an excessive
- 2572 voltage drop with a 120-volt AC control system.
- 2573 2. In this system, the remote-control panel switches that, in turn, control
- 2574 the miscellaneous lighting circuits activate sensitive pilot relays.
- 2575 3. The DC control system is adequate for up to 7,900 ft. (2,408 m)
- 2576 separation.
- 2577 6.2.3 Duct and Conduit System.
- 2578 6.2.3.1 For an underground power supply, install cable runs in ducts or conduits
- 2579 in areas that are to be stabilized or surfaced.
- 2580 6.2.3.2 Install cable runs to the top of towers in conduit. This provides ready
- 2581 access for maintenance, modification of circuits, and protection to cables
- 2582 during repairs of surface or stabilized areas.
- 2583 6.2.3.3 Provide a reasonable number of spare ducts or conduits in each
- 2584 underground bank for maintenance and future expansion of facilities.
- 2585 6.2.3.4 Avoid routing underground duct or conduit through areas that may have to
- 2586 be excavated. Ensure that all duct and conduit dimensions meet national,
- 2587 state, and local electrical codes.
- 2588 6.3. **Installation.**
- 2589 6.3.1 Rotating Beacons.
- 2590 6.3.1.1 **Mounting the Beacon.**
- 2591 6.3.1.1.1 **Mount** all airport rotating beacons higher than any surrounding
- 2592 obstructions so that the bottom edge of the beacon's light beam, when
- 2593 adjusted correctly, will clear all obstructions.
- 2594 6.3.1.1.2 Beacons may be mounted on the roof of hangars or other buildings; on top
- 2595 of control towers when authorized by the local FAA regional office, or on
- 2596 wooden power pole towers and metal towers.
- 2597 6.3.1.1.3 Check the mounting for the beacon support legs with the appropriate space
- 2598 and dimensions **per the** beacon manufacturer's **recommendations**.
- 2599 6.3.1.2 **Hoisting and Securing.**
- 2600 6.3.1.2.1 Prior to hoisting the beacon, review the manufacturer's assembly drawings
- 2601 of the beacon.
- 2602 6.3.1.2.2 Where it is impractical to hoist the assembly in one piece, disassemble the
- 2603 beacon into parts following the manufacturer's recommendations.

- 2604 6.3.1.2.3 Ensure the mounting platform at the top of the tower has the correct bolt
2605 pattern from the manufacturer's installation drawings.
- 2606 6.3.1.2.4 Hoist the beacon into place by means of a sling, taking care not to chafe
2607 any surface of the assembly.
- 2608 6.3.1.2.5 Once in place, secure the base of the beacon to the mounting platform and
2609 reassemble per the manufacturer's instructions.
- 2610 6.3.1.3 **Leveling.**
2611 Level the beacon following the manufacturer's instructions.
- 2612 6.3.1.4 **Servicing.**
2613 Before placing the beacon in operation, check the manufacturer's manual
2614 for proper servicing requirements (including any beam adjustments).
2615 Follow the manufacturer's servicing requirements for each size beacon.
- 2616 6.4. **Maintenance.**
2617 Maintenance must be performed per AC 150/5340-26.
- 2618 6.5. **Beacon Towers.**
2619 Typical beacon towers are per Figure A-72, Figure A-73, and Figure A-74.
- 2620 6.5.1 Location.
- 2621 6.5.1.1 AC 150/5300-13 contains the standards for locating beacon towers.
- 2622 6.5.1.2 The FAA may recommend obstruction lights on beacon towers that are
2623 less than 200 ft. (61 meters) above ground level (AGL) or Title 14 CFR
2624 Part 77, *Objects Affecting Navigable Airspace*, standards because of a
2625 particularly sensitive location.
- 2626 6.5.1.3 Ensure that all requirements in AC 70/7460-1, *Obstruction Lighting and*
2627 *Marking*, are met before erecting any structure that may affect the
2628 *National Airspace System (NAS)*.
- 2629 6.5.2 Description of Towers.
- 2630 6.5.2.1 **Structural steel towers.**
- 2631 6.5.2.1.1 **Towers** must conform to AC 150/5370-10, *Standards for Specifying*
2632 *Construction of Airports*, and consist of structural steel parts for the basic
2633 tower.
- 2634 6.5.2.1.2 Standard tower heights are 51, 62, 75, 91, 108, 129, and 152 ft. (15.5, 19,
2635 23, 28, 33, 39, and 46 meters, *respectively*).

- 2636 6.5.2.1.3 Each tower is supplied with a telescoping ladder and a mounting platform
2637 for a high intensity beacon, approximately 7 ft. square (0.65 meters
2638 square) with rails and grating.
- 2639 6.5.2.1.4 The railings are punched to permit mounting of a “T” cabinet on any inner
2640 surface.
- 2641 6.5.2.1.5 See Figure A-72 for typical 51-foot (15.5 m) tower installations.
- 2642 6.5.2.2 **Tubular steel towers.**
- 2643 6.5.2.2.1 **Towers** consist of different lengths of low alloy, high strength tubular steel
2644 sections with 60,000 PSI yield strength, welded together to obtain a basic
2645 tower **height** of 51 ft. (15.5 m).
- 2646 6.5.2.2.2 At the top of the tower is a platform (welded) to accommodate a high
2647 intensity beacon, and a safety device consisting of a cable, locking clip,
2648 and belt combination, that permits a workman to climb the tower and to
2649 secure himself in the event of a misstep.
- 2650 6.5.2.2.3 Check with the airport beacon manufacturer to ensure the best tower
2651 design is selected for the model of beacon purchased. Be prepared to
2652 supply local wind velocity and ice load data to the tower manufacturer.
2653 See Figure A-73.
- 2654 6.5.2.3 **Prefabricated Tower Structure.**
- 2655 Prefabricated tower structure components consist of two lower sections
2656 fabricated in 20-foot (6 m) lengths with one 11-foot (3.5 m) upper section
2657 and an 8-foot (2.4 m) diameter service platform with rails and caging for
2658 mounting a beacon, and a steel rung ladder for entrance to the platform.
2659 See Figure A-75.
- 2660 6.5.2.4 **Tip-down pole towers.**
- 2661 6.5.2.4.1 **These towers** consist of a two-section octagonal tapered structure with a
2662 counterweight and hinge.
- 2663 6.5.2.4.2 The top section/counterweight is attached to the bottom section using a
2664 hinge that rotates upon a 1 1/4-inch diameter stainless steel rod.
- 2665 6.5.2.4.3 The top section can easily be raised and lowered by one person using an
2666 internal hand-operated winch.
- 2667 6.5.2.4.4 Pole lengths to 55 ft. are available.
- 2668 6.5.2.4.5 Check with the beacon manufacturer about the proper model of beacon to
2669 use with this type of tower. Be prepared to supply local wind velocity and
2670 ice loading data to the tower manufacturer.
- 2671 **Note:** A fall protection device must be installed on all ladders per OSHA
2672 requirements.

2673 6.5.3 Installation.2674 6.5.3.1 **Clearing and Grading.**

2675 6.5.3.1.1 Clear and level the site where the beacon tower is to be erected. Remove
2676 all trees and brush from the area within 25 ft. (7.6 m) from the tower or as
2677 specified in the job plans.

2678 6.5.3.1.2 Remove tree stumps to a depth of 18 inches (0.5 m) below finished grade,
2679 **then** fill the excavation with dirt and tamp.

2680 6.5.3.1.3 If a transformer vault or other structure is included as part of the
2681 installation, clear the area **within** 25 ft. (7.6 m) from these structures.

2682 6.5.3.1.4 Level the ground near the tower to permit the operation of mowing
2683 machines. Extend the leveling at least 2 ft. (0.6 m) outside the tower legs.

2684 6.5.3.1.5 Dispose of all debris from the tower site per federal, state, or local
2685 regulations.

2686 6.5.3.2 **Excavation and Fill.**

2687 6.5.3.2.1 Carry the excavation for the tower footing to a minimum of 4 inches (100
2688 mm) below the footing depth.

2689 6.5.3.2.2 Then backfill the excess excavation below the footing depth with gravel or
2690 crushed stone and compact to the required level.

2691 6.5.3.2.3 Install the footing plates and then place a thickness of not less than 18
2692 inches (0.5 m) of the same gravel or crushed stone immediately above the
2693 footing plates in layers of not over 6 inches (152 mm).

2694 6.5.3.2.4 Thoroughly tamp in place each layer above the footing plates.

2695 6.5.3.2.5 The remainder of the backfill may be of excavated earth placed in layers
2696 not to exceed 6 inches (152 mm).

2697 6.5.3.2.6 Thoroughly compact each layer by tamping.

2698 6.5.3.2.7 **Where solid rock is encountered:**

2699 1. Cut the tower anchor posts off at the required length and install the
2700 hold down bolts as indicated in the plans.

2701 2. Anchor each tower leg to the rock **with** two 7/8-inch (22 mm) diameter
2702 by 3-foot (0.9 m) long expansion or split hold down bolts and then
2703 grout each bolt into holes drilled into the natural rock with neat
2704 Portland cement.

2705 3. Except as required for rock foundations, do not cut off or shorten the
2706 footing members.

2707 4. If the excavated material is not readily compacted when backfilled, use
2708 concrete or other suitable material.

2709 5. Install the concrete footing for tubular towers per the manufacturer's
2710 recommendations.

2711 6. Footing height does not include the footing portions located in the
2712 topsoil layer.

2713 6.6. **Wind Cones.**

2714 6.6.1 General.

2715 6.6.1.1 This section covers the installation of **two** types of wind cones: L-806
2716 (supplemental wind cone) and L-807 (primary wind cone).

2717 6.6.1.2 Title 14 CFR Part 139 requires that an airport must have a wind cone that
2718 visually provides surface wind direction information to pilots.

2719 6.6.1.3 If a primary wind cone is not visible to pilots on approach and takeoff at
2720 each runway end, supplemental wind cone(s) must be provided.

2721 6.6.1.4 If the airport is open for air carrier operations at night, the wind cones
2722 (both primary and supplemental) must be lit.

2723 6.6.1.5 The guidance in this AC is recommended for all applications involving
2724 wind cones.

2725 6.6.2 Discussion.

2726 The primary wind cone is needed at any airport without a 24-hour ATCT. At an airport
2727 certificated **per** Title 14 CFR Part 139 a primary wind cone is required whether the **ATCT** is full-
2728 time or part-time.

2729 6.6.2.1 The source of airport wind information reported to pilots may be 2 to 3
2730 miles (3.2 to 4.8 km) from the approach end of a runway.

2731 6.6.2.2 Factors such as topography, approaching fronts or thunderstorms could
2732 result in much different wind conditions near runway ends than those
2733 reported to pilots from the primary wind information source.

2734 6.6.2.3 Supplemental wind cones may be useful to provide pilots a continuing
2735 visual indication of wind conditions near the runway ends during landing
2736 and takeoff operations.

2737 6.6.3 Siting.

2738 6.6.3.1.1 The primary wind cone will likely be located within a segmented circle
2739 and should be installed so that it is readily visible to pilots.

2740 6.6.3.1.2 The primary wind cone should be installed so there is no conflict with
2741 airport design criteria requirements in AC 150/5300-13.

2742 6.6.3.1.3 See Title 14 CFR Part 77 to determine if obstruction lights will be
2743 required. See Figure E-18 and Figure E-19 for installation details.

- 2744 6.6.3.2 The supplemental wind cone must be located near the runway end so that
2745 pilots have an unobstructed view during either landing or takeoff
2746 operations.
- 2747 6.6.3.2.1 The preferred location is on the left side of the runway when viewed from
2748 a landing aircraft. However, it may be located on the right side of the
2749 runway where conditions such as the existence of another runway,
2750 taxiway, apron, terrain problems, or navigational aids preclude its
2751 installation on the left side.
- 2752 6.6.3.2.2 The supplemental wind cone must be installed outside the RSA.
- 2753 6.6.3.2.3 The supplemental wind cone must not be inside the **ROFA** unless there is
2754 a need; and if so, documentation must be provided to explain the reason
2755 for the location.
- 2756 6.6.3.2.4 The supplemental wind cone must not penetrate the obstacle free zone
2757 (OFZ) per AC 150/5300-13.
- 2758 6.6.3.2.5 The proposed **supplemental** wind cone location must be coordinated with
2759 the local Technical Operations (Airway Facilities) Office to ensure that it
2760 will not cause interference with the radiation pattern of any navigational
2761 aid facility.
- 2762 6.6.3.2.6 See Figure A-76 and Figure A-77 for installation details on supplemental
2763 wind cones.
- 2764 6.6.3.2.7 The supplemental wind cone longitudinal tolerance is ± 500 feet (152.4
2765 meters) and ± 50 feet (15.2 meters) lateral tolerance from the location
2766 shown in Figure A-76.
- 2767 6.6.4 Performance Requirements.
2768 Locally fabricated or commercially available supplemental wind cones may be used,
2769 provided they meet the criteria in AC 150/5345-27, *Specification for Wind Cone*
2770 *Assemblies*.
- 2771 6.6.5 Wind Cone Mounting Structures.
2772 **Mount** the primary wind cone on a rigid supporting structure, Type L-807. **Mount** the
2773 supplemental wind cone on a frangible structure, Type L-806. See AC 150/5345-27 for
2774 detailed descriptions of the mounting structures.
- 2775 6.6.6 Maintenance.
2776 **Perform** maintenance in accordance with AC 150/5340-26.
- 2777 6.7. **Obstruction Lights.**
- 2778 6.7.1 Location.
2779 AC 70/7460-1 contains the criteria for locating obstruction lights. Obstruction lights
2780 must be per AC 150/5345-43, *Specification for Obstruction Lighting Equipment*.

- 2781 6.7.1.1 **Selection Consideration.**
2782 AC 70/7460-1 contains guidance on the type of obstruction lights to be
2783 used as well as the placement and number of lights required to light the
2784 obstruction properly.
- 2785 6.7.1.2 **Obstruction Light Installation.**
2786 6.7.1.2.1 Obstruction lights are installed on all obstructions that present a hazard to
2787 air traffic to warn pilots of obstructions during hours of darkness and
2788 during periods of limited daytime visibility.
- 2789 6.7.1.2.2 An obstruction's height, size, shape, and **location** determine the position of
2790 lights on the obstruction, and the number of lights required to assure
2791 visibility of such lighting from an aircraft at any angle of approach.
- 2792 6.7.1.2.3 Standards for determining obstructions to air commerce are in **14 CFR**
2793 **Part 77. See also AC 70/7460-1.**
- 2794 6.7.1.3 **Power Supply.**
2795 Design the power supply to ensure that the specified voltage is available at
2796 the input terminals of the obstruction light. Coordinate with the
2797 equipment manufacturer for proper operating voltage and tolerance.
- 2798 6.7.1.4 **Control System.**
2799 6.7.1.4.1 Obstruction lights installed in conjunction with a rotating beacon may be
2800 controlled from a tell-tale relay within the beacon controller.
- 2801 6.7.1.4.2 Other obstruction lights may be controlled from a photosensitive device.
- 2802 1. Adjust the device so that the lights automatically turn on when the
2803 north sky light intensity reaches a level of 35 foot-candles, and
2804 automatically turned off when the north sky light intensity reaches a
2805 level of 58 foot-candles.
- 2806 2. Where the connected load exceeds the contact rating in the light
2807 sensitive control device, design the control circuit to include a load
2808 contactor relay properly rated for the load.
- 2809 6.7.1.5 **Duct and Conduit System.**
2810 Design the duct and conduit system for the wind cone obstruction light per
2811 paragraph 6.1.3 for rotating beacons.
- 2812 6.7.2 Installation.
- 2813 6.7.2.1 **Placing the Obstruction Lights.**
2814 Install obstruction lights per AC 70/7460-1.
- 2815 6.7.2.2 **Installation on Poles.**
2816 6.7.2.2.1 Where obstruction lights are to be mounted on poles, install each
2817 obstruction light with its hub sized per **the** NEC.

- 2818 6.7.2.2.2 If pole steps are specified, install the lowest step 5 ft. above ground level.
- 2819 6.7.2.2.3 Install steps alternately on diametrically opposite sides of the pole to give
- 2820 a rise of 18 inches (0.5 m) for each step.
- 2821 6.7.2.2.4 Fasten conduit to the pole with galvanized steel pipe straps secured by
- 2822 galvanized lag screws.
- 2823 6.7.2.3 **Installation on Beacon Towers.**
- 2824 6.7.2.3.1 Where obstruction lights are installed on beacon towers, mount two
- 2825 obstruction lights on top of the tower using rigid steel conduit.
- 2826 6.7.2.3.2 The method of installation must be per AC 150/5370-10, Item L-101,
- 2827 Lighting Installation - Airport Rotating Beacons.
- 2828 6.7.2.3.3 If obstruction lights are specified at lower levels, install not less than 1/2
- 2829 inch (13 mm) galvanized rigid steel conduit with standard conduit fittings
- 2830 for mounting the fixtures.
- 2831 6.7.2.3.4 Mount all **obstruction light** fixtures in an upright position. |
- 2832 6.7.2.4 **Installation on Buildings, Towers, Smokestacks, etc.**
- 2833 Mount the hub of the obstruction light not less than 1 foot (0.3 m) above
- 2834 the highest point of the obstruction, except in the case of smokestacks.
- 2835 For smokestacks, mount the uppermost units not less than 5 ft. (1.5 m) or
- 2836 more than 10 ft. (3 m) below the top of the stack.
- 2837 6.7.2.5 **Wiring.**
- 2838 If underground cable is required for the power feed, and if duct is required
- 2839 under paved areas, install the duct and cable per Items L-108 and L-110.
- 2840 Install overhead line wire from pole to pole, where specified, conforming
- 2841 to Federal Specification J-C-145, *Cable, Power, Electrical and Wire,*
- 2842 *Electrical (Weather-Resistant).*
- 2843 6.7.2.5.1 **Lamps.** |
- 2844 Install one or two lamps, as required. All lamps used must be listed in AC
- 2845 150/5345-53, Addendum, Appendix 3.
- 2846 6.7.3 Maintenance.
- 2847 See AC 150/5340-26 for additional details about wind cone maintenance.
- 2848 6.8. **Equipment and Materials.**
- 2849 See Chapter 12 for additional information.
- 2850 • Light Bases, Transformer Housings and Junction Boxes. See paragraph 12.2.
- 2851 • Duct and Conduit. See paragraph 12.3.
- 2852 • Cable, Cable Connectors, Plugs and Receptacles. See paragraph 12.4.
- 2853 • Counterpoise (Lightning Protection). See paragraph 12.5.

- 2854 • Light Base Ground. See paragraph 12.6.
- 2855 • Light Fixture Bonding. See paragraph 12.7.
- 2856 • Concrete. See paragraph 12.8.
- 2857 • Steel Reinforcement. See paragraph 12.9.
- 2858 • Adhesive and Sealants. See paragraph 12.10.
- 2859 • Load-bearing Lighting Fixtures. See paragraph 12.11.
- 2860 • Inspection. See paragraph 12.12.
- 2861 • Testing. See paragraph 12.12.1.
- 2862 • Auxiliary Relays. See paragraph 12.13.
- 2863 • Vault. See paragraph 12.14.
- 2864 • Maintenance. See paragraph 12.14.2.

2865

Page Intentionally Blank

CHAPTER 7 Economy Approach Aids.

7.1. Introduction.

Economy approach lighting aids were developed to make visual aids available to airports at a low cost. The design and installation requirements are flexible to permit the equipment to be installed and operated with minimal changes to the power distribution system at the airport.

The drawings required to plan and install a system are described and referenced throughout this chapter. These are drawings of typical installations. Local applications may require variations from the drawings, but no variations in the layout, spacing, and tolerances are permitted. Although it is possible to plan an installation from the drawings, various characteristics affecting the systems and their design, equipment, and installation deserve special consideration.

7.2. Types of Economy Approach Lighting Aids.

- Medium Intensity Approach Lighting System with or Without Sequenced Flashing Lights (MALSF or MALS). If medium intensity approach lights are to be installed without sequenced flashing lights, apply only the applicable portions of the paragraphs for MALSF.
- Omni-directional Approach Lighting System (ODALS).
- Runway End Identifier Lights (REIL).
- PAPI

7.3. Selection Considerations.

Select a particular system on the basis of an operational requirement for light signals in addition to runway edge lights. Consider the following when selecting an economy approach lighting aid:

7.3.1 The airport's current operations and forecasts for three years indicate that the airport will not meet the criteria under the FAA's planning standards for the installation of an instrument landing system/approach lighting system (ILS/ALS). See the paragraphs below for a listing of FAA owned approach lighting systems. (Configurations and design details pertaining to these systems are in FAA JO 6850.2, *Visual Guidance Lighting Systems*.)

7.3.2 The runway to be served has at least a MIRL lighting system.

7.3.3 If installing a **Medium-Intensity Approach Lighting Systems with Runway Alignment Indicator Lights (MALSF)**, the airport should have assigned, or have the potential for, a non-precision instrument approach procedure other than ILS/precision approach radar (PAR). See AC 150/5300-13, paragraph 317, for additional information about non-precision approach requirements.

- 2902 7.3.4 MALSF and REIL are not installed on the same end of a runway. If required, install
2903 PAPI with either MALSF or REIL on the same end of a runway.
- 2904 7.3.5 MALSFs are not installed where in-pavement approach light fixtures are required.
- 2905 7.3.6 Prior to selecting a lighting aid, discuss with regional airport FAA personnel the
2906 operations and environmental needs of the individual site. In addition, make an
2907 individual site evaluation to determine which aid will best serve in reducing the
2908 deficiency(s) in a particular area. Reduction to instrument approach minimums may be
2909 made per FAA Order 8260.3B, *U.S. Standard for Terminal Instrument Procedures*.
2910 Use the following information as a guide for selecting a particular system.
- 2911 7.3.6.1 **MALS/MALSF.**
2912 These systems provide early runway lineup and lead-in guidance, runway
2913 end identification and roll guidance. The lights are also helpful during
2914 some periods of restricted visibility.
- 2915 7.3.6.1.1 MALS is beneficial where extraneous lighting prevents the pilot from
2916 lining up with the runway centerline or where the surrounding terrain is
2917 devoid of lighting and does not provide the cues necessary for proper
2918 aircraft attitude control.
- 2919 7.3.6.1.2 At locations where approach area identification is difficult at night due to
2920 surrounding lights, MALSF installed at the three outermost bars should
2921 resolve this problem.
- 2922 7.3.6.1.3 See FAA JO 6850.2, *Visual Guidance Lighting Systems*, for details on
2923 Medium-intensity Approach Lighting Systems with Runway Alignment
2924 Indicator Lights (MALSR).
- 2925 7.3.6.2 **REIL.**
2926 These lights aid in early identification of the runway and runway end.
- 2927 7.3.6.2.1 REIL are more beneficial in areas having a large concentration of lights
2928 and in areas of featureless terrain. They must be installed where there is
2929 only a circling approach or a circling and non-precision straight-in
2930 approach.
- 2931 7.3.6.2.2 If it is operationally acceptable at an airport, omnidirectional REIL
2932 provides good circling guidance and is the preferred system.
- 2933 7.3.6.2.3 Unidirectional REIL must be installed where environmental conditions
2934 require that the area affected by the flash from the REIL be greatly
2935 limited.
- 2936 7.3.6.3 **ODALS.**
2937 This system provides visual guidance for circling, offset, and straight-line
2938 approaches to non-precision runways.

- 2939 7.3.6.3.1 ODALS (or MALS, SSALS, SALS) is required where the visibility
 2940 minimum is less than one statute mile, **the paved runway length is at least**
 2941 3,200 ft. (975 meters), and **the runway is equipped with MIRL.**
- 2942 7.3.6.3.2 ODALS is recommended for a minimum visibility **of one** statute mile on
 2943 runways **that are at least** 3,200 ft. **and equipped** with MIRL/LIRL.
- 2944 7.3.6.3.3 See AC 150/5300-13 for additional details about ODALS and runway
 2945 lengths less than 3,200 ft.
- 2946 7.3.6.3.4 ODALS use for unpaved runways **requires** an evaluation by the regional
 2947 Flight Standards personnel before it can be implemented.
- 2948 7.3.6.4 **PAPI.**
 2949 This system enhances safety by providing beneficial visual approach slope
 2950 guidance to assist the pilot of an aircraft in flying a stabilized approach.
- 2951 7.3.6.4.1 **PAPI** has an effective visual range of approximately 5 miles during the
 2952 day and up to 20 miles at night.
- 2953 7.3.6.4.2 The presence of objects in the approach area may present a serious hazard
 2954 if an aircraft descends below the normal path. This is especially true
 2955 where sources of visual reference information are lacking or deceptive:
 2956 i.e., hilltops, valleys, terrain grades, and remote airports.
- 2957 7.3.6.4.3 PAPI **helps** the pilot maintain a safe distance above hazardous objects.
- 2958 7.3.6.4.4 The visual aiming point obtained with PAPI reduces the probability of
 2959 undershoots or overshoots.
- 2960 7.3.6.4.5 The 2-box PAPI system (**L-881**) is normally installed on runways that are
 2961 not provided with electronic guidance, on non-Part 139 airports, or when
 2962 there is a serious hazard where the aircraft descends below the normal
 2963 approach path angle. The system can be expanded to a 4-box system (**L-**
 2964 **880**) when jet aircraft operations are introduced at a future time.

2965 7.4. **Configurations.**

2966 7.4.1 **MALSF.**

- 2967 7.4.1.1 Provide a configuration of steady burning and flashing lights arranged
 2968 symmetrically about and along the extended runway centerline per Figure
 2969 A-78. Begin the system approximately 200 ft. (61 m) from the runway
 2970 threshold and extend it to an **overall length of** approximately 1,400 foot
 2971 (427 m). (See Figure A-78 for tolerances.)
- 2972 7.4.1.2 Use seven light stations with five steady-burning lights at each station.
 2973 Provide one flashing light at each of the three outermost stations. At the
 2974 station 1,000 ft. (305 m) from the runway threshold, use two additional
 2975 bars (one of each side of the centerline bar) each with five steady-burning
 2976 lights.

2977	7.4.1.3	All lights in the system emit white light. Only two intensity steps are
2978		required for MALSF; three steps are desirable.
2979	7.4.2	<u>REIL.</u>
2980	7.4.2.1	Provide two flashing lights near the end of the runway as shown in <u>Figure</u>
2981		<u>A-79</u> . The optimum location of the lights is 40 ft. (12 m) from the runway
2982		edge, and in line with the existing runway threshold lights.
2983	7.4.2.2	The light units may be located laterally up to 75 feet (23 m) from the
2984		runway edge and longitudinally 30 feet (9 m) downwind and 100 feet (27
2985		m) upwind from the line of threshold lights.
2986	7.4.2.3	These location tolerances ensure that the light units a minimum distance of
2987		40 feet (12 m) from other runways or taxiways.
2988	7.4.3	<u>ODALS.</u>
2989	7.4.3.1	Provide seven omnidirectional sequenced discharge type strobe lights in
2990		the runway approach area.
2991	7.4.3.2	Install five runway alignment strobe lights along the extended runway
2992		centerline beginning 300 ft. (91 meters) from the threshold and spaced 300
2993		ft. (91 meters) apart.
2994	7.4.3.3	Place one runway end identifier light 40 ft. (12 meters) from each of the
2995		left and right runway edges adjacent to the runway threshold.
2996	7.4.3.4	The ideal ODALS system consists of all seven strobe lights in a single
2997		horizontal plane.
2998	7.4.3.5	Sloping installations are permitted with a maximum positive slope of 2
2999		percent and a maximum negative slope of one percent. See <u>Figure A-80</u>
3000		for a typical ODALS layout.
3001	7.4.4	<u>PAPI.</u>
3002	7.4.4.1	Provide light units that project the visual signal towards an approaching
3003		aircraft with the innermost light unit located 50 ft. (15 m) from the left
3004		runway edge.
3005	7.4.4.2	Install the light units in a line perpendicular to the runway edge. Each
3006		light unit emits a two-color (red and white) light beam. When the light
3007		units are properly aimed, the optical system provides visual approach
3008		slope information.

3009 7.4.4.3 Where terrain, intersecting runways, or taxiways make an installation on
3010 the left side of the runway impractical, the light housing units may be
3011 located on the right side of the runway.

3012 7.4.4.4 See paragraph 7.5.4.6 for **PAPI** aiming criteria. See Figure A-82 for PAPI
3013 signal presentation as seen from the approaching aircraft.

3014 **Note:** If the PAPI is installed on the right-hand side of the runway, the light housing
3015 assemblies nearest the runway (inboard) must be seen as red and the two farthest from
3016 runway (outboard) must be seen as white. See Figure A-82.

3017 7.5. **Design.**

3018 7.5.1 **MALSF.**

3019 7.5.1.1 **Electrical Systems.**

3020 The design of the electrical system is identified by the method used to
3021 control the on/off operation of the lights. The controls available are
3022 remote, radio, and control from the runway edge lighting circuit. Select
3023 the type of control best suited for the airport's operation.

3024 7.5.1.1.1 **Remote Control.**

- 3025 1. A typical remotely controlled system consists of on/off and brightness
3026 switches, control relays, distribution transformers, MALSF equipment,
3027 and interconnecting wires. See Figure A-84 for a typical wiring
3028 diagram.
- 3029 2. Normally the initial installation cost for remote controls is more than
3030 that for a system with radio controls or controls from the runway
3031 lighting circuit.

3032 7.5.1.1.2 **Radio Control.**

- 3033 1. Use the system wiring diagram per Figure A-84 with the exceptions
3034 listed below.
- 3035 2. Select radio controls if the lights are **routinely** needed for short
3036 duration (less than 15 minutes at a time).
- 3037 3. Locate the **L-854** (see AC 150/5345-49) near the MALSF to eliminate
3038 costly underground cables.
- 3039 4. Substitute the L-854 radio controls for the on/off switch per Figure
3040 A-84 and use a control relay with a coil compatible with the output of
3041 the L-854 receiver.
- 3042 5. Use a photoelectric device in lieu of the high/low switch per Figure
3043 A-84.

7.5.1.1.3 Runway Lighting Circuit Control.

1. See Figure A-85 for a typical system controlled from the runway edge lighting circuit. Use components such as an isolation transformer, a series control device, and a distribution transformer in conjunction with the MALSF equipment to assure proper on/off operation.
2. Select the brightness control as specified in FAA Order 6850.2.

7.5.1.1.4 Power Supply and Wiring.

1. Use a distribution transformer with a center tap to obtain the 120-volt AC and 60-volt AC input to the MALS PAR 38 spotlights. As an alternate, use two distribution transformers with the necessary switching equipment to connect these transformers alternately in series and parallel to obtain 120-volt AC and 60-volt AC across the MALS PAR 38, 120-watt spotlights. Obtain the high setting of the MALS lamp with the 120-volt AC and the low setting with the 60 volts.
2. Transformer Rating. Obtain a transformer with a minimum rating of 10 kilowatts at 120-volt AC, 60 Hz. Use this power to supply the lamp load and field wiring per Figure A-86. Select a transformer designed to carry the rated load continuously under expected environmental conditions.
3. Field Wire Sizes. Calculate the minimum wire sizes for each installation. If the field wiring is similar to the typical layout per Figure A-86, use a No. 4 AWG wire (maximum) for power circuits and a No. 19 AWG wire (minimum) for sequenced flashing lights timing circuits. Provide not less than 114 volts, 60 Hz, nor more than 126 volts AC, 60 Hz at all steady-burning and flashing MALSF lamps.

7.5.1.1.5 Structures.

1. Where possible, mount all lights in the inner 1,000 ft. (305 m) section of the MALSF on frangible structures, meeting the RSA standards of AC 150/5300-13.
2. Use semi-frangible structures at all light stations of the MALSF where the distance from ground level to lamp center is over 40 ft. (12 m). Semi-frangible structures have the upper 20-foot (6 m) portion frangible and the remaining portion rigid.
3. Structure must be per FAA-E-2702, *Specification for Low Impact Resistant Structures*, and AC 150/5345-45, *Low-Impact Resistant (LIR) Structures*.

7.5.2 REIL.

7.5.2.1 Electrical Systems.

Design the system to permit operation of the light units within the rated tolerances of the equipment. Select light units that operate either in a

parallel circuit or series circuit. Light units **must** conform to AC 150/5345-51, Specification for Discharge-Type Flashing Light Equipment, Type L-849.

7.5.2.1.1

Controls.

Control the operation of the light units with one of the methods listed below:

1. Remote Controls. Provide an on/off switch per Figure A-88 at a remote location. Use this switch to control the input power to the light unit. Select a switch rated to carry continuously the required rated load. Figure A-88 shows a **generic** single intensity system powered by 120/240-volt AC. See the manufacturer's installation instructions for three-step intensity control remote control.
2. Radio Controls. Use the L-854 receiver in conjunction with a pilot relay to control the light units. Select a relay with contacts rated to carry continuously the required rated load.
3. Runway CCR Controls.
 - a. See Figure A-89 for a typical installation of REIL in a series lighting circuit. Provide a selector switch to permit the independent control of the REIL, though the REIL may share a common power source with the runway edge lights.
 - b. A series circuit adapter may be required to provide operating power to the REIL from the series lighting circuit.
 - c. Some manufacturers may include the series adapter as part of the control cabinet. Include any current sensing options (if required) for a three-intensity step REIL for both parallel and series power.
 - d. Consult the manufacturer's representative for information relevant to options and configurations.

7.5.2.1.2

Power Supply and Wiring.

1. Use a source capable of producing 120-volt AC ± 6 volts, 60 Hz or 240-volt AC ± 12 volts, 60 Hz at the terminal of a 1.3 kilowatt inductive load.
2. Calculate the wire size used to connect the multiple light units to the source voltage. See Figure A-89 for a typical example.
3. Use 5 kilovolt (kV) cables (L-824) for connecting REIL **lights** into series circuits.
4. If using a CCR for REIL primary power, ensure that the CCR will accommodate a pulsing load that may have reactive components.
5. Consult the manufacturers of both the CCR and REIL before making a final decision.

3123	7.5.2.2	Structures.
3124	7.5.2.2.1	Install per the manufacturer's requirements.
3125	7.5.2.2.2	Use a 2.197 inch (56 mm) or 2.375 inch (60 mm) outside diameter pipe
3126		support to secure the light unit.
3127	7.5.2.2.3	Ensure that any frangibility requirements are addressed for the equipment
3128		installation. See <u>AC 150/5345-51</u> for additional information about
3129		frangible couplings. See also <u>Figure A-93</u> .
3130	7.5.3	<u>ODALS.</u>
3131	7.5.3.1	Electrical Systems.
3132	7.5.3.1.1	The ODALS electrical system design is primarily based upon the method
3133		used to control the on/off operation of the lights.
3134	7.5.3.1.2	The controls available are remote, radio, and control from the runway
3135		edge lighting circuit.
3136	7.5.3.1.3	Select the type of control best suited for the airport's operation.
3137	7.5.3.1.4	See <u>AC 150/5345-51</u> L-859V (powered by airport voltage source) or L-
3138		859I (powered by airport series 6.6 Amp power source).
3139	7.5.3.1.5	ODALS requires three intensity steps, HIGH, MEDIUM, and LOW. For
3140		voltage powered systems, intensity control will be internally generated.
3141	7.5.3.1.6	For series powered ODALS, 6.6A corresponds to HIGH, 5.5A to
3142		MEDIUM, and 4.8A to LOW intensity.
3143	7.5.3.1.7	See the manufacturer's approved installation manual for additional details
3144		and criteria.
3145	7.5.4	<u>PAPI.</u>
3146	7.5.4.1	Siting Considerations.
3147	7.5.4.1.1	Locate the PAPI system at the approach end of the runway on the left side.
3148	7.5.4.1.2	Site and aim the PAPI so it defines an approach path with sufficient
3149		clearance over obstacles and a minimum threshold crossing heights per
3150		<u>Table 7-1</u> .
3151	7.5.4.1.3	See the manufacturer's installation manual for a light housing assembly
3152		(LHA) aiming procedure.
3153	7.5.4.1.4	Other PAPI alignment tolerances and considerations common to
3154		installations are in paragraph <u>7.5.4.7</u> .
3155	7.5.4.2	Siting PAPI on a Runway with an ILS Glide Path.
3156	7.5.4.2.1	When siting PAPI on a runway with an ILS, the PAPI visual approach
3157		path coincides with the ILS glide path.

- 3158 7.5.4.2.2 **Place** the PAPI at the same distance from the threshold as the touchdown
 3159 point of the ILS glide path with a tolerance of ± 30 ft. (± 10 m).
- 3160 7.5.4.2.3 If the PAPI is installed on an ILS runway primarily used by aircraft in
 3161 height group 4 (see Table 7-1), the PAPI distance from the threshold must
 3162 equal the distance to the ILS glide path touchdown point plus an additional
 3163 300 ft. +50, -0 (90 m +15, -0) from the runway threshold.
- 3164 7.5.4.3 **Siting PAPI on a Runway Without an ILS Glide Path.**
 3165 When a runway is not ILS equipped, **align** the **PAPI's** position and aiming
 3166 to produce the required threshold crossing height and obstacle clearance
 3167 for the runway approach path per the following:
- 3168 **Note:** The following method can be used to determine the PAPI distance
 3169 from the runway threshold provided there are no obstacles in the area from
 3170 which the PAPI signals can be observed, no differences in elevation
 3171 between the threshold and the installation zone of the PAPI or between the
 3172 units, **and there is no** reduced length of runway.
- 3173 7.5.4.3.1 **Calculate the distance of the PAPI units from the runway threshold**
 3174 **using the following equation:**
 3175 $D1 = TCH \times \text{cotangent (angle of lowest on-course signal)}$
 3176 $D1 = \text{calculated distance of the PAPI unit from the runway threshold}$
 3177 $TCH = \text{threshold crossing height}$
- 3178 7.5.4.3.2 The TCH is determined by the height group of aircraft that primarily use
 3179 the runway. Refer to Table 7-1 **to** determine the recommended TCH.
- 3180 7.5.4.3.3 Refer to Table 7-2 **to** determine the lowest on-course signal for the third
 3181 light unit from the runway edge - 10 minutes (') below glidepath.
- 3182 7.5.4.3.4 The standard visual glideslope for PAPI is 3° . For non-jet runways, the
 3183 glideslope may be increased to 4° to provide obstacle clearance.
- 3184 7.5.4.3.5 **The aiming angle of the third light unit is:**
 3185 $3^\circ - 10' = 2^\circ 50'$
- 3186 7.5.4.3.6 **Determine the distance of the PAPI from the runway threshold (TCH**
 3187 **= 45 ft., Height Group 2):**
 3188 $D1 = 45 \times \text{cotangent } 2^\circ 50' (2^\circ 50' = 2.833^\circ) (\text{cotangent} = 1/\tan)$
 3189 $D1 = 45 \times 20.20579$
 3190 $D1 = 909.26$ ft. from the runway threshold
- 3191 7.5.4.4 **PAPI OCS.**
- 3192 7.5.4.4.1 The PAPI obstacle clearance surface is established to provide the pilot
 3193 with a minimum clearance over obstacles during approach. **Reference**
 3194 Figure A-81.
- 3195 7.5.4.4.2 **Position and aim** the PAPI so that no obstacles penetrate this surface.

- 3196 7.5.4.4.3 The surface begins 300 ft. (90 m) in front of (closer to the runway
3197 threshold) the PAPI system and proceeds outward into the approach zone
3198 at an angle one degree less than the aiming angle of the third LHA (lowest
3199 on course signal, L-880) from the runway.
- 3200 7.5.4.4.4 For an L-881 PAPI (two box), the lowest on course signal is for the unit
3201 farthest from the runway.
- 3202 7.5.4.4.5 The OCS extends 10° on either side of the runway centerline to a distance
3203 of 4 miles (6.44 km) from the point of origin.
- 3204 **Note:** See paragraph 7.7.6.6.4 item 3 for additional information about
3205 commissioning inspections. Areas outside of the OCS may be considered
3206 by inspectors.
- 3207 7.5.4.4.6 Position and aim the PAPI so that there is no risk of an obstruction
3208 penetrating the OCS. Perform a site survey to verify that an obstacle will
3209 not penetrate the OCS.
- 3210 7.5.4.4.7 If an obstruction penetrates the OCS and cannot be removed, increase the
3211 PAPI glideslope angle or move the PAPI farther from the threshold to
3212 provide an increased TCH equal to the obstacle penetration height. Use
3213 the following formula:
3214
$$D1 = TCH + H \times \cotangent \theta$$

3215 where:
3216 D1 = calculated distance of the PAPI from the runway threshold
3217 TCH = threshold crossing height
3218 H = the height of the object above the OCS
3219 θ = PAPI lowest on course signal
- 3220 7.5.4.5 **Threshold Crossing Height (TCH).**
3221 The TCH is the height of the lowest on-course signal at a point directly
3222 above the intersection of the runway centerline and the threshold.
- 3223 7.5.4.5.1 The minimum TCH varies with the height group of aircraft that primarily
3224 use the runway.
- 3225 7.5.4.5.2 The PAPI approach path must provide the proper TCH for the most
3226 demanding height group using the runway per Table 7-1.
- 3227 7.5.4.6 **PAPI Aiming.**
3228 The standard aiming angles for Type L-880 and Type L-881 systems are
3229 shown in Table 7-2 and Table 7-3.

3230

Table 7-1. Threshold Crossing Heights.

Representative aircraft. Type	Approximate Cockpit-to-wheel height	Visual Threshold Crossing Height	Remarks
<u>Height Group 1</u> General aviation Small commuters Corporate turbo jets	10 ft. (3 m) or less	40 ft. (+5, -20) 12 m (+2, -6)	Many runways less than 6,000 ft. (1829 m) long with reduced widths and/or restricted weight bearing that would normally prohibit landings by larger aircraft.
<u>Height Group 2</u> F-28, CV-340/440/580 B-737, DC-9, DC-8	15 ft. (4.5 m)	45 ft. (+5, -20) 14 m (+2, -6)	Regional airport with limited air carrier service
<u>Height Group 3</u> B-727/707/720/757	20 ft. (6 m)	50 ft. (+5, -15) 15 m (+2, -6)	Primary runways not normally used by aircraft with ILS glide-path-to-wheel heights exceeding 20 ft. (6 m).
<u>Height group 4</u> B-747/767, L-1011, DC-10 A-300	Over 25 ft. (7.6 m)	75 ft. (+5, -15) 23 m (+2, -4)	Most primary runways at major airports.

3231

Table 7-2. Aiming of Type L-880 (4 Box) PAPI Relative to Pre-Selected Glide Path.

Light Unit	Aiming Angle (in minutes of arc)	Height group 4 aircraft on runway with ILS
	Standard installation	
Unit nearest runway	30' above glide path	35' above glide path
Next adjacent unit	10' above glide path	15' above glide path
Next adjacent unit	10' below glide path	15' below glide path
Next adjacent Unit	30' below glide path	35' below glide path

Table 7-3. Aiming of Type L-881 (2 Box) PAPI Relative to Pre-Selected Glide Path.

Light Unit	Aiming angle (in minutes of arc)
Unit nearest runway	15' above glide path
Unit farthest from runway	15' below glide path

7.5.4.7 Other Siting Dimensions and Tolerances.

7.5.4.7.1 Distance from Runway Edge:

1. The inboard light unit must be not less than 50 ft., +10, -0, (15 m, +3, -0) from the runway edge (see Figure A-81) or **from** other runways or taxiways.
2. The distance from the runway edge may be reduced to 30 ft. (10 m) for small general aviation runways used by non-jet aircraft.

7.5.4.7.2 Separation Between Light Units:

1. PAPI light units must have a lateral separation of:
 - a. Between 20 and 30 ft. (6 to 9 m) for L-880 systems.

Note: the distance between light units is measured center to center.

- b. For the L-880, the distance between light units may not vary by more than ± 1 foot (0.3 m).

7.5.4.7.3 Azimuth Aiming.

Aim each light unit outward into the approach zone on a line parallel to the runway centerline within a tolerance of $\pm 1/2$ degree.

7.5.4.7.4 Mounting Height Tolerances.

1. The beam centers of all light units must be within ± 1 inch of a horizontal plane.
2. The PAPI horizontal plane must be within 1 foot (0.3 m) of the elevation of the runway centerline at the intercept point of the visual glide path with the runway (except for the siting conditions in paragraph 7.5.4.7.7 below).

7.5.4.7.5 Tolerance Along Line Perpendicular to Runway.

The front face of each light unit in a bar must be located on a line perpendicular to the runway centerline within +6 inches (+152 mm).

7.5.4.7.6 Correction for Runway Longitudinal Gradient (see Figure A-83).

1. On runways where there is a difference in elevation between the runway threshold and the PAPI, it may be necessary to adjust the location of the light units with respect to the threshold to meet the required obstacle clearance and TCH.

2. When an elevation difference exists, **use** the following steps (reference Figure A-83) to compute the change in the distance from the threshold required, **to** preserve the proper geometry.

- a. Obtain the runway longitudinal gradient (RWY) from “as-built” drawings or airport obstruction charts.

Note: If the information cannot be obtained from the above sources, **perform** a survey to obtain RWY.

- b. Determine the ideal (D1, zero gradient) PAPI distance from the runway threshold (T).

- c. Assume a level reference plane at the runway threshold elevation. Plot the location determined in (2) above.

- d. Plot the runway longitudinal gradient (RWY).

- e. Project the visual glide path angle (θ) to its intersection with the runway longitudinal gradient (RWY).

- f. Solve for the adjusted distance from threshold (d) either mathematically or graphically.

- g. Double-check to see that the calculated location gives the desired TCH.

7.5.4.7.7 Additional Siting Considerations.

1. If the terrain drops off rapidly near the approach threshold and severe turbulence is **common at that location**, **place the** PAPI farther from the threshold to keep the aircraft at the maximum possible threshold crossing height.
2. For short runways, **locate** the PAPI as near the threshold as possible to provide the maximum amount of runway for braking after landing.
3. At locations where snow is likely to obscure the light beams, the light units may be installed so the top of the unit is a maximum of 6 ft. (2 m) above ground level.
4. PAPI LHAs must not be located closer than 50 ft. from a crossing runway, taxiway, or warm-up apron or within the ILS critical area.
5. The inboard light housing may be located up to 75 ft. (23 m) from the runway edge where damage may occur arising from jet blast and wing vortices. **Submit** this deviation from standard to the local Airport District Office for approval prior to installation.

Notes:

1. Increasing the height of the PAPI light units also raises the **TCH** for the glide path.
2. This may also require locating the light units farther from the runway edge to ensure adequate clearance for aircraft.

3. The location for the light units (closer to the runway threshold) must be recalculated to maintain the correct TCH and OCS.

7.5.4.8 **Electrical Systems.**

Select equipment and connect the light units for continuous operation, series operation. See Figure A-90 and Figure A-91 for typical wiring diagrams.

7.5.4.8.1 **Continuous Operation.**

Provide a continuous power source to permit the PAPI to be energized at all times.

7.5.4.8.2 **Series Operation.**

1. Use isolation transformers (not supplied with PAPI equipment) in conjunction with the light unit to connect them into the series lighting circuit.
2. The CCR will control the brightness of the system. Select a series circuit capable of accepting an additional load for each installation.
3. Provide a selector switch per Figure A-91 to permit independent control of the PAPI.
4. At an existing runway lighting installation, the 2-box PAPI may be connected into the series runway lighting circuit; however, **this requires** burning the runway edge lights at top brightness if approach slope information is needed during **the** daytime.

7.5.4.8.3 **Multiple Operation.**

1. Use the light boxes with accessories provided for **in this** specification to permit operation from a 2 kW, 120-volt AC ± 10 percent, 60 Hz source or a 240 volt ± 10 percent, 60 Hz source.
2. Control the on/off operation of the light units with a remote switch or with radio controls.
3. Provide pilot relays with contacts rated to operate the 2-kilowatt load on a continuous basis.

7.5.4.8.4 **Wire.**

Use No. 8 AWG wires to connect light units in series circuits. Make connections to multiple circuits with wire insulated for 600 volts, minimum.

7.5.4.9 **Foundation.**

See Figure A-92 for design details for the light unit's foundation.

7.5.4.10 **Feeder Circuit.**

The PAPI may be specified to operate from a standard utility voltage (Style A) or from a constant current power supply (Style B).

- 3341 7.5.4.10.1 The power cable must be per FAA Type L-824 per AC 150/5345-7,
 3342 *Specification for L-624 Underground Electrical Cable for Airport*
 3343 *Lighting Circuit*, or equivalent.
- 3344 7.5.4.10.2 Lightning arresters for both power and control lines must be provided per
 3345 AC 150/5345-28, *Precision Approach Path Indicator (PAPI) Systems*.
 3346 **Note:** The output power lines for an L-828 CCR used for Style B systems
 3347 already have integral lightning protection.
- 3348 7.5.4.10.3 **Ensure** all fuses or circuit breakers **are** within the equipment ratings.
- 3349 7.5.4.11 **Style A PAPI Systems.**
- 3350 7.5.4.11.1 **Input Voltage.**
 3351 Although PAPI systems may be designed to operate from any standard
 3352 utility voltage:
- 3353 1. Ensure the PAPI will operate from the airfield service voltage
 3354 available and avoid installing a transformer for the system operating
 3355 voltage.
 - 3356 2. Determine if there is any fluctuation in the utility line voltage
 3357 exceeding the PAPI power design limits that will cause reduced lamp
 3358 life.
 - 3359 3. If the line voltage variations exceed the PAPI power regulation limits,
 3360 then **provide** a voltage regulator to ensure the PAPI provides its
 3361 specified lamp brightness.
 - 3362 4. **Size** the power distribution cabling to individual light units so that any
 3363 voltage drop does not exceed the PAPI power design limits.
- 3364 7.5.4.11.2 **Location of the PCU.**
- 3365 1. **Locate** the PCU as far from the runway as possible for a minimum
 3366 obstruction to aircraft.
 - 3367 2. If the PCU is integral with a light unit, place **it** farthest from the
 3368 runway.
 - 3369 3. If the PCU is a separate unit, mount **it** at the minimum possible height,
 3370 and locate **it** outside the RSA.
 - 3371 4. If the PCU cannot be located outside the RSA, it must be mounted
 3372 with frangible couplings and breakaway cabling.
- 3373 7.5.4.12 **Style B PAPI System.**
- 3374 7.5.4.12.1 PAPI systems that operate from a constant current source must use several
 3375 types of FAA equipment:
- 3376 1. The system power source is an L-828 CCR (AC 150/5345-10), with an
 3377 output current of 6.6 amps.

- 3378 2. The CCR automatically compensates for up to -5 percent to +10
3379 percent deviations from its nominal input voltage, and may be ordered
3380 with three or five brightness steps.
- 3381 3. The five-step CCR is recommended, since the lowest brightness step
3382 on a three-step CCR may be too bright for some rural PAPI
3383 installations.
- 3384 7.5.4.12.2 The output of the CCR powers L-830 isolation transformers (per AC
3385 150/5345-47). The isolation transformer wattage must be chosen for PAPI
3386 maximum load.
- 3387 7.5.4.13 **Wiring the PAPI Light Units.**
- 3388 7.5.4.13.1 For Style A systems, the cable used to deliver the power to the individual
3389 light units must be a gauge large enough to minimize any voltage drop.
- 3390 7.5.4.13.2 Ensure all PAPI light boxes are properly grounded to the connection point
3391 provided by the manufacturer.
- 3392 7.5.4.13.3 All wiring entering the PAPI light unit must be through plugs and
3393 receptacles that will separate if the box is struck by an aircraft. The
3394 receptacles are located and secured at the frangible couplings.
- 3395 7.5.4.13.4 A length of flexible watertight conduit conveys the PAPI wiring between
3396 the frangible coupling and the PAPI light box. The flexible conduit is
3397 required so the PAPI box has sufficient movement for proper aiming.
- 3398 7.5.4.13.5 **Make** all underground connections with either splices or plugs, and **with**
3399 receptacles per AC 150/5345-26, *FAA Specification For L-823 Plug And*
3400 *Receptacle, Cable Connectors*.
- 3401 7.5.4.14 **PAPI Lamp Brightness Control.**
- 3402 7.5.4.14.1 **Style A Systems.**
- 3403 1. The Style A PAPI system automatically selects day or night intensity
3404 settings with a photocell.
- 3405 2. There are two night-intensity settings (one time manual configuration),
3406 approximately 5 and 20 percent of full intensity when the PAPI is in
3407 night mode.
- 3408 7.5.4.14.2 **Style B Systems.**
- 3409 The lamp intensity of style B systems is controlled by the tap settings on
3410 an L-828 regulator. See AC 150/5345-10.
- 3411 1. We recommend that the PAPI not be powered from a runway edge
3412 lighting circuit, as this requires the edge lights to be at full intensity
3413 during day operations.
- 3414 2. A dedicated L-828 CCR with five current steps (2.8 to 6.6A) is the
3415 preferred method of powering the PAPI.

- 3416 3. The CCR current steps may be controlled either manually or
3417 automatically via a photocell.
- 3418 **7.5.4.15 PAPI Power Control.**
3419 The PAPI may be turned on and off by a number of different methods.
- 3420 **7.5.4.15.1** For Style A systems, a contactor is provided in the PCU, allowing the
3421 system to be turned on and off via control signals.
- 3422 **7.5.4.15.2** For Style B systems, the PAPI is turned on and off by the L-828 CCR
3423 control circuitry.
- 3424 **7.5.4.15.3** The remote control that activates either Style A or B systems may be
3425 located in the control tower, flight service station, or other attended
3426 facility.
- 3427 **7.5.4.15.4** Alternatively, the PAPI power control lines may be activated by an L-854
3428 radio control receiver (see AC 150/5345-49).
- 3429 **7.5.4.15.5** The L-854 allows the PAPI to be energized by either a pilot on approach,
3430 or by an airport ground control station. **See Chapter 8 for additional**
3431 **information.**
- 3432 **7.5.4.16 Other PAPI Power Control Configurations.**
- 3433 **7.5.4.16.1 PAPIs On Both Runway Ends.**
- 3434 1. It is desirable to independently control PAPIs for each runway end,
3435 energizing only the PAPI that serves the active runway end.
- 3436 2. Turning off both systems when the runway is inactive conserves
3437 energy.
- 3438 **7.5.4.16.2 Interlock Relay.**
- 3439 1. During the night, it is desirable that the PAPI be energized only when
3440 the runway lights are on.
- 3441 2. To provide this feature, **install** an interlock relay in series with the
3442 night intensity contacts on the photocell controller.
- 3443 3. The normally open contacts of the interlock relay are closed only when
3444 it is night or the runway edge lights are on.
- 3445 4. Daylight PAPI operation must not be affected.
- 3446 **7.5.4.17 Style B PAPI Lamp Bypass.**
- 3447 **7.5.4.17.1** CCRs will increase the output current as the number of isolation
3448 transformers with an open secondary (caused by burned-out lamps)
3449 increases.
- 3450 **7.5.4.17.2** The increased current will cause more lamp failures, increasing the
3451 regulator current. This situation is particularly critical when the connected
3452 load is small (less than 50 percent) compared to the CCR rating.

3453 7.5.4.17.3 A lamp bypass device prevents the runaway effect by shorting the
3454 secondary of the isolating transformer and simulating the resistance of a
3455 lamp.

3456 7.5.4.17.4 Lamp bypass devices are an optional feature, **but** are recommended for all
3457 Style B PAPIs powered by resonant-type CCRs.

3458 7.6. **Equipment and Material.**

3459 7.6.1 Specifications and Standards.

3460 7.6.1.1 Equipment and material covered by specifications are referred to by
3461 specification number.

3462 7.6.1.2 Use distribution transformers, oil switches, cutouts, relays, terminal
3463 blocks, transfer relays, circuit breakers, photoelectric controls, and all
3464 other commercial items of electrical equipment not covered by FAA
3465 specifications that conform to the applicable rulings and standards of the
3466 electrical industry.

3467 7.6.2 Shelter.

3468 If power supplies and accessories are not designed for outdoor service, enclose them in
3469 a prefabricated metal housing or other outdoor enclosure conforming to industry
3470 standards.

3471 7.6.3 Wires.

3472 Use No. 12 to No. 4 AWG wires per AC 150/5345-7. Use No. 19 AWG wires per
3473 ANSI/ICEA S-85-625, *Telecommunications Cable Air Core, Polyolefin Insulated,*
3474 *Copper Conductor, Technical Requirements.*

3475 7.6.4 Concrete.

3476 Use concrete and reinforcing steel per AC 150/5370-10, Item P-610.

3477 7.6.5 Radio Controls.

3478 Select radio controls per Chapter 8.

3479 7.6.6 Isolation Transformer.

3480 If control is provided from the runway lighting circuit, select an isolation transformer
3481 per FAA Order JO 6850.2, *Visual Guidance Lighting Systems*, to obtain a sensing
3482 current from the circuit.

3483 7.6.7 MALSF.

3484 7.6.7.1 **Equipment.**

3485 Select equipment per the guidance in Specification FAA-E-2325, *Medium*
3486 *Intensity Approach Lighting System with Runway Alignment Indicator*
3487 *Lights.*

- 3488 7.6.7.2 **Aiming Device.**
3489 Obtain a device for aiming the light units from the equipment
3490 manufacturer.
- 3491 7.6.8 REIL.
- 3492 7.6.8.1 **Light Unit.**
3493 Only select condenser discharge lights and accessories per AC 150/5345-
3494 51. Obtain L-868 fittings to permit the installation of the light unit on a
3495 2.197-inch (56 mm) or 2.375-inch (60 mm) diameter frangible vertical
3496 support.
- 3497 7.6.8.2 **Aiming Device.**
3498 Obtain a device for aiming the REIL unit from the equipment
3499 manufacturer.
- 3500 7.6.9 ODALS.
3501 Select equipment per AC 150/5345-51.
- 3502 7.6.10 PAPI.
- 3503 7.6.10.1 **Light Unit.**
3504 Select light units per AC 150/5345-28. Items not covered in the
3505 specification are provided by the installation contractor.
- 3506 7.6.10.2 **Aiming Device.**
3507 Obtain a device for aiming the PAPI light unit from the equipment
3508 manufacturer.
- 3509 See Chapter 12 for additional information.
- 3510 7.7. **Installation.**
3511 Install the economy approach lighting aid per AC 150/5370-10. Additional details are
3512 contained in the following paragraphs:
- 3513 7.7.1 Wiring.
3514 Install underground cable per the requirements of AC 150/5370-10, Item L-108. Make
3515 installations of wiring in vaults or prefabricated metal housings per AC 150/5370-10,
3516 Item L-109.
- 3517 7.7.2 Duct.
3518 Install underground electrical duct per the requirements of AC 150/5370-10, Item
3519 L-110.
- 3520 7.7.3 Equipment.
3521 Assemble the lighting equipment per the manufacturer's instructions.

3522 7.7.4 MALSF.3523 7.7.4.1 **Approach Light Plane.**

3524 7.7.4.1.1 Define the approach light plane as an imaginary plane **that** passes through
3525 the beam center of the steady-burning lights in the system.

3526 7.7.4.1.2 The plane is rectangular in shape, 400 ft. (122 m) wide, and centered on
3527 the MALSF centerline.

3528 7.7.4.1.3 It originates at the landing threshold and extends 200 ft. (61 m) beyond the
3529 last light bar at the approach end of the MALSF.

3530 7.7.4.1.4 You may consider elevated lights in station 2 + 00, at runway elevation
3531 even though they project several inches above it (see FAA Order JO
3532 6850.2, *Visual Guidance Lighting Systems*, for additional information
3533 about station numbers).

3534 7.7.4.2 **Clearance.**

3535 7.7.4.2.1 Permit no objects above the approach light plane.

3536 7.7.4.2.2 For approach light plane clearance purposes, consider all roads, highways,
3537 vehicle parking areas, and railroads as vertical solid objects.

3538 7.7.4.2.3 Make the clearance required above interstate highways 17 ft. (5 m), for
3539 railroads 23 ft. (7 m), and for all other roads, highways, and vehicle
3540 parking areas 15 ft. (4.6 m).

3541 7.7.4.2.4 Measure the clearance for roads and highways from the crown and edges
3542 of the road and make measurements for railroads from the top of rails.

3543 7.7.4.2.5 Make measurements for vehicle parking area clearances from the grade in
3544 the vicinity of the highest point.

3545 7.7.4.2.6 Airport service roads, where vehicular traffic is controlled in any manner
3546 that would preclude blocking the view of the approach lights by landing
3547 aircraft, are not considered as obstructions in determining the approach
3548 light plane.

3549 7.7.4.3 **Location and Orientation.**

3550 7.7.4.3.1 Install all light bars perpendicular to the vertical plane containing the
3551 MALSF centerline.

3552 7.7.4.3.2 **Visibility.**

3553 1. Provide a clear line of sight to all lights of the system from any point
3554 on a surface, 1/2-degree below a 3-degree glide path, intersecting the
3555 runway 1,000 ft. (305 m) from the landing threshold.

3556 2. This line of sight applies to 250 ft. (76 m) each side of the entire length
3557 of the MALSF and extends up to 1,600 ft. (488 m) in advance of the
3558 outermost light in the system. See Figure A-78 for details.

- 3559 7.7.4.4 **Slope Gradient.**
3560 Keep the slope gradient as small as possible and do not exceed 2 percent
3561 for a positive slope or one percent for a negative slope. For additional
3562 guidance, see FAA JO 6850.2.
- 3563 7.7.4.5 **Frangible Structures.**
3564 Install frangible MALS structures per Figure A-87.
- 3565 7.7.4.6 **Equipment.**
3566 Assemble the lighting equipment per the manufacturer's instructions.
- 3567 7.7.5 **REIL.**
- 3568 7.7.5.1 **Location.**
3569 Locate **and aim** the REIL units per Figure A-79.
- 3570 7.7.5.1.1 When possible, install the two light units equidistant from the runway
3571 centerline.
- 3572 7.7.5.1.2 When location adjustments are necessary, the difference in the distance of
3573 the two lights to the runway centerline may not exceed 10 ft. (3 m).
- 3574 7.7.5.1.3 Each light unit must be a minimum of 40 ft. (12 m) from the edge of
3575 taxiways and other runways.
- 3576 7.7.5.1.4 The elevation of both units must be within 3 ft. (0.9 m) of a horizontal
3577 plane through the runway centerline, with the maximum height above
3578 ground limited to 3 ft. (0.9 m) (See Figure A-93.)
- 3579 7.7.5.1.5 When the centerline elevation varies, use the centerline point in line with
3580 the two units to measure the centerline elevation.
- 3581 7.7.5.1.6 Orient the beam axis of an un-baffled unit 15 degrees outward from a line
3582 parallel to the runway and inclined at an angle 10 degrees above the
3583 horizontal.
- 3584 7.7.5.1.7 If this standard setting is operationally objectionable, provide optical
3585 baffles (per the manufacturer's instructions) and orient the beam axis of
3586 the unit 10 degrees outward from a line parallel to the runway centerline
3587 and inclined at an angle of 3 degrees above the horizontal.
- 3588 7.7.5.2 **Structures.**
3589 See Figure A-93 for typical installation details.
- 3590 7.7.6 **PAPI.**
- 3591 7.7.6.1 **Location.**
3592 Locate the PAPI and aim the light units per Figure A-81.

- 3593 7.7.6.2 **Structures.**
3594 Install light units on supports and concrete foundations per Figure A-92.
- 3595 7.7.6.3 **Foundations.**
3596 7.7.6.3.1 **Make** foundations for mounting light boxes of concrete (or comparable
3597 material) and design **them** to prevent frost heave or other displacement.
- 3598 7.7.6.3.2 **Extend** the foundation at least 1 foot (0.3 m) below the frost line.
3599 7.7.6.3.3 A column may be provided under each mounting leg for attachment of the
3600 mounting flanges, or a pad with appropriate reinforcement may be used.
- 3601 7.7.6.3.4 The pad or surface stabilization must extend at least 1 foot (0.3 m) beyond
3602 the light boxes, to minimize damage from mowers, and should not be
3603 more than 1 inch (25 mm) above grade.
- 3604 7.7.6.3.5 **Mount** all PAPI light boxes to the foundation with frangible fittings.
3605 7.7.6.3.6 For Style B systems, a transformer housing may be installed in the pad
3606 below grade to provide both a convenient and protected location for the
3607 isolation transformer (see AC 150/5345-47).
- 3608 7.7.6.4 **Interfering Airport Lighting.**
3609 Because PAPI system is dependent upon the pilot seeing a red and/or
3610 white signal from the light units, **ensure** that no other lights are located
3611 close enough to the system to interfere with the signal presentation.
- 3612 7.7.6.5 **Electrical.**
3613 The PAPI installation must conform to the NEC and any local codes.
- 3614 7.7.6.5.1 **Make** all electrical connections to the light unit with plugs and receptacles
3615 designed to separate in the event of an aircraft strike.
- 3616 7.7.6.5.2 **House** extra control circuitry in an enclosure for protection from the
3617 airport environment.
- 3618 7.7.6.5.3 **Install** all underground cable per item L-108 of AC 150/5370-10.
- 3619 7.7.6.6 **Commissioning Notice to Airmen (NOTAM).**
3620 7.7.6.6.1 The Flight Service Station (FSS) has jurisdiction over the airport where
3621 the PAPI is installed and must be notified when the system is ready to be
3622 commissioned.
- 3623 7.7.6.6.2 **Ask** the FSS to issue a commissioning NOTAM, and to forward copies of
3624 this NOTAM to the National Flight Data Center, the local ATCT, the Air
3625 Route Traffic Control Center, and the FAA Regional Office. This ensures
3626 that the new PAPI system will be included in the Airport Facility
3627 Directory.
- 3628 7.7.6.6.3 **Report the following items to the FSS:**
3629 1. Airport name and location.

2. Runway number and location of PAPI (left or right side of runway).
3. Type of PAPI (L-880 or L-881).
4. Glide path angle.
5. Runway threshold crossing height.
6. Date of commissioning.

7.7.6.6.4 **Flight Inspection Procedures for PAPI and Other Visual Glideslope Indicators (VGSI).**

1. A commissioning inspection is required for all new VGSI with an associated Instrument Flight Rules (IFR) procedure (to include circling approaches).
2. Because many existing VGSI systems were placed into service without flight inspection, they may remain in service until reconfigured to new systems or the addition of electronic vertical guidance to that runway.
3. Specific VGSI facility data per FAA Order 8240.52, *Aeronautical Data Management*, (see [Appendix D](#) for information about obtaining a copy of the FAA Order) is required for any VGSI inspection except Surveillance.
4. Do not attempt to conduct the inspection using data from other facilities on the runway, e.g., ILS data.
5. There is no periodic inspection requirement for VGSI facilities. However, the confirmation of safe operation should be accomplished in conjunction with other flight inspections involving the associated runway.
6. Flight check personnel will evaluate PAPI obstacle clearance within the lateral limits of the “visible” light beam; this evaluation may exceed the standard OCS in paragraph [7.5.4.4](#) and [Figure A-81](#).
7. The visible PAPI horizontal beam width may be in excess of 10 degrees either side of runway centerline (20 degrees total) because of horizontal beam spill over.
8. See [AC 150/5345-28](#) for additional information about PAPI horizontal beam width.
9. It is vital that personnel installing the PAPI and the cognizant engineer be thoroughly familiar with the requirements in FAA Order 8200.1, *U.S. Standard Flight Inspection Manual*, before a flight commissioning check is authorized.
10. For detailed information about current Flight Inspection Procedures and **Generic Visual Glideslope Indicators (GVGI)** systems, see FAA Order 8200.1, *United States Standard Flight Inspection Manual*, Chapter 7, Lighting Systems. [The document is available for download](#)

3669 at: www.faa.gov/regulations_policies/orders_notices. Use the search
3670 window to find the document.

3671 11. For help with PAPI OCS and obstruction problems contact:

3672 FAA Technical Center
3673 ANG-E261, Bldg. 296
3674 Atlantic City International Airport, NJ 08405

3675
3676 Telephone: 609-485-8034

3677 7.7.7 Alternate PAPI Installation Details.

3678 Use details contained in FAA Order JO 6850.2 for guidance to obtain alternate methods
3679 of installing economy approach lighting aids. Use the same URL link per paragraph
3680 7.7.6.6.4 item 10 to download the FAA Joint Order document.

3681

CHAPTER 8 Radio Control Equipment.

8.1. Radio Control Equipment.

Air-to-ground radio control may be used to turn on and adjust the intensity of airport lighting systems by clicking the aircraft radio microphone. This system permits a pilot to select the light intensity while minimizing power consumption when the runway is not in use. The airport operator must review the operating configurations described in this circular and implement the ones which give the pilot the greatest possible utilization of the airport lighting systems while keeping operating expenses at a minimum.

8.1.1 Restrictions on Use of Radio Control.

Air-to-ground radio control may be used at uncontrolled airports or at controlled airports during periods when the ATCT is closed. Obstruction lights and the airport beacon may not be radio controlled. All other lighting systems on the airport may be operated by air-to-ground radio control.

8.1.2 Radio Control Equipment

8.1.2.1 **Operation.**

8.1.2.1.1 The air-to-ground radio control equipment permits a pilot to turn on the airfield lights and select any one of the available intensity steps (normally three).

8.1.2.1.2 The pilot selects the intensity by keying the microphone of the aircraft communication transmitter a prescribed number of times in a 5-second interval.

8.1.2.1.3 Keying the microphone three times selects the lowest intensity; five times selects a medium intensity; and seven times selects the highest intensity.

8.1.2.1.4 Once energized, the lights stay on for 15 minutes. At the end of the 15-minute cycle, the lights either turn off or return to a preset brightness depending on the selected operating mode.

8.1.2.1.5 The system may be recycled at any time for another 15-minute period at any intensity step desired by keying the microphone the appropriate number of times.

8.1.2.1.6 Except for REILs with 1 or 2 steps, the lighting systems may not be turned off by radio control before the end of the 15-minute cycle.

8.1.2.2 **Frequency.**

8.1.2.2.1 The radio control is tuned to a single frequency in the range of 118-136 MHz, which is assigned as described in paragraph 8.1.4.1.

8.1.2.2.2 Whenever possible, the Common Traffic Advisory Frequency (CTAF) is used for radio control of airport lighting.

3719 8.1.2.2.3 The CTAF may be UNICOM, MULTICOM, FSS, or tower frequency and
3720 will be identified in appropriate aeronautical publications. Airport
3721 diagrams with CTAF information may be downloaded from:

3722 www.airnav.com/

3723 Consult with the local FAA ADO to obtain L-854 operation frequency
3724 information for your location – see paragraph 8.1.4 for more information.

3725 8.1.2.3 **FAA-Owned Radio Controls.**

3726 8.1.2.3.1 At some airports, the FAA owns and maintains an air-to-ground radio
3727 control that operates FAA-owned approach light systems and/or PAPIs.

3728 8.1.2.3.2 This radio control may not be used to control airport-owned lighting
3729 systems. If a second radio control is installed to operate the airport's
3730 lighting systems, it must **not** operate on the same frequency as the FAA
3731 unit.

3732 8.1.2.3.3 See [AC 150/5345-49](#) for additional information about **FAA owned**
3733 **ground-to-ground radio control systems (typically ATCT to ground**
3734 **equipment).**

3735 8.1.2.3.4 See FAA JO 6850.2 for additional requirements relevant to control of
3736 approach lighting systems, runway lighting, and other visual aids. The
3737 FAA publication can be downloaded at:

3738 [www.faa.gov/regulations_policies/orders_notices/index.cfm/go/document.](http://www.faa.gov/regulations_policies/orders_notices/index.cfm/go/document.information/documentID/321004)
3739 [information/documentID/321004](http://www.faa.gov/regulations_policies/orders_notices/index.cfm/go/document.information/documentID/321004)

3740 8.1.2.4 **Equipment.**

3741 Specifications for radio control equipment are in [AC 150/5345-49](#).

3742 If power supplies and accessories are not designed for outdoor service,
3743 enclose them in a prefabricated metal housing or other outdoor enclosure
3744 conforming to industry standards.

3745 8.1.2.5 **Lightning Protection.**

3746 Furnish and install lightning protection for the radio set per the
3747 manufacturer's instructions.

3748 8.1.3 **Interfacing the Radio Control with the Lighting Systems.**

3749 The output of a single airport-owned radio controller is usually connected to the control
3750 inputs of several lighting systems. The radio controller may be directly connected to
3751 the lighting systems, or an interface box may be used to reduce the load on the radio
3752 controller's output relays or to allow additional switching capabilities. The following
3753 paragraphs discuss the design considerations when interfacing a radio control with
3754 several lighting systems.

- 3755 8.1.3.1 **Standard System Configurations.**
- 3756 8.1.3.1.1 **Configure** the radio control system so that the runway lights are on
3757 whenever the other lighting systems serving the runway are on, except
3758 during day operations. See paragraph 8.1.3.4.
- 3759 8.1.3.1.2 When a runway has approach lights that are radio controlled and edge
3760 lights that are not, then **leave** the edge lights on at a brightness selected
3761 according to the anticipated weather conditions during the hours of night
3762 operation.
- 3763 8.1.3.1.3 If the runway lights are radio controlled and the approach lights are not,
3764 **either leave** the approach lights off or **leave** both the runway lights and
3765 approach lights at a preset brightness.
- 3766 8.1.3.1.4 **Never allow** the approach lights **to** be on while the runway lights are off.
- 3767 8.1.3.2 **Intensity Control.**
- 3768 8.1.3.2.1 **Linking of Approach Lights and Edge Lights.**
3769 On runways where the approach lights and the runway lights are both
3770 radio controlled, the intensities of both systems are increased or decreased
3771 simultaneously by the radio control.
- 3772 8.1.3.2.2 **Selection of Intensity Settings.**
- 3773 1. While the radio control equipment is equipped with three intensity
3774 settings, airport lighting systems may have one, two, three, or five
3775 intensity steps.
- 3776 2. Table 8-1 gives guidance on how to interface the radio control with the
3777 intensity steps of the airport lighting system.
- 3778 3. For example, a lighting system with five intensity steps would be
3779 connected so that three clicks of the microphone would energize
3780 brightness step 1 or 2, five clicks would energize step 3, and seven
3781 clicks would energize step 5.
- 3782 4. The airport authority may select either step 1 or 2 for the lowest
3783 brightness setting, depending on the background lighting at the airport.
- 3784 8.1.3.2.3 **Systems with Automatic Intensity Control.**
3785 On systems where the intensity is automatically controlled by a photocell
3786 or other means, the radio control simply energizes the system and the
3787 intensity **is** selected automatically by the photocell.
- 3788 8.1.3.2.4 **REILS.**
- 3789 1. REIL systems may have **either** one or three intensity steps.
- 3790 2. **See AC 150/5345-51 for more information about REIL intensity steps.**
- 3791 3. The radio control of REIL should be tailored to the equipment used
3792 and the needs of the facility.

- 3793 4. The common practice is to have the REIL turned off at the lower
3794 intensities and energized at the higher intensities.
- 3795 8.1.3.3 **Idle Setting.**
- 3796 8.1.3.3.1 When air-to-ground radio control is used at night, the lighting system may
3797 not be energized for long periods of time.
- 3798 8.1.3.3.2 During these “idle” periods, the airport beacon, obstruction lights, and any
3799 other lighting systems that are not radio controlled will continue to operate
3800 while the radio-controlled systems are off.
- 3801 8.1.3.3.3 As an option, the runway edge lights may be left on **at** a low intensity step.
3802 (The step selected will depend on local conditions.)
- 3803 8.1.3.3.4 If the runway lights are left on during idle periods, other lighting systems
3804 may also be left on at pre-selected intensities.
- 3805 8.1.3.4 **Radio Control for Day Operations.**
- 3806 8.1.3.4.1 Because the runway and taxiway edge lights, approach lights and lighting
3807 for taxiway signs are not normally needed during the day (except during
3808 restricted visibility conditions), the radio control system may be
3809 configured with a day mode that energizes only those lighting systems
3810 which are useful during the day.
- 3811 8.1.3.4.2 Using this control mode, however, means that daytime IFR procedures
3812 associated with the deactivated lighting systems may not be used. The day
3813 mode may be selected automatically by means of a photocell or manually
3814 by use of a switch.
- 3815 8.1.3.4.3 In areas with heavy voice traffic on the frequency used by the radio
3816 controller, there may be nuisance activation due to three random
3817 microphone clicks in a 5-second period. If this is a problem, the three-
3818 click setting on the radio control may be bypassed for daytime use.
- 3819 8.1.3.5 **Interface Box.**
- 3820 8.1.3.5.1 Other control devices, such as interlocks, photocells, and switches, may be
3821 used to provide flexibility of the radio control system under differing
3822 operational conditions.
- 3823 8.1.3.5.2 These devices are not included as part of the FAA L-854 air-to-ground
3824 radio controller and must be procured separately and installed in an
3825 appropriate interface panel or box.
- 3826 8.1.3.5.3 For runways with lighting systems on both ends of a runway, or at airports
3827 with more than one runway, it may be desirable to incorporate a manual
3828 switching system to allow the airport operator to choose which lighting
3829 systems will be energized by the radio control.
- 3830 8.1.3.5.4 This will permit the pilot to activate only those lighting systems that serve
3831 the active approach runway and taxiways.

3832

Table 8-1. Interface of Radio Control with Airport Visual Aids.

Lighting System	Number of intensity steps	Status during idle periods*	Intensity step selected per no. of microphone clicks		
			<u>3 clicks</u>	<u>5 clicks</u>	<u>7 clicks</u>
Approach Lights	2	Off	Low	Low	High
	3	Off	Low	Medium	High
	5	Off	1 or 2	3	5
Edge Lights					
Low Intensity	1	Off	on	On	On
Medium Intensity	3	Off or Low	Low	Medium	High
High Intensity	5	Off or Low	1 or 2	3	5
Taxiway Edge Lights	1	Off	on	On	On
	2	Off	Low	Low	High
	3	Off	Low	Medium	High
Runway Centerline, Touchdown Zone Lights.	5	Off	1 or 2	3	5
Taxiway Centerline	3	Off	Low	Medium	High
Lights	5	Off	1 or 2	3	5
REIL	1	Off	Off	Off	On
	2	Off	Off	Low	High
	3	Off	Low	Medium	High
Visual Glideslope Systems	3	On ¹	On	On	On
	5	On ²	1 and 2 Low	3 Medium	5 High

3833 * If the runway lights are left on during idle periods, other lighting systems may also be left on at a
 3834 pre-selected brightness.

3835 **Notes 1 and 2:** If the VGSI equipment is not equipped with heaters to prevent lens fogging due to
 3836 condensation or frost, it must remain energized at a low intensity setting. There is a possibility of
 3837 light signal interruption due to dew and/or frost forming on the outside glass of the PAPI units if not
 3838 operated continuously such as units activated by pilot-controlled-lighting (PCL) systems. To mitigate
 3839 this risk, the following is recommended:

- 3840 a. At airports where PAPI units are not operated continuously, change the airport lighting
 3841 circuitry to ensure PAPIs are preset to operate continuously on a low power setting, either 5
 3842 percent or 20 percent of full intensity as necessary for local site conditions.

- b. Airport operators must submit changes as per the front cover of the Airport/Facility Directory removing the PAPI reference.

It is also highly recommended to contact the VGSI equipment manufacturer for any equipment modifications that may be required.

8.1.4 Coordination With FAA.

8.1.4.1 **Frequency Selection.**

Assignment of a radio control frequency in the 118-136 MHz range must be obtained from the regional Frequency Management Officer, Airways Facilities Division, prior to ordering the radio control equipment.

8.1.4.2 **Data Reporting.**

8.1.4.2.1 At least 90 days prior to implementing new or retrofitting existing radio control systems, report information concerning the use of the system to the FAA for publication in appropriate documents.

8.1.4.2.2 Information to be reported includes airport name, city or state, sponsor, facilities controlled, runway(s), frequency, and hours of operation.

8.1.4.2.3 Any special operating features should also be described. This data must be reported to the nearest FAA Flight Service Station or directly to:

FAA National Flight Data Center
Air Traffic Operations
Washington, DC 20591

CHAPTER 9 Standby Power – Non-FAA.

9.1. Background.

FAA policy requires that visual aids associated with facilities in the NAS have a definite configuration for electrical power. This chapter contains electrical power details acceptable for non-FAA owned lighting aids, as described in paragraph 9.4.

9.2. Definitions.

9.2.1 “Prime Power Source” denotes the normally available supply of electrical power. This is power furnished by a utility company, the military, or other government agencies.

9.2.2 “Emergency Power Unit(s)” denotes any self-contained device, (e.g., engine generator, battery backup, thermo-electric device) from which electrical power can be obtained upon failure of the prime power source. See Article 700 of the NEC and local code.

9.2.3 “Alternate Prime Power Source” is of the type described in paragraph 9.2.1 above and is a system substantially separate from the first source in that it is arranged so that any single equipment failure, accident, lightning strike, or damage which interrupts power from the first source will not normally interrupt power from the second source.

9.2.4 “Quality of Power” denotes the availability of useable electrical power. A power interruption or a variation of voltage or frequency outside the standards set for the facility will degrade the quality of power for the facility.

9.2.5 “Continuous Power Facility” is a facility so designated herein and provided with the quality of power required to assure that the facility’s services continue to meet operational requirements even in the event of an extended widespread loss of commercial power. Continuous power facilities will have power Configuration “A”, as specified in paragraph 9.4.1.1.

9.2.6 “Continuous Power Airport” is an airport equipped with an emergency power unit(s) which will provide the power required for facilities on the selected runway to sustain operations in the event of an area-wide or catastrophic-type prime power failure.

9.2.7 “Uninterruptible Power” is Configuration “A” power augmented, as necessary, with a device which will assure that power to the load is not interrupted during the 15 second transfer time allowed for Configuration “A,”

9.3. FAA Policy.

Policy requirements are in FAA Order 6030.20, *Electrical Power Policy*. The power systems for NAS facilities will be of quality sufficient for:

- Safety of aircraft movement.
- Efficient air traffic operations.

- Meeting requirements of national defense.
- Minimizing inconvenience and cost to the aviation community.

9.4. **Electrical Power Configurations.**

9.4.1 Basic Configurations.

9.4.1.1 The minimum quality of power needed at a facility varies with the effect that an outage of the facility would have on the provisions of paragraph 9.3.

9.4.1.2 The exact relationship of an individual facility to its environment is, of course, unique; but each type of facility (e.g., HIRL, centerline lights, etc.) has been evaluated for its **criticality** in the NAS. The evaluation resulted in the development of the configurations “A,” “B,” and “C” discussed below:

9.4.1.2.1 **Configuration “A”**

1. This configuration provides facilities with power from an emergency power unit within 15 seconds after failure of the prime power source, except those CAT II lighting aids (listed in paragraph 9.4.1.2) requiring a one-second transfer.
2. Details concerning CAT II operation are contained in AC 120-29, Criteria for Approval of Category I and Category II Weather Minima for Approach. The system consists of:
 - a. Connection to a prime power source.
 - b. Emergency power unit(s).
 - c. Automatic transfer capability.

9.4.1.2.2 **Configuration “B”**

1. This configuration provides facilities with power from an alternate prime power source within 15 seconds after failure of the prime power source except those CAT II lighting aids requiring a one-second transfer.
2. These are CAT II HIRL, centerline lights, and touchdown zone lights. The system consists of:
 - a. Connection to a prime power source.
 - b. Connection to an alternate prime power source.
 - c. Automatic transfer capability.

- 3930 9.4.1.2.3 **Configuration “C”**
- 3931 1. Configuration “C” provides connections of the facility to a single
- 3932 power source.
- 3933 2. There are no provisions for alternate prime power or engine generator
- 3934 sets.
- 3935 3. All lighting aids not covered in Configurations “A” and “B” are in
- 3936 Configuration “C,”
- 3937 4. Though standby power is not required for Configuration “C”, a higher-
- 3938 grade configuration of power is encouraged for airport lighting
- 3939 systems where a second source of power can be provided at a
- 3940 reasonable cost.

3941 9.4.2 Combined Configurations.

- 3942 9.4.2.1 **Design** systems having two sources of power (Configuration “A” and “B”)
- 3943 so the second source is available to the facility within 15 seconds after
- 3944 interruption of the prime power, except that the essential visual aids for
- 3945 CAT II operations require a one-second changeover time.

- 3946 9.4.2.2 Where the second source of power is an engine generator, the one-second
- 3947 changeover time may be obtained by powering the visual aid facility by
- 3948 the engine generator during CAT II operations using commercial power as
- 3949 the second source (standby).

- 3950 9.4.2.3 Failure of the engine generator plant is monitored by safety devices that
- 3951 automatically transfer the facility load to commercial power in a nominal
- 3952 one-second changeover time.

- 3953 9.4.2.4 After prime power is restored and stabilized, the facility must
- 3954 automatically return to the prime power supply.

3955 9.5. **Design.**

3956 Design power systems at all facilities to meet the requirements of the applicable

3957 electrical codes. The detailed design requirements for the systems in this AC are

3958 flexible to permit the equipment to be installed and operated with minimum changes to

3959 the power distribution system at the airport.

- 3960 9.5.1.1 **Configuration “A” Power.**
- 3961 See Figure A-94 for configuration.

- 3962 9.5.1.1.1 **KVA Requirements.**
- 3963 Prior to the selection of standby power equipment, determine the kilovolt
- 3964 ampere (kVA) input to the **CCR**. Specification values may be used for
- 3965 this purpose. If qualified personnel are used and the proper equipment is

available, the actual input requirements may be determined by the following method:

1. Set the CCR to supply **its** maximum output current (**usually 6.6A**).
2. Energize the CCR with the lighting load connected.
3. Measure the volts and amperes at the CCR's input terminals.

Caution: Only qualified personnel must make the measurements at the high voltage input of the CCR.

4. Calculate the input kVA by multiplying the measured volts times the measured amperes and dividing by 1,000. Normally, the measured kVA input to the CCR is less than the calculated kVA input.
5. If the CCR does not have rated load connected to the output circuit, calculate the kVA input to the CCR with rated load connected. This can be calculated by dividing the rated kW of the CCR by the CCR's efficiency and power factor. Typical calculations are shown in Figure A-95.

9.5.1.2 **Power and Control.**

9.5.1.2.1 Design the system to provide an automatic changeover for the prime power to the engine generator equipment within 15 seconds after a power failure occurs.

9.5.1.2.2 The detailed design requirement for the installation may vary to conform to local conditions, but no variations are permitted in the system's performance requirements. Additional details are contained in paragraph 9.4 and in Figure A-96.

9.5.1.2.3 If the engine generator set is not designed to operate continuously under a no-load condition, provide a relay or some other protective device per Figure A-96.

9.5.1.2.4 **The relay** prevents the engine generator set from operating under a no-load condition in **the event** a power failure occurs when the CCR's remote control switch is in the "off" position.

1. This is accomplished by bypassing the control switch used to control **the** on/off operation of the CCR.
2. **Continuously operating an engine generator with no load can adversely affect the performance of the engine generator.**

9.5.1.2.5 **Space and Ventilation.**

Provide adequate space and ventilation for the engine generator equipment.

1. The required space, ventilation, and engine exhaust provisions **are** controlled by the kVA rating of the engine generator, the design characteristics of the equipment, and the space required to maintain the engine generator set and its auxiliary equipment.

4006 2. Locate the engine generator as close as practical to the CCR it is
4007 serving.

4008 3. Typical equipment layout and floor spaces are per Figure A-97.

4009 9.5.2 Configuration “B” Power.

4010 9.5.2.1 Connection Requirements. Obtain connections with one of the methods
4011 listed below. See Figure A-99 and Figure A-100 for typical electrical
4012 diagrams and connection details.

4013 9.5.2.2 Dual Feeders. Separate feeders to the extent that electrical malfunction or
4014 physical damage is unlikely to result in outage of both.

4015 9.5.3 Configuration “C” Power.

4016 This configuration has no provisions for standby power; however, **either** configuration
4017 “A” or “B” is recommended for all visual aids where it can be provided at a reasonable
4018 cost.

4019 9.5.4 Category II Runway.

4020 9.5.4.1 Provide a one second power transfer for runway centerline lights,
4021 touchdown zone lights, and high intensity runway edge lights on CAT II
4022 runways.

4023 9.5.4.2 Methods of obtaining this one-second transfer are in paragraph 9.4.

4024 9.5.4.3 At CAT II locations with an engine generator set, use a remote-controlled
4025 switch on the L-821 control panel to start the standby power when CAT II
4026 weather is approaching.

4027 9.5.4.4 Provide a red indicator light on the L-821 panel to indicate “standby on”
4028 when the engine generator is running.

4029 9.5.4.5 If the CAT II runway has Configuration “B” power, use automatic transfer
4030 switches designed for a one-second or less transfer.

4031 9.5.5 Emergency Lighting.

4032 Ensure that an adequate number of battery-powered emergency **runway** lights are
4033 available at all lighted airports for emergency use, per AC 150/5345-50, *Specification*
4034 *for Portable Runway and Taxiway Lights*.

4035 9.5.6 Maintenance Controls.

4036 Provide means in the system whereby the maintenance personnel can lock out **and tag**
4037 control switches to avoid the equipment being turned on while maintenance personnel
4038 are working on the engine generator equipment.

9.5.7 Terminal System Integrity.

Recognizing that both FAA facilities and those owned by the airport sponsor must be operational to provide basic landing minimums during a power failure, FAA will not upgrade power to existing facilities unless the associated airport-owned facilities conform to the applicable provisions in *FAA Order 6030.20, Electrical Power Policy*.

9.6. **Equipment and Material.**

9.6.1 Engine Generator Set.

Unless otherwise specified, select engine generator equipment designed to meet the applicable industry standards and code requirements (see Article 700 of the NEC and local code). When the engine generator is supplying power to FAA facilities, the engine generator unit must meet the requirements of Specification FAA-E-2204, *Engine Generator Sets (EGS) Diesel and Propane Fueled Engine Generator Sets, 10kW to 750kW*.

9.6.1.1 **General Requirements.**

9.6.1.1.1 Provide an engine generator set for installation in a shelter that is automatic, quick starting, and capable of carrying its rated load at all ambient temperatures between 20°F (7°C) and 120°F (49°C).

9.6.1.1.2 For temperatures below 20°F (7°C), an alternate to supplement shelter heat is an immersion heater.

9.6.1.1.3 Standby equipment must carry its rated load within 15 seconds after a power failure.

9.6.1.1.4 The output voltage of the generator must be a value acceptable for connection to the input and control circuit of CCRs.

9.6.1.1.5 Generators required for operation of CCRs have a step-up transformer, if required, between the CCRs and the generator.

1. Adequate voltage **must be provided** for the CCR control circuits.
2. The output frequency of the generator **must be 60 Hz**, plus or minus commercially acceptable tolerances.
3. Additional details concerning the engine generator set are in paragraph 9.12.

9.6.1.2 **Exhaust System.**

9.6.1.2.1 Provide exhaust silencers (mufflers) and pipes as required for the particular installation.

9.6.1.2.2 Exhaust pipes, when required, are black steel per ASTM Specification A-53, Standard Specification for Pipe, Steel, Black and Hot-Dipped, Zinc-coated, Welded and Seamless, Type F, Grade A.

- 4075 9.6.1.3 **Batteries.**
- 4076 9.6.1.3.1 Provide batteries that have a terminal voltage suitable for starting the
- 4077 engine generator and a minimum watt-hour rating per FAA-E-2204.
- 4078 9.6.1.3.2 Provide racks for the batteries as required.
- 4079 9.6.1.4 **Battery Charger.**
- 4080 9.6.1.4.1 Provide a battery charger with the generator set.
- 4081 9.6.1.4.2 Unless otherwise specified, battery chargers meet the requirements in
- 4082 FAA-E-2204.
- 4083 9.6.2 Transformer.
- 4084 9.6.2.1 Provide a step-up transformer, **if it is required**, to make the output voltage
- 4085 of the engine generator set compatible with the input voltage to the CCR.
- 4086 9.6.2.2 Transformers may also be used to step down primary power and permit
- 4087 the use of low voltage automatic transfer switches and to supply control
- 4088 circuits.
- 4089 9.6.2.3 Select commercial equipment **per** the applicable industry and electrical
- 4090 standards.
- 4091 9.6.2.4 Select a transformer rated to continuously supply the required input to the
- 4092 equipment.
- 4093 9.6.3 Fuel Storage Tank.
- 4094 9.6.3.1 Provide a fuel storage tank with a fuel gauge for the engine generator set.
- 4095 9.6.3.2 Select a tank with **sufficient** capacity to provide reliable operation for the
- 4096 minimum period of time established by **the airport authority**.
- 4097 9.6.3.3 If no emergency operating periods are established locally, provide
- 4098 **sufficient** fuel tank capacity for at least 24 hours **of** continuous operation.
- 4099 9.6.3.4 When selecting **the fuel tank**, consider the time required to replenish the
- 4100 fuel supply, the availability of fuel, the accessibility of fuel under adverse
- 4101 weather conditions, fuel required for maintenance test runs (paragraph
- 4102 9.10.3), and the frequency of maintenance inspections of the fuel tank and
- 4103 supply.
- 4104 9.6.3.5 Select a fuel tank that meets the requirements of the NFPA and local
- 4105 codes.
- 4106 9.6.3.6 Provide fuel lines from the engine generator set to the tank as required by
- 4107 the equipment design.

- 4108 9.6.3.7 Provide an auxiliary tank (day tank) and a transfer pump as required.
- 4109 9.6.3.8 **Both** storage and auxiliary tanks must be vented per NFPA code.
- 4110 9.6.4 Mounting Pads.
- 4111 If required, provide a mounting pad (foundation) for the engine generator set per the
- 4112 manufacturer's instructions. If required, provide resilient or shock mounts or an
- 4113 isolated base to control vibration and noise.
- 4114 9.6.5 Conduit and Wiring.
- 4115 Provide all conduit and wiring in the vault or engine generator shelter per the
- 4116 requirements of the NEC and local codes.
- 4117 9.6.6 Radiator Air Duct.
- 4118 Provide, if required, an air duct from the engine radiator to a wall opening. The air
- 4119 intake must be adequate for proper operation and cooling of the equipment.
- 4120 9.6.7 Switch guard.
- 4121 9.6.7.1 Provide a switch guard with the engine generator set.
- 4122 9.6.7.2 This equipment has provisions to switch the CCR's input from the prime
- 4123 power source to the standby engine generator within the required time
- 4124 interval after power failure is detected. Use a voltage sensing device to
- 4125 detect a power failure.
- 4126 9.6.7.3 When prime power is restored, the input to the CCR is switched from the
- 4127 standby power source to the prime power source.
- 4128 9.6.7.4 The automatic transfer switch must meet the performance requirements of
- 4129 Specification FAA-E-2204, *Diesel Engine Generator Sets, 10kW to*
- 4130 *750kW*. This type of automatic switch used with the engine generator is
- 4131 acceptable for Configuration "B" installations.
- 4132 9.6.7.5 The switchboard must include safety devices consisting of low oil cutout,
- 4133 high temperature cutout, over-crank cutout, and overspeed cutout. The
- 4134 switchboard must also include indicators such as a voltmeter, ammeter, oil
- 4135 pressure indicator, and water temperature indicator.
- 4136 9.6.7.6 Provide a bypass switch per Figure A-96 to permit running the engine
- 4137 generator on manual start-stop to facilitate servicing. The bypass switch
- 4138 **must** meet the requirements of Specification FAA-E-2083, *Bypass Switch,*
- 4139 *Engine Generator.*

9.7. Installation.

9.7.1 Configuration “A.”

9.7.1.1 **Engine Generator Set and Accessories.**

Install the engine generator and its accessories per the manufacturer’s instructions. The completed installation must meet all requirements of the NEC and local codes. A typical installation is per Figure A-97.

9.7.1.1.1 **Air Intake.**

Provide access to an adequate quantity of air for the intake of the engine generator. A typical air intake system is per Figure A-97. A wind baffle fence or other suitable provision may be installed to reduce the backpressure imposed on the engine generator.

9.7.1.1.2 **Exhaust System.**

1. Support the exhaust pipe when it is installed through a wall.
2. Where metal plates or metal sleeves are required, use a layer or layers of fireproof vibration-absorbent material **per** ASTM C-892, Standard Specification for High Temperature Fiber Blanket Thermal Insulation.
3. If the exhaust piping and muffler are not protected, paint them with heat resistant aluminum paint **per** Federal Specification TT-P-28, *Paint, Aluminum, Heat Resisting (1200 Deg. F.)*.
4. When the exhaust pipe terminates in a vertical direction, install an exhaust pipe rain cap.

9.7.1.1.3 **Batteries, Battery Charger, and Battery Rack.**

Install the batteries, battery charger, and battery rack at the location indicated in the plans for the installation. Place the electrolyte in the battery cells after the batteries are in their final position.

9.7.1.2 **Fuel Storage Tank and Lines.**

Install the fuel storage tank and lines and auxiliary tank (day tank) per the equipment manufacturer’s instructions, NFPA code, and local code requirements.

9.7.1.3 **Transformer.**

If a step transformer is required, install the step-up transformer at the location indicated in the plans. Make connections to the transformer per the equipment manufacturer’s instructions.

9.7.1.4 **Mounting Pads.**

Specify mounting pads to support the equipment being installed.

- 4175 9.7.1.5 **Transfer Switch.**
4176 Install the transfer switch at the location indicated in the plans. A typical
4177 location of this equipment is per Figure A-97.
- 4178 9.7.1.6 **Conduit and Wiring.**
4179 Install conduit and wiring per the NEC and local code requirements.
- 4180 9.7.2 Configuration “B.”
- 4181 9.7.2.1 The Configuration “B” power for non-FAA airport lighting systems is
4182 normally installed by the utility company.
- 4183 9.7.2.2 **Before proceeding with an installation of equipment**, obtain assurance that
4184 the installation will meet the configuration and design requirements of
4185 paragraphs 9.4 and 9.5, respectively.
- 4186 9.7.3 Configuration “C.”
4187 There are no provisions for the installation of standby power with this configuration.
4188 **Either** configuration “A” or “B” is encouraged for all visual aids where it can be
4189 provided at a reasonable cost. See Figure A-100 for a typical electrical layout.
- 4190 9.8. **Inspection.**
- 4191 9.8.1 System.
4192 Check the electrical configuration of the system to determine if the design
4193 meets **all** the requirements of this chapter.
- 4194 9.8.2 Engine Generator Set.
- 4195 9.8.2.1 Inspect the engine generator set and its accessories to assure that the
4196 equipment is installed per the equipment manufacturer’s **installation**
4197 instructions **and/or equipment handbook**.
- 4198 9.8.2.2 Check the mounting of the engine and generator to determine if the
4199 equipment is securely **installed**.
- 4200 9.8.2.3 Check all pipes, conduits, and accessories to determine if each item is
4201 securely fastened.
- 4202 9.8.2.4 Check all wiring to determine if it is correct and that all connections are
4203 secure.
- 4204 9.8.3 Fuel Storage Tank and Line.
4205 Inspect the fuel storage tank, auxiliary tank (day tank), and lines to determine if the
4206 equipment is properly installed and that there are no fuel leaks.

- 4207 9.8.4 Batteries.
4208 Check all connections to determine if they are secure and that the electrolyte in the
4209 battery cells is at the proper level.
- 4210 9.8.5 Output Voltage.
4211 Check the output from the engine generator set to determine if the voltage is adequate
4212 for the CCR's input power and control circuits. Make this check prior to connecting the
4213 CCR to the engine generator set.
- 4214 9.9. **Tests.**
- 4215 9.9.1 Engine Generator Set and Switchboard:
4216 1. Conduct tests recommended in the manufacturer's instructions.
4217 2. Test the installation by operating the system continuously for at least one hour.
4218 3. In addition, simulate at least 10 power failures and check the starting time of the
4219 engine generator equipment.
4220 4. Check the operation of all safety and indicating devices specified in paragraph 9.6.
4221 5. Test the operation of the bypass switch.
4222 6. Test the operation of components used to obtain an automatic transfer of power
4223 from the prime source to the standby equipment.
- 4224 9.9.2 Batteries.
4225 Test the batteries to determine if the specific gravity is within the range recommended
4226 by the manufacturer.
- 4227 9.10. **Maintenance.**
- 4228 9.10.1 General.
4229 1. The equipment manufacturers issue specific instructions for their engine generator
4230 equipment. These instructions contain information obtained through experience and
4231 they are provided to assure reliable and efficient service from the equipment.
4232 2. The instructions must be read, understood, and followed.
4233 3. Qualified personnel must maintain the engine generator set and its accessories.
- 4234 9.10.2 Engine Generator Set.
4235 Perform preventive maintenance on the engine generator set per equipment
4236 manufacturer's instructions.

4237 9.10.3 Operational Check.

4238 1. Make a weekly operational check of the engine generator and associated equipment
4239 operating the emergency system for one-hour minimum, while it is supplying power
4240 to the **airfield** lighting systems, preferably at maximum brightness.

4241 2. Coordinate all operational checks with **maintenance and ATCT** personnel, **because**
4242 **the engine generator feeds the lighting system rather than a load bank**

4243 9.10.4 Vault or Shelter.

4244 Keep the enclosure housing, the engine generator set, and its accessories clean and
4245 uncluttered to prevent dirt from accumulating in control compartments and to allow
4246 equipment to be accessible at all times. Mount warning signs in conspicuous locations.

4247 9.10.5 Tank and Fuel Line.

4248 Check fuel tank covers and fuel line after each refueling to determine that these
4249 components are secure and that there are no fuel leaks.

4250 9.10.6 Spare Parts.

4251 Stock adequate spare parts for maintenance purposes. Use the manufacturer's
4252 instructions as a guide concerning maintenance spares.

4253 9.10.7 Log.

4254 Keep a log of engine generator operating hours (or provide an elapsed time meter) and a
4255 record of maintenance work performed on the equipment.

4256 9.10.8 Fuel Supply.

4257 Establish a regular schedule for checking the fuel supply. **Establish the frequency of**
4258 **checks** on the basis of the type facility, location of the engine generator sets, and
4259 location of the fuel supply.

4260 9.11. **Reducing Electrical Power Interruptions.**

4261 The sections of FAA Order 6950.11, *Southwest Region Policy Pertaining to Work on*
4262 *Electrical Power Distribution Systems*, pertaining to non-FAA airport lighting systems,
4263 are applicable to this circular.

4264 9.12. **Engine Generator Equipment Performance Requirements.**4265 9.12.1 Referenced Specification.

4266 Specification FAA-E-2204 may be used as a guide in selecting standby power
4267 equipment.

4268 Because the requirements for airport lighting are not as rigid as those for supplying
4269 power to radar and communication facilities operated and maintained by the FAA, the
4270 requirements in FAA-E-2204 may be modified as indicated below.

9.12.2 Modification to FAA-E-2204C, pages 3-32:

Chapter 3. Requirements.

Paragraph 3.1 Description. Modify to permit transfer switches to be mounted on the wall instead of on the engine generator.

Paragraph 3.2.2 Interchangeability. Delete. Not applicable.

Paragraph 3.2.4 Painting. Modify to eliminate any certain color, to permit use of manufacturers' standard colors.

Paragraph 3.2.7 Spare Parts. Delete.

Paragraph 3.2.8 Nameplate and Serial Numbers. Delete requirements for FAA standard nameplate. All other nameplates should be required.

Paragraph 3.2.10 Instruction Book. Delete all reference to Specification FAA-D-2494.

Paragraph 3.3.2 Engine Description. In the second paragraph, this specification states that the "Maximum brake horsepower and speed of the engine must be as specified in the Classification Table, Figure 1." This Classification Table should be modified to delete the developed horsepower at synchronous speed and permit higher speed on the larger plants.

Paragraph 3.3.10 Governor and Frequency Regulation. Close tolerances on frequency requirements may be relaxed. Standard commercial tolerance is acceptable.

Paragraph 3.4.1 Generator. Eliminate the requirement for parallel operation.

Paragraph 3.4.11 Load Test Jacks. Load test jacks are not required and should be eliminated.

Paragraph 3.4.12 Automatic Power Transfer Equipment. Modify this item to permit the transfer switch and equipment to be mounted on the wall adjacent to the engine generator.

Paragraph 3.4.12.2 Automatic Transfer Switch. Modify to permit wall mounting.

Chapter 4. Inspection and Tests.

Chapter 5. Preparation for Delivery. All reference to the tests and inspections shown in 4.1 to 4.2.5, pages 32-42, should be deleted. However, the manufacturer must certify that the plant furnished will meet the above tests.

Page 44, Classification Table. Delete developed HP at synchronous speed. The manufacturer must supply an engine of sufficient horsepower rating to develop the full kVA rating of the plant.

4303

Maximum Speed RPM. Increase all 1200 RPM to 1800 RPM.

4304

CHAPTER 10 Pavement Types.4305 10.1. **General.**

4306 There are four types of pavements used in the construction and installation of airfield
4307 lighting systems. These can be capable of rollover (considered full strength), or not
4308 capable of rollover (on a shoulder area, etc.).

4309 10.2. **New Pavement – Rigid (Concrete).**

4310 One of two conditions will be encountered during installation. The edge of an existing
4311 pavement will be available as a reference for the new bases, or if an existing edge is not
4312 available, the bases **will** be set “in space.” The availability of an existing pavement
4313 edge simplifies the task of locating the light base. In both cases, a setting jig or fixture
4314 is required to hold the base in position while the concrete anchor is placed.

- 4315 1. Azimuth and the elevation of the base with respect to the pavement surface are two
4316 parameters that **must** be met.
- 4317 2. The elevation of the mounting flange **must** be at least $\frac{3}{4}$ inch (19 mm) below the
4318 finished surface of the pavement. If the base is positioned less than $\frac{3}{4}$ inch (19 mm)
4319 below the pavement surface, the light fixture will protrude above the pavement
4320 surface - this may adversely affect its performance and present a hazard to vehicles
4321 operating on the pavement, such as snowplows.
- 4322 3. If more than $\frac{3}{4}$ inch (19 mm) is left, spacer rings can be used to bring the light
4323 fixture to the correct elevation.
- 4324 4. To preserve the base integrity and proper bolt torque, a maximum of three spacer
4325 rings may be stacked together. Note: **See paragraph 5.3.4 “Runway and Taxiway
4326 In-pavement Lighting Systems” of AC 150/5340-26 for bolt torque maintenance
4327 requirements for in-pavement light fixtures.**
- 4328 5. A paving tolerance of $\frac{1}{2}$ inch (13 mm) should be anticipated when setting the
4329 elevation of the base, so the light fixture can be set at +0 to $-\frac{1}{16}$ inch (+0 to -1.5
4330 mm) below the low side of the pavement surface.
- 4331 6. Excavate conduit runs in the base or sub-base supporting the rigid pavement. Place
4332 conduit and counterpoise at this time.
- 4333 7. **Install the** counterpoise above the conduit. See paragraph 12.5 for additional
4334 information about counterpoise installation height above conduit.
- 4335 8. At each light location, excavate the pavement base or sub base to accommodate the
4336 L-868 light base, the steel reinforcing cage, and concrete for the anchor.
- 4337 9. The concrete anchor should provide a 6-inch (152 mm) thickness below the light
4338 base and a 12-inch (305 mm) thickness of concrete around the perimeter of the light
4339 base.
- 4340 10. The volume of the concrete anchor must not be less than $\frac{1}{3}$ cubic yard.
- 4341 11. The reinforcing steel cage is made from #4 steel bars, ASTM grade A-184 or A-704.

- 4342 12. The vertical bars of the cage are spaced 12 inches (305 mm) apart and arranged in a
4343 circular pattern 6-inches (152 mm) greater in diameter than the light base. The
4344 vertical bars extend from 3 inches (78 mm) below the theoretical pavement surface
4345 to 6 inches (152 mm) into the concrete base, with 4-inch (102-mm) 90-degree hooks
4346 at each end.
- 4347 13. The horizontal bars are spaced at 12 inches (305 mm), beginning at the 90-degree
4348 hook, and encircle the vertical bars.

4349 10.2.1 After Excavation.

- 4350 1. After the excavation is complete, install the light base and reinforcing steel cage and
4351 hold them in place with the setting jig.
- 4352 2. **Cover** the top of the light base with a steel mud plate and a $\frac{5}{8}$ inch (16-mm) thick
4353 plywood cover to protect the top of the light base immediately prior to paving.
- 4354 3. The setting jig will establish the elevation and azimuth of the base and maintain this
4355 position until the concrete anchor is placed.
- 4356 4. **Connect** each **light** base to the conduit system per Figure A-36.
- 4357 5. Flexible conduit may be used will allow adjustments in light base elevation and
4358 alignment before the concrete anchor is placed.
- 4359 6. If the conduit/light base misalignment is not more than approximately 15 degrees, a
4360 flexible grommet may be used on the light base vice a threaded hub.
- 4361 7. When using a flexible grommet, steel conduit should enter the light base about $\frac{3}{4}$
4362 inch and PVC should enter about $\frac{1}{4}$ inch.
- 4363 8. Connect conduits to the bases and pull the cabling into the bases.
- 4364 9. Bond the counterpoise to the light base and rebar cage.
- 4365 10. Exothermic welds are the preferred connection method of connection. If exothermic
4366 welds are not possible, ensure that all connector materials are UL listed for direct
4367 earth burial and/or installation in concrete. See paragraph 12.5 for additional details
4368 about counterpoise bonding.
- 4369 11. Set the final position of the bases with the setting jig.
- 4370 12. The top of the light base should be $1\frac{1}{2}$ -inch (35 mm) below the finished surface of
4371 the pavement.
- 4372 13. This can be accomplished by using a $\frac{3}{4}$ inch (19 mm) spacer between the setting jig
4373 and the plywood cover. See *“The Design, Installation, and Maintenance of In-
4374 Pavement Airport Lighting”*, Arthur S. Schai, for additional information.
- 4375 **Note:** Coordinate the pavement and lighting installation activities to avoid an
4376 incorrectly installed light fixture base or excessive variations in pavement thickness.
- 4377 14. Place a sufficient amount of concrete (1/3 cubic yard minimum) to completely fill
4378 the excavation for the anchor up to the level of the pavement base or sub-base.

- 4379 a. The light base concrete anchor must not encroach upon the structural pavement
4380 thickness. The concrete should conform to the requirement cited in paragraph
4381 12.7.
- 4382 b. Take care while placing the concrete anchor that neither the jig nor the light base
4383 alignment is disturbed.
- 4384 c. **Leave** the jig in place until the concrete has set, usually 24 hours. Backfill the
4385 conduit runs with concrete at this time.
- 4386 15. Prior to paving, remove the plywood cover and fit the light base with a steel mud
4387 plate. **After paving is completed, bore a 2-inch (50 mm) hole through the pavement**
4388 **surface layer to accurately locate the center punch mark of the cover plate.**
- 4389 a. **Core a hole 1 inch (25 mm) larger in diameter than the base centered over the**
4390 **base.**
- 4391 b. After the paving train has cleared the light base, remove the concrete from the
4392 top of the base and finish the edge of the opening around the base to a smooth
4393 radius.
- 4394 c. The surface of the pavement around the light base must be level with the
4395 surrounding pavement; dished or mounded areas are not acceptable.
- 4396 d. The grooved spacer ring or flat spacer ring may also be provided with an
4397 integral protective dam that will allow the installation of AC 150/5370-10, P-
4398 605 or P-606, sealant in the annular space around the fixture.
- 4399 e. After the concrete has set, remove the mud plate and determine the actual
4400 thickness of concrete above the light base.
- 4401 f. It may be necessary to install a grooved space ring, or grooved spacer ring and
4402 flat spacer ring, or set this level of adjustable cans to bring the light fixture to the
4403 correct elevation.
- 4404 g. To preserve the base integrity and proper bolt torque, a maximum of three
4405 spacer rings may be stacked together.
- 4406 16. The top of the fixture edge (highest edge if fixture is not exactly level and/or
4407 installed on a crowned pavement) must be between +0 inch (0 mm) and $-1/16$ inch (2
4408 mm) from the pavement surface.
- 4409 a. Take remedial action if the fixture is too high.
- 4410 b. This could result in field modification of the base that could affect equipment
4411 certification.
- 4412 c. Prior to any remedial action, consult with the base manufacturer.
- 4413 d. See Figure A-35 for application of tolerance on crowned pavement sections.
- 4414 17. The installation of the primary cable, transformers, and connectors can be
4415 completed **at this step**.
- 4416 a. Install an "O" ring gasket (normally supplied with the light fixture).

- b. Then, install the hold-down bolts, with 2-piece anti-vibration lock washers, and tighten them to the manufacturer's recommended torque.

18. If the paving technique utilizes more than one lift to achieve the required thickness, the procedure in paragraph 10.2 item 9 is altered as follows:

- a. A sectional light base is required and, after the bottom section has been installed, the first paving lift should be placed.
- b. Expose and clean the flange and install the next base section with a silicone sealant, equal to RTV-118, between the sections.
- c. Tighten in place.
- d. The paving operation and the fixture installation are as described above.

10.3. New Pavement – Flexible (Bituminous).

10.3.1 A sectional base is required for flexible pavements.

10.3.1.1 **Install** the bottom section of the light base, concrete anchor, and conduit system in the pavement base using procedures similar to those for rigid pavements.

10.3.1.2 Certified adjustable bases can also be installed. See paragraphs 11.1 and 11.4.

10.3.1.3 No steel reinforcing cage is used in this application.

10.3.1.4 See "*The Design, Installation, and Maintenance of In-Pavement Airport Lighting*", Arthur S. Schai, for additional information.

Note: Because of the loads placed on the cover plate during paving, **use** a plywood cover with a minimum thickness of $\frac{5}{8}$ inch (16 mm). If the top section will not be installed right away, a galvanized steel mud plate $\frac{1}{8}$ inch (3 mm) thick should be used.

10.3.2 The first two steps of this procedure are identical to those for the installation of fixed body length bases in rigid pavement, except that a steel reinforcing cage is not required.

10.3.3 After the excavation is complete, install the bottom section of the light base and hold it in place with the setting jig.

1. Install a $\frac{5}{8}$ inch (16-mm) thick plywood cover to the top of the bottom section to protect the top prior to and during paving.
2. The setting jig will establish the elevation and azimuth and maintain this position until the concrete anchor is placed.
3. A recommended practice is to connect each bottom section to the conduit system with a length of liquid tight flexible conduit, as shown in Figure A-36.

- 4450 4. Flexible conduit will allow adjustments in light base elevation and alignment before
4451 the concrete anchor is placed.
- 4452 10.3.4 Connect conduits to the base and pull the cabling into the bottom section of the base.
4453 Bond the counterpoise to the light base.
- 4454 10.3.5 Set the final position of the bottom section of the base with the setting jig. Install a $\frac{5}{8}$
4455 inch (16-mm) thick plywood cover to the top of the bottom section to protect the top
4456 prior to and during paving. This can be accomplished by using a $\frac{3}{4}$ inch (19-mm) flat
4457 spacer ring between the setting jig and the plywood cover.
- 4458 10.3.6 Place a sufficient amount of concrete to completely fill the excavation for the anchor up
4459 to the level of the pavement layer to be placed.
- 4460 1. **Ensure** the concrete conforms to the requirement cited in paragraph 12.7.
4461 2. Take care while placing the concrete anchor so neither the jig nor the light base
4462 alignment is disturbed.
- 4463 3. **Leave** the jig in place until the concrete has set, usually 24 hours.
- 4464 10.3.7 After the paving train has cleared the light base, remove the paving material and
4465 plywood cover from the top of the bottom section of the base, exposing the flange. .
- 4466 10.3.8 Attach the middle section of the sectional base to the bottom section, per manufacturer
4467 recommendations.
- 4468 10.3.8.1 The thickness of the middle section should be such that the elevation of
4469 the top of the middle section is $1\frac{3}{8}$ inch (35 mm) below the finished
4470 surface of the next pavement layer to be placed.
- 4471 10.3.8.2 Install a $\frac{5}{8}$ inch (16-mm) thick plywood cover to the top of the middle
4472 section to protect the top prior to and during paving.
- 4473 10.3.9 Once again, after the next pavement layer has been placed, remove the paving material
4474 and plywood cover from the top of the middle section of the base, exposing the flange.
- 4475 10.3.10 Bolt a top section of a base onto the middle section, per manufacturer
4476 recommendations. The thickness of the top section should be such that the elevation of
4477 the top of the section is $1\frac{3}{8}$ inch (35 mm) below the finished surface of the flexible
4478 pavement.
- 4479 10.3.11 After paving is completed, bore a 2-inch (50 mm) hole through the pavement surface
4480 layer to accurately locate the center punch mark of the cover plate.
- 4481 1. Core a hole 1 inch (25 mm) larger in diameter than the base centered over the base.
4482 2. Install the grooved spacer ring and any necessary flat spacer rings to position the
4483 light fixture at the FAA specified elevation for the lighting system being installed.

3. To preserve the base integrity and proper bolt torque, a maximum of three spacer rings may be stacked together.

Note: The 3-maximum spacer ring requirement includes the upper flange ring – so there would be 2 spacer rings with the flange ring (or a grooved flange ring with a mud dam).

- 10.3.12 The top of the fixture edge (highest edge if fixture is not exactly level and/or installed on a crowned pavement) must be between +0 inch (0 mm) and $-1/16$ inch (2 mm) from the pavement surface. See Figure A-35 for application of tolerance on crowned pavement sections.

- 10.3.13 Fill the space between the walls of the cored hole and the outer walls of the top section with liquid **P-606 sealant that is compatible with surrounding asphalt per AC 150/5370-10**, P-606. After the P-606 sealant has cured, fill the remaining space with AC 150/5370-10, P-605 Type III sealant (compatible with asphalt) up to the top of the protective dam, if installed, or up to the top of the grooved spacer ring.

- 10.3.14 Complete the installation of the primary cable, transformers, and connectors. Install an “O” ring gasket. Then, install the bolts, with lock washers, and tighten them to the manufacturer’s recommended torque.

10.4. Overlay – Rigid.

10.4.1 With Existing Lights.

This procedure assumes that the existing pavement being overlaid has load bearing lights that are in satisfactory condition:

1. Remove all existing light fixtures and related components. Existing components in good condition may be reused, if appropriate. Protect the ends of existing cables with tape.
2. Determine the length of the light base extension required to position the light fixture at the specified elevation for each light location.
 - a. Fit each extension with a mud plate and plywood cover to protect the flange during the paving operation.
 - b. After the paving train has cleared the light base, remove excess concrete from the top of the extension and finish the edge of the opening around the base to a smooth radius.
 - c. The surface of the pavement around the light base must be level with the surrounding pavement; dished or **mounded** areas are not acceptable.
 - d. See Figure A-35 for the tolerances on light fixture elevations on crowned pavement.
 - e. The installation should be made with utmost care to avoid costly remedial action.

- 4521 f. The thickness of the plywood and mud plate must be such that the mud plate is
4522 level with the surface of the pavement to be overlaid to allow clearance for the
4523 paving operation.
- 4524 3. After the pavement has hardened, check the elevation of the top flange in relation to
4525 the finished surface.
- 4526 a. If necessary, install a grooved spacer ring, or grooved spacer ring and flat spacer
4527 ring, to bring the light fixture to the correct elevation.
- 4528 b. For adjustable **light bases**, see paragraphs 11.1 and 11.4.
- 4529 4. Next, install primary cable, transformers, and connectors. Install an “O” ring
4530 gasket. Then, install the hold-down bolts and tighten them to the manufacturer’s
4531 recommended torque.
- 4532 5. If the paving technique uses more than one lift to achieve the required thickness,
4533 alter the above procedure, as follows:
- 4534 a. A sectional light base is required.
- 4535 b. After the bottom section has been installed as described above, place the first
4536 paving lift.
- 4537 c. When the flange is exposed, clean it and install the next base section with a
4538 silicone sealant equal to RTV-118 between the sections.
- 4539 d. Tighten the sections in place.
- 4540 e. Install lights.
- 4541 f. See paragraph 10.4.1 item 4 above.

4542 10.4.2 Without Existing Lights.

4543 The installation of a light base and conduit system in a pavement to be overlaid with
4544 concrete is similar to that of a new rigid pavement installation, except that the bottom
4545 section of the light base and the conduit are set in openings made in the existing
4546 pavement.

4547 10.4.2.1 The required concrete anchor and steel reinforcing cage will be similar to
4548 that described in paragraph 10.2 item 2.

4549 10.4.2.2 The use of a short length of liquid-tight flexible conduit is usually
4550 necessary to allow proper alignment.

4551 10.4.2.3 The installation of the conduit system requires sawing and trenching the
4552 existing pavement or the use of directional boring beneath the existing
4553 pavement.

4554 10.4.2.4 Directional boring techniques have been successfully used for lights
4555 located nearer the edge of wide pavements.

10.5. **Overlay – Flexible.**

10.5.1 With Existing Lights.

This procedure assumes that the pavement being overlaid has existing load bearing lights that are in satisfactory condition. See Figure A-101.

10.5.1.1 Remove all existing light fixtures and related components. Existing components in good condition may be reused, if appropriate. Protect the ends of existing cables with tape.

10.5.1.2 Install a plywood cover with a mud plate (see AC 150/5345-42) on the existing base. The thickness of the plywood and mud plate must be such that the mud plate is level with the surface of the pavement to be overlaid to allow clearance for the paving operation.

10.5.1.3 After the pavement overlay has been placed, locate the mud plate by using a metal detector, magnet, or precise surveying.

10.5.1.3.1 Core out a 1 to 2-inch (25 to 50 mm) diameter hole in the overlay pavement down to the mud plate.

10.5.1.3.2 Using the pattern of the raised concentric circles on the mud plate, determine the center of the light base.

10.5.1.4 Mark the pavement for coring using the center of the light base as the center of the core.

10.5.1.4.1 The core diameter should be equal to the light base diameter, plus 1 inch (25 mm).

10.5.1.4.2 Core drill through the new overlay pavement sufficiently deep to remove the overlay pavement, the steel protection plate, and the plywood cover.
For adjustable **light** bases, see paragraphs 11.1 and 11.4.

10.5.1.5 Order light base extensions and grooved spacer rings to the total length required to place the light fixture at the proper elevation.

10.5.1.6 Once the extensions and grooved spacer rings are received, bolt them in place on the existing light bases.

10.5.1.6.1 Install the “O” ring in the grooved spacer rings in the light fixture.

10.5.1.6.2 Install the light fixture and apply nickel-based anti-seize compound to all bolts and torque them to the manufacturer recommendations.

10.5.1.6.3 Fill the void surrounding the extension with sealant until it is level with the top of the protective dam.

10.5.1.7 Take **care** to prevent any sealant from flowing over the top of the protective dam.

- 4591 10.5.2 Without Existing Lights
- 4592 10.5.2.1.1 The installation of a light base and conduit system in a pavement without
- 4593 lights to be overlaid is similar to that of a new flexible pavement
- 4594 installation, except that the bottom section of the light base and the
- 4595 conduit are set in openings made in the existing pavement.
- 4596 10.5.2.1.2 The required concrete anchor and encasement of the conduit **is** similar to |
- 4597 that described in paragraph 10.5.1.
- 4598 10.5.2.1.3 The use of a short length of liquid-tight flexible conduit allow**s** proper |
- 4599 alignment.

4600

Page Intentionally Blank

CHAPTER 11 Fixture Mounting Bases

11.1. General.

This section recommends installation methods and techniques. Other methods and techniques, and variations of those outlined here, may be used provided they are approved by the appropriate district FAA Airports Office. Correct placement of the lights is of prime importance; to achieve this, careful attention to detail is required. Survey instruments may be used to accurately position all fixtures for their precise location, elevation, and azimuth. The tolerances required in other FAA Advisory Circulars, this specification, and the plans must not be exceeded. The light beam must be aligned as described in the lighting system manual with a tolerance of ± 1 degree. The lighting fixture must be level, and the top of the fixture edge must be between +0 inch and -1/16 inch from the pavement top; see [Figure A-35](#) for application of tolerance on crowned pavement sections:

11.2. L-868 Mounting Bases.

The L-868 bases are load-bearing bases and are certified per [AC 150/5345-42](#). There are adjustable height bases that are certified. Installation methods for these bases must adhere to manufacturer's instructions.

11.2.1 New Rigid Pavements.

11.2.1.1 This system requires careful attention to detail during installation. One of two conditions will be encountered during installation: the edge of existing pavement **is** available as a reference for setting the new bases; or no existing edge is available and the bases must be set "in space."

11.2.1.2 The availability of an existing pavement edge simplifies the task of positioning the light base to the theoretical pavement grade.

11.2.1.3 A setting jig is required to hold the base in position while the concrete anchor is placed. See [Figure A-36](#), [Figure A-102](#) and [Figure A-103](#).

11.2.1.4 Elevation of the base with respect to the runway surface and azimuth with respect to the centerline are two parameters that must be met.

11.2.1.5 It is absolutely necessary that the elevation of the light base top flange be at least the thickness of the light fitting plus the thickness of typical paving tolerances ($\pm \frac{1}{2}$ inch (13 mm)) below the pavement finished surface.

11.2.1.6 If less than that remains after paving, the lighting fixture will be unacceptably high. If more than 3/4 inch (19 mm) is left, flat spacer rings can be used to bring the lighting fixtures up to the correct elevation.

11.2.1.7 To preserve the base integrity and proper bolt torque, a maximum of three spacer rings may be stacked together.

Note: Spacer rings starting at 1/16 in. and flange rings starting at 1/4 in. can be used in increments of 1/16 in. You can combine spacer rings of different thickness, just as you can combine spacer and flange rings. Nevertheless, avoid using more than three rings if each is less than 3/8 in. thick.
Never use more than two rings to make adjustments under 3/8 in.

11.2.1.8 At each light location, make an excavation in the runway base which is large enough to accommodate the light base, the reinforcing steel cage, and concrete for the anchor. Typical excavation is 6 inches (152 mm) around the base and 6 inches (152 mm) beneath the base.

11.2.1.9 After the excavation is completed, the light base and reinforcing steel cage are installed and held in place with the jig.

1. The jig establishes the elevation and azimuth of the base and maintain this position until the concrete anchor is placed.
2. If bases have threaded conduit openings, ensure the conduit does not move the base. Using 2 ft. (0.6 m) of flexible conduit on one entry to the base can resolve this concern.
3. If bases are provided with openings, neoprene grommet slip connections offer more flexibility and can be installed directly into the base.
4. Flexible conduit or grommet conduit openings allow adjustments in light base alignment before the concrete anchor is placed.
5. Take care while placing the concrete anchor that neither the jig nor the light base alignment is disturbed.
6. The jig must remain in place until the concrete has set. During paving operations, the light base may be fitted with a steel cover plate (mud plate).
7. After the paving train has cleared the light base, remove excess concrete from the top of the base, and the edge of the opening around the base should be finished to a smooth radius.
8. An alternative is to allow the pavement to cure and, using a core bit, core the opening directly over the light base.

11.2.1.10 The surface of the pavement around the light base must be level with the surrounding pavement; dished and mound areas are not acceptable.

1. Check the elevation of the top flange in relation to the finished surface.
2. If necessary, install a grooved spacer ring, and/or flat spacer ring, to bring the light fixture to correct elevation.
3. Next, install primary cable, transformers, and connectors.
4. Connect lighting fixture to secondary cable.

5. Install “O” ring gasket if using grooved spacer ring and torque hold-down bolts to manufacturer’s recommendations.

11.2.1.11 If the paving technique utilizes more than one “pass” of the paving machine, the above procedure is altered as follows:

1. A sectional light base is required; after the bottom section is installed as described above, the first pass is completed.
2. The flange is then cleaned and the next section is installed, and torqued in place.
3. The paving proceeds, and the fixtures are installed as above.
4. Equip the system with drains as required at the low spots.

11.2.2 New Flexible Pavement.

A sectional base is required for flexible pavement. Because flexible pavement finished elevation can settle, it is necessary for the installation design to take this fact into account. The light fixture must be able to be lowered without requiring the base to be removed.

1. The bottom section of the light base (including concrete anchor) and the conduit system are installed in the pavement base as described in the preceding paragraph.
2. It is then paved over. The light base with a 5/8 inch (16 mm) thick plywood cover and mud plate (target plate), concrete anchor, and conduit backfill must not be higher than the base surface.
3. After the paving is completed, bore a 2 to 4-inch (50-100 mm) hole to accurately locate the center punch mark of the bottom section of the mud plate.
4. If the bottom section is to be buried for longer than 90 days before discovering, it is suggested a 3/4 inch (19 mm) thick galvanized mud plate be utilized in lieu of plywood.
5. Obtain a combination of a base top section and a grooved spacer ring or flat spacer ring (for future adjustability) that equals 3/4 (19 mm) less than the dimension measured.
6. When the top section is received, drill a core opening one inch larger than the diameter of the light base and install the top section, grooved spacer ring and light fixture.
7. Fill the space between the walls of the hole up to the top of the top section with AC 150/5370-10, P-606 sealant compatible with asphalt.
8. Fill the remaining space with AC 150/5370-10, P-605 sealant to the top of the protective pavement dam on the grooved spacer ring or flat spacer ring. See Figure A-37.

Note: Determine if sealants are compatible before application. Consult the sealant manufacturer about sealant compatibilities.

11.2.3 Flexible Overlay.

The installation of the light base and conduit system in a pavement to be overlaid is similar to that of a new flexible pavement except the bottom section of the light base and the conduit are set in openings made in the existing pavement. The required concrete anchor and encasement of the conduit **is** similar to that described in paragraph 11.2.2.

11.2.4 Rigid Overlay.

The installation of the lighting base and conduit system requires a combination of techniques outlined in preceding paragraph 11.2.1, and paragraph 11.2.3. The base and conduit are installed as in paragraph 11.2.3; concrete is placed as in paragraph 11.2.1.

11.3. **Direct-Mounted (Inset) Fixtures.**

While the installation of direct mounted fixtures is becoming less common, there are instances when they are still applicable, e.g., overlays.

11.3.1 We do not recommend the use of direct mounted fixtures for flexible pavements in very cold climates.

11.3.1.1 There are two different types of direct mounting: base-mounted and direct mounted.

11.3.1.2 Base mounting requires shallow inset bases that provide a mounting flange and a cavity for the cabling.

11.3.1.3 Direct mounted fixtures are constructed so that the fixture itself can be mounted in the pavement.

11.3.1.4 Installation details are similar for both types.

11.3.1.5 In both instances, the pavement directly supports the base or fixture. The pavement is cored to a depth necessary to accept the shallow base, and the base is secured to the bottom of the cored hole with mechanical fasteners and adhesives.

11.3.1.6 For additional details, see Figure A-39, Figure A-40, Figure A-41, Figure A-42, Figure A-43, Figure A-104, Figure A-105, Figure A-106, Figure A-107 and Figure A-108.

11.3.2 Rigid Pavements.

The installation procedures for direct mounted fixtures in rigid pavements are the same, whether the pavement is new, overlay, or existing.

11.3.2.1 **Core** holes or recesses in the pavement to accommodate the shallow bases or fixtures, and **saw** wire ways to accommodate electrical wiring.

- 4748 11.3.2.2 If wire ways have been wet-sawn, flush these wire ways with a high
4749 velocity stream of water immediately after sawing.
- 4750 11.3.2.3 Prior to installation of the sealer, **clean and dry** the wire ways.
- 4751 11.3.2.4 Pavement Coring and Sawing — Provide approximately ¼ inch (6 mm)
4752 clearance for sealant material between the bottom and sides of the shallow
4753 base or fixture and the recess. Provide extra depth where sawed wire ways
4754 cross pavement joints. See Figure A-39 for details.
- 4755 1. Prior to placing the shallow inset base or fixture into the cored hole,
4756 clean all external surfaces to ensure adequate bond between the base,
4757 sealer, and pavement.
 - 4758 2. Sandblast the area as necessary.
 - 4759 3. When placing the light fixtures, avoid handling the fixtures by the
4760 electrical leads.
 - 4761 4. Orient the fixture and arrange the leads with respect to their splicing
4762 position in the wire ways.
 - 4763 5. Use temporary dams, if required, to block the wire way entrance into
4764 the drilled hole.
 - 4765 6. These dams will retain the sealer during the setting of the inset base
4766 receptacle.
 - 4767 7. The positioning tolerances for the base or fixture must be per FAA
4768 specifications for the type of lighting system being installed.
 - 4769 8. Rugged, well-designed jigs are required to ensure proper azimuth,
4770 elevation, and level.
 - 4771 9. Cover the bottom of the inset base or fixture with AC 150/5370-10, P-
4772 606 or an approved **equivalent** paste type adhesive material.
 - 4773 10. Also, place paste in the cored hole. Place the base or fixture in the
4774 cored hole to force adhesive up the sides of the base at least ⅛ inch (3
4775 mm).
 - 4776 11. Work out any entrapped air. Use a liquid sealer, AC 150/5370-10, P-
4777 605 or approved equivalent, to fill the space between the base and the
4778 sides of the cored hole.
 - 4779 12. **Apply** liquid sealer only between the inset base receptacle and the
4780 sides of the cored hole; **do not be apply the sealer** between the sides of
4781 the cored hole and the top assembly (see Figure A-105).
 - 4782 13. Typical transformer housing and conduit installation details for direct
4783 mounted lighting systems are shown in Figure A-38, Figure A-41 and
4784 Figure A-104.

11.3.2.5 Wire ways.

Prior to installing the wires in the pavement, chamfer or round to a 2-inch (50 mm) radius the vertical edges of the wire ways at intersections and corners (see Figure A-105). Sandblast and clean wire ways to ensure a proper bond between the pavement and the sealer.

11.3.2.6 Wires

1. Place the #10 AWG THWN wires in the wire ways from the transformers near the taxiway edge to the light fixture leads.
2. Use an adequate number of wedges, clips, or similar devices to hold the wires in place at least ½ inch (13 mm) below the pavement surface.
 - a. The spacing between wedges, clips, etc., must not exceed 3 ft. (0.9 m). Wood wedges and plugs are not acceptable.
 - b. Install the tops of the wedges below the pavement surface.
3. Splice the light fixture leads to the #10 AWG wires. Use pre-insulated connectors. Make the crimped splice with a tool that requires a complete crimp before releasing.
 - a. Stagger the location of the splices. Permit no splices in the single conductor wires at each fixture.
 - b. Where splices are unavoidable, **only make them in** approved L-868 bases (see Figure A-43).
 - c. If the installation is made in stages, tape or seal the ends of exposed wires to prevent the entrance of moisture.
4. Seal the wires in the wire ways with AC 150/5370-10, P-606 material.
 - a. **Apply** adhesive **only** on a dry, clean surface, free of grease, dust, and other loose particles.
 - b. The method of mixing and application must be per AC 150/5370-10, and in accordance with manufacturer recommendations.
 - c. Installation methods, such as surface preparation, mixing ratios, and pot life, are as important to satisfactory performance as the properties of the material.
 - d. You may wish to require a manufacturer's representative to be present during the initial installation of the material to ensure the installation procedures are per manufacturer directions and the following steps:
 - e. Pour sealant in the wire way until the surface of the wire is covered.
 - f. If recommended by the manufacturer, pour clean sand into the liquid sealant until a slight amount of sand shows on the surface. Use clean sand that can pass through a number 40 (425 µm) sieve.

- g. Fill the remainder of the wire way with a liquid sealant to between 1/8 inch (3 mm) and 1/4 inch (6 mm) below the pavement surface.

11.3.3 Flexible Pavements

The installation procedures for direct mounted fixtures in flexible pavements are the same whether the pavement is new, overlay, or existing. Install direct mounted light fixtures and wires in flexible pavements in a manner similar to the installation procedures for rigid pavements, with the following precautions:

1. Clean the holes and wire ways immediately before installation so that the clean, dry aggregate of the pavement is exposed.
2. **To seal wires in wire ways**, use a sealant that conforms to AC 150/5370-10, P-606 and is compatible with asphalt per ASTM D-3407, Standard Test Method for Joint Sealants, Hot Poured, for Concrete and Asphalt Pavements.
3. Mix the AC 150/5370-10, P-606 sealant (for use on fixtures) so that it sets up within 15 minutes.
4. Install the junction boxes on runways where overlays are anticipated.
5. When additional pavement is required, remove the inset light and fit the base with a cover.
6. Apply paving over the light base and junction box.
7. When the paving is complete, expose the junction box and light base by coring.
8. Remove the covers.

11.4. **Field Adjustable L-868 Mounting Bases.**

11.4.1 General.

11.4.1.1 L-868 bases may be utilized that have an integral top section and an extension that **can be** field adjusted to the height of the surrounding pavement.

11.4.1.2 The bases are suitable for use in many of the applications that would normally require the addition of bases' extensions or flat spacer rings to raise the base flange ring to the surrounding pavement elevation (see paragraph 11.2.2 item 2 as an example).

11.4.1.3 The field adjustable bases and extensions vary in how they must be installed, but they still must be able to meet the same elevation and azimuth alignment requirement (paragraph 11.1) along with a future adjustability capability, as required, of conventional bases and extensions.

11.4.1.4 The inspection authority must, at the time of installation, ensure that the bases are installed per the manufacturer's instructions and that the locking devices are correctly installed.

11.4.1.5 Failure to do so may compromise the base's ability to withstand the loading and torque requirements specified for a load bearing base.

11.5. Installation.

The systems must be installed per the NEC as applicable, and/or local code requirements:

11.5.1 L-867 Light Base and Transformer Housing for Elevated Light Fixtures.

1. When using non-adjustable cans, the light base must be as shown in Figure A-24.
2. If the soil is unsuitable, then **remove** an adequate depth of soil and replace **it** with compacted acceptable material.
3. **Orient** the cable entrance hubs in the proper direction.
4. Level the light base so that the mounting flange surface is approximately one inch above the finished grade.
5. With the base properly oriented and held at the proper elevation, place approximately 4 inches (10 cm) of concrete backfill around the outside of the base.
6. **Slope** the top of the concrete away from the flange portion of the base so the sloped outer edges of the concrete are at surface grade.
7. If concrete backfill is omitted, select earth backfill must be compacted to maintain proper orientation and elevation of the base.
8. In closed duct systems installed in soil conditions of good drainage, use light bases having a drain to prevent **excessive** water accumulation.

11.5.2 Light Base and Transformer Housing for In-pavement Light Fixtures.

1. **Support** the light base in the leave-out or excavated area in a position as shown in Figure A-36 and Figure A-37.
2. Orient the light base so that the cable entrance hubs on the base are properly aligned and so that the in-pavement light fixture will be properly aligned, when installed, prior to placing the concrete backfill.
3. When installed in bituminous pavement, leave the concrete backfill 3-4 inches (8-10 cm) low to allow completing the backfill with bituminous material after the concrete has cured.

11.5.3 Stake (Angle Iron) Mounting.

1. Install the stake in a 6-inch (15 cm) diameter hole at a depth of 30 inches (76 cm) as shown in Figure A-24.
2. **Do not** install stake by driving. Make electrical connections and backfill around the stake with thoroughly compacted earth passing a 1 inch (2.54 cm) sieve.
3. Where required due to unstable soil conditions, backfill with concrete.

4. Install the top of the stake even with, or not more than ½-inch (1.3 cm), above the finished grade, and maintain within one degree of the vertical.
5. In areas where frost may cause heaving, anchor the stake with concrete and use a permeable backfill material such as sand around the buried electrical components, and then cover the top surface with an impervious material to reduce moisture penetration.

11.5.4 Light Fixtures - General.

11.5.4.1 The light fixtures consist of an optical system, lamp, connecting leads, and a mounting assembly.

11.5.4.2 Connect **the light fixture** to **its** mounting, level, and adjust the light fixture per the manufacturer's instructions.

11.5.4.3 For incandescent light fixtures, **ensure** that the lamp specified by the manufacturer for the particular use of the light fixture is installed.

11.5.4.4 For LED light fixtures, do not attempt disassembly unless it is directed in the manufacturer's instructions.

11.5.4.5 Level and align the light fixtures per the manufacturer's instructions.

11.5.4.6 The standard height of the top of the elevated light fixture is 14 inches (35 cm) above the finished grade.

11.5.4.7 In areas where the mean annual total snowfall exceeds 2 ft. (0.6 m), this standard elevation may be increased as illustrated in Figure A-109.

11.5.4.8 To facilitate maintenance of light fixtures, we recommend that identification numbers be assigned and installed by one of the following or similar methods:

1. Stencil numbers with black paint on the runway side of the base plate.
 - a. Attach a non-corrosive disc with permanent numbers to the **light** fixture.
 - b. A minimum height of the numbers of 2 inches (5 cm) **is recommended.**
2. Impress numbers on a visible portion of the concrete backfill.
 - a. **It is** recommended that the minimum height of the numbers be 3 inches (8 cm).
 - b. A permanent survey marker may also be installed in the concrete base or pavement.

11.5.5 Base-mounted Light Fixtures.

1. This type of installation is normally used only with series circuits to house the isolation transformer and accommodate a closed duct system.
2. Prior to mounting the light fixture on the base, **install** an AC 150/5345-26, L-823 connector kit on the primary power cable ends and **then install** the appropriate AC 150/5345-47, L-830 isolation transformer.
3. Wrap the connector joints in the primary circuit with at least one layer of rubber or synthetic rubber tape and one layer of plastic tape, one-half lapped, extending at least 1-1/2 inches (4 cm) on each side of the joint.
4. Heat-shrink tubing may be substituted.
5. Typical **light** fixture and cable details are shown in Figure E-8 of Appendix E and Figure A-24 of Appendix A.
6. Plug the light disconnecting plug into the transformer secondary receptacle. Do not tape this connection.

11.5.6 Stake-mounted Light Fixtures.

1. For series circuits, make connections and install the transformer as detailed in the previous paragraph.
2. Bury the transformer primary cable connectors at least 10 inches (25 cm) deep and adjacent to the stake as shown in Figure A-24. By burying the components in like locations at each stake, maintenance of the underground system is facilitated.
3. When installed in a location where the frost line depth exceeds the minimum cable installation depth, as specified in AC 150/5370-10, Item L-108, increase to a maximum of 2 ft. (0.6 m) in depth the installation of the cable, transformers, and connectors.
4. Do not attach cable connectors to the stakes.
5. Install primary cable connectors, splices, and transformers at the same depth and in the same horizontal plane as the primary cable with adequate slack provided.
6. The radius of cable bends must not be less than 10 inches (25 cm).
7. Place the secondary leads from the transformer to the lamp socket in a loose spiral with excess slack at the bottom.

11.5.7 Shielding Taxiway Lights.

1. To shield undesirable blue light to landing pilots or lessen the “sea-of-blue” effect, metal shields or hoods are available, as an option, from the lamp manufacturers.
2. Orient **light** fixtures with masked lamps by rotating the fixture on its mounting for proper light pattern before securing in place.
3. **For both incandescent and LED lamps the use of the minimum current step possible is desirable to adjust the blue light level to match visibility conditions. This feature also prolongs lamp life (applicable to incandescent lamps only).**

4966
4967

4. Proper control circuiting also helps to eliminate the “sea-of-blue” effect by providing lighting only where it is needed.

|

4968

Page Intentionally Blank

CHAPTER 12 Equipment and Material.

12.1. General.

This chapter covers the equipment and materials used for the installation of the airport lighting systems.

12.2. Light Bases, Transformer Housings, and Junction Boxes.

Use a base and transformer housing per AC 150/5345-42. If the secondary wires are routed to the in-pavement lights through a saw kerf, **weld** a one-inch hub to the base at 90 degrees from the two existing two inch hubs, which are 180 degrees apart. A gasket and suitable cover also are required for off-taxiway installation. Local conditions may require other modifications to the bases.

12.2.1 Definitions:

12.2.1.1 Load Bearing.

Any application which is subjected to aircraft and/or other heavy vehicular loading, either static or dynamic; these are generally located on runway and taxiway roll-over areas (stabilized zones).

12.2.1.2 Non-Load Bearing.

Any application where a light fixture might be subjected to an occasional light vehicle load, but not aircraft or heavy vehicles. A typical installation area would be off the main stabilized area adjacent to a runway or taxiway.

12.3. Duct and Conduit.

Specifications and standards for electrical duct and conduit are available in AC 150/5370-10, Item L-110.

12.3.1.1 Duct and Cable Markers.

All locations of the ends of ducts and all direct burial cable must be marked with concrete marker slabs, as discussed below (see Figure A-110 for duct and cable marker details):

12.3.1.1.1 Duct Markers.

1. Mark the location of the ends of all ducts by a concrete marker slab 2 ft. (0.6 m) square and 4 inches (100 mm) thick extending approximately 1 inch (25 mm) above the surface.
2. Locate the markers above the ends of all ducts or duct banks, except where ducts terminate in a handhold, manhole, or building.
3. **Impress the** word “duct” on each marker slab, as well as the number and size of ducts beneath the marker.

4. The letters must be 4 inches (100 mm) high and 3 inches (75 mm) wide, with width of stroke ½ inch (12 mm) and ¼ inch (6 mm) deep or as large as the available space permits.

12.3.1.1.2 Cable Markers.

1. Mark the location of underground cables by a concrete marker slab, 2 ft. (0.6 m) square and 4 inches (100 mm) thick, extending approximately 1 inch (25 mm) above the surface.
2. Mark each cable run from the line of runway lights to the equipment vault at approximately every 200 ft. (61 m) along the cable run, with an additional marker at each change of direction of cable run.
3. **Mark** all other cable buried directly in the earth in the same manner. Markers are not required where cable lies in straight lines between obstruction light poles that are spaced 300 ft. (90 m) apart or less.
4. Install cable markers immediately above the cable.
5. The word “cable” and directional arrows must be impressed on each cable-marking slab.
6. The letters must be approximately 4 inches (100 mm) high and 3 inches (75 mm) wide, with width of stroke ½ inch (12 mm) and ¼ inch (6 mm) deep.
7. **Mark** the locations of each underground cable connection, except at lighting units or isolation transformers, by a concrete marker slab placed above the connection.
8. **Impress** the word “splice” on each marker slab. Additional circuit information may also be required on each marker slab.

12.4. Cable, Cable Connectors, Plugs, and Receptacles.

Specifications and standards for airport cable are available in AC 150/5345-7. Specifications and standards for plugs, receptacles, and cable connectors are available in AC 150/5345-26.

12.4.1 Cable Installation Series Circuit.

12.4.1.1 General.

Although primary cables and control cables may be direct buried, it is preferred to install them in conduits per AC 150/5370-10, Item L-108. Primary cables carry the current from the output of the CCR to the primary side of the isolation transformers.

12.4.1.2 EMI.

Airfield lighting circuits can generate excessive EMI that can degrade the performance of some of the airport critical air navigational systems, such as RVR equipment, ILS equipment, etc. The following cautionary steps

may help to decrease EMI and/or its adverse effects in the airport environment:

1. Do not install cables for airfield lighting circuits in the same conduit, cable duct, or duct bank as control and communications cables.
2. Do not install cables for airfield lighting systems so that they cross control and/or communications cables.
3. In some cases, you can install harmonic filters at the CCR output to reduce EMI emitted by the CCR. These filters are available from some CCR manufacturers.
4. Ground spare control and communication cables.
5. Notify manufacturers, designers, engineers, etc. about existing navigational equipment and the potential for interference.
6. Require electromagnetic compatibility between new equipment and existing equipment in project contracts. Operational acceptance tests may be required to verify compliance.

12.4.1.3 **Direct Burial Cable.**

1. Seal cable ends during construction to prevent the entrance of moisture.
2. When using L-867 light bases in a system, provide at least 2 ft. of slack cable to permit connections of the primary cable and the isolation transformer primary leads to be made above ground.
3. Trenching, installation of cable, backfilling trenches, and the installation of cable markers must conform to AC 150/5370-10, Item L-108.
4. Cable plowing is allowed where suitable soil conditions exist.

12.4.1.4 **Primary Cable Installation.**

1. We recommend installing the primary cable in a duct or conduit from the CCR into a light base and transformer housing in the field.
2. Provide slack cable in each light base and transformer housing to permit connections of the primary cable and the isolation transformer primary leads to be made above ground.
3. Seal the cable entrance of the light base transformer housing with squeeze connectors, where specified.
4. The squeeze connectors are provided with a rubber bushing of the correct size to fit the outside diameter of the cable.
5. Tighten the squeeze connectors to provide a watertight seal without deforming the insulation and jacket of the cable.

6. Tape the ends of the cables to prevent the entry of moisture until connections are made.

12.4.1.5 Cable in Duct and/or Conduit.

1. Install all power or control cables in ducts and conduits to conform to AC 150/5370-10, paragraph 108-3.2.
2. Provide slack cable for connections.
3. Install the duct and/or conduit conforming to the requirements of AC 150/5370-10, paragraph 110-3.1.

12.4.1.6 Primary Cable Connections.

1. Make inline splices on the primary underground cables **per** AC 150/5370-10, Item L-108.
2. Use connectors conforming to AC 150/5345-26.
3. Splices in ducts, conduits, or in the primary cables between light base and transformer housings are not permitted.
4. When field-attached plug-in connectors are employed, use a crimping tool designed for the specific type of connector to ensure that crimps or indents meet the necessary tensile strength.
5. Wrap the connector joints in the primary circuit with at least one layer of rubber or synthetic rubber tape and one layer of plastic tape, one-half lapped, extended at least 1½ inches (38 mm) on each side of the joint.
6. Heat-shrink material may be used.
7. We recommend that the heat-shrink material be installed over the completed connection.

12.4.1.7 Secondary Lead Connections.

1. **Make** connections between the secondary isolation transformer leads and the wires with a disconnecting plug and receptacle conforming to AC 150/5345-26.
2. Attach the L-823, Class B, Type II; Style 4 plug on the ends of the two wires using a crimping tool designed for this connector to ensure that a crimp or indent meets the necessary tensile strength.
3. Insert this connector into the transformer secondary receptacle.

12.4.1.8 Identification Numbers.

1. **Assign** identification numbers to each station (transformer housing installation) per the plans.

2. Place the numbers to identify the station by one of the following methods:
 - a. Stencil numbers of a 2 inch (51 mm) minimum height using black paint on the pavement side of the transformer housing base plate.
 - b. Attach a non-corrosive metal disc of 2 inch (51 mm) minimum diameter with numbers permanently stamped or cut out under the head of a transformer housing base plate bolt.
 - c. Stamp numbers of a 3 inch (75 mm) minimum height on a visible portion of the concrete backfill surrounding the L-867 base.

12.5. Counterpoise (Lightning Protection System).

The purpose of the counterpoise system (lightning protection system) is to provide a low resistance preferred path for the energy from lightning discharges to enter the earth and safely dissipate without causing damage to equipment or injury to personnel. The counterpoise system is installed on airfields to provide some degree of protection against the energy induced from lightning strikes to underground power and control cables.

The counterpoise is a separate system and must not be confused with the light base ground (for series constant current circuits) and equipment grounds (for parallel voltage circuits). Both grounding methods are intended to provide a low impedance current path to earth for an unintentional conductive connection between an ungrounded conductor (power) and normally non-current carrying conductors (example: a short from the power conductors to the light base).

For additional details about airfield lightning protection systems, see NFPA 780, *Standard for the Installation of Lightning Protection Systems*.

12.5.1 Counterpoise Conductor.

The counterpoise conductor is a bare solid copper wire, **minimum #6 AWG. The design engineer may specify #4 AWG if in areas of high lightning frequency. Using #4 AWG wire will result in higher cost.**

12.5.1.1 The #6 AWG conductor is bonded to ground rods spaced a maximum of 500 ft. (152 m) apart.

12.5.1.2 The #6 AWG conductor is bonded to the ground rod using an exothermic weld.

12.5.1.3 The ground rods may be in-line with the #6 AWG counterpoise conductor.

12.5.2 Counterpoise Installation.

1. Where cable and/or conduit runs are adjacent to pavement, such as along runway or taxiway edges, **install** the counterpoise 8 inches (203 mm) below grade and located half the distance from edge of pavement to the cable and/or conduit runs (see Figure A-111).

2. For light base/light fixtures not embedded in rigid or flexible pavement, where the counterpoise cannot be installed in a separate trench, the counterpoise is routed around the light base and is not physically bonded to the light fixture base or mounting stake.
 3. For locations where there is an added potential for lightning damage (for example, airports located in the southern United States), the counterpoise may be bonded to the light base or light fixture mounting stake.
 4. For light bases/light fixtures embedded in rigid or flexible pavement, **bond** the counterpoise conductor to an exterior ground lug on the light fixture bases (for example: runway touchdown zone lights, runway centerline lights, and taxiway centerline lights) installed in pavement.
 5. Where cable and/or conduit runs are under pavements, **install** the counterpoise 4 inches (102 mm) minimum above the cable and/or conduit.
 6. **Calculate** the height above the cable and/or conduit to ensure the cables and/or conduits to be protected are within a 45-degree zone of protection below the counterpoise.
 7. **Bond** the counterpoise conductor to ground rods that are located on each side of a duct crossing (terminating the counterpoise on each side of a duct crossing).
 8. Where conduit or duct runs continue beneath pavement (i.e., apron areas, etc.), install the counterpoise a minimum of 4 inches above conduits or ducts along the entire run.
- Note:** For galvanized steel light bases, see Galvanized Light Base Exception.
9. The counterpoise is also bonded to the rebar cage (if used) that is installed around the light base.
 10. Where non-metallic light bases (Type L-867, Class II) are used under rigid or flexible pavement, the counterpoise is not bonded to the light base and must be routed around it.
 11. Type L-867, Class I bases (metal) that are installed under rigid or flexible pavement must bond the counterpoise to the exterior ground lug.

12.5.3 Bonding with Exothermic Welds.

- 12.5.3.1 **Use** exothermic welding for the permanent bonding of copper conductors to steel, stainless steel, and copper (see exception for galvanized light bases).
- 12.5.3.2 This includes the light base rebar cage, stainless steel light bases, and copper conductors (wire and grounding rods).
- 12.5.3.3 After the weld is completed, clean the surfaces so they are free from any slag or other debris. See AC 150/5370-10, Item L-108-3, Exothermic Bonding, for additional detailed requirements about exothermic welding.

12.5.4 Surface Preparation.

See FAA-STD-019e, December 22, 2005, *Lightning and Surge Protection, Grounding, Bonding and Shielding Requirements for Facilities and Electronic Equipment*, paragraph 4.1.1.7, for additional information about proper preparation and preservation of surfaces that are to be bonded.

Note: The FAA Standard is available for download at:

https://www.faa.gov/regulations_policies/orders_notices/index.cfm/go/document.information/documentid/1027366

12.5.5 Galvanized Light Base Exception.

Using an exothermic weld to bond the counterpoise conductor to the external lug on a galvanized light base is not recommended unless:

1. The light base has a specially designed connection (for example: a ¾ inch × 3-inch steel rod) to prevent damage to the light base body zinc coating from the heat evolved during exothermic welding.
2. Contact the light base manufacturer for additional information and availability.
3. **Strictly observe** proper methods of corrosion protection and personnel protection from irritating fumes (**which** may cause metal fume fever).
4. The heat used for the weld causes the emission of potentially irritating zinc oxide fumes and severely damages the light base protective zinc coating.
5. When the hot dip galvanized layer on a steel light base is compromised, the underlying steel will quickly rust.
6. The application of cold galvanizing compounds to the damaged areas that are both inside and outside the light base **do** not provide adequate protection against corrosion unless the surface is properly prepared prior to application of the coating.
7. This involves grit blasting or using a powered wire brush to clean all residues and slag so that a clean bare metal surface results.
8. Even with a properly applied coating, the level of corrosion protection of a coating is inferior to that of factory hot dip galvanizing.
9. The proper cleaning **of** a light base after exothermic welding may not be possible for all installations, especially where access to the interior of the light base is required.
10. If all the requirements in AC 150/5370-10, Item L108-3.7, cannot be satisfied for an exothermic weld on galvanized steel lights bases where:
 - a. a specially designed connection is not available for exothermic welding or the light base location is such that an exothermic weld is not possible;
 - b. proper surface preparation for the application of cold galvanizing compound cannot be performed;
 - c. then a connection must be used with properly listed UL 467 components that are approved for direct earth burial or installation in concrete.

- 5228 d. Certified light base manufacturers may be able to provide the required hardware
5229 (grounding straps and cable clamps) for bonding to the counterpoise – this is
5230 considered as an acceptable method of connection.

5231 **12.6. Light Base Ground.**

5232 The light base ground is a separate system and must never be confused with the
5233 counterpoise system. A ground must be installed at each light fixture **in order** to
5234 provide a degree of protection for maintenance personnel from possible contact with an
5235 energized light base or mounting stake that may result from a shorted power cable or
5236 isolation transformer.

5237 12.6.1 The light base ground must be a #6 AWG bare copper wire jumper bonded to the
5238 ground lug at the light fixture base or stake to a 5/8 inch (16 mm) by 8-foot (2.4 m)
5239 minimum ground rod installed beside the fixture.

5240 12.6.2 Installing the ground rod within the light base excavation is acceptable.

5241 12.6.3 The resistance from the ground rod to earth ground must be 25 ohms or less via
5242 measurement with a ground tester. See AC 150/5340-26 for additional information
5243 about ground rod resistance testers.

5244 12.6.4 If the soil resistivity is high (typical of well drained sandy soils or dry desert locations),
5245 additional grounding rods or other means may be necessary to meet the 25 ohms
5246 requirement. Grounding electrodes per description in NFPA 70, *National Electric*
5247 *Code*, Article 250.52 and/or NFPA 780, *Standard for the Installation of Lightning*
5248 *Protection Systems*, Article 4.13 may be used in lieu of ground rods.

5249 12.6.5 See the NEC Handbook, Article 250.56, Resistance of Rod, Pipe, and Plate Electrodes
5250 for additional information about multiple electrode installation.

5251 12.6.6 For parallel voltage power systems only, an equipment ground must be installed and
5252 connected to the ground bus at the airfield lighting vault.

- 5253 1. The equipment ground conductor must be a #6 AWG insulated wire for 600 volts
5254 (Type XHHW insulation per UL 44, Thermoset-Insulated Wires and Cables).
- 5255 2. The insulation color must be colored green.
- 5256 3. Attach the equipment ground conductor to the light base internal grounding lug (see
5257 AC 150/5345-42 for additional information about grounding lugs) at each light base
5258 or mounting stake.
- 5259 4. Connect the entire lighting circuit equipment ground to the ground bus at the vault.
- 5260 5. **Install** the safety ground conductor circuit installed in the same duct or conduit as
5261 the lighting power conductors.

5262 12.7. **Light Fixture Bonding.**

5263 **Bond** the light fixture to the light base internal ground lug via a #6 AWG stranded
5264 copper wire rated for 600 volts with green XHHW insulation or a braided ground strap
5265 of equivalent current rating. The ground wire length must be sufficient to allow the
5266 removal of the light fixture from the light base for routine maintenance. See the light
5267 fixture manufacturer's instructions for proper methods of attaching a bonding wire.

5268 12.8. **Concrete.**

5269 Specifications and standards for structural concrete are available in AC 150/5370-10,
5270 Item P-610.

5271 12.9. **Steel Reinforcement.**

5272 Steel reinforcement should conform to ASTM-A184, Standard Specification for
5273 Fabricated Deformed Steel Bar Mats for Concrete Reinforcement, or ASTM-A704,
5274 Standard Specification for Welded Steel Plain Bar or Rod Mats for Concrete
5275 Reinforcement.

5276 12.10. **Adhesive and Sealants.**

5277 12.10.1 Tape.

5278 Plastic electrical insulating tape is the type specified in Item L-108 of AC 150/5370-10.

5279 12.10.2 Wire Ways and Inset Fixtures.

5280 Specifications and standards for adhesives and sealants for wire ways and inset fixtures
5281 are available in AC 150/5370-10, Item P-606.

5282 12.10.3 Joints.

5283 Specifications and standards for joint sealant are available in AC 150/5370-10, Item P-
5284 605.

5285 12.11. **Load-Bearing Lighting Fixtures.**

5286 12.11.1 Specifications, Standards, and Certification.

5287 12.11.1.1 Specifications and standards for equipment and materials used in load
5288 bearing lighting systems are generally available in ACs published by the
5289 FAA.

5290 12.11.1.2 In addition, a third-party certification program is in effect, whereby
5291 equipment is tested and certified for conformance to FAA specifications
5292 by independent, third party certifiers. A description of the third-party
5293 certification program is available in AC 150/5345-53. A list of certified
5294 equipment is available in AC 150/5345-53, **Appendix 3**, Addendum.

5295 12.11.2 Lighting Fixture Loads.

5296 12.11.2.1 Load bearing lighting fixtures are subject to extremely heavy loads and
5297 must be installed with precision to function as intended.

5298 12.11.2.2 Aircraft parked on the fixtures generate high static loads.

5299 12.11.2.3 Static loads in excess of 200 PSI (1380 kilopascals (kPa)) completely
5300 covering the entire light fixture are common.

5301 12.11.2.4 Landing aircraft often strike the lights, generating high impact loads.

5302 12.11.2.5 Locked wheel turns and eccentric braking loads tend to twist the fixtures.
5303 Concrete anchors, some with steel reinforcing cages, support light bases.

5304 12.11.2.6 The supporting systems for lights should be accurately placed and capable
5305 of withstanding very heavy static, impact, and torsional loads.

5306 12.11.3 Lighting Fixture Alignment.

5307 12.11.3.1 All light fixtures must be aligned so that they can be seen from the desired
5308 viewpoint. See Chapter 10 and Chapter 11 for installation sequencing.

5309 12.11.3.2 The top of the fixture edge must be between +0 and $-1/16$ inch (+0 mm
5310 and -2 mm) from the low side of the pavement surface.

5311 12.11.3.3 To achieve this result, the light base, whether in one piece or in sections,
5312 must be aligned and held in place with jigs until finally secured.

5313 12.11.3.4 This method of installation requires precise surveying and requires utmost
5314 care to avoid costly remedial action, such as removal for azimuth or
5315 elevation correction.

5316 12.11.4 Lighting Fixture Elevation.

5317 12.11.4.1 Another important consideration common to the installation of all base-
5318 mounted lights is the need to avoid setting the lights too high (elevation).

5319 12.11.4.2 Lights that are too high may adversely affect the desired light output, and
5320 interfere with paving equipment (thus preventing proper pavement
5321 placement), and interfere with snow removal equipment.

5322 12.11.4.3 Ideally, light bases should be set at an elevation that provides the correct
5323 elevation of the light fixture and proper pavement placement, with
5324 minimal final adjustment.

5325 12.11.4.4 Use spacer rings and extensions to adjust the elevation of light fixtures
5326 supported on fixed length bases and extensions that are set low.

5327 12.11.5 Lighting Fixture Water Protection.

5328 12.11.5.1 In-pavement lighting systems are subject to water intrusion and moisture
5329 from condensation. Water can adversely affect the performance of the
5330 lights and ice can damage systems when water expands as it freezes.

5331 12.11.5.2 Some de-icing chemicals may cause accelerated corrosion to galvanized
5332 products, as well as damage to cables and deterioration of connections.

5333 12.11.5.3 **Lighting systems may be designed as wet or dry systems.**

5334 1. In wet systems, water is expected to enter the system and provisions
5335 are made to drain it away.

5336 2. In dry systems, more emphasis is placed on preventing water from
5337 entering the system. Making provisions for water drainage is highly
5338 encouraged, even in dry systems. This can be accomplished by
5339 routing drainage conduits to low spots in the system.

5340 3. Consider base elevations, base heights, conduit slopes drain holes, and
5341 other provisions to facilitate removal of water from the base and
5342 conduit system.

5343 4. In drier areas, water may be drained from the system through drain
5344 holes in the bottom of the bases, where the water is percolated into the
5345 pavement sub-base.

5346 12.11.6 Lighting Fixture Installation.

5347 12.11.6.1 Installation methods for in-pavement load bearing lights can be grouped
5348 into four categories, fixed body length base, adjustable body length base,
5349 ground support base, and direct mounted.

5350 12.11.6.2 Light bases introduce a discontinuity in rigid pavements resulting in stress
5351 concentrations. To minimize their effects, bases should be installed so
5352 that their nearest edge is approximately 2 ft. (0.6 m) from any rigid
5353 pavement joint or another fixture. In the event of a conflict between any
5354 of the light fixtures and undesirable areas, such as rigid pavement joints,
5355 etc., the spacing should be varied per the tolerance specified for the
5356 lighting system being installed to resolve the conflict.

5357 12.12. **Inspection.**

5358 1. Inspect each light fixture to determine that it is installed correctly, at the proper
5359 height, in line with the other fixtures, level, and properly oriented.

5360 2. Check all fixture securing screws or bolts to ensure that they **are** tightened per
5361 manufacturer recommendations. Use an anti-seize compound on bolts made of
5362 stainless steel. The use of anti-seize coatings is not required when using coated

- bolts (ceramic-metallic/fluoropolymer coating) per EB #83, In-Pavement Light Fixture Bolts.
3. Check each light fixture to determine that the lenses are clean and unscratched and the channels in front of the lenses are clean.
 4. Inspect lighting fixtures concurrently with installation because of the subsequent inaccessibility of some components.
 - a. Test circuits for continuity and insulation resistance to ground before filling wire ways.
 - b. After fixtures and cables are installed, inspect the AC 150/5370-10, P-606 compound in the wire ways and around the fixtures to determine that all voids are filled and that the compound is at the proper level with respect to the pavement surface.
 5. Check fuses and circuit breakers to determine **that** they are of the proper rating.
 6. Check any light fixtures with asymmetrical lenses to determine that they are properly oriented with respect to the runway longitudinal sides and the threshold. Check all lights for alignment.
 7. Check identification numbers for each light unit to determine that the number at the installation is as assigned in the plans.
 8. Check equipment covered by FAA specifications to determine if the manufacturers have supplied certified equipment. Also check the equipment for general conformance with specification requirements.
 9. Inspect all cables, wiring, and splices to obtain assurance that the installation is per AC 150/5370-10, the NEC, and local codes. Inspect and test insulation resistance of underground cables before backfilling.
 10. Check all ducts and duct markers to determine that the installation is per AC 150/5370-10. Inspect underground ducts before backfill is made.
 11. Check the input voltage at the power and control circuits to determine that the voltage is within limits required for proper equipment operation. Select the proper voltage tap on equipment where taps are provided. Check the proper operation of the CCR's open-circuit protection. **Also check** circuitry per the manufacturer's requirements.
 12. Check base plates for damage during installation and refinish, **as required**, according to manufacturer's instructions.
 13. Check the current or voltage at the lamps to determine if the CCR current or supply voltage is within specified tolerance. If a current or voltage exceeds rated values, the lamp life will be reduced.
- 12.12.1 Testing.
- Require the Contractor to furnish all necessary equipment and appliances for testing the underground cable circuits after installation. Testing is as follows:
1. **Verify that** all circuits are properly connected per applicable wiring diagrams.

2. **Ensure that** all lighting power and control circuits are continuous and free from short circuits.
 3. **Confirm that** all circuits are free from unspecified grounds.
 4. Check that the insulation resistance to ground of all non-grounded series circuits is not less than 50 megohms. See FAA-C-1391, *Installation and Splicing of Underground Cable*.
 5. Check that the insulation resistance to ground of all non-grounded conductors of multiple circuits is not less than 50 megohms.
 6. Test installations by operating the system continuously for at least ½ hour. During this period, change the intensity of variable intensity components to ensure proper operation. Test proper operation of any photocells. In addition, operate each control within the system at least 10 times.
 7. If the system contains a monitoring system, test its operation by sequentially removing light fixtures from the circuit until the monitor indicates an error.
- Safety Warning:** Power to the circuit should be disconnected each time before a light fixture is removed from the circuit.
8. **Ensure that** the monitor indicates an error when the appropriate numbers of lights are removed from the circuit.
 9. Test the equipment for proper grounding. This test includes a check to determine that the resistance to ground on any part of the grounding system **does** not exceed the specified resistance.

12.13. **Auxiliary Relays.**

Where required, use a hermetically sealed relay having a single pole double throw (SPDT) contact arrangement rated for 5-amperes at 120-volt AC and a coil resistance of 5000 ohms in a 120-volt AC control circuit. Relay connections may be either solder terminals or plug-in.

12.14. **Vault.**

12.14.1.1 **Construct** The vault with reinforced concrete, concrete masonry, brick wall, or prefabricated steel.

12.14.1.2 All regularly used commercial items of equipment such as distribution transformers, oil switches, cutouts, etc., which is not covered by FAA specifications, must conform to the applicable standards of the electrical industry.

12.14.1.3 Use design considerations for vaults contained in AC 150/5370-10, Item L-109.

- 5438 12.14.1.4 Provide at least 2 square ft. (0.2 sq. m.) net vent area per 100 kVA
5439 installed transformer capacity in the vault where the 24-hour average-
5440 ambient temperature does not exceed 86°F (30°C).
- 5441 12.14.1.5 If the average ambient temperature exceeds 86°F (30°C), **provide** auxiliary
5442 means for removing excess heat.
- 5443 12.14.1.6 Install vault equipment, conduit, cables, grounds, and supports necessary
5444 to ensure a complete and operable electrical distribution center for lighting
5445 systems. **Keep** an up-to-date “as constructed” lighting plan available in
5446 the vault.
- 5447 12.14.1.7 When required, provide an emergency power supply and transfer switch
5448 (see Chapter 1). Install and mount the equipment to comply with the
5449 requirements of the NEC and local code agencies having jurisdiction.
- 5450 12.14.2 Maintenance.
5451 General. A maintenance program is necessary at airports with low visibility taxiway
5452 lighting systems to ensure proper operation and dependable service from the equipment.
5453 The taxiway lighting systems may be of the highest order of reliability, but their
5454 effectiveness will soon decline unless they are properly maintained. Refer to AC
5455 150/5340-26.

CHAPTER 13 Power Distribution and Control Systems.

13.1. Introduction.

This chapter discusses design considerations of power distribution and control systems used on airport visual aids. To conform to the NEC, AC power distribution to the constant current source (a CCR) and constant voltage (parallel) circuits) is required.

13.2. Power Distribution.

13.2.1 Continuous Load.

All lighting circuits and systems are considered continuous loads by the requirements of the NEC. Continuous loads are those loads that operate continuously for three hours or more. Size the feeder circuit conductors supplying the CCR or parallel circuit to carry 125% of the actual full load amperes imposed on the circuit. Also size the over current protective device (circuit breaker or fuse) protecting the feeders at 125% of the full load current on the circuit.

13.2.2 Available Fault Current.

Specify the components of the power distribution system within their fault current withstand and interrupting ratings. Perform a short circuit analysis to ensure NEC compliance.

13.2.2.1 Short Circuit Analysis.

Perform a short circuit analysis as part of the design process to enhance reliability and safety. Short circuit analysis should comply with: NEC Section 110-9, Section 110-10 and Section 110-12; and FAA Order 6950.27, *Short Circuit Analysis and Protective Device Coordination Study*. Include in the analysis critical points such as:

- Service entrance.
- Switchboards and panel boards.
- Transformer's primary and secondary.
- Transfer switches.
- Load centers.
- Fusible disconnects.

13.2.3 Equipment Layout.

When designing the equipment layout inside an airfield electrical vault, maintain the working clearances as specified in articles 110.26 and 110.34 of the NEC.

13.2.4 Balanced Load.

Balance connected loads on the distribution system between all phase legs. CCRs are single phase loads, and when supplied from a 3-phase system can cause an unbalance in

the system phases. Design the system to distribute the load among all three phases as much as possible.

13.2.5 Installation of Cables.

1. Install cables in conduit or enclosed wire ways.
2. The standard L-824 airfield lighting primary series circuit cable does not comply with NEC for installation in open trays.
3. **Run** high voltage conductors (exceeding 600 volt) in rigid steel galvanized conduit, intermediate metal conduit, flexible metal conduit, liquid tight flexible metal conduit, metal wire ways, or PVC conduit.
4. Low voltage feeders and control wires may be run in rigid steel galvanized conduit, intermediate metal conduit or PVC conduit when run under the floor slab; in rigid steel galvanized conduit, intermediate metal conduit, or electrical metal tubing (EMT) when run on the walls or ceiling; and in cable trays supported from the ceiling or walls when there are many cables and the possibility of future expansion.
5. Do not install conduit in concrete slabs on grade. Bring the primary series cable from the CCRs and various other feeders out of the vault in coated rigid steel galvanized conduit or PVC conduit, a minimum of 2 ft. (0.6 m) below grade.

13.2.6 Control Systems.

13.2.6.1 **Airfield Lighting Control.**

The control system for airfield lighting consists of control panels, relaying equipment, accessories, and circuits which energize, de-energize, select lamp brightness, and otherwise control various airfield lighting circuits based on operational requirements. Control of any one airfield lighting system is normally provided at two points only: the ATCT, and the vault which powers the system.

Note: Airport Operators should inform Air Traffic Control of variances for or modifications to airfield lighting preset standards prescribed in **FAA** requirements (see **FAA** Order JO 7110.65, *Air Traffic Control*, for additional information and requirements for airport runway and taxiway lighting).

A transfer relay assembly is provided at the vault to transfer control from the remote location to the vault when necessary:

13.2.6.1.1 **Control Voltages.**

1. Standard practice is to provide a 120-volt AC control system using low burden pilot relays (pilot relay assemblies) to activate the power switches, contacts, and relays controlling the CCRs and transformers supplying power to the airfield lighting circuits.

2. Consider the distance between the ATCT and the lighting vault when designing the control system voltage drop. Perform calculations to ensure proper operation of the relays that are being controlled.
3. The calculations could include coil burden, energize and drop-out voltage. Where the voltage-drop calculation indicates the proposed voltage may not energize the control relay, consider using a 48 volt DC control system.
4. Where both types of control systems are installed, ensure the control power systems are isolated. (See Figure A-112.)

13.2.6.1.2 **Control System Components.**

1. Control system components, such as L-821 control panels, L-841 auxiliary relay cabinets, L-847 air-to-ground radio controllers, etc., are specified in the AC 150/5345 series and are certified under AC 150/5345-53.
2. We are currently developing computerized system components and system design guidelines which will be published in AC 150/5345-56.
3. Computerized Control Systems.

13.2.6.2 Traditional control/monitoring systems are relay systems. L-821 control and relay panels are very reliable and are suitable for nearly all airfields.

13.2.6.3 Typically, cables required for these types of systems are multi-pair (50 or more pairs) cables to connect the airfield lighting vault on the airfield with the ATCT.

13.2.6.3.1 On many airports, the distance between the two facilities is great, resulting in a costly cable installation with the cable vulnerable to damage or failure of one or more pairs in the cable.

13.2.6.3.2 In addition, these communications cables require separate duct systems to eliminate interference from the power cables.

13.2.6.4 The traditional relay panel and multi-conductor control cable can also be simplified by using a multiplexer, which requires only one pair cable to communicate between the vault and tower (or other station). A multiplexer can also be built into a PLC system.

13.2.6.4.1 Some airfield control/monitoring systems have been installed using Programmable Logic Controllers (PLCs), which have good industrial standards and proven reliability.

13.2.6.4.2 The PLC industrial systems use high I/O modules that reduce the need for multi-pair cable installation. Cables with 2 to 6 pairs are typically needed, although fiber optic cable can also be used. See Figure A-113.

13.2.6.5 PC-based systems have come into use, with computers located in the ATCT, the vault, and/or other work stations.

- 5567 13.2.6.5.1 These systems display the necessary information on a monitor.
- 5568 13.2.6.5.2 This is the most flexible system in use today, with off-the-shelf units
5569 readily available.
- 5570 13.2.6.5.3 Typically, standard operating software is used, and off-the-shelf graphics
5571 software is tailored for a specific site.
- 5572 13.2.6.5.4 The communications cable requirements are 2 to 6 pairs of cable or fiber
5573 optics. Fiber optic cable eliminates the need for separate ducts since there
5574 will be no interference between power cable and fiber optic cable. See
5575 Figure A-114.
- 5576 13.2.6.6 Compared to the traditional FAA Type L-821 control/monitoring systems,
5577 the PLC or PC-based systems are easily expanded and provide data for the
5578 controller and maintenance personnel.
- 5579 13.2.6.7 **Selection and Specifying.**
- 5580 13.2.6.7.1 In selecting and specifying a computerized control system, technology
5581 continues to evolve. Consider the characteristics presented in Table 13-1.
- 5582 13.2.6.7.2 In addition, see Appendix F for additional design and selection criteria for
5583 computerized control systems.
- 5584 13.2.7 General function for Control and Monitoring must provide the following:
- 5585 1. Minimum operating capabilities: determination of the functional status of the
5586 system; identification of the intensity level at which each circuit is operating.
- 5587 2. Suitability for complexity and the particular needs of the airfield, and adaptability to
5588 changes (modular).
- 5589 3. Redundancy of equipment or elements crucial for safety.
- 5590 4. High degree of reliability and availability.
- 5591 5. Capability of data exchange with related systems.
- 5592 6. Provision of an intuitive operator interface. Include the capability of monitoring
5593 and controlling all visual navigation aids controllable by a conventional control
5594 system.
- 5595 7. **Ability to** identify alarm conditions.
- 5596 13.2.8 Basic Peripherals and Features:
- 5597 13.2.8.1 User interfaces (controller, maintenance staff, other) **must be** user-friendly
5598 with secure transfer and relevant status information for each station.
- 5599 13.2.8.2 Typical installations use touch screen or track-ball, based on local
5600 preference.

5633 13.2.14 System Response Time.

5634 13.2.14.1 The response time of a computerized control system may vary.

5635 13.2.14.2 It is therefore recommended that minimum response times be considered
5636 when selecting a system.5637 13.2.14.3 The response times in Table 13-1 are recommended in specifying a
5638 computerized airfield ground lighting (AGL) control system.5639 13.2.14.4 See Appendix F for additional information about system response times
5640 and testing criteria.5641 13.2.15 Operations and Maintenance Log.5642 13.2.15.1 **The log must record** all operationally significant events.5643 13.2.15.2 The log may be compiled manually or by electronic means and be retained
5644 for at least 30 days.5645 13.2.15.3 The ability to display or print out periodic or summary compilations of
5646 important operational and failure events is recommended.5647 13.2.16 Product Considerations.5648 13.2.16.1 **Hardware.**5649 Maximize off-the-shelf components. Each component must comply with
5650 industry standards.5651 13.2.16.2 **Monitor.**

5652 Minimum 17 inch (432 mm), flat screen.

5653 13.2.16.3 **Software.**5654 Common operating system (e.g., Windows or UNIX). Tailored packaged
5655 graphics program, easily modified.5656 **Table 13-1. AGL Control System Response Times.**

Time Characteristic	Response Time (seconds)
From command input until acceptance or rejection	< 0.5
From command input until control signal output to CCR or other controlled unit	< 1.0
For system to indicate that a control device has received the control signal	< 2.0

Time Characteristic	Response Time (seconds)
Back indication to tower display of CCR initiation	< 1.0
Switch-over time to redundant components in event of system faults (no command execution during this time)	< 0.5
Automatic detection of failed units and communication lines of the monitoring system	< 10


5657

Page Intentionally Blank

5658

APPENDIX A Figures.

5659

Figure A-1. Legend and General Notes for Figures A-1 through A-23

5660

Figure A-2. Runway and Threshold Lighting Configuration (LIRL Runways and MIRL Visual Runways)






Figure A-3. Runway and Threshold Lighting Configuration (HIRL Precision Instrument Approach - runway centerline not shown for HIRL. Non-Precision Instrument Approach for MIRL)




5668

Figure A-4. Runway with Blast Pad (No Traffic)




5669

5670

Figure A-5. Lighting for Runway with Displaced Threshold


5671

5672

Figure A-6. Normal Runway with Taxiway


5673

5674


Figure A-7. Lighting for Runway with Displaced Threshold

5675


Figure A-8. Lighting for Runway with Displaced Threshold/Usable Pavement



5678 **Figure A-9. Lighting for Runway with Displaced Threshold Not Coinciding with Opposite**
5679 **Runway End**




5681


Figure A-10. Lighting for Runway with Stopway

5682


5683

Figure A-11. Lighting for Runway with Displaced Threshold and Stopway


5684

Figure A-12. Lighting for Crossover Taxiway


5686

Figure A-13. Lighting for Runway Entrance, TDG 6, 600 to 150 Foot Runway


5687

Figure A-14. Lighting for Taxiway Intersection

5689


Figure A-15. Typical Straight Taxiway Sections (Less Than 200 Ft. (61 m))

5690

Figure A-16. Spacing of Lights on Curved Taxiway Edges**Notes:**

1. This figures illustrates the center point of the inner edge light radius and center point of the outer edge light radius have different locations.
2. For radii not listed, determine "z" spacing by linear interpolation.
3. "Z" is the arc length.
4. Uniformly space lights on curved edges. Do not exceed the values determined from the associated table.
5. On curved edges in excess of 30 degrees arc install at least three lights including those at the point of tangency (PT).
6. To determine the metric equivalent of the radius (R) and dimension "Z" multiply by 0.3048.

5692

Figure A-17. Taxiway Edge Lights for Standard Taxiway Turns

5693

5694



Figure A-18. Taxiway Edge Lights for Runway/Taxiway Intersection**FIGURE 2A. SAMPLE LAYOUT FOR RUNWAY AND TAXIWAY INTERSECTION**
($L = 3' \leq L < 10'$)**FIGURE 2B. SAMPLE LAYOUT FOR RUNWAY AND TAXIWAY INTERSECTION**
($L = 10' \leq L \leq 40'$)

TABLE 1			
SECTION LENGTH (L)	NUMBER, EDGE LIGHTS (N) PER SIDE	MAXIMUM SPACING	SPACING
$L < 3'$	1	N/A	N/A
$3' \leq L < 10'$	2	10'	L
$10' \leq L \leq 40'$	3	20'	$L / 2$
$L > 40'$	$[(L/\text{MAX}) + 1]^*$	20'	$L / (N-1)$


* ROUND VALUE UP TO THE NEXT WHOLE NUMBER

SPACING NOTES:

1. THE LAST TAXIWAY EDGE LIGHT AT A RUNWAY/TAXIWAY INTERSECTION MUST BE PLACED AT AN ADDITIONAL 3 FEET FROM THE RUNWAY EDGE LIGHT OFFSET LINE. THE OFFSET IS NECESSARY TO MINIMIZE ANY POTENTIAL CONFLICT WITH RUNWAY EDGE LIGHTS.
2. SEE TABLE OPPOSITE FOR SPACING REQUIREMENTS.
3. INSTALL ONLY ONE LIGHT WHERE TAXIWAY AND TAPER INTERSECT WHEN $L < 3$ FEET.

5695


5696

Figure A-19. Typical Single Straight Taxiway Edges (More Than 200 Ft. (61 m))

5697


5698

Figure A-20. Typical Single Straight Taxiway Edges (Less Than 200 Ft. (61 m))



5699


5700

Figure A-21. Typical Taxiway Edge Lighting Configuration

5701

5702
5703


Figure A-22. Typical Taxiway Edge Lighting for Portions of Runways Used as Taxiway (When Taxiway Lights Are “ON”)



5704

5705
5706


**Figure A-23. Typical Edge Lighting for Portions of Runways Used as Taxiway
(When Runway Lights Are “ON”)**




5707

5708

Figure A-24. Light Fixture Wiring.




5709

5710
5711**Figure A-25. Typical Wiring Diagram Utilizing L-828 Step-type Regulator with External Remote Primary Oil Switch**

5712


5713
5714

Figure A-26. Typical Wiring Diagram Utilizing L-828 Step-type Regulator with Internal Control Power and Primary Oil Switch




5715

5716

Figure A-27. Typical Basic 120-Volt AC Remote Control System


5717


5718

Figure A-28. Alternative 120-Volt AC Remote Control System

5719


Figure A-29. Typical 120-Volt AC Remote Control System with L-847 Circuit Selector Switch




5723
5724**Figure A-30. Typical 48 VDC Remote Control System with 5-Step Regulator and L-841 Relay Panel**

5725

Figure A-31. Typical 48 VDC Remote Control System with 3-Step Regulator and L-841 Relay Panel



5729

Figure A-32. Curves for Estimating Loads in High Intensity Series Circuits

Using curves to determine total Kilowatt Load

Step 1

Find the length of the feeder cable:
 $\text{Runway/Taxiway Length} \times 2$

Use Curve A to determine the KW needed for feeder cable.

Step 2

Use Curve B to determine KW needed for the number of fixtures in the circuit.


Step 3

Total KW load for the circuit equals the sum of the KW loads from step 1 (curve A) and step 2 (curve B).

Typical Guidance only. Consideration must be given for wattage of lamps.


5730

5731

Figure A-33. Curves for Estimating Loads in Medium Intensity Series Circuits


5732

5733

Figure A-34. Runway Centerline Lighting Layout

5734

5735

Figure A-35. Touchdown Zone Lighting Layout

5736

Figure A-36. Section Through Non-adjustable Base and Anchor, Base and Conduit System, Rigid Pavement






Figure A-37. Section Through Non-adjustable Base and Anchor, Base and Conduit System, Flexible Pavement




5743

Figure A-38. Runway Centerline Light – Shallow Base and Conduit Installation


5744

5745

Figure A-39. Saw Kerf Wireway Details


5746

5747

Figure A-40. Saw Kerf Orientation Details – R/W Centerline and TDZ Lights

5748


5749

Figure A-41. Transformer Housing Installation Details Inset Type Lighting Fixtures

5750


5751

Figure A-42. Typical Equipment Layout, Inset Type Lighting Fixtures




5752

5753


Figure A-43. Junction Box for Inset Fixture Installation

5754

Figure A-44. Typical Taxiway Centerline Lighting Configuration for Non-Standard Fillets
(Centerline light spacing for operations above 1,200 ft. (365 m) RVR)




5758

Figure A-45. Color-Coding of Exit Taxiway Centerline Lights

5759


5760

Figure A-46. Taxiway Centerline Lighting Configuration for Acute-Angled Exits

5761

5762


Figure A-47. Controlled Stop Bar Design and Operation – “GO” Configuration



5763


5764
5765

**Figure A-48. Typical Taxiway Centerline Lighting Configuration for Standard Fillets
(Centerline light spacing for operations above 1,200 ft. (365 m) RVR)**




5766

5767

Figure A-49. Taxiway Centerline Light Beam Orientation


5768

5769

Figure A-50. In-Pavement Runway Guard Light Configuration


5770

5771

Figure A-51. Elevated RGL and Stop Bar Configuration


5772

5773


Figure A-52. Typical Light Beam Orientation for In-Pavement RGLs and Stop Bars

5774

5775


Figure A-53. Clearance Bar Configuration at a Low Visibility Hold Point

5776

5777
5778**Figure A-54. Curves for Estimating Primary Load for Taxiway Centerline Lighting Systems**

5779

5780

Figure A-55. Typical Elevated RGL Installation Details

5781

Figure A-56. Typical In-Pavement RGL External Wiring Diagram – Power Line Carrier Communication, One Light Per Remote




Figure A-57. Typical In-Pavement RGL External Wiring Diagram – Power Line Carrier Communication, Multiple Lights per Remote







Figure A-58. Typical In-Pavement RGL External Wiring Diagram – Dedicated Communication Link



5791


Figure A-59. In-Pavement RGL Alarm Signal Connection

5792

5793 **Figure A-60. Controlled Stop Bar Design and Operation – “STOP” Configuration**


5794

5795

Figure A-61. Controlled Stop Bar Design and Operation – Intermediate Configuration


5796

5797 **Figure A-62. Controlled Stop Bar Design and Operation – “STOP” Configuration for A/C**
 5798 **2**




5799

5800

Figure A-63. Typical Layout for Land and Hold Short Lights


5801

5802

Figure A-64. Typical Wireway Installation Details for Land and Hold Short Lights


5803

5804

Figure A-65. Sawing and Drilling Details for In-pavement Land and Hold Short Lights


5805

5806


Figure A-66. Typical Block Diagram for Land and Hold Short Lighting System

5807

Figure A-67. Typical Curve for Determining Maximum Separation Between Vault and Control Panel with 120-Volt AC Control



5811

Figure A-68. Beacon Dimensions and Wiring Diagram

5812

Figure A-69. Calculations for Determining Wire Size.**Copper-Wire, American Wire Gauge B&S**

B&S Gauge No.	Ohms Per 1,000 ft. 25°C., 77°F.	Area Circular Mils	Diameter in Mils at 20°C.	Approximate Pounds Per 1,000 ft. (305 M)
2	0.1593	66,370	257.6	201
4	0.2523	41,740	204.3	126
6	0.4028	26,250	162.0	79
8	0.6405	16,510	128.5	50
10	1.018	10,380	101.9	31
12	1.619	6,530	80.81	20

Calculations

1. To determine the AWG size wire necessary for a specific connected load to maintain the proper voltage for each miscellaneous lighting visual aid, use the above table and

Ohms Law $I = \frac{E}{R}$ as follows:

- a. **Example.** What size wire will be necessary in a circuit of 120-volt AC to maintain a 2 percent voltage drop with the following connected load which is separated 500 ft. from the power supply?

- (1) Lighted Wind Tee Load - 30 lamps, 25 watts each = 750 watts.

- (2) The total operating current for the wind tee is

$$I = \frac{\text{watts}}{\text{volts}} = \frac{750}{120} = 6.25 \text{ amperes}.$$

- (3) Permissible voltage drop for homerun wire is 120 volts \times 2% = 2.4 volts.

- (4) Maximum resistance of homerun wires with a separation of 500 ft. (1,000 ft. (305 m) of wire used) to maintain not more than 2.4 volts drop is

$$R = \frac{E}{I} = \frac{2.4 \text{ volts}}{6.25 \text{ amperes}} = 0.384 \text{ ohms per 1,000 ft. (305 m) of wire.}$$

- (5) From the above table, obtain the wire size having a resistance per 1,000 ft. (305 m) of wire that does not exceed 0.384 ohms per 1,000 ft. (305 m) of wire. The wire size that meets this requirement is No. 4 AWG wire with a resistance of 0.2523 ohms per 1,000 ft. (305 m) of wire.




- (6) By using No. 4 AWG wire in this circuit, the voltage drop is $E=IR=6.25\text{-amperes} \times 0.2523 \text{ ohms}=1.58 \text{ volts}$ which is less than the permissible voltage drop of 2.4 volts.

2. Where it has been determined that it will require an extra-large size wire for homeruns to compensate for voltage drop in a 120-volt AC power supply, one of the following methods should be considered.

- a. A 120/240-volt AC power supply.


- b. A booster transformer, in either a 120-volt AC or 120/240-volt AC power supply, if it has been determined its use will be more economical.

5842

Figure A-70. Typical Automatic Control**(a) 120 VOLTS AC, 2 WIRE SERVICE****(b) 120 VOLTS AC, 2 WIRE SERVICE WITH LOAD CONTACTOR****(c) 120 VOLTS AC, 3 WIRE SERVICE WITH LOAD CONTACTOR**


5843

5844

Figure A-71. 120-Volt AC and 48-Volt DC Remote Control.


5845

5846

Figure A-72. Typical Structural Beacon Tower


5847

5848

Figure A-73. Typical Tubular Steel Beacon Tower


5849

5850

Figure A-74. Typical Airport Beacon Tip-Down Pole


5851

5852

Figure A-75. Typical Pre-Fabricated Beacon Tower Structure


5853

5854

Figure A-76. Typical Location of Supplemental Wind Cone


5855

5856

Figure A-77. Externally Lighted Wind Cone Assembly (Frangible)

5857


5858

Figure A-78. Typical Layout for MALSF

5859


5860

Figure A-79. Typical Layout for REIL




5861

5862

Figure A-80. Typical ODALS Layout


5863

5864

Figure A-81. PAPI Obstacle Clearance Surface


5865

5866


Figure A-82. PAPI Signal Presentation

5867

5868

Figure A-83. Correction for Runway Longitudinal Gradient

a. siting station displaced toward threshold



b. siting station displaced from threshold

SYMBOLS:

D1 = ideal (zero gradient) distance from threshold

RWY = runway longitudinal gradient

TCH = threshold crossing height

T = threshold

e = elevation difference between threshold and RRP


RRP = runway reference point (where aiming angle or visual approach path intersects runway profile)

d = adjusted distance from threshold

 θ = aiming angleS = percent slope of runway = e/d


5869

5870


Figure A-84. General Wiring Diagram for MALSF with 120-Volt AC Remote Control

5871

Figure A-85. Typical Wiring Diagram for MALSF Controlled from Runway Lighting Circuit



5875


Figure A-86. Typical Field Wiring Circuits for MALSF

5876

5877
5878




5880

Figure A-88. Typical Wiring for REILs Multiple Operation

5881

5882


Figure A-89. Typical Wiring for REIL Series Operation



5883


5884

Figure A-90. FAA L-880 Style B (Constant Current) System Wiring Diagram




5885

5886

Figure A-91. FAA L-880 Style A (Constant Voltage) System Wiring Diagram


5887

5888

Figure A-92. PAPI Light Housing Unit (LHU) Installation Detail


5889

5890

Figure A-93. Typical Installation Details for Runway End Identifier Lights (REILs)


5891

5892

Figure A-94. Configuration “A” Electrical Power


5893

5894

Figure A-95. Typical kVA Input Requirements


5895

5896

Figure A-96. Typical Wiring Diagram for Configuration “A” Electrical Power


5897

5898

Figure A-97. Typical Equipment Layout for Configuration "A" Electrical Power


5899

5900

Figure A-98. Configuration “B” Electrical Power


5901

5902

Figure A-99. Typical Wiring Diagram for Configuration “B” Electrical Power


5903

5904

Figure A-100. Typical Wiring Diagram for Configuration “C” Power

5905

5906

Figure A-101. Flexible Pavement or Overlay Installation

5907

Figure A-102. Use of Alignment Jig, No Reference Edge Available, Non-adjustable Base and Conduit System







Figure A-103. Use of Alignment Jig, Reference Edge Available, Non-adjustable Base and Conduit System




5916

Figure A-105. In-pavement Shallow Base Runway Centerline or TDZ Light

5917


5918 **Figure A-106. Sawing and Drilling Details for In-Pavement Taxiway Centerline Lights**

5920


Figure A-107. Wiring Details for Direct- and Base-Mounted Taxiway Centerline Lights

5921

Figure A-108. Typical Transformer Housing and Conduit Installation Details for Taxiway Centerline Lights




5925

Figure A-109. Adjustment of Edge Light Elevation for High Snowfall Areas


5926

5927

Figure A-110. Cable and Duct Markers


5928

5929

Figure A-111. Counterpoise Installation


5930

5931

Figure A-112. Power and Control System Block Diagram


5932

Figure A-113. Typical PLC Control System Block Diagram



5935


Figure A-114. PC Control System Block Diagram



5936

Figure A-115. Typical Spacing for GA Airport Edge Lights

(see paragraph 2.5.2.5.4)



5940

Page Intentionally Blank

5941

APPENDIX B Airport Technical Advisory.**B.1 Electromagnetic interference (EMI) induced by L-828, SCR Type, Constant Current Regulators (CCRs).**

5944 Some airports have experienced excessive levels of EMI which degrades the
5945 performance of some of the airport's air navigational systems, i.e. RVRs, glide slope
5946 localizers, ATCTS, etc., SCR type, L-828, CCRs, are the likely sources of EMI due to
5947 their inherent operating characteristics. The following are some of the cautionary steps
5948 that may help decrease EMI and/or its adverse effects in the airport environment.

- 5949 1. Cables for airfield lighting circuits should not be installed in the same conduit, cable
5950 duct or duct bank as control and communication cables.
- 5951 2. Cables for airfield lighting systems should not be installed such that they cross
5952 control and/or communications cables.
- 5953 3. In some cases, harmonic filters may be installed at the regulator output to reduce the
5954 EMI emitted by the CCR. These filters are available from some CCR
5955 manufacturers.
- 5956 4. Spare control and communications cables should be grounded.
- 5957 5. Inform manufacturers, designers, engineers, etc., about the existing navigational
5958 equipment and the potential for interference.
- 5959 6. Electromagnetic compatibility between new equipment and existing equipment
5960 should be a requirement in project contracts. Operational acceptance test(s) may be
5961 required to verify compliance.

5962 For more information contact the FAA Office of Airport Safety and Standards, FAA
5963 Engineering, 800 Independence Avenue, SW, Washington, DC 20591.

Page Intentionally Blank

5965

APPENDIX C Terms and Acronyms.

5966	AC	Advisory Circular	
5967		Alternating Current	
5968	Accelerate-stop distance available (ASDA)		
5969		The runway plus stopway length declared available and suitable	
5970		for the acceleration and deceleration of an airplane aborting a	
5971		takeoff	
5972	AIP	Airport Improvement Program	
5973	ALD	Available Landing Distance	
5974	ALS	Approach Lighting System	
5975	ALSF	Approach Lighting System with Sequenced Flashing Lights	
5976	ANSI	American National Standards Institute	
5977	ASDA	Accelerated-stop distance available	
5978	ASTM	American Society for Testing and Materials	
5979	ATC	Air Traffic Control	
5980	ATCT	Air Traffic Control Tower	
5981	CAT I	Facility providing operation down to 200 ft. (61 m) decision height	
5982		and runway visual range not less than 2,400 ft. (732 m)	
5983	CAT II	Facility providing operation down to 100 ft. (30 m) decision height	
5984		and runway visual range not less than 1,200 (366 m) ft.	
5985	CAT III	Facility providing operation with no decision height limit and	
5986		along the surface of the runway with external visual reference	
5987		during final phase of landing and with a runway and runway visual	
5988		range not less than 600 ft. (183 m), down to 0.	
5989	CCR	Constant Current Regulator	
5990	Cd	Candela (a unit of luminous intensity)	
5991	CL	Center Line	
5992	CTAF	Common Traffic Advisory Frequency	
5993	DC	Direct Current	
5994	DEB	Direct Earth Burial	
5995	Declared Distances	The distances declared available and suitable for satisfying the	
5996		airplane takeoff run, takeoff distance, accelerate-stop distances,	
5997		and landing distance requirements. The distances are ASDA,	
5998		LDA, TORA and TODA.	
5999	Displaced Threshold	A threshold that is located at a point on the runway other than the	
6000		designated beginning of the runway.	
6001	DWG	Drawing	
6002	EMI	Electromagnetic Interference	
6003	EMT	Electro-Mechanical Tubing	

6004	FAA	Federal Aviation Administration
6005	HIRL	High Intensity Runway Edge Lights
6006	I/O	Input/Output
6007	ICEA	Insulated Cable Engineers Association
6008	IFR	Instrument Flight Rules
6009	ILS	Instrument Landing System
6010	kV	Kilovolt
6011	kVA	Kilovolt Ampere
6012	kW	Kilowatt
6013	L-850C	Style 3 Flush in-pavement light fixture
6014	L-852D	Taxiway centerline for CAT III
6015	L-852E, F	Runway Guard Light in-pavement
6016	L-852G	Combination Runway Guard
6017	L-852G/S	Combination Runway Guard/Stop Bar Light in-pavement
6018	L-852S	Stop Bar Light in-pavement
6019	L-853	Reflective Markers
6020	L-854	Radio Controller (Pilot Controlled Lights)
6021	L-858R, Y, L, B	Guidance Signs
6022	L-860	Low-Intensity Elevated Light
6023	L-861	Medium-Intensity Elevated Runway/Taxiway Light
6024	L-862	High-Intensity Elevated Runway Edge Light
6025	L-867	Non-load Bearing Base Cans
6026	L-868	Load Bearing Base Cans
6027	L-880/ L-881	Precision Approach Path Indicators (PAPI)
6028	L-884	Land and Hold Short Operations (LAHSO) Power Control Unit
6029		(PCU)
6030	LAHSO	Land and Hold Short Operations
6031	Landing Distance Available	The runway length declared available and suitable for a landing
6032		aircraft.
6033	LDA	Landing Distance Available
6034	LDIN	Lead-In Lighting System
6035	LHU	Light Housing Unit
6036	LIRL	Low Intensity Runway Edge Lights
6037	MALS	Medium-intensity Approach Lighting System
6038	MALSF	Medium-intensity Approach Lighting System with Sequenced
6039		Flashers
6040	MALSR	Medium-intensity Approach Lighting System with Runway
6041		Alignment Indicator Lights
6042	MIRL	Medium Intensity Runway Edge Lights

6043	MITL	Medium Intensity Taxiway Lights
6044	MLS	Microwave Landing System
6045	NAS	National Airspace System
6046	NEC	National Electrical Code
6047	NEMA	National Electrical Manufacturers Association
6048	NFPA	National Fire Protection Association
6049	Non-precision Approach Runway	
6050		Runway with only horizontal guidance available
6051	Non-precision Instrument Runway	
6052		A runway having an existing instrument approach procedure
6053		utilizing air navigation facilities with only horizontal guidance for
6054		which a straight-in or side-step non-precision approach procedure
6055		has been approved.
6056	NOTAM	Notice to Airmen
6057	NRTL	Nationally Recognized Testing Laboratory
6058	OCS	Obstacle Clear Surface
6059	ODALS	Omnidirectional Approach Lighting System
6060	OFZ	Obstacle Free Zone
6061	OSHA	Occupational Safety and Health Administration
6062	PAPI	Precision Approach Path Indicator
6063	PAR	Precision Approach Radar
6064	PC	Point of Curvature
6065	PCU	Power and Control Unit
6066	PLC	Programmable Logic Controller
6067	POFZ	Precision Obstacle Free Zone
6068	Precision Approach Runway	
6069		Full instrument approach procedure and equipment available (ILS
6070		or MLS)
6071	Precision Instrument Runway	
6072		A runway having an existing instrument approach procedure
6073		utilizing air navigation facilities with both horizontal and vertical
6074		guidance for which a precision approach procedure has been
6075		approved.
6076	PT	Point of Tangency
6077	RCL	Runway Centerline Lighting
6078	REIL	Runway End Identifier Lights
6079	RGL	Runway Guard Lights
6080	ROFA	Runway Object Free Area
6081	RPZ	Runway Protection Zone
6082	RSA	Runway Safety Area

6083	RSAT	Runway Safety Action Team
6084	Runway Environment	The physical runway and the areas surrounding the runway out to
6085		the holding position marking.
6086	Runway Object Free Area	An area on the ground centered on a runway provided to enhance
6087		the safety of aircraft operations by having the area free of objects,
6088		except for objects that need to be located in the OFA for air
6089		navigation or aircraft ground maneuvering purposes.
6090	Runway Protection Zone	An area off the runway end used to enhance the protection of
6091		people and property on the ground.
6092	Runway Safety Area	A defined surface surrounding the runway prepared or suitable for
6093		reducing the risk of damage to airplanes in the event of an
6094		undershoot, overshoot, or threshold.
6095	RVR	Runway Visual Range
6096	RWSL	Runway Status Lights
6097	SCR	Silicon Controlled Rectifier
6098	SCRS	
6099	SMGCS	Surface Movement Guidance and Control System
6100	SPDT	Single Pole Double Throw
6101	SPST	
6102	Takeoff distance available	The TORA plus the length of any remaining runway and/or
6103		clearway beyond the far end of the TORA.
6104	Takeoff runway available	The runway length declared available and suitable for the ground
6105		run of an airplane taking off.
6106	TDZ	Touchdown Zone
6107	Threshold	A line perpendicular to the runway centerline marking the
6108		beginning of the runway surface available for a landing.
6109	TODA	Takeoff distance available
6110	TORA	Takeoff run available
6111	UL	Underwriter's Laboratory
6112	UPS	Uninterruptible Power Supply
6113	VAC	Voltage Alternating Current
6114	VDC	Voltage Direct Current
6115	VFR	Visual Flight Rules
6116	Visual Runway	Runway with no instrument approach procedure/equipment

APPENDIX D Bibliography.**D.1 FAA Advisory Circulars, Federal Aviation Regulations, and other publications are available on the FAA website.**

For an explanation of the Advisory Circular numbering system, see FAA Order 1320.46, **FAA** Advisory Circular System.

D.1.1 FAA ACs

All ACs are available online at

http://www.faa.gov/regulations_policies/advisory_circulars/.

1. AC 70/7460-1, *Obstruction Marking and Lighting*.
2. AC 120-29, *Criteria for Approval of Category I and Category II Landing Minima for Approach*.
3. AC 120-57, *Surface Movement Guidance and Control System*.
4. AC 150/5000-13, *Announcement of Availability--RTCA Inc., Document RTCA-221*.
5. AC 150/5200-30, *Airport **Field Condition Assessments and** Winter Operations*.
6. AC 150/5300-13, *Airport Design*.
7. AC 150/5300-18, ***General Guidance and Specifications for Submission of Aeronautical Surveys to NGS: Field Data Collection and Geographic Information System (GIS) Standards***.
8. AC 150/5340-1, *Standards for Airport Markings*.
9. AC 150/5340-18, ***Standards for Airport Sign Systems***.
10. AC 150/5340-26, *Maintenance of Airport Visual Aid Facilities*.
11. AC 150/5345-3, *Specification for L-821 Panels for Control of Airport Lighting*.
12. AC 150/5345-5, *Circuit Selector Switch*.
13. AC 150/5345-7, *Specification for L-824 Underground Electrical Cable for Airport Lighting Circuits*.
14. AC 150/5345-10, *Specification for Constant Current Regulators and Regulator Monitors*.
15. AC 150/5345-12, *Specification for Airport and Heliport Beacons*.
16. AC 150/5345-13, *Specification for L-841 Auxiliary Relay Cabinet Assembly for Pilot Control of Airport Lighting Circuits*.
17. AC 150/5345-26, *FAA Specification For L-823 Plug and Receptacle, Cable Connectors*.
18. AC 150/5345-27, *Specification for Wind Cone Assemblies*.
19. AC 150/5345-28, *Precision Approach Path Indicator (PAPI) Systems*.

- 6151 20. AC 150/5345-39, *FAA Specification L-853, Runway and Taxiway Retroreflective*
6152 *Markers.*
- 6153 21. AC 150/5345-42, *Specification for Airport Light Bases, Transformer Housings,*
6154 *Junction Boxes, and Accessories.*
- 6155 22. AC 150/5345-43, *Specification for Obstruction Lighting Equipment.*
- 6156 23. AC 150/5345-44, *Specification for Runway and Taxiway Signs.*
- 6157 24. AC 150/5345-45, *Low-Impact Resistant (LIR) Structures.*
- 6158 25. AC 150/5345-46, *Specification for Runway and Taxiway Light Fixtures.*
- 6159 26. AC 150/5345-47, *Specification for Series to Series Isolation Transformers for*
6160 *Airport Lighting Systems.*
- 6161 27. AC 150/5345-49, *Specification L-854, Radio Control Equipment.*
- 6162 28. AC 150/5345-50, *Specification for Portable Runway and Taxiway Lights.*
- 6163 29. AC 150/5345-51, *Specification for Discharge-Type Flasher Equipment.*
- 6164 30. AC 150/5345-53, *Airport Lighting Equipment Certification Program.*
- 6165 31. AC 150/5345-54, *Specification for L-884 Power and Control Unit for Land and*
6166 *Hold Short Lighting Systems.*
- 6167 32. AC 150/5345-56, *Specification for L-890 Airport Lighting Control and Monitoring*
6168 *Systems (ALCMs).*
- 6169 33. AC 150/5370-2, *Operational Safety on Airports During Construction.*
- 6170 34. AC 150/5370-10, *Standards for Specifying Construction of Airports.*

6171 **D.1.2 Engineering Briefs (EBs)**

6172 All engineering briefs are available online at:
6173 www.faa.gov/airports/engineering/engineering_briefs.

- 6174 1. EB #64, *Runway Status Lights System.*
- 6175 2. EB #67, *Light Sources Other than Incandescent and Xenon for Airport and*
6176 *Obstruction Lighting Fixtures.*
- 6177 3. EB #83, *In Pavement Light Fixture Bolts.*
- 6178 4. EB #92, *Light Spacing Guidance for New Taxiway Fillet Geometry.*

6179 **D.1.3 FAA Orders**

6180 All FAA Orders are available online at:
6181 https://www.faa.gov/regulations_policies/orders_notices/.

- 6182 1. FAA Order 7110.118, *Land and Hold Short Operations (LAHSO).*
- 6183 2. FAA Order 6030.20A, *Electrical Power Policy.*
- 6184 3. FAA JO 6850.2, *Visual Guidance Lighting Systems.*
- 6185 4. FAA Order 6950.11, *Reduced Electrical Power Interruptions at FAA Facilities.*

5. FAA Order 6950.27, *Short Circuit Analysis and Protective Device Case Study*.

6. FAA Order 8900.1, *Flight Standards Information Systems (FSIMS)*.

D.1.4 FAA Drawings

FAA drawings may be obtained from:

FAA William J. Hughes Technical Center
NAS Documentation Facility, ACK-1
Atlantic City International Airport
New Jersey, 08405

1. FAA DWG C-6046, *Frangible Coupling Type I and Type IA, Details*.

D.1.5 FAA Specifications and Standards

FAA Specifications and Standards may be obtained from: www.faa.gov

1. FAA-C-1391, *Installation and Splicing of Underground Cable*.

2. FAA-E-2083, *Bypass Switch, Engine Generator*.

3. FAA-E-2204, *Diesel Engine Generator Sets, 10kW to 750kW*.

4. FAA-E-2325, *Medium Intensity Approach Lighting System with Runway Alignment Indicator Lights*.

5. FAA-STD-019e, *Lightning and Surge Protection, Grounding, Bonding and Shielding Requirements for Facilities and Electronic Equipment*.

D.1.6 Combined Federal Regulations

Combined Federal Regulations may be obtained from:

[http://rgl.faa.gov/Regulatory and Guidance Library/rgFar.nsf/MainFrame?OpenFrame Set](http://rgl.faa.gov/Regulatory%20and%20Guidance%20Library/rgFar.nsf/MainFrame?OpenFrameSet).

1. 14 CFR Part 77, *Objects Affecting Navigable Airspace*.

2. 14 CFR Part 139, *Certification of Airports*.

D.1.7 Aeronautical Information Manual (AIM)

The Aeronautical Information Manual (AIM) may be obtained from: www.faa.gov.

D.2 Federal Specifications

Federal Specifications may be obtained from: <https://gsa.gov/>.

U.S. General Services Administration
1800 F Street, NW
Washington, DC 20405

1. Federal Specification J-C-145, *Cable, Power, Electrical and Wire, Electrical (Weather-Resistant)*.

2. Federal Specification TT-P-28, *Paint, Aluminum, Heat Resisting (1200 Deg. F.)*.

3. FED-STD-595, *Colors Used in Government Procurement*.

D.3 Radio Technical Commission for Aeronautics (RTCA).

Copies of RTCA documents (there is a charge for documents) may be obtained at:
<http://www.rtca.org/>

1. RTCA–DO-221, *Guidance and Recommended Requirements for Airport Surface Movement Sensors*.

D.4 American Society for Testing and Materials (ASTM) Specifications, Test Methods, Standard Practices, and Recommended Practices.

ASTM specifications, test methods, and recommended practices may be obtained from the American Society for Testing and Materials website at www.astm.org. Contact them at:

American Society for Testing and Materials
1916 Race Street
Philadelphia, PA 19103

1. ASTM C-892, *Standard Specification for High Temperature Fiber Blanket Thermal Insulation*.
2. ASTM D-3407, *Standard Test Method for Joint Sealants, Hot Poured, for Concrete and Asphalt Pavements*.
3. ASTM A-53, *Standard Specification for Pipe, Steel, Black and Hot-Dipped, Zinc-coated, Welded and Seamless*.
4. ASTM-A184, *Standard Specification for Fabricated Deformed Steel Bar Mats for Concrete Reinforcement*.
5. ASTM-A704, *Standard Specification for Welded Steel Plain Bar or Rod Mats for Concrete Reinforcement*.

D.5 National Fire Protection Association (NFPA):

Copies of the National Electrical Code (NEC) Handbook (NFPA 70), NFPA 70E, Standard for Electrical Safety in the Workplace, and NFPA 780, *Standard for the Installation of Lightning Protection Systems*, may be obtained at: www.nfpa.org.

NFPA
1 Batterymarch Park
Quincy, Massachusetts
USA 02169-7471

D.6 American National Standards Institute (ANSI).

Copies of ANSI standards may be obtained from the National Standards Institute. Contact them at: www.ansi.org

ANSI
1819 L Street, NW, 6th floor

6257 Washington, DC 20036

6258 1. ANSI/ICEA S-85-625, *Telecommunications Cable Air Core, Polyolefin Insulated,*
6259 *Copper Conductor, Technical Requirements*

6260 **D.7 The Design, Installation, and Maintenance of In-Pavement Airport Lighting**

6261 *The Design, Installation, and Maintenance of In-Pavement Airport Lighting*, by Arthur
6262 S. Schai, Library of Congress Catalog Card Number #86-81865.

6263 This publication is available on the FAA website: <http://www.faa.gov/airports/>

6264

Page Intentionally Blank

6265 **APPENDIX E Typical Installation Drawings for Airport Lighting Equipment.**


6266 The following drawings depict typical installation methods for various types of airport
6267 lighting equipment and are acceptable for use on projects funded under the AIP.

6268 However, the drawings may need to be revised to accommodate local site conditions
6269 and/or special requirements.


6270 Details of equipment and installation methods will be provided by manufacturers.

6271
6272


Figure E-1. Typical Standard Details for Runway and Taxiway Edge Lights –High Intensity Light – Non-adjustable Base-mounted



6273


6274
6275**Figure E-2. Typical Standard Details for Runway and Taxiway Edge Lights –Medium / High Intensity Light – Non-adjustable Base-mounted**

6276

6277
6278**Figure E-3. Typical Standard Details for Runway and Taxiway Edge Lights –Medium Intensity Light – Stake-mounted**


6279

6280

Figure E-4. Typical Counterpoise and Ground Rod Connections

6281


6282

Figure E-5. Identification (ID) Tag Detail

6283

6284
6285

Figure E-6. Standard Details for Underground Cable Installation – Typical Multiple Bank Layout




TYPICAL MULTIPLE BANK LAYOUT

NOTES:

- 1- CROWN DUCTS TO A NORMAL 1% SLOPE FOR DRAINAGE.
- 2- DUCTS ARE 3" [8 cm] UNLESS OTHERWISE SPECIFIED
- 3- NUMBER OF BANKS AND CONFIGURATION AS SPECIFIED ON THE PLANS.


6286

6287

Figure E-7. Standard Details for Underground Cable Installation – Type A


6288

6289

Figure E-8. Standard Details for Underground Cable Installation – Type B


6290

6291

Figure E-9. Standard Details for Underground Cable Installation – Type C


6292

6293

Figure E-10. Standard Details for Underground Cable Installation – Plowed Cable

6294

6295

Figure E-11. Standard Details for Underground Cable Installation – Plowed Cable

6296

Figure E-12. Standard Details for Taxiway Hold and Guidance Sign – Sign – Single Pedestal







Figure E-13. Standard Details for Taxiway Hold and Guidance Sign – Sign – Multiple Pedestal



6303


Figure E-14. Standard Details for Taxiway Hold and Guidance Sign – Detail A

6304

6305
6306**Figure E-15. Standard Details for Pivoting Rotating Beacon Pole – Rotating Beacon and Mounting Bracket Detail**


6307

6308

Figure E-16. Standard Details for Pivoting Rotating Beacon Pole – Locking Device Detail

6309


6310

Figure E-17. Standard Details for Pivoting Rotating Beacon Pole – Pivot Detail**PIVOT DETAIL**

NOT TO SCALE


6311

6312

Figure E-18. Standard Details for Pivoting Rotating Beacon Pole

6313


6314

Figure E-19. Standard Details for Wind Cone Foundation (L-807)

6315

6316


Figure E-20. Standard Details for Wind Cone – 12 ft. (3.7 m) Wind Cone



6317


6318
6319

Figure E-21. Standard Details for Precision Approach Path Indicators (PAPIs) – PAPI Light Unit Locations




6320

6321


Figure E-22. Standard Details for Precision Approach Path Indicators (PAPIs)

6322


Figure E-23. Standard Details for Precision Approach Path Indicators (PAPIs) – Section A-A




**Figure E-24. Standard Details for Runway End Identifier Light Power and Control
Derived from Runway Circuit – Profile View**



**Figure E-25. Standard Details for Runway End Identifier Light Power and Control
Derived from Runway Circuit – Plan View**



6332

Figure E-26. Location of Entrance-Exit Lights (in lieu of guidance signs)

6333

6334 **E.1 Electrical Notes**

6335 E.1.1 General

- 6336 1. The electrical installation, at a minimum, must meet the NEC and local regulations.
- 6337 2. The contractor must ascertain that all lighting system components furnished
6338 (including FAA approved equipment) are compatible in all respects with each other
6339 and the remainder of the new/existing system. Any non-compatible components
6340 furnished by the contractor must be replaced at no additional cost to the airport
6341 sponsor with a similar unit that is approved by the engineer and compatible with the
6342 remainder of the airport lighting system.
- 6343 3. In case the contractor elects to furnish and install airport lighting equipment
6344 requiring additional wiring, transformers, adapters, mountings, etc., to those shown
6345 on the drawings and/or listed in the specifications, any cost for these items must be
6346 incidental to the equipment cost.
- 6347 4. The contractor-installed equipment (including FAA approved) must not generate
6348 any EMI in the existing and/or new communications, weather, air navigation, and
6349 ATC equipment. Any equipment generating such interference must be replaced by
6350 the contractor at no additional cost with equipment meeting the applicable
6351 specifications.
- 6352 5. When a specific type, style, class, etc., of FAA approved equipment is specified
6353 only that type, style, class, etc., will be acceptable, though equipment of other types,
6354 style, class, etc., may be FAA approved.
- 6355 6. Any and all instructions from the engineer to the contractor regarding changes in, or
6356 deviations from, the plans and specifications must be in writing with copies sent to
6357 the airport sponsor and the FAA field office (Airports District Office
6358 (ADO)/Airports Field Office (AFO)). The contractor must not accept any verbal
6359 instructions from the engineer regarding any changes from the plans and
6360 specifications.
- 6361 7. A minimum of three copies of instruction books must be supplied with each type of
6362 equipment. For more sophisticated types of equipment, such as regulators, PAPI,
6363 REIL, etc., the instruction book must contain the following:
- 6364 a. A detailed description of the overall equipment and its individual components.
- 6365 b. Theory of operation including the function of each component.
- 6366 c. Installation instructions.
- 6367 d. Start-up instructions.
- 6368 e. Preventative maintenance requirements.
- 6369 f. Chart for troubleshooting.
- 6370 g. Complete power and control detailed wiring diagram(s), showing each
6371 conductor/connection/component; "black" boxes are not acceptable. The
6372 diagram or the narrative must show voltages/currents/wave shapes at strategic
6373 locations to be used when checking and/or troubleshooting the equipment.

When the equipment has several brightness steps, these parameters must be indicated for all the different modes.

- h. Parts list will include all major and minor components, such as resistors, diodes, etc. It must include a complete nomenclature of each component and, if applicable, the name of its manufacturer and the catalog number.
- i. Safety instructions.

E.1.2 Power and control

1. Stencil all electrical equipment to identify function, circuit voltage and phase. Where the equipment contains fuses, also stencil the fuse or fuse link ampere rating. Where the equipment does not have sufficient stenciling area, the stenciling must be done on the wall next to the unit. The letters must be one inch (25 mm) high and painted in white or black paint to provide the highest contrast with the background. Engraved plastic nameplates may also be used with one inch (25 mm) white (black background) or black (white background) characters. All markings must be of sufficient durability to withstand the environment.
2. Color code all phase wiring by the use of colored wire insulation and/or colored tape. Where tape is used, the wire insulation must be black. Black and red must be used for single-phase, three wire systems and black, red and blue must be used for three-phase systems. Neutral conductors, size No. 6 AWG or smaller, must be identified by a continuous white or natural outer finish. Conductors larger than No. 6 AWG must be identified either by a continuous white or natural gray outer finish along its entire length or by the use of white tape at its terminations and inside accessible wireways.
3. All branch circuit conductors connected to a particular phase must be identified with the same color. The color coding must extend to the point of utilization.
4. In control wiring, the same color must be used throughout the system for the same function, such as 10%, 30%, 100% brightness control, etc.
5. All power and control circuit conductors must be copper; aluminum must not be accepted. This includes wire, cable, busses, terminals, switch/panel components, etc.
6. Low voltage (600 V) and high voltage (5000 V) conductors must be installed in separate wireways.
7. Neatly lace wiring in distribution panels, wireways, switches and pull/junction boxes.
8. The minimum size of pull/junction boxes, regardless of the quantity and the size of the conductors shown, must be as follows:
 - a. In straight pulls, the length of the box must not be less than eight times the trade diameter of the larger conduit. The total area (including the conduit cross-sectional area) of a box end must be at least 3 times greater than the total trade cross-sectional area of the conduits terminating at the end.

- 6414 b. In angle or u-pulls, the distance between each conduit entry inside the box and
6415 the opposite wall of the box must not be less than six times the trade diameter of
6416 the largest conduit. This distance must be increased for additional entries by the
6417 amount of the sum of the diameters of all other conduit entries on the same wall
6418 of the box. The distance between conduit entries enclosing the same conductor
6419 must of not be less than six times the trade diameter of the largest conduit.
- 6420 9. A run of conduit between terminations at equipment enclosures, square ducts and
6421 pull/junction boxes, must not contain more than the equivalent of four quarter bends
6422 (360 degrees total), including bends located immediately at the terminations. Cast,
6423 conduit type outlets must not be treated as pull/junction boxes.
- 6424 10. Equipment cabinets must not be used as pull/junction boxes. Only wiring
6425 terminating at the equipment must be brought into these enclosures.
- 6426 11. Splices and junction points must be permitted only in junction boxes, ducts
6427 equipped with removable covers, and at easily accessible locations.
- 6428 12. Circuit breakers in power distribution panel(s) must be thermal-magnetic, molded
6429 case, permanent trip with 100-ampere, minimum, frame.
- 6430 13. Dual lugs must be used where two wires, size No. 6 or larger, are to be connected to
6431 the same terminal.
- 6432 14. All wall mounted equipment enclosures must be mounted on wooden mounting
6433 boards.
- 6434 15. Wooden equipment mounting boards must be plywood, exterior type, 3/4 inch (19
6435 mm) minimum thickness, both sides painted with one coat of primer and two coats
6436 of gray, oil-based paint.
- 6437 16. Rigid steel conduit must be used throughout the installation unless otherwise
6438 specified. The minimum trade size must be 3/4 inch (19 mm).
- 6439 17. All rigid conduit must be terminated at CCRs with a section (10 inch (254 mm)
6440 minimum) of flexible conduit.
- 6441 18. Unless otherwise shown all exposed conduits must be run parallel to, or at right
6442 angles with, the lines of the structure.
- 6443 19. All steel conduits, fittings, nuts, bolts, etc., must be galvanized.
- 6444 20. Use conduit bushings at each conduit termination. Where No. 4 AWG or larger
6445 ungrounded wire is installed, use insulated bushings.
- 6446 21. Use double lock nuts at each conduit termination. Use weather tight hubs in damp
6447 and wet locations. Sealing locknuts must not be used.
- 6448 22. Wrap all primary and secondary power transformer connections with sufficient
6449 layers of insulating tape and cover with insulating varnish for full value of cable
6450 insulation voltage.
- 6451 23. Unless otherwise noted, all indoor single conductor control wiring must be No. 12
6452 AWG.

- 6453 24. Both ends of each control conductor must be terminated at a terminal block. The
6454 terminal block must be of proper rating and size for the function intended and must
6455 be located in equipment enclosures or special terminal cabinets.
- 6456 25. All control conductor terminators must be of the open-eye connector/screw type.
6457 Soldered, closed-eyed terminators, or terminators without connectors are not
6458 acceptable.
- 6459 26. In terminal block cabinets, the minimum spacing between parallel terminal blocks
6460 must be 6 inches (152 mm). The minimum spacing between terminal block
6461 sides/ends and cabinet sides/bottom/top must be 5 inches (127 mm). The minimum
6462 spacing will be increased as required by the number of conductors. Additional
6463 spacing must be provided at conductor entrances.
- 6464 27. Both ends of all control conductors must be identified as to the circuit, terminal,
6465 block, and terminal number. Only stick-on labels must be used.
- 6466 28. A separate and continuous neutral conductor must be installed and connected for
6467 each breaker circuit in the power panel(s) from the neutral bar to each power/control
6468 circuit.
- 6469 29. The following must apply to relay/contactors panel/enclosures:
- 6470 a. All components must be mounted in dust proof enclosures with vertically hinged
6471 covers.
- 6472 b. The enclosures must have ample space for the circuit components, terminal
6473 blocks, and incoming internal wiring.
- 6474 c. All incoming/outgoing wiring must be terminated at terminal blocks.
- 6475 d. Each terminal on terminal blocks and on circuit components must be clearly
6476 identified.
- 6477 e. All control conductor terminations must be of the open-eye connector/screw
6478 type. Soldered, closed-eye connectors, or terminations without connectors are
6479 not acceptable.
- 6480 f. When the enclosure cover is opened, all circuit components, wiring, and
6481 terminals must be exposed and accessible without any removal of any panels,
6482 covers, etc., except those covering high voltage components.
- 6483 g. Access to, or removal of, a circuit component or terminal block will not require
6484 the removal of any other circuit component or terminal block.
- 6485 h. Each circuit component must be clearly identified indicating its corresponding
6486 number shown on the drawing and its function.
- 6487 i. A complete wiring diagram (not a block or schematic diagram) must be mounted
6488 on the inside of the cover. The diagram must represent each conductor by a
6489 separate line.
- 6490 j. The diagram must identify each circuit component and the number and color of
6491 each internal conductor and terminal.
- 6492 k. All wiring must be neatly trained and laced.

1. Minimum wire size must be No. 12 AWG.

E.1.3 Field lighting

1. Unless otherwise stated, all underground field power multiple and series circuit conductors (whether **direct earth burial (DEB)** or in duct/conduit) must be FAA approved Type L-824. Insulation voltage and size must be as specified.
2. No components of the primary circuit such as cable, connectors and transformers must be brought above ground at edge lights, signs, REIL, etc.
3. There must be no exposed power/control cables between the point where they leave the underground (DEB or L-867 bases) and where they enter the equipment (such as taxiway signs, PAPI, REIL, etc.). Enclosures. These cables must be enclosed in rigid conduit or in flexible water-tight conduit with frangible coupling(s) at the grade or the housing cover, as shown in applicable details.
4. The joints of the L-823 primary connectors must be wrapped with one layer of rubber or synthetic rubber tape and one layer of plastic tape, one half lapped, extending at least 1-1/2 inches (38 mm) on each side of the joint, as shown in Figure E-9.
5. The cable entrance into the field attached L-823 connectors must be enclosed by heat-shrinkable tubing with continuous internal adhesive as shown in Figure E-9.
6. The ID of the primary L-823 field attached connectors must match the cable ID to provide a watertight cable entrance. The entrance must be encapsulated in heat shrinkable tubing with continuous factory applied internal adhesive, as shown in Figure E-9.
7. L-823 type 11, two-conductor secondary connector must be class "A" (factory molded).
8. There must be no splices in the secondary cable(s) within the stems of a runway/taxiway edge/threshold lighting fixtures and the wireways leading to taxiway signs and PAPI/REIL equipment.
9. Electrical insulating grease must be applied within the L-823, secondary, two conductor connectors to prevent water entrance. The connectors must not be taped.
10. DEB isolation transformers must be buried at a depth of 10 inches (254 mm) on a line crossing the light and perpendicular to the runway/taxiway centerline at a location 12 inches (305 mm) from the light opposite from the runway/taxiway.
11. DEB primary connectors must be buried at a depth of 10 inches (254 mm) near the isolation transformer. They must be orientated parallel with the runway/taxiway centerline. There must be no bends in the primary cable 6 inches (152 mm), minimum, from the entrance into the field-attached primary connection.
12. A slack of 3 ft. (0.9 m), minimum, must be provided in the primary cable at each transformer/connector termination. At stake-mounted lights, the slack must be loosely coiled immediately below the isolation transformer.

13. Direction of primary cables must be identified by color coding as follows when facing light with back facing pavement: cable to the left is coded red and cable to the right is coded blue, this applies to the stake-mounted lights and base-mounted lights where the base has only one entrance.
14. L-867 bases must be size B, 24" (610 mm) deep Class 1 unless otherwise noted.
15. Base-mounted frangible couplings must not have weep holes to the outside. Plugged holes are not acceptable. The coupling must have a 1/4" (6 mm) diameter minimum or equivalent opening for drainage from the space around the secondary connector into the L-867 base.
16. The elevation of the frangible coupling groove must not exceed 1-1/2" (38 mm) above the edge of the cover for base-mounted couplings or the top of the stake for stake-mounted couplings.
17. Where the frangible coupling is not an integral part of the light fixture stem or mounting leg, a bead of silicone rubber seal must be applied completely around the light stem or wireway at the frangible coupling to provide a watertight seal.
18. Tops of the stakes supporting light fixtures must be flush with the surrounding grade.
19. Plastic lighting fixture components, such as lamp heads, stems, frangible couplings, base covers, brackets, stakes, are not acceptable. L-867 plastic transformer housings are acceptable. A metal threaded fitting must be set in flange during casting process. Base cover bolts must be fabricated from 18-8 stainless steel.
20. The tolerance for the height of runway/taxiway edge lights must be ± 1 inch (25 mm). For stake-mounted lights, the specified lighting fixture height must be measured between the top of the stake and the top of the lens. For base-mounted lights, the specified lighting fixture height must be measured between the top of the base flange and the top of the lens, and includes the base cover, the frangible coupling, the stem, the lamp housing and the lens.
21. The tolerance for the lateral spacing (light lane to runway/taxiway centerline) of runway/taxiway edge lights must be ± 1 inch (25.4 mm). This also applies at intersections to lateral spacing between lights of a runway/taxiway and the intersecting runway/taxiway.
22. L-867 bases may be precast. Entrances into L-867 bases must be plugged from the inside with duct seal.
23. Galvanized/painted equipment/component surfaces must not be damaged by drilling, filing, etc. – this includes drain holes in metal transformer housings.
24. Edge light numbering tags must be facing the pavement.
25. Cable/splice/duct markers must be pre-cast concrete of the size shown. Letters/numbers/arrows for the legend to be impressed into the tops of the markers must be pre-assembled and secured in the mold before the concrete is poured. Legends inscribed by hand in wet concrete are not acceptable.

26. All underground cable runs must be identified by cable markers at 200 ft. (61 m) maximum spacing with an additional marker at each change of direction of the cable run. Cable markers must be installed above the cable.
27. Locations of all DEB underground cable splice/connections, except those at isolation transformers, must be identified by splice markers. Splice markers must be placed above the splice/connections.
28. The cable and splice markers must identify the circuits to which the cables belong. For example: RWY 4-22, PAPI-4, PAPI-22.
29. Locations of ends of all underground ducts must be identified by duct markers.
30. The preferred mounting method of runway and taxiway signs is by the use of single row of legs. However, two rows will be acceptable.
31. Reference Figure E-13 and Figure E-14 for an example of a lighted sign installation.
- a. Power to the sign must be provided through breakaway cable connectors installed within the frangible point portion of the sign's mounting legs.
 - b. There must be no above ground electrical connection between signs in a sign array.
32. Stencil horizontal and vertical aiming angles on each REIL flash head or equipment enclosure. The numerals must be black and one inch (25 mm) minimum height.
33. Stencil vertical aiming angles on the outside of each PAPI lamp housing. The numerals must be black and one inch (25 mm) minimum height.
34. All power and control cables in man/hand holes must be tagged. Use embossed stainless steel strips or tags attached at both ends to the cable by the use of UV resistant plastic straps. A minimum of two tags must be provided on each cable in a man/hand hole - one at the cable entrance, and one at the cable exit.
35. Apply a corrosion inhibiting, anti-seize compound to all screws, nuts and frangible coupling threads. If coated bolts are used per EB #83, do not apply anti-seize compound.
36. There must be no splices between the isolation transformers. L-823 connectors are allowed at transformer connections only, unless shown otherwise.
37. DEB splices in home runs must be of the cast type, unless shown otherwise.
38. Where a parallel, constant voltage PAPI system is provided, the "T" splices must be of the cast type.
39. Concrete used for slabs, footing, backfill around transformer housings, markers, etc., must be 3000 PSI, min., air-entrained.

E.1.4 Equipment Grounding

1. Ground all non-current-carrying metal parts of electrical equipment by using conductors sized and routed per NEC Handbook, Article 250.

- 6609 2. All ground connections to ground rods, busses, panels, etc., must be made with
6610 pressure type solderless lugs and ground clamps. Soldered or bolt and washer type
6611 connections are not acceptable. Clean all metal surfaces before making ground
6612 connections. Exothermic welds are the preferred method of connection to a ground
6613 rod
- 6614 3. Tops of ground rods must be 6 inches (152 mm) below grade.
- 6615 4. The resistance to ground of the vault grounding system with the commercial power
6616 line neutral disconnected must not exceed 10 ohms.
- 6617 5. The resistance to ground of the counterpoise system, or at isolation locations, such
6618 as airport beacon must not exceed 25 ohms.

6619

Page Intentionally Blank

6620

APPENDIX F Application Notes.**6621 F.1 Purpose.**

6622 The purpose of these Application Notes is to provide additional information to better
6623 guide consultants and designers when developing airfield lighting designs.

6624 F.2 Signs with Internal Power Supplies (Style 2/3).


6625 This section provides some application guidelines to be considered when designing
6626 airfield lighting systems that include certain types of style 2 and 3 signs. There are
6627 several manufacturers of these products and not all products will behave exactly as
6628 described in this Appendix. This information is intended to provide some general
6629 guidelines. The designer should always consult the manufacturer for characteristics and
6630 application information that is specific to each product.

6631 The style 2 lighted sign is for circuits powered by a 3-step CCR where the sign input
6632 current ranges from 4.8 to 6.6 amps. The style 3 lighted sign is for circuits powered by
6633 a 5 step CCR where the sign input current ranges from 2.8 to 6.6 amps (or alternately
6634 from 8.5 to 20 amps).

6635 For the discussion and description below, the examples used are the style 3, 2.8 to 6.6-
6636 amp sign. Most of this information applies to the style 2 signs however; the designer
6637 should consult the manufacturer for specific information.

6638 F.2.1 General Description.

6639 Figure F-1 shows a simplified block diagram of a controlled output sign. A power
6640 supply provides the lamps with a fixed or nearly fixed load current while its input is 2.8
6641 to 6.6 amps current from the series circuit. In this application, the sign may be installed
6642 on a circuit that also has other lighting fixtures that must have their brightness
6643 controlled by selecting CCR current steps. The sign must maintain its brightness at the
6644 required level (10 to 30 foot lamberts – see AC 150/5345-44, Specification for Runway
6645 and Taxiway Signs) when any of the steps are selected on the circuit.

Figure F-1. Controlled Output Sign Block Diagram

This is achieved by holding the current of the lamps to a constant level – the sign lamp intensity will remain nearly the same regardless of the CCR current setting. Since the circuit current operates within a range of 2.8 to 6.6 amps, the sign power supply must continue to provide the same wattage to the load when the CCR current is changed to a lower step. The sign power supply will require more input voltage from the circuit when the circuit current decreases to continue to supply the load with the same wattage.

F.2.2 Circuit Loading Considerations.

To determine the load requirements and CCR sizing for these styles of signs, it would be incorrect to simply add the volt-amps (VA) required by the signs, the load of the remaining items on the circuit, and perform the normal calculations for cable losses, transformer efficiency, etc. This calculation would only be valid if the circuit was kept at the top step, 6.6 amps.

Consider a circuit with multiple signs that has a sign load of 10,000 VA with other lights and losses of 3,000 VA, for a total of 13,000 VA. A 15kVA CCR should be adequate for this load at the top step. A 15kVA CCR has a maximum nominal output voltage of 2,272 volts, at 6.6 amps. The 10,000VA of sign load requires about 1515 volts at 6.6 amps. If the CCR is set to a lower step, the sign components on the circuit will still require 10,000 VA to maintain their brightness. Considering only the sign load and excluding any losses or efficiency issues, the 10,000 VA at 2.8 amps is now a voltage of about 3,570 volts. The CCR however, can only supply 2,772 volts, and is now undersized.

To provide the proper power to the sign, the maximum voltage needed by the signs at the lowest circuit step to be used must be considered along with the VA of the remaining circuit components, cable losses, and series isolation transformer efficiency.

F.2.3 Potential for Conducted Emissions.

Style 2 and 3 signs include a power supply that must maintain a constant brightness on the sign even if the series circuit current is set to any of the 3 or 5 steps from a CCR. To accomplish this, the sign power supply often includes high frequency switching components which have the potential for creating conducted emissions. These

emissions can adversely affect devices on the circuit or other proximate circuits. If any remote switching devices that use power line carrier technology are installed at the airport for applications such as runway guard lights or stop bars, the designer should consider conducted emissions when sharing the circuit with style 2 or 3 signs. In addition, circuits that share a conduit with sign circuits may be subject to any sign emissions cross talk. The designer should consider the application design of these components and consult the manufacturer of these products to determine if a potential problem exists.

F.2.4 Circuit stability on circuits including style 2 or 3 signs.

Some Style 2 or 3 signs may have large swings in the load they present to the series circuit during start up or after a lamp fails. This type of load may not be well tolerated by certain CCRs, resulting in instability or shutdown of the circuit. The designer should consult the manufacturer of both the sign and CCR to determine proper compatibility.

F.3 Series Circuit Addressable Devices.

This section provides some application guidelines to be considered when designing airfield lighting systems that include addressable switching devices.

F.3.1 Addressable Lights General Description.

Figure F-2 shows a typical power line carrier arrangement for addressable switching devices.

1. Each fixture is connected to an Addressable Control and Monitoring Unit (ACMU) on the secondary of an L-830/L-831 isolation transformer.
2. There is an interface in the vault (Series Circuit Interface) that sends messages onto the series lighting circuit.
3. The ACMUs in the field receive these signals and provide a response to the interface in the vault, providing control and monitoring functionality for the lights on the circuit.
4. Each ACMU is programmed with unique configuration parameters that control its associated fixture.




Figure F-2. Typical Power Line Carrier System

5. The fixture is also monitored by the ACMU to detect a lamp failure.
6. Addressable switching systems are also available using fiber optic or twisted pair copper wire as a substitute for the power line carrier data communications on the series circuit. However, the designer must be aware that each type of data communications has its own set of design requirements.
7. The majority of systems will use a power line carrier system since no additional cable is required. Consult with the system manufacturer for an optimal data communications design.
8. Some of the applications information may apply to these systems but due to their varied configurations are not covered here.

F.3.2 Response Time Related Requirements.

There are several issues relating to the technology and electrical environment that impact the general response times of ACMU components. Depending on the application, the response time requirements may be significantly different.

F.3.2.1 **Time to change state example- Stop Bars.**

In this example, a button is pressed in the tower to clear an aircraft onto or across a runway. A critical response time in this situation is the time required from the button being pushed until all of the lights on the stop bar are lit (otherwise known as change state).

In some cases, the addressable system must send the messages to the addressable devices multiple times in the event that some of the devices do not properly receive and acknowledge the change state command - more time will be required to complete the execution of the command.

If some of the lights in a stop bar change state while others do not (the initial command is not properly received by all of the devices in the group), all of the lights in the stop bar may not be lit at the same time.

The designer must work closely with the manufacturer to ensure that response times are considered when addressable device systems are installed.

F.3.2.2

Sensor Timing.

There are applications such as stop bars that require the use of sensors on the airfield to detect a vehicle or aircraft passage at a specific location.

The sensor behavior, detection zones and response time is unique to the technology used (i.e., inductive loops, Doppler RADAR, etc.).

Typically, a detection event is passed to a special addressable device that is designed to accept a logic state change or contact closure to report a detection event.

The response time of an addressable system to report these detection events can vary greatly depending on how the system has been designed, the communications capabilities and performance margins, and other factors.

For example, if the addressable system is polling the device that reports the status of a sensor, the time required to collect a valid status must be much shorter than the time the sensor event is present on the detection system or there is a risk of missing the detection.

The sensor may be designed to retain the changed state of the sensor for a programmable time to ensure that the addressable system has reported the status. This holding time however, cannot be so long as to show the sensor in the “detect” state so that the detection of a closely following vehicle or aircraft may be missed.

The addressable system support of sensor self-testing (if available) must also be considered as to how it is initiated and reported. Refer to RTCA DO-221, Guidance and Recommended Requirements for Airport Surface Movement Sensor, for additional information about airfield sensors.

The designer should discuss the specific application with the manufacturer of the addressable control component to develop appropriate sensor performance for the application.

F.3.2.3

Time to report status.

When the groups of lights in a stop bar change state, the next area to consider is the time required for the status of the lighting groups that have

6767 changed state to be presented on the air traffic control tower (ATCT)
6768 monitor.

6769 Generally, the tower monitor needs to display the status of lighting
6770 components as a group (i.e., stop bar, RGL bar, lead on lights, etc.) and
6771 not individual fixtures unless there is a specific requirement.

6772 To display the status of lights in a group, it is necessary for the
6773 addressable lighting system to collect the status of all of the individual
6774 fixtures and determine the operational state of the group of lights.

6775 The time required to present the status will depend on the technology used
6776 and also if the messages involved in collecting the status have to be
6777 retransmitted multiple times in the event that there is a marginal
6778 communications condition.

6779 F.3.2.4 **Failed Lamp Reporting.**

- 6780 1. Another consideration is the time required to report a failed lamp.
- 6781 2. This is typically a lower priority than the response time for
6782 commanding lighting groups.
- 6783 3. Individual lamps that have failed but have not caused the lighting
6784 group to be below its operational criteria (one lamp out or two non-
6785 adjacent lamps out) is not as critical as two adjacent or any three lamps
6786 out, which causes the lighting group to not be operationally available.
- 6787 4. The designer should consider the application to determine the
6788 appropriate time the system requires when reporting a failed lamp or
6789 group of lamps.

6790 F.3.2.5 **Incorrect status.**

6791 Poor data communications between the vault interface equipment and
6792 addressable field components may result in an incorrect status being
6793 reported with resulting nuisance alarms at the ATCT monitor.
6794 Consideration should be given to this potential issue when designing
6795 addressable lighting systems.

6796 F.3.2.6 **Wattage capacity of the switching device.**

6797 In some cases, the switching capacity of the addressable switching device
6798 may depend on the CCR supplied waveform. High crest factor CCR
6799 current may not allow the use of the maximum rated load wattage. The
6800 designer should consider the application to ensure proper operation. The
6801 choice of CCR may impact the loading required. Consult with the
6802 manufacturer about potential CCR issues.

6803 F.3.3 Cabling issues6804 F.3.3.1 **Systems using power line carrier communications.**

- 6805 1. The cable layout design for the series lighting circuit must be
6806 considered. The optimal layout of the cable can maximize
6807 communications performance and improve communications noise and
6808 interference operating margins.
- 6809 2. For new installations, separating the series circuit from other circuits
6810 on the airfield may improve communications reliability.
- 6811 3. The prevention of undesirable crosstalk arising from coupling from
6812 one cable to another is of importance.
- 6813 4. Electrical noise from other airfield components (i.e., CCRs, LED
6814 fixtures, certain types of signs of flashing lights) can also interfere
6815 with reliable communication.
- 6816 5. The designer should consult with the manufacturer to develop the best
6817 cable layout design.

6818 F.3.3.2 **Systems Using Fiber Optic Communications.**

- 6819 1. Addressable devices may be available that use fiber optic cables
6820 connected to each device. Designers should evaluate the difficulty of
6821 installation and maintainability when considering these products.
- 6822 2. The routing of fiber in the proximity of series circuit cables may
6823 require separate conduits depending on the standards required by the
6824 airport.
- 6825 3. The fiber optic connector that is used to connect the addressable
6826 device to the communications system must be capable of withstanding
6827 the airfield environment in duct banks that are frequently or most
6828 always submerged in water that may have deicing chemicals present.
- 6829 4. The removal and replacement of a device with a fiber connector must
6830 be practical for airfield electrical maintenance personnel.
- 6831 5. This is particularly true for maintenance procedures that protect the
6832 fiber optics and connector from any damage or possible contamination.

6833 F.3.3.3 **Systems using a separate cable for data communications.**

- 6834 1. Addressable devices may be available that use separate copper (hard-
6835 wired) cables connected to each device.
- 6836 2. These types of systems use a set of manufacturer defined conductors
6837 that may be daisy chained from one addressable device to the next and
6838 ultimately to the vault interface.
- 6839 3. Designers should evaluate the difficulty of installation and
6840 maintainability when considering these products.

4. The hard-wired connector that is used to connect the addressable device to the communications system must be capable of withstanding the airfield environment in duct banks that are frequently or most always submerged in water or water that may have deicing chemicals present.
5. Since the data communication is on a low voltage cable, it must be separated from the series lighting circuit unless the twisted pair cable insulation rating is the same as the insulation rating on the series circuit cable (typically 5 kilovolts).
6. In addition, an airport's restriction on allowed distance between splices should be considered as it may not be possible to get 5kV rated cable greater than the airport's maximum splice distance limitation.
7. The designer should consider system communication effects due to opens and/or shorts on the cable.
8. A hard-wired system may require significant shielding to reduce the risk of interference.
9. Any break in the shield due to poor installation or maintenance may cause the entire system to be more susceptible to noise.

F.3.3.4 **Existing cable.**

Following optimal cable layout guidelines may not be possible for airports with existing series lighting circuits. An aging series lighting cable with multiple ground faults or arcing splices may prevent the proper operation of an addressable lighting system and may significantly impact the quality and performance of the data communications.

F.3.4 Transformer age and selection.

Old isolation transformers with poor insulation or connectors also impact the addressable lighting system. The designer should be aware of the current airfield electrical system condition to determine if the existing transformers can be used or must be replaced. Generally, the smallest transformer capacity that will meet the fixture load requirements should be used. In some cases, larger capacity transformers can cause more loss in any data communications methodology. Consult the manufacturer of the power line carrier product when selecting isolation transformers.

F.3.5 Load calculation.

Each addressable device will consume power on the secondary of the isolation transformer. When calculating the load, consider the peak power consumption of the device and add the loss in the additional secondary cable, particularly if there is a secondary extension cable.

F.3.6 Load characteristics.

Most addressable devices are designed to handle incandescent loads. Generally, circuit current is checked to the load. If other types of loads (for example, LED or flashing) are to be used, consult the manufacturer to determine compatibility.

F.3.7 Potential susceptibility to conducted emissions from other airfield devices.

LED fixtures and certain types of signs may cause conducted emissions that can propagate on the series circuit. These emissions are also able to couple from one circuit to another potentially interfering with data communications on power line carrier systems.

F.3.8 Choice of CCR.

1. The selection of a particular CCR on a power line carrier circuit can improve the overall system performance.
2. CCRs with high levels of harmonics can reduce operating performance margins. This may be true for CCRs that reconstruct the sinusoidal waveform via high frequency switching and produce output current that contain artifacts of the switching frequency.
3. Consult the manufacturer to ensure compatibility if these types of CCRs are known to be in use.

F.3.9 Maintainability.

F.3.9.1 **Reporting of failed components.**

1. In the event of a lamp failure or any component of the addressable system, the capability to convey the information to maintenance personnel should be considered.
2. The failure reporting capability of the addressable system must be consistent with the maintenance philosophy at the airport.
3. The reporting and locating of a failed component must be readily recognized and understood by those responsible for system maintenance.

F.3.9.2 **Programming of spares.**

In the event that a failed addressable device needs replacement, the spare component will have to be configured. Some systems support in-circuit replacement while others provide a programming tool. These features should be considered as to how they impact the airport maintenance capabilities.

F.3.10 Constant Current Regulators.

1. This section provides some application guidelines to be considered when designing airfield lighting systems with relevance to the electrical characteristics of CCRs.
2. It should be noted that there are several manufacturers of these products and not all products will operate exactly as described in this Appendix.
3. This information is intended to provide some general guidelines on selected topics.
4. The designer should always consult the manufacturer for characteristics and application information that is specific to each product.

6920 F.3.11 Circuit Loading Considerations


- 6921 1. Some lighting circuits on the airfield include components that load the CCR with a
6922 varying current. Examples of these loads are segmented circuits that are switched
6923 by selector switches, stop bar components, or all types of runway guard lights with
6924 flashing loads.
- 6925 2. Calculations that involve efficiency or power factors can vary greatly depending on
6926 the circuit load at a particular time.
- 6927 3. The designer should consider the extremes of the loading to ensure that the
6928 calculations include the lowest and highest possible loads.

6929 F.3.12 Extended load range issues.

6930 Regulator efficiency can be significantly reduced if its load is reduced to a low level.
6931 The combination of a light load (less than 50% of CCR capacity) and many open
6932 secondary isolation transformers can cause some CCRs to become unstable.

6933 F.3.13 Synchronously flashing loads.

- 6934 1. The in-pavement runway guard light (IPRGL) circuit is an example of a potentially
6935 large load swing on a circuit in the range of 30 to 32 flash cycles per minute.
- 6936 2. If all of the IPRGL fixtures on the circuit are exactly synchronized, half of the
6937 fixtures are on and off at any point in time.
- 6938 3. But as the lamps change state, the lamps that have just been turned off provide
6939 almost no load, and the lamps that have just been turned on provide about half of
6940 their load, since the filaments are still warm.
- 6941 4. As the filaments warm to full output, the “on” lamps then provide their full load. A
6942 graph that illustrates the circuit loading is shown in Figure F-3.

Figure F-3. Load Example for In Pavement RGL Circuit

5. In Figure F-3, it is assumed that a 100% load is with all IPRGL fixtures energized. The selection of the CCR should include consideration for this type of loading. The designer must ensure that the calculations with regard to efficiency and loading are correct.
6. The CCR manufacturer should also be consulted as to the suitability of a given CCR to this application.
7. The available IPRGL systems may include a built-in functionality to distribute the loading to somewhat reduce the dynamics for the circuit.
8. In addition, the timing of the IPRGLs may be critical to avoid the case where both even and odd lights are off at the same time, resulting in very low loading by the IPRGLs.
9. There may be a small amount of acceptable, normal CCR output current variation as the load is changing. For monitored series circuits, it is acceptable to slightly widen CCR output current monitoring alarm levels to eliminate unnecessary nuisance alarms.
10. There may be a small amount of acceptable, normal CCR output current variation as the load is changing. For monitored series circuits, it is acceptable to slightly widen CCR output current monitoring alarm levels to eliminate unnecessary nuisance alarms.
11. The designer should consult the manufacturer of the CCR and IPRGL controls about the compatibility and application of these components.

F.3.14 Asynchronously flashing loads.

1. An example of an asynchronously flashing load is the elevated runway guard light flashing in the range of 45 to 50 flash cycles per minute.
2. Typically, the timing of each flashing device is unsynchronized and the series lighting circuit loading at any given moment may drift.
3. The average loading tends to normalize over larger circuits over time, but there can be periods of time where loading is quite variable.
4. There may be a small amount of acceptable, normal CCR output current variation as the load is changing.
5. For monitored series circuits, it is acceptable to slightly widen CCR output current monitoring alarm levels to eliminate unnecessary nuisance alarms.
6. The designer should consult the manufacturer of the CCR and elevated RGLs as to the compatibility and application of these components.

F.3.15 Non-Linear or Reactive Loads.

1. Electronic devices such as LED fixtures, style 2 and 3 signs, and addressable components, can provide a non-linear or reactive load on the circuit. These devices can include switching power supplies which may impart a capacitive characteristic to the circuit load.
2. In addition, when the circuit is energized, these devices can initially appear to provide a relatively high voltage drop and suddenly change to a lower drop.
3. The designer should consult with the CCR and electronic component manufacturer to determine if there are compatibility issues to consider.

F.3.16 CCR-related emissions.

AC 150/5345-10 includes requirements for EMI in this excerpt:

3.3.12 Electromagnetic Interference.

The regulator must cause the minimum possible radiated or conducted electromagnetic interference (EMI) to airport and FAA equipment (e.g., computers, radars, instrument landing systems, radio receivers, VHF Omni-directional Range, etc.) that may be located on or near an airport.

There is also the potential for conducted emissions from a CCR to couple to other circuits, particularly if the circuit cable is in the same conduit for long distances on the airfield.

CCRs that use thyristors to control the conduction duty cycle may cause significant harmonic distortion. On the field circuit, the fast “turn on” of the thyristor can contain high order harmonics of sufficient energy to couple to other circuits through cross talk to the field cable.

Another source of conducted emissions may be from CCRs that use high frequency switching to approximate a sinusoidal current waveform. This waveform can include high frequency artifacts, which can couple to other circuits on the airfield if any cables

are in proximity. These circuits can be lighting or other control circuits. The emissions can adversely affect the proper operation of devices on the circuit or other proximate circuits.

If any remote switching devices that use power line carrier technology are used at the airport, the designer should include considerations for the CCR selection. The designer should consider the application design of these components, and consult the manufacturer of the products to determine if a potential problem exists.

F.4 Airfield Lighting Control and Monitoring Systems (ALCMS).

This section provides some application guidelines to be considered when specifying an ALCMS or items that interface to it.

F.4.1 Response Times.

1. In the specification for the L-890 ALCMS defined in AC 150/5345-56, response times are described only in the certification testing process.
2. The following provides instructions to test the ALCMS within a lab certification environment. Generally, the system is connected with a relatively small complement of components to be controlled and monitored by the ALCMS. The response times required in AC 150/5345-56 and referred to this AC are, for the most part, included in Table 13-1.

Time Characteristic	Response Time (seconds)
From command input until acceptance or rejection	< 0.5
From command input until control signal output to regulator or other controlled unit	< 1.0
For system to indicate that a control device has received the control signal	< 2.0
Back indication to tower display of regulator initiation	< 1.0
Switch-over time to redundant components in event of system faults (no command execution during this time)	< 0.5
Automatic detection of failed units and communication lines of the monitoring system	< 10

3. It must be noted that the response times shown refer only to the ALCMS. Equipment that is controlled is not part of this table. The designer must consider this and in particular, establish response times at the system level that includes the response times of components that are controlled by the ALCMS. Establish timing


budgets at each interface to ensure that each product specified has its response time budget included so it can be verified on site in the event the system level response time is not acceptable.

4. In addition, **because** the response times are listed in the context of a certification test (the system is loaded with relatively few components), the designer should also address all response times in the ALCMS and connected components in the specifications when it is installed on site with all systems operational. After installation, there will be many more regulators, possibly multiple vaults, remote locations for maintenance, and some number of ATCT Human Machine Interfaces (HMI). Each of these items can change the system response time.

F.4.2 Failover and recovery.

1. Depending on the level of redundancy in the ALCMS, the failover and recovery functions can have wide spread implications. The most common redundancy is in the network that connects different locations in the ALCMS (i.e., ATCT, vault(s) maintenance terminals, etc.).
2. Redundancy protects the system from a network fault and prevents a loss of system control if a network connection fails. A more sophisticated design includes most critical components being redundant with two network connections. Each location would have two network switches and be independently powered. Within each location there would be an internal redundant network so that each component to be controlled or monitored connects to both local networks. The example from AC 150/5345-56 is shown below:

7051

Figure F-4. ALCMS Block Diagram from AC 250/5345-56

7052

7053

7054

7055

7056

7057

7058

7059

7060

7061

3. The issue for the designer is to consider how each failure is processed by the system. If a component on the vault communications network loses its connection on one of its networks but not the other, different system designs will imply different failover mechanisms. A simplistic design might switch all networks on the ALCMS to the backup network. This would probably take longer to complete since all components must detect and act on a network changeover. The more likely switchover is either the vault network switching over or just the data between a failed vault component and the system is supported on the operating network segment.
4. Some designs may actively use both networks and fully load one network in the event the other fails. The failover design must be able to detect the loss of a component. The system must then determine the alternate means to be used as a backup and then communicate with any system components that must take some

7062

7063

7064

7065

kind of action to switch over. The system must retain the status and locations of all of the components. In the event of a failure, the current system status must continue to be maintained on the backup computer or server. During the failover process, no data can be lost and the critical element is the time the ATCT HMI may be without any method of control – this is a critical system parameter. The system must also detect that a failure (component or network) has been repaired and returned to normal operation (the recovery mechanism also includes the same timing issues as fault detection).

5. There are many scenarios of failed components where each may cause different failover behavior with different timing. The designer must consult the manufacturer to determine the appropriate failover architecture for the airport and establish the details of the failover/recovery functionality.

F.4.3 Site acceptance test (SAT).

1. AC 150/5345-56 only refers to a site acceptance test (SAT) in general terms. The designer should review (consulting the manufacturer when necessary) what critical parameters are to be considered during an SAT.
2. For example, checking the system functionality, system and component response times, loss of power, network failure, and labeling. The AC leaves it up to the supplier to develop a test plan with the designer providing approval.
3. However, the designer can include a more detailed set of guidelines regarding site acceptance testing. This would ensure that the test is of more value to the airport owner and addresses any exceptional conditions that are likely to arise during operation.

F.4.4 Interfaces.

1. If there is equipment to be connected to the ALCMS that is from different suppliers, the designer should develop a complete understanding of how each component will interact.
2. If the control and monitoring functions are discrete wiring and contact closures or simple analog voltages to be measured, these are more common and will be less of a problem. In the case that the interface is a more complex communication interface, the designer should ensure that these interfaces are supported by both systems and in particular that the functions defined for the application are fully supported.
3. This should be part of the factory and site acceptance tests. If the interface is to be developed by two parties, an interface control document (ICD) should be developed.

APPENDIX G Runway Status Light (RWSL) System.

G.1 Purpose

1. This Appendix describes the installation requirements for RWSL. While RWSL may be an FAA owned and operated system, the designer and airport authorities must be aware of how the installation of the system may impact airport operations.
2. The RWSL system will require the installation of in-pavement lighting fixtures (consisting of Runway Entrance Lights (RELs) and Takeoff Hold Lights (THLs)), associated installation hardware that includes conduit, high voltage cable, equipment vault(s), and data links from the air traffic control tower to the electrical vault(s).
3. Airport Authorities should be prepared to participate in meetings with the FAA to establish consensus and approve installation plans/schedules, any airport related operational impacts/associated costs, and optimal equipment and light locations.
4. Additionally, RWSL construction activities may affect multiple taxiway and runway operations. Therefore, airport authorities should be prepared to fully assess and agree to any prolonged operational impacts and unique airport specific requirements.

G.1.1 System Description.

1. The purpose of the RWSL System is to reduce the number of runway incursions without interfering with normal airport operations. Runway status lights display critical, time-sensitive safety status information directly to pilots and vehicle operators via in-pavement lights giving them an immediate indication of potentially unsafe situations. Runway status lights indicate runway status only; they do not indicate clearance.
2. The RWSL System uses computer processing of integrated surface and terminal surveillance information to establish the presence and motion of aircraft and surface vehicles on or near the runways. The system illuminates red runway-entrance lights (RELs) if the runway is unsafe for entry or crossing, and illuminates red takeoff-hold lights (THLs) if the runway is unsafe for departure. The system extinguishes the lights automatically as appropriate when the runway is no longer unsafe.
3. The RWSL System consists of an RWSL processor and a Field Lighting System (FLS). The RWSL processor receives surveillance data of aircraft and vehicles on or near the airport surface from the ground surface surveillance system. The RWSL processor uses this surveillance data to determine when to activate and deactivate the RELs and THLs. The light commands are sent to the RWSL FLS.
4. The FLS includes a Light Computer (LC), in pavement light fixtures, and all light system circuitry. The FLS receives the light commands and illuminates and extinguishes the lights as commanded by the RWSL processor. The system will automatically determine runway configurations and will adjust the activation and

deactivation of RELs and THLs accordingly. The system will automatically adjust light intensity according to time of day.

5. Air Traffic supervisors control the system using a cab control panel. Control functions will include light intensity control (override of automatic intensity adjustment) separately by RELs and THLs. Status indicators will be provided such as system online/offline and if maintenance is required. A separate kill switch will be provided to deactivate all RWSL fixtures in the event of a system malfunction.
6. The RWSL System includes a maintenance terminal for Technical Operations personnel to control the RWSL System and to assist with identification of failed line replaceable units (LRUs). The maintenance terminal also provides all tools and controls necessary to configure and optimize the system.

G.2 Installation.

G.2.1 Runway Entrance Lights (REL)

RELs are installed at taxiway/runway intersections and advise aircrews or vehicle operators when it unsafe to cross or enter a runway. The airport authority should ensure that RELs are certified to AC 150/5345-46, Type L-852S, Class 2, Mode 1, Style 3.

G.2.2 REL Light Base.

Light mounting bases should be Type L-868, Class IA or IB, Size B per AC 150/5345-42. Ensure that all light bases are installed per Chapter 11 and Chapter 12.

G.2.3 REL Configurations.

The following standards apply for the most common REL configurations:


- Basic Configuration (straight taxiway perpendicular to the runway)
- Angled Configuration (straight taxiway not perpendicular to the runway)
- Curved Configuration (curved taxiway at a varying angle to the runway)

G.2.3.1 Basic (90-degree) Configuration.

1. This is the most common intersection. See Figure G-1. Because the taxiway centerline is perpendicular to the runway centerline, the longitudinal line of RELs is also perpendicular to the runway, and all the lights are aimed along the taxiway path, that is perpendicular to the runway centerline.
2. RELs are installed parallel to the taxiway centerline and spaced laterally 2 ft. (0.6 m) from the taxiway centerline on the opposite side of taxiway centerline lights (if installed).
3. A REL array will typically consist of a minimum of six (6) lights and may include more (there may be fewer than 6 RELs for short taxiway segments), depending on the distance between the runway centerline and the holding position.

4. The first light in the taxiway segment is installed two (2) ft. prior to the runway holding position marking. The next to last light is installed two (2) ft. prior to the runway edge stripe.
5. The last light in the array is installed 2 ft. (0.6 m) to the side of the runway centerline lights toward the intersecting taxiway (See [Table 4-1](#) for longitudinal spacing standards.)
6. The REL light base installation must be no closer than 2 ft. (0.6 m) (measured to the edge of the fixture base) to any pavement joints.

Figure G-1. REL Configuration for Taxiways at 90 Degrees




G.2.3.2 Angled Configuration.

1. See [Figure G-2](#). This configuration is used where the intersecting taxiway is not perpendicular to the runway centerline but not less than 60 degrees from the runway centerline.
2. The location and spacing of the REL lights along the taxiway centerline is identical to the one used on perpendicular intersections.
3. Ensure that RELs cannot be seen by traffic on the runway. For highly angled taxiways (e.g. less than 60 degrees from the runway centerline

heading), the fixtures used and aiming will be determined on a case by case basis.

Figure G-2. Angled Configuration



G.2.3.3 Curved Configuration.

1. When the taxiway centerline marking between the holding position marking and the runway is curved, the maximum REL longitudinal spacing must be per EB #64.
2. The runway centerline REL will be located on the extended line of the last two longitudinal lights near the runway edge.
3. Where a tangent to the curve of the taxiway centerline intersects the runway centerline at not less than 60 degrees, aiming must comply with **this AC** for taxiway centerline lights.
4. When the angle is less than 60 degrees, aiming must be determined on a case-by-case basis. Contact AAS-100 for specific guidance.

7210 G.2.4 Takeoff Hold Lights (THL).

- 7211 1. THLs are used at the runway departure area to warn aircrews and vehicle operators
7212 that the runway is unsafe for takeoff. See Figure G-3. THLs are a double row of
7213 unidirectional in-pavement red lights aligned with the runway centerline lights
7214 (centerline of light fixture) aimed toward the approach path to the runway.
- 7215 2. THLs begin at a point that is 375 ft. (± 25 ft.) ($99 \text{ m} \pm 7.6 \text{ m}$) from the runway
7216 threshold and are displaced 6 ft. on either side of the runway centerline lights.
- 7217 3. THLs are placed every 100 ft. (30.5 m) for 50 ft. (15.2 m) spaced centerline lights
7218 (between the centerline lights in every other space). There will be 1500 ft. (457.2
7219 m) of lights (32 lights) in the array.


7220 G.2.4.1 **THL Fixtures**

7221 THLs are a Type L-850T, Class 2, Mode 1, Style 3 light fixture. The
7222 airport authority should ensure that all installation guidelines in Chapter
7223 11 and Chapter 12 are followed.

7224 G.2.4.2 **THL Mounting Base.**

7225 THL mounting bases are identical to those used for RELs.

7226

Figure G-3. Takeoff/Hold Lights

7227

7228 **G.2.5** Constant Current Regulator (CCR) Power Supply.

- 7229 1. This unit provides constant current power (via series lighting circuit high voltage
7230 cable) to all RWSL THL/REL lamps.
- 7231 2. The CCR is either FAA Type L-828 (no monitoring), Class 1 (6.6 Amps), Style 2 (5
7232 brightness steps) or FAA Type L-829 (with monitoring), Class 1 (6.6 Amps), Style
7233 2 (5 brightness steps) per AC 150/5345-10.
- 7234 3. The lighting vault housing the CCRs and other commercial AC Power equipment
7235 will be located in an area mutually acceptable to the FAA and the Airport Authority.

7236 **G.2.6** Isolation Transformer.

7237 The RWSL isolation transformers will be Type L-830-18 (for both THLs and RELs) per
7238 AC 150/5345-47. All connectors used should be per AC 150/5345-26.

7239 **G.2.7** Individual Light Controller (ILC).

- 7240 1. The ILC input connects to the secondary side of the isolation transformer and
7241 enables computer control of the THL or REL lamp via power line carrier based data
7242 communications.
- 7243 2. The ILC provides monitoring of lamp current, voltage, and load status, including a
7244 lamp out detection when it is not processing commands.
- 7245 3. If a lamp fails, the ILC places a short across the secondary side of the isolation
7246 transformer to maintain light system loading.

7247 **G.3** **Runway Intersection Lights (RIL)**

- 7248 1. RILs are used at runway/runway intersections and provide an indication to aircrews
7249 and vehicle operators that there is high-speed traffic on the intersecting runway and
7250 that it is unsafe to enter or cross.
- 7251 2. They are red unidirectional lights installed in a double longitudinal row aligned and
7252 offset from either side of the runway centerline lighting in the same fashion as
7253 THLs.
- 7254 3. See paragraph G.2.4 item 1 for a more detailed THL runway location description
7255 and diagrams.


7256 **G.3.1** RIL Mounting Base

7257 RIL light fixtures are the same as those used for THLs: Type L-850T Class 2, Style 3,
7258 Mode 1.

7259 **G.3.2** RIL General Installation

- 7260 1. See Figure G-4. RILs are a double row (31 pairs) of in-pavement red lights that are
7261 aligned with the runway centerline lights and aimed toward an aircraft or vehicle
7262 that is approaching an intersecting runway.

- 7263 2. They begin at the Land and Hold Short (LAHSO) in pavement lights or the runway
7264 holding position marking and extend toward the approach end of the runway for
7265 3000 ft. (914.4 m).
- 7266 3. In the absence of either LAHSO lights or a runway holding position marking, the
7267 equivalent point of the runway holding position must be determined (see AC
7268 150/5340-1 for additional information about the location of the runway holding
7269 position marking).
- 7270 4. See Figure G-4 Detail. The first pair of RIL light fixtures is located 6 ft. (measured
7271 to the centerline of the RIL light fixture) from the outer edge of the first solid line of
7272 the runway holding position marking toward the approach end of the runway.
- 7273 5. If LAHSO in-pavement lights are installed, the first pair of RIL light fixtures is
7274 located 6 ft. (1.8 m) (measured to the centerline of the RIL light fixture) from the
7275 centerline of the LAHSO light bar.
- 7276 6. The tolerance for both installation cases is plus 25 ft. (7.6 m) or less toward the
7277 approach end of the runway to achieve the RIL spacing requirement. RILs are
7278 installed every 100 ft. (30.5 m) and displaced 6 ft. (1.8 m) either side of the runway
7279 centerline lights in the same manner as THLs.

Figure G-4. Runway Intersection Lights

G.3.3 RIL Installation on a Runway with No Centerline Lights

1. There may be circumstances where RILs are to be installed on a runway that does not have centerline lights. For these locations, the RIL array must accommodate an imaginary line that would represent the location of the runway centerline lights (2.5 ft. (0.8 m)) from the physical centerline of the runway to the centerline of the light fixture).
2. Per Figure G-1, the RILs are offset 6 ft. (1.8 m) from the physical centerline (both sides) of the imaginary runway centerline light fixtures.

G.3.4 Overlapping RILs and THLs

In some situations, RIL and THL light fixtures may overlap. When there is overlapping, first determine the layout of the RILs. Then continue with the THL light fixtures (using the last pair of RIL fixtures as a point of reference) until the last pair of THL fixtures is 375 ± 25 ft. ($99 \text{ m} \pm 7.6 \text{ m}$) from the runway threshold (departure end).

7295 **G.4 DESIGN.**

7296 G.4.1 General Guidelines.

- 7297 1. The RWSL will be installed using new conduit where possible for existing
7298 runways/taxiways. Future installations of in-pavement L-868 light bases and
7299 conduit should be done, if possible, while the pavement is under construction or
7300 when an overlay is made.
- 7301 2. Installation of conduit and light bases after paving is very costly and requires a
7302 lengthy shutdown of the taxiway or runway.
- 7303 3. The airport authority should ensure that all installation guidelines, methods and
7304 techniques (Chapter 10, Chapter 11, and Chapter 12) guidelines in this AC are
7305 followed when an RWSL installation is scheduled.

7306 G.4.2 Layout.

7307 A design drawing must be developed prior to construction (coordinated with and
7308 approved by the airport authority) showing the dimensional layout of each RWSL
7309 lighting system to be installed.

7310 G.4.3 Overlay Rigid and Flexible Pavements.

7311 See Chapter 10 for installation guidance and information.

7312 G.4.4 Existing Pavements.

7313 See Chapter 10 for installation guidance.

7314 **G.5 Surface Movement Guidance Control System (SMGCS)**

7315 Any potential impacts of the RWSL system on airport SMGCS operation must be
7316 evaluated and resolved with the local Airport Authority and Airports District Office
7317 prior to commencing any installation activities.

7318 G.5.1 Equipment and Material.

7319 All equipment and material will be supplied by the sponsoring activity.

7320 G.5.2 Lighting Vault.

7321 The vault location is subject to the approval of the local Airport Authority before
7322 installation begins.

7323 **G.6 Operational Testing.**

7324 The airport authority should be prepared to coordinate with the FAA to minimize
7325 potential impacts to airport operations.

7326

Appendix H Legacy Figures.

7327

7328

7329

This section has been reserved for Legacy Figures A-2, A-3, A-5, A-6, A-7, A-8, A-9, A-10, A-11, A-12 and A-17 originally published in AC 150/5340-30H. They are being maintained in this appendix for reference and maintenance purposes.

Figure H-1. Runway and Threshold Lighting Configuration (LIRL Runways and MIRL Visual Runways)




Figure H-2. Runway and Threshold Lighting Configuration (HIRL Precision Instrument Approach - Runway Centerline Not Shown for HIRL; Non-precision Instrument Approach for MIRL)




Figure H-3. Runway with Blast Pad (No Traffic)




Figure H-4. Lighting for Runway with Displaced Threshold





Figure H-5. Normal Runway with Taxiway


Figure H-6. Lighting for Runway with Displaced Threshold


Figure H-7. Lighting for Runway with Displaced Threshold/Usable Pavement

Figure H-8. Lighting for Runway with Displaced Threshold Not Coinciding with Opposite Runway End




Figure H-9. Lighting for Runway with Stopway




Figure H-10. Lighting for Runway with Displaced Threshold and Stopway





Figure H-11. Spacing of Lights on Curved Taxiway Edges

RADIUS (R) OF CURVE (IN FEET)	DIMENSION "Z" (IN FEET)
15	20
25	27
50	35
75	40
100	50
150	55
200	60
250	70
300	80
400	95
500	110
600	130
700	145
800	165
900	185
1000	200 MAXIMUM

NOTES:

1. FOR RADII NOT LISTED, DETERMINE "Z" SPACING BY LINEAR INTERPOLATION.
2. "Z" IS THE ARC LENGTH.
3. UNIFORMLY SPACE LIGHTS ON CURVED EDGES. DO NOT EXCEED THE VALUES DETERMINED FROM THE TABLE OPPOSITE.
4. ON CURVED EDGES IN EXCESS OF 30 DEGREES ARC DO NOT INSTALL LESS THAN THREE LIGHTS INCLUDING THOSE AT THE POINTS OF TANGENCY (PT).
5. TO DETERMINE THE METRIC EQUIVALENT OF THE RADIUS (R) AND DIMENSION "Z" MULTIPLY BY 0.3048.

7343

Advisory Circular Feedback

7344 If you find an error in this AC, have recommendations for improving it, or have suggestions for
7345 new items/subjects to be added, you may let us know by (1) mailing this form to Manager,
7346 Airport Engineering Division, Federal Aviation Administration ATTN: AAS-100,
7347 800 Independence Avenue SW, Washington DC 20591 or (2) faxing it to the attention of the
7348 Office of Airport Safety and Standards at (202) 267-5383.

7349 Subject: AC 150/5340-30J Date: _____

7350 *Please check all appropriate line items:*

7351 ☐ An error (procedural or typographical) has been noted in paragraph _____ on page
7352 _____.

7353 ☐ Recommend paragraph _____ on page _____ be changed as follows:

7354 _____
7355 _____
7356 _____

7357 ☐ In a future change to this AC, please cover the following subject:
7358 *(Briefly describe what you want added.)*

7359 _____
7360 _____
7361 _____

7362 ☐ Other comments:

7363 _____
7364 _____
7365 _____

7366 ☐ I would like to discuss the above. Please contact me at (phone number, email address).

7367 _____
7368 _____
7369 _____

7370 Submitted by: _____ Date: _____

