

CHANGE

**U.S. DEPARTMENT OF TRANSPORTATION
FEDERAL AVIATION ADMINISTRATION**

**JO 7110.65AA
CHG 1**

Air Traffic Organization Policy

Effective Date:
October 5, 2023

SUBJ: Air Traffic Control

- 1. Purpose of This Change.** This change transmits revised pages to Federal Aviation Administration Order JO 7110.65AA, Air Traffic Control, and the Briefing Guide.
- 2. Audience.** This change applies to all Air Traffic Organization (ATO) personnel and anyone using ATO directives.
- 3. Where Can I Find This Change?** This change is available on the FAA website at http://faa.gov/air_traffic/publications and https://employees.faa.gov/tools_resources/orders_notices/.
- 4. Explanation of Policy Change.** See the Explanation of Changes attachment that has editorial corrections and changes submitted through normal procedures. The Briefing Guide lists only new or modified material, along with background.
- 5. Distribution.** This change is distributed to select offices in Washington headquarters, service area offices, the William J. Hughes Technical Center, the Mike Monroney Aeronautical Center, air traffic field facilities, and international aviation offices. This change is distributed electronically to all who subscribe to receive email notification through the FAA's website. All organizations are responsible for viewing, downloading, and subscribing to receive email notifications when changes occur to this order. Subscriptions to air traffic directives can be made through the Air Traffic Plans and Publications website at https://www.faa.gov/air_traffic/publications/ or directly via the following link: https://public.govdelivery.com/accounts/USAFAA/subscriber/new?topic_id=USAFAA_39.
- 6. Disposition of Transmittal.** Retain this transmittal until superseded by a new basic order.
- 7. Page Control Chart.** See the page control chart attachment.

NATASHA A. DURKINS Digitally signed by
NATASHA A. DURKINS
Date: 2023.08.03
14:31:18 -04'00'

Natasha A. Durkins
Vice President, Mission Support Services
Air Traffic Organization

FINAL MONITOR CONTROLLER– Air Traffic Control Specialist assigned to radar monitor the flight path of aircraft during simultaneous parallel (approach courses spaced less than 9000 feet/9200 feet above 5000 feet) and simultaneous close parallel approach operations. Each runway is assigned a final monitor controller during simultaneous parallel and simultaneous close parallel ILS approaches.

FIR–

(See **FLIGHT INFORMATION REGION**.)

FIRST PERSON VIEW– UAS operation in which imagery is transmitted to the UAS pilot by an onboard UA camera.

FIRST TIER CENTER– An ARTCC immediately adjacent to the impacted center.

FIS-B–

(See **FLIGHT INFORMATION SERVICE-BROADCAST**.)

FIX– A geographical position determined by visual reference to the surface, by reference to one or more radio NAVAIDs, by celestial plotting, or by another navigational device.

FIX BALANCING– A process whereby aircraft are evenly distributed over several available arrival fixes reducing delays and controller workload.

FLAG– A warning device incorporated in certain airborne navigation and flight instruments indicating that:

- a. Instruments are inoperative or otherwise not operating satisfactorily, or
- b. Signal strength or quality of the received signal falls below acceptable values.

FLAG ALARM–

(See **FLAG**.)

FLAMEOUT– An emergency condition caused by a loss of engine power.

FLAMEOUT PATTERN– An approach normally conducted by a single-engine military aircraft experiencing loss or anticipating loss of engine power or control. The standard overhead approach starts at a relatively high altitude over a runway (“high key”) followed by a continuous 180 degree turn to a high, wide position (“low key”) followed by a continuous 180 degree turn final. The standard straight-in pattern starts at a point that results in a straight-in approach with a high rate of descent to the runway. Flameout approaches terminate in the type approach requested by the pilot (normally fullstop).

FLIGHT CHECK– A call sign prefix used by FAA aircraft engaged in flight inspection/certification of navigational aids and flight procedures. The word “recorded” may be added as a suffix; e.g., “Flight Check 320 recorded” to indicate that an automated flight inspection is in progress in terminal areas.

(See **FLIGHT INSPECTION**.)

(Refer to AIM.)

FLIGHT DATA [FSS]– The primary task of the FSS flight data position is information management. Flight data services include the development, translation, processing, and coordination of aeronautical, meteorological, and aviation information.

FLIGHT FOLLOWING–

(See **TRAFFIC ADVISORIES**.)

FLIGHT INFORMATION REGION– An airspace of defined dimensions within which Flight Information Service and Alerting Service are provided.

a. **Flight Information Service**. A service provided for the purpose of giving advice and information useful for the safe and efficient conduct of flights.

b. **Alerting Service**. A service provided to notify appropriate organizations regarding aircraft in need of search and rescue aid and to assist such organizations as required.

FLIGHT INFORMATION SERVICE– A service provided for the purpose of giving advice and information useful for the safe and efficient conduct of flights.

FLIGHT INFORMATION SERVICE–BROADCAST (FIS–B)– A ground broadcast service provided through the ADS–B Broadcast Services network over the UAT data link that operates on 978 MHz. The FIS–B system provides pilots and flight crews of properly equipped aircraft with a cockpit display of certain aviation weather and aeronautical information.

FLIGHT INSPECTION– Inflight investigation and evaluation of a navigational aid to determine whether it meets established tolerances.

(See FLIGHT CHECK.)

(See NAVIGATIONAL AID.)

FLIGHT LEVEL– A level of constant atmospheric pressure related to a reference datum of 29.92 inches of mercury. Each is stated in three digits that represent hundreds of feet. For example, flight level (FL) 250 represents a barometric altimeter indication of 25,000 feet; FL 255, an indication of 25,500 feet.

(See ICAO term FLIGHT LEVEL.)

FLIGHT LEVEL [ICAO]– A surface of constant atmospheric pressure which is related to a specific pressure datum, 1013.2 hPa (1013.2 mb), and is separated from other such surfaces by specific pressure intervals.

Note 1: A pressure type altimeter calibrated in accordance with the standard atmosphere:

- a. When set to a QNH altimeter setting, will indicate altitude;
- b. When set to a QFE altimeter setting, will indicate height above the QFE reference datum; and
- c. When set to a pressure of 1013.2 hPa (1013.2 mb), may be used to indicate flight levels.

Note 2: The terms ‘height’ and ‘altitude,’ used in Note 1 above, indicate altimetric rather than geometric heights and altitudes.

FLIGHT LINE– A term used to describe the precise movement of a civil photogrammetric aircraft along a predetermined course(s) at a predetermined altitude during the actual photographic run.

FLIGHT MANAGEMENT SYSTEMS– A computer system that uses a large data base to allow routes to be preprogrammed and fed into the system by means of a data loader. The system is constantly updated with respect to position accuracy by reference to conventional navigation aids. The sophisticated program and its associated data base ensures that the most appropriate aids are automatically selected during the information update cycle.

FLIGHT PATH– A line, course, or track along which an aircraft is flying or intended to be flown.

(See COURSE.)

(See TRACK.)

FLIGHT PLAN– Specified information relating to the intended flight of an aircraft that is filed electronically, orally, or in writing with an FSS, third–party vendor, or an ATC facility.

(See FAST FILE.)

(See FILED.)

(Refer to AIM.)

FLIGHT PLAN AREA (FPA)– The geographical area assigned to a flight service station (FSS) for the purpose of establishing primary responsibility for services that may include search and rescue for VFR aircraft, issuance of NOTAMs, pilot briefings, inflight services, broadcast services, emergency services, flight data processing, international operations, and aviation weather services. Large consolidated FSS facilities may combine FPAs into larger areas of responsibility (AOR).

(See FLIGHT SERVICE STATION.)

(See TIE-IN FACILITY.)

FLIGHT RECORDER– A general term applied to any instrument or device that records information about the performance of an aircraft in flight or about conditions encountered in flight. Flight recorders may make records of airspeed, outside air temperature, vertical acceleration, engine RPM, manifold pressure, and other pertinent variables for a given flight.

(See ICAO term FLIGHT RECORDER.)

FLIGHT RECORDER [ICAO]– Any type of recorder installed in the aircraft for the purpose of complementing accident/incident investigation.

Note: See Annex 6 Part I, for specifications relating to flight recorders.

FLIGHT SERVICE STATION (FSS)– An air traffic facility which provides pilot briefings, flight plan processing, en route flight advisories, search and rescue services, and assistance to lost aircraft and aircraft in emergency situations. FSS also relay ATC clearances, process Notices to Air Missions, and broadcast aviation weather and aeronautical information. In Alaska, FSS provide Airport Advisory Services.

(See FLIGHT PLAN AREA.)

(See TIE-IN FACILITY.)

FLIGHT STANDARDS DISTRICT OFFICE– An FAA field office serving an assigned geographical area and staffed with Flight Standards personnel who serve the aviation industry and the general public on matters relating to the certification and operation of air carrier and general aviation aircraft. Activities include general surveillance of operational safety, certification of airmen and aircraft, accident prevention, investigation, enforcement, etc.

FLIGHT TERMINATION– The intentional and deliberate process of terminating the flight of a UA in the event of an unrecoverable lost link, loss of control, or other failure that compromises the safety of flight.

FLIGHT TEST– A flight for the purpose of:

- a. Investigating the operation/flight characteristics of an aircraft or aircraft component.
- b. Evaluating an applicant for a pilot certificate or rating.

FLIGHT VISIBILITY–

(See VISIBILITY.)

FLIP–

(See DoD FLIP.)

FLY-BY WAYPOINT– A fly-by waypoint requires the use of turn anticipation to avoid overshoot of the next flight segment.

FLY HEADING (DEGREES)– Informs the pilot of the heading he/she should fly. The pilot may have to turn to, or continue on, a specific compass direction in order to comply with the instructions. The pilot is expected to turn in the shorter direction to the heading unless otherwise instructed by ATC.

FLY-OVER WAYPOINT– A fly-over waypoint precludes any turn until the waypoint is overflowed and is followed by an intercept maneuver of the next flight segment.

FLY VISUAL TO AIRPORT–

(See PUBLISHED INSTRUMENT APPROACH PROCEDURE VISUAL SEGMENT.)

FLYAWAY– When the pilot is unable to effect control of the aircraft and, as a result, the UA is not operating in a predictable or planned manner.

FMA–

(See FINAL MONITOR AID.)

FMS–

(See FLIGHT MANAGEMENT SYSTEM.)

FORMATION FLIGHT– More than one aircraft which, by prior arrangement between the pilots, operate as a single aircraft with regard to navigation and position reporting. Separation between aircraft within the formation is the responsibility of the flight leader and the pilots of the other aircraft in the flight. This includes transition periods when aircraft within the formation are maneuvering to attain separation from each other to effect individual control and during join-up and breakaway.

a. A standard formation is one in which a proximity of no more than 1 mile laterally or longitudinally and within 100 feet vertically from the flight leader is maintained by each wingman.

b. Nonstandard formations are those operating under any of the following conditions:

1. When the flight leader has requested and ATC has approved other than standard formation dimensions.
2. When operating within an authorized altitude reservation (ALTRV) or under the provisions of a letter of agreement.

3. When the operations are conducted in airspace specifically designed for a special activity.

(See ALTITUDE RESERVATION.)

(Refer to 14 CFR Part 91.)

FRC-

(See REQUEST FULL ROUTE CLEARANCE.)

FREEZE/FROZEN- Terms used in referring to arrivals which have been assigned ACLTs and to the lists in which they are displayed.

FREEZE HORIZON- The time or point at which an aircraft's STA becomes fixed and no longer fluctuates with each radar update. This setting ensures a constant time for each aircraft, necessary for the metering controller to plan his/her delay technique. This setting can be either in distance from the meter fix or a prescribed flying time to the meter fix.

FREEZE SPEED PARAMETER- A speed adapted for each aircraft to determine fast and slow aircraft. Fast aircraft freeze on parameter FCLT and slow aircraft freeze on parameter MLDI.

FRIA-

(See FAA-RECOGNIZED IDENTIFICATION AREA.)

FRICION MEASUREMENT- A measurement of the friction characteristics of the runway pavement surface using continuous self-watering friction measurement equipment in accordance with the specifications, procedures and schedules contained in AC 150/5320-12, Measurement, Construction, and Maintenance of Skid Resistant Airport Pavement Surfaces.

FSDO-

(See FLIGHT STANDARDS DISTRICT OFFICE.)

FSPD-

(See FREEZE SPEED PARAMETER.)

FSS-

(See FLIGHT SERVICE STATION.)

FUEL DUMPING- Airborne release of usable fuel. This does not include the dropping of fuel tanks.

(See JETTISONING OF EXTERNAL STORES.)

FUEL REMAINING- A phrase used by either pilots or controllers when relating to the fuel remaining on board until actual fuel exhaustion. When transmitting such information in response to either a controller question or pilot initiated cautionary advisory to air traffic control, pilots will state the APPROXIMATE NUMBER OF MINUTES the flight can continue with the fuel remaining. All reserve fuel SHOULD BE INCLUDED in the time stated, as should an allowance for established fuel gauge system error.

FUEL SIPHONING- Unintentional release of fuel caused by overflow, puncture, loose cap, etc.

FUEL VENTING-

(See FUEL SIPHONING.)

FUSED TARGET-

(See DIGITAL TARGET)

FUSION [STARS]- the combination of all available surveillance sources (airport surveillance radar [ASR], air route surveillance radar [ARSR], ADS-B, etc.) into the display of a single tracked target for air traffic control separation services. FUSION is the equivalent of the current single-sensor radar display. FUSION performance

is characteristic of a single-sensor radar display system. Terminal areas use mono-pulse secondary surveillance radar (ASR 9, Mode S or ASR 11, MSSR).

IFWP– Intermediate Fix Waypoint

ILS–

(See INSTRUMENT LANDING SYSTEM.)

ILS CATEGORIES– 1. Category I. An ILS approach procedure which provides for approach to a height above touchdown of not less than 200 feet and with runway visual range of not less than 1,800 feet.– 2. Special Authorization Category I. An ILS approach procedure which provides for approach to a height above touchdown of not less than 150 feet and with runway visual range of not less than 1,400 feet, HUD to DH. 3. Category II. An ILS approach procedure which provides for approach to a height above touchdown of not less than 100 feet and with runway visual range of not less than 1,200 feet (with autoland or HUD to touchdown and noted on authorization, RVR 1,000 feet).– 4. Special Authorization Category II with Reduced Lighting. An ILS approach procedure which provides for approach to a height above touchdown of not less than 100 feet and with runway visual range of not less than 1,200 feet with autoland or HUD to touchdown and noted on authorization (no touchdown zone and centerline lighting are required).– 5. Category III:

a. IIIA.–An ILS approach procedure which provides for approach without a decision height minimum and with runway visual range of not less than 700 feet.

b. IIIB.–An ILS approach procedure which provides for approach without a decision height minimum and with runway visual range of not less than 150 feet.

c. IIIC.–An ILS approach procedure which provides for approach without a decision height minimum and without runway visual range minimum.

IM–

(See INNER MARKER.)

IMC–

(See INSTRUMENT METEOROLOGICAL CONDITIONS.)

IMMEDIATELY– Used by ATC or pilots when such action compliance is required to avoid an imminent situation.

INCERFA (Uncertainty Phase) [ICAO]– A situation wherein uncertainty exists as to the safety of an aircraft and its occupants.

INCREASED SEPARATION REQUIRED (ISR)– Indicates the confidence level of the track requires 5 NM separation. 3 NM separation, 1 ½ NM separation, and target resolution cannot be used.

INCREASE SPEED TO (SPEED)–

(See SPEED ADJUSTMENT.)

INERTIAL NAVIGATION SYSTEM (INS)– An RNAV system which is a form of self-contained navigation.

(See Area Navigation/RNAV.)

INFLIGHT REFUELING–

(See AERIAL REFUELING.)

INFLIGHT SERVICES [FSS]– Services provided to or affecting aircraft inflight or otherwise operating on the airport surface. This includes services to airborne aircraft, such as the delivery of ATC clearances, advisories or requests, issuance of military flight advisory messages, NOTAM delivery, search and rescue communications searches, flight plan handling, transcribed or live broadcasts, weather observations, PIREPs, and pilot briefings.

INFLIGHT WEATHER ADVISORY–

(See WEATHER ADVISORY.)

INFORMATION REQUEST (INREQ)– A request originated by an FSS for information concerning an overdue VFR aircraft.

INITIAL APPROACH FIX (IAF)– The fixes depicted on instrument approach procedure charts that identify the beginning of the initial approach segment(s).

(See FIX.)

(See SEGMENTS OF AN INSTRUMENT APPROACH PROCEDURE.)

INITIAL APPROACH SEGMENT–

(See SEGMENTS OF AN INSTRUMENT APPROACH PROCEDURE.)

INITIAL APPROACH SEGMENT [ICAO]– That segment of an instrument approach procedure between the initial approach fix and the intermediate approach fix or, where applicable, the final approach fix or point.

INLAND NAVIGATION FACILITY– A navigation aid on a North American Route at which the common route and/or the noncommon route begins or ends.

INNER MARKER– A marker beacon used with an ILS (CAT II) precision approach located between the middle marker and the end of the ILS runway, transmitting a radiation pattern keyed at six dots per second and indicating to the pilot, both aurally and visually, that he/she is at the designated decision height (DH), normally 100 feet above the touchdown zone elevation, on the ILS CAT II approach. It also marks progress during a CAT III approach.

(See INSTRUMENT LANDING SYSTEM.)

(Refer to AIM.)

INNER MARKER BEACON–

(See INNER MARKER.)

INREQ–

(See INFORMATION REQUEST.)

INS–

(See INERTIAL NAVIGATION SYSTEM.)

INSTRUMENT APPROACH–

(See INSTRUMENT APPROACH PROCEDURE.)

INSTRUMENT APPROACH OPERATIONS [ICAO]– An approach and landing using instruments for navigation guidance based on an instrument approach procedure. There are two methods for executing instrument approach operations:

- a.** A two-dimensional (2D) instrument approach operation, using lateral navigation guidance only; and
- b.** A three-dimensional (3D) instrument approach operation, using both lateral and vertical navigation guidance.

Note: Lateral and vertical navigation guidance refers to the guidance provided either by:

- a) a ground-based radio navigation aid; or
- b) computer-generated navigation data from ground-based, space-based, self-contained navigation aids or a combination of these.

(See ICAO term INSTRUMENT APPROACH PROCEDURE.)

INSTRUMENT APPROACH PROCEDURE– A series of predetermined maneuvers for the orderly transfer of an aircraft under instrument flight conditions from the beginning of the initial approach to a landing or to a point from which a landing may be made visually. It is prescribed and approved for a specific airport by competent authority.

(See SEGMENTS OF AN INSTRUMENT APPROACH PROCEDURE.)

(Refer to 14 CFR Part 91.)

(Refer to AIM.)

a. U.S. civil standard instrument approach procedures are approved by the FAA as prescribed under 14 CFR Part 97 and are available for public use.

b. U.S. military standard instrument approach procedures are approved and published by the Department of Defense.

c. Special instrument approach procedures are approved by the FAA for individual operators but are not published in 14 CFR Part 97 for public use.

(See ICAO term INSTRUMENT APPROACH PROCEDURE.)

INSTRUMENT APPROACH PROCEDURE [ICAO]– A series of predetermined maneuvers by reference to flight instruments with specified protection from obstacles from the initial approach fix, or where applicable, from the beginning of a defined arrival route to a point from which a landing can be completed and thereafter, if a landing is not completed, to a position at which holding or en route obstacle clearance criteria apply.

(See ICAO term INSTRUMENT APPROACH OPERATIONS)

INSTRUMENT APPROACH PROCEDURE CHARTS–

(See AERONAUTICAL CHART.)

INSTRUMENT DEPARTURE PROCEDURE (DP)– A preplanned instrument flight rule (IFR) departure procedure published for pilot use, in graphic or textual format, that provides obstruction clearance from the terminal area to the appropriate en route structure. There are two types of DP, Obstacle Departure Procedure (ODP), printed either textually or graphically, and, Standard Instrument Departure (SID), which is always printed graphically.

(See IFR TAKEOFF MINIMUMS AND DEPARTURE PROCEDURES.)

(See OBSTACLE DEPARTURE PROCEDURES.)

(See STANDARD INSTRUMENT DEPARTURES.)

(Refer to AIM.)

INSTRUMENT DEPARTURE PROCEDURE (DP) CHARTS–

(See AERONAUTICAL CHART.)

INSTRUMENT FLIGHT RULES (IFR)– Rules governing the procedures for conducting instrument flight. Also a term used by pilots and controllers to indicate type of flight plan.

(See INSTRUMENT METEOROLOGICAL CONDITIONS.)

(See VISUAL FLIGHT RULES.)

(See VISUAL METEOROLOGICAL CONDITIONS.)

(See ICAO term INSTRUMENT FLIGHT RULES.)

(Refer to AIM.)

INSTRUMENT FLIGHT RULES [ICAO]– A set of rules governing the conduct of flight under instrument meteorological conditions.

INSTRUMENT LANDING SYSTEM (ILS)– A precision instrument approach system which normally consists of the following electronic components and visual aids:

a. Localizer.

(See LOCALIZER.)

b. Glideslope.

(See GLIDESLOPE.)

c. Outer Marker.

(See OUTER MARKER.)

d. Middle Marker.

(See MIDDLE MARKER.)

e. Approach Lights.

(See AIRPORT LIGHTING.)

(Refer to 14 CFR Part 91.)

(Refer to AIM.)

INSTRUMENT METEOROLOGICAL CONDITIONS (IMC)– Meteorological conditions expressed in terms of visibility, distance from cloud, and ceiling less than the minima specified for visual meteorological conditions.

(See INSTRUMENT FLIGHT RULES.)

(See VISUAL FLIGHT RULES.)

(See VISUAL METEOROLOGICAL CONDITIONS.)

INSTRUMENT RUNWAY– A runway equipped with electronic and visual navigation aids for which a precision or nonprecision approach procedure having straight-in landing minimums has been approved.

(See ICAO term INSTRUMENT RUNWAY.)

NON-COOPERATIVE SURVEILLANCE– Any surveillance system, such as primary radar, that is not dependent upon the presence of any equipment on the aircraft or vehicle to be tracked.

(See COOPERATIVE SURVEILLANCE.)

(See RADAR.)

NONDIRECTIONAL BEACON– An L/MF or UHF radio beacon transmitting nondirectional signals whereby the pilot of an aircraft equipped with direction finding equipment can determine his/her bearing to or from the radio beacon and “home” on or track to or from the station. When the radio beacon is installed in conjunction with the Instrument Landing System marker, it is normally called a Compass Locator.

(See AUTOMATIC DIRECTION FINDER.)

(See COMPASS LOCATOR.)

NONMOVEMENT AREAS– Taxiways and apron (ramp) areas not under the control of air traffic.

NONPRECISION APPROACH–

(See NONPRECISION APPROACH PROCEDURE.)

NONPRECISION APPROACH PROCEDURE– A standard instrument approach procedure in which no electronic glideslope is provided; e.g., VOR, TACAN, NDB, LOC, ASR, LDA, or SDF approaches.

NONRADAR– Precedes other terms and generally means without the use of radar, such as:

a. Nonradar Approach. Used to describe instrument approaches for which course guidance on final approach is not provided by ground-based precision or surveillance radar. Radar vectors to the final approach course may or may not be provided by ATC. Examples of nonradar approaches are VOR, NDB, TACAN, ILS, RNAV, and GLS approaches.

(See FINAL APPROACH COURSE.)

(See FINAL APPROACH-IFR.)

(See INSTRUMENT APPROACH PROCEDURE.)

(See RADAR APPROACH.)

b. Nonradar Approach Control. An ATC facility providing approach control service without the use of radar.

(See APPROACH CONTROL FACILITY.)

(See APPROACH CONTROL SERVICE.)

c. Nonradar Arrival. An aircraft arriving at an airport without radar service or at an airport served by a radar facility and radar contact has not been established or has been terminated due to a lack of radar service to the airport.

(See RADAR ARRIVAL.)

(See RADAR SERVICE.)

d. Nonradar Route. A flight path or route over which the pilot is performing his/her own navigation. The pilot may be receiving radar separation, radar monitoring, or other ATC services while on a nonradar route.

(See RADAR ROUTE.)

e. Nonradar Separation. The spacing of aircraft in accordance with established minima without the use of radar; e.g., vertical, lateral, or longitudinal separation.

(See RADAR SEPARATION.)

NON-RESTRICTIVE ROUTING (NRR)– Portions of a proposed route of flight where a user can flight plan the most advantageous flight path with no requirement to make reference to ground-based NAVAIDS.

NOPAC–

(See NORTH PACIFIC.)

NORDO (No Radio)– Aircraft that cannot or do not communicate by radio when radio communication is required are referred to as “NORDO.”

(See LOST COMMUNICATIONS.)

NORMAL OPERATING ZONE (NOZ)– The NOZ is the operating zone within which aircraft flight remains during normal independent simultaneous parallel ILS approaches.

NORTH AMERICAN ROUTE– A numerically coded route preplanned over existing airway and route systems to and from specific coastal fixes serving the North Atlantic. North American Routes consist of the following:

- a.** Common Route/Portion. That segment of a North American Route between the inland navigation facility and the coastal fix.
- b.** Noncommon Route/Portion. That segment of a North American Route between the inland navigation facility and a designated North American terminal.
- c.** Inland Navigation Facility. A navigation aid on a North American Route at which the common route and/or the noncommon route begins or ends.
- d.** Coastal Fix. A navigation aid or intersection where an aircraft transitions between the domestic route structure and the oceanic route structure.

NORTH AMERICAN ROUTE PROGRAM (NRP)– The NRP is a set of rules and procedures which are designed to increase the flexibility of user flight planning within published guidelines.

NORTH ATLANTIC HIGH LEVEL AIRSPACE (NAT HLA)– That volume of airspace (as defined in ICAO Document 7030) between FL 285 and FL 420 within the Oceanic Control Areas of Bodo Oceanic, Gander Oceanic, New York Oceanic East, Reykjavik, Santa Maria, and Shanwick, excluding the Shannon and Brest Ocean Transition Areas. ICAO Doc 007 *North Atlantic Operations and Airspace Manual* provides detailed information on related aircraft and operational requirements.

NORTH PACIFIC– An organized route system between the Alaskan west coast and Japan.

NOT STANDARD– Varying from what is expected or published. For use in NOTAMs only.

NOT STD-

(See NOT STANDARD.)

NOTAM–

(See NOTICE TO AIR MISSIONS.)

NOTAM [ICAO]– A notice containing information concerning the establishment, condition or change in any aeronautical facility, service, procedure or hazard, the timely knowledge of which is essential to personnel concerned with flight operations.

- a.** I Distribution– Distribution by means of telecommunication.
- b.** II Distribution– Distribution by means other than telecommunications.

NOTICE TO AIR MISSIONS (NOTAM)– A notice containing information (not known sufficiently in advance to publicize by other means) concerning the establishment, condition, or change in any component (facility, service, or procedure of, or hazard in the National Airspace System) the timely knowledge of which is essential to personnel concerned with flight operations.

a. NOTAM (D)– A NOTAM given (in addition to local dissemination) distant dissemination beyond the area of responsibility of the Flight Service Station. These NOTAMs will be stored and available until canceled.

b. FDC NOTAM– A NOTAM regulatory in nature, transmitted by USNOF and given system wide dissemination.

(See ICAO term NOTAM.)

NRR–

(See NON-RESTRICTIVE ROUTING.)

NRS–

(See NAVIGATION REFERENCE SYSTEM.)

NUMEROUS TARGETS VICINITY (LOCATION)– A traffic advisory issued by ATC to advise pilots that targets on the radar scope are too numerous to issue individually.

(See TRAFFIC ADVISORIES.)

P

P TIME–

(See PROPOSED DEPARTURE TIME.)

P-ACP–

(See PREARRANGED COORDINATION PROCEDURES.)

PAN-PAN– The international radio-telephony urgency signal. When repeated three times, indicates uncertainty or alert followed by the nature of the urgency.

(See MAYDAY.)

(Refer to AIM.)

PAO–

(See PUBLIC AIRCRAFT OPERATION.)

PAR–

(See PRECISION APPROACH RADAR.)

PAR [ICAO]–

(See ICAO Term PRECISION APPROACH RADAR.)

PARALLEL ILS APPROACHES– Approaches to parallel runways by IFR aircraft which, when established inbound toward the airport on the adjacent final approach courses, are radar-separated by at least 2 miles.

(See FINAL APPROACH COURSE.)

(See SIMULTANEOUS ILS APPROACHES.)

PARALLEL OFFSET ROUTE– A parallel track to the left or right of the designated or established airway/route. Normally associated with Area Navigation (RNAV) operations.

(See AREA NAVIGATION.)

PARALLEL RUNWAYS– Two or more runways at the same airport whose centerlines are parallel. In addition to runway number, parallel runways are designated as L (left) and R (right) or, if three parallel runways exist, L (left), C (center), and R (right).

PBCT–

(See PROPOSED BOUNDARY CROSSING TIME.)

PBN–

(See ICAO Term PERFORMANCE-BASED NAVIGATION.)

PDC–

(See PRE-DEPARTURE CLEARANCE.)

PDRR–

(See PRE-DEPARTURE REROUTE.)

PERFORMANCE-BASED NAVIGATION (PBN) [ICAO]– Area navigation based on performance requirements for aircraft operating along an ATS route, on an instrument approach procedure or in a designated airspace.

Note: Performance requirements are expressed in navigation specifications (RNAV specification, RNP specification) in terms of accuracy, integrity, continuity, availability, and functionality needed for the proposed operation in the context of a particular airspace concept.

PERMANENT ECHO– Radar signals reflected from fixed objects on the earth's surface; e.g., buildings, towers, terrain. Permanent echoes are distinguished from "ground clutter" by being definable locations rather than large areas. Under certain conditions they may be used to check radar alignment.

PERTI–

(See PLAN, EXECUTE, REVIEW, TRAIN, IMPROVE.)

PGUI–

(See PLANVIEW GRAPHICAL USER INTERFACE.)

PHOTO RECONNAISSANCE– Military activity that requires locating individual photo targets and navigating to the targets at a preplanned angle and altitude. The activity normally requires a lateral route width of 16 NM and altitude range of 1,500 feet to 10,000 feet AGL.

PILOT BRIEFING– The gathering, translation, interpretation, and summarization of weather and aeronautical information into a form usable by the pilot or flight supervisory personnel to assist in flight planning and decision-making for the safe and efficient operation of aircraft. These briefings may include, but are not limited to, weather observations, forecasts, and aeronautical information (for example, NOTAMs, military activities, flow control information, and temporary flight restrictions [TFR]).

(Refer to AIM.)

PILOT IN COMMAND– The pilot responsible for the operation and safety of an aircraft during flight time.

(Refer to 14 CFR Part 91.)

PILOT WEATHER REPORT– A report of meteorological phenomena encountered by aircraft in flight.

(Refer to AIM.)

PILOT'S DISCRETION– When used in conjunction with altitude assignments, means that ATC has offered the pilot the option of starting climb or descent whenever he/she wishes and conducting the climb or descent at any rate he/she wishes. He/she may temporarily level off at any intermediate altitude. However, once he/she has vacated an altitude, he/she may not return to that altitude.

PIREP–

(See PILOT WEATHER REPORT.)

PITCH POINT– A fix/waypoint that serves as a transition point from a departure procedure or the low altitude ground-based navigation structure into the high altitude waypoint system.

PLAN, EXECUTE, REVIEW, TRAIN, IMPROVE (PERTI)– A process that delivers a one-day detailed plan for NAS operations, and a two-day outlook, which sets NAS performance goals for high impact constraints. **PLAN:** Increase lead time for identifying aviation system constraint planning and goals while utilizing historical NAS performance data and constraints to derive successful and/or improved advance planning strategies. **EXECUTE:** Set goals and a strategy. The Air Traffic Control System Command Center (ATCSCC), FAA field facilities, and aviation stakeholders execute the strategy and work to achieve the desired/planned outcomes. **REVIEW:** Utilize post event analysis and lessons learned to define and implement future strategies and operational triggers based on past performance and outcomes, both positive and negative. **TRAIN:** Develop training that includes rapid and continuous feedback to operational personnel and provides increased data and weather knowledge and tools for analytical usage and planning. **IMPROVE:** Implement better information sharing processes, technologies, and procedures that improve the skills and technology needed to implement operational insights and improvements.

PLANS DISPLAY– A display available in EDST that provides detailed flight plan and predicted conflict information in textual format for requested Current Plans and all Trial Plans.

(See EN ROUTE DECISION SUPPORT TOOL)

PLANVIEW GRAPHICAL USER INTERFACE (PGUI)– A TBFM display that provides a spatial display of individual aircraft track information.

POFZ–

(See PRECISION OBSTACLE FREE ZONE.)

POINT OUT–

(See RADAR POINT OUT.)

POINT-TO-POINT (PTP)– A level of NRR service for aircraft that is based on traditional waypoints in their FMSs or RNAV equipage.

POLAR TRACK STRUCTURE– A system of organized routes between Iceland and Alaska which overlie Canadian MNPS Airspace.

POSITION REPORT– A report over a known location as transmitted by an aircraft to ATC.

(Refer to AIM.)

POSITION SYMBOL– A computer-generated indication shown on a radar display to indicate the mode of tracking.

POSITIVE CONTROL– The separation of all air traffic within designated airspace by air traffic control.

PRACTICE INSTRUMENT APPROACH– An instrument approach procedure conducted by a VFR or an IFR aircraft for the purpose of pilot training or proficiency demonstrations.

PRE-DEPARTURE CLEARANCE– An application with the Terminal Data Link System (TDLS) that provides clearance information to subscribers, through a service provider, in text to the cockpit or gate printer.

PRE-DEPARTURE REROUTE (PDRR)– A capability within the Traffic Flow Management System that enables ATC to quickly amend and execute revised departure clearances that mitigate en route constraints or balance en route traffic flows.

PREARRANGED COORDINATION– A standardized procedure which permits an air traffic controller to enter the airspace assigned to another air traffic controller without verbal coordination. The procedures are defined in a facility directive which ensures approved separation between aircraft.

PREARRANGED COORDINATION PROCEDURES– A facility’s standardized procedure that describes the process by which one controller shall allow an aircraft to penetrate or transit another controller’s airspace in a manner that assures approved separation without individual coordination for each aircraft.

PRECIPITATION– Any or all forms of water particles (rain, sleet, hail, or snow) that fall from the atmosphere and reach the surface.

PRECIPITATION RADAR WEATHER DESCRIPTIONS– Existing radar systems cannot detect turbulence. However, there is a direct correlation between the degree of turbulence and other weather features associated with thunderstorms and the weather radar precipitation intensity. Controllers will issue (where capable) precipitation intensity as observed by radar when using weather and radar processor (WARP) or NAS ground-based digital radars with weather capabilities. When precipitation intensity information is not available, the intensity will be described as UNKNOWN. When intensity levels can be determined, they shall be described as:

- a. LIGHT (< 26 dBZ)
- b. MODERATE (26 to 40 dBZ)
- c. HEAVY (> 40 to 50 dBZ)
- d. EXTREME (> 50 dBZ)

(Refer to AC 00-45, Aviation Weather Services.)

PRECISION APPROACH–

(See PRECISION APPROACH PROCEDURE.)

PRECISION APPROACH PROCEDURE– A standard instrument approach procedure in which an electronic glideslope or other type of glidepath is provided; e.g., ILS, PAR, and GLS.

(See INSTRUMENT LANDING SYSTEM.)

(See PRECISION APPROACH RADAR.)

PRECISION APPROACH RADAR– Radar equipment in some ATC facilities operated by the FAA and/or the military services at joint-use civil/military locations and separate military installations to detect and display azimuth, elevation, and range of aircraft on the final approach course to a runway. This equipment may be used

to monitor certain non-radar approaches, but is primarily used to conduct a precision instrument approach (PAR) wherein the controller issues guidance instructions to the pilot based on the aircraft's position in relation to the final approach course (azimuth), the glidepath (elevation), and the distance (range) from the touchdown point on the runway as displayed on the radar scope.

(See GLIDEPATH.)

(See PAR.)

(See ICAO term PRECISION APPROACH RADAR.)

(Refer to AIM.)

PRECISION APPROACH RADAR [ICAO]– Primary radar equipment used to determine the position of an aircraft during final approach, in terms of lateral and vertical deviations relative to a nominal approach path, and in range relative to touchdown.

PRECISION OBSTACLE FREE ZONE (POFZ)– An 800 foot wide by 200 foot long area centered on the runway centerline adjacent to the threshold designed to protect aircraft flying precision approaches from ground vehicles and other aircraft when ceiling is less than 250 feet or visibility is less than 3/4 statute mile (or runway visual range below 4,000 feet.)

PRECISION RUNWAY MONITOR (PRM) SYSTEM– Provides air traffic controllers monitoring the NTZ during simultaneous close parallel PRM approaches with precision, high update rate secondary surveillance data. The high update rate surveillance sensor component of the PRM system is only required for specific runway or approach course separation. The high resolution color monitoring display, Final Monitor Aid (FMA) of the PRM system, or other FMA with the same capability, presents NTZ surveillance track data to controllers along with detailed maps depicting approaches and no transgression zone and is required for all simultaneous close parallel PRM NTZ monitoring operations.

(Refer to AIM)

PREDICTIVE WIND SHEAR ALERT SYSTEM (PWS)– A self-contained system used on board some aircraft to alert the flight crew to the presence of a potential wind shear. PWS systems typically monitor 3 miles ahead and 25 degrees left and right of the aircraft's heading at or below 1200' AGL. Departing flights may receive a wind shear alert after they start the takeoff roll and may elect to abort the takeoff. Aircraft on approach receiving an alert may elect to go around or perform a wind shear escape maneuver.

PREFERRED IFR ROUTES– Routes established between busier airports to increase system efficiency and capacity. They normally extend through one or more ARTCC areas and are designed to achieve balanced traffic flows among high density terminals. IFR clearances are issued on the basis of these routes except when severe weather avoidance procedures or other factors dictate otherwise. Preferred IFR Routes are listed in the Chart Supplement U.S., and are also available at https://www.fly.faa.gov/rmt/nfdc_preferred_routes_database.jsp. If a flight is planned to or from an area having such routes but the departure or arrival point is not listed in the Chart Supplement U.S., pilots may use that part of a Preferred IFR Route which is appropriate for the departure or arrival point that is listed. Preferred IFR Routes may be defined by DPs, SIDs, or STARs; NAVAIDs, Waypoints, etc.; high or low altitude airways; or any combinations thereof. Because they often share elements with adapted routes, pilots' use of preferred IFR routes can minimize flight plan route amendments.

(See ADAPTED ROUTES.)

(See CENTER'S AREA.)

(See INSTRUMENT APPROACH PROCEDURE.)

(See INSTRUMENT DEPARTURE PROCEDURE.)

(See STANDARD TERMINAL ARRIVAL.)

(Refer to CHART SUPPLEMENT U.S.)

PRE-FLIGHT PILOT BRIEFING–

(See PILOT BRIEFING.)

PREVAILING VISIBILITY–

(See VISIBILITY.)

PRIMARY RADAR TARGET– An analog or digital target, exclusive of a secondary radar target, presented on a radar display.

PRM–

(See AREA NAVIGATION (RNAV) GLOBAL POSITIONING SYSTEM (GPS) PRECISION RUNWAY MONITORING (PRM) APPROACH.)

(See PRM APPROACH.)

(See PRECISION RUNWAY MONITOR SYSTEM.)

PRM APPROACH– An instrument approach procedure titled ILS PRM, RNAV PRM, LDA PRM, or GLS PRM conducted to parallel runways separated by less than 4,300 feet and at least 3,000 feet where independent closely spaced approaches are permitted. Use of an enhanced display with alerting, a No Transgression Zone (NTZ), secondary monitor frequency, pilot PRM training, and publication of an Attention All Users Page are required for all PRM approaches. Depending on the runway spacing, the approach courses may be parallel or one approach course must be offset. PRM procedures are also used to conduct Simultaneous Offset Instrument Approach (SOIA) operations. In SOIA, one straight-in ILS PRM, RNAV PRM, GLS PRM, and one offset LDA PRM, RNAV PRM or GLS PRM approach are utilized. PRM procedures are terminated and a visual segment begins at the offset approach missed approach point where the minimum distance between the approach courses is 3000 feet. Runway spacing can be as close as 750 feet.

(Refer to AIM.)

PROCEDURAL CONTROL [ICAO]– Term used to indicate that information derived from an ATS surveillance system is not required for the provision of air traffic control service.

PROCEDURAL SEPARATION [ICAO]– The separation used when providing procedural control.

PROCEDURE TURN– The maneuver prescribed when it is necessary to reverse direction to establish an aircraft on the intermediate approach segment or final approach course. The outbound course, direction of turn, distance within which the turn must be completed, and minimum altitude are specified in the procedure. However, unless otherwise restricted, the point at which the turn may be commenced and the type and rate of turn are left to the discretion of the pilot.

(See ICAO term PROCEDURE TURN.)

PROCEDURE TURN [ICAO]– A maneuver in which a turn is made away from a designated track followed by a turn in the opposite direction to permit the aircraft to intercept and proceed along the reciprocal of the designated track.

Note 1: Procedure turns are designated “left” or “right” according to the direction of the initial turn.

Note 2: Procedure turns may be designated as being made either in level flight or while descending, according to the circumstances of each individual approach procedure.

PROCEDURE TURN INBOUND– That point of a procedure turn maneuver where course reversal has been completed and an aircraft is established inbound on the intermediate approach segment or final approach course. A report of “procedure turn inbound” is normally used by ATC as a position report for separation purposes.

(See FINAL APPROACH COURSE.)

(See PROCEDURE TURN.)

(See SEGMENTS OF AN INSTRUMENT APPROACH PROCEDURE.)

PROFILE DESCENT– An uninterrupted descent (except where level flight is required for speed adjustment; e.g., 250 knots at 10,000 feet MSL) from cruising altitude/level to interception of a glideslope or to a minimum altitude specified for the initial or intermediate approach segment of a nonprecision instrument approach. The profile descent normally terminates at the approach gate or where the glideslope or other appropriate minimum altitude is intercepted.

PROGRESS REPORT–

(See POSITION REPORT.)

PROGRESSIVE TAXI– Precise taxi instructions given to a pilot unfamiliar with the airport or issued in stages as the aircraft proceeds along the taxi route.

PROHIBITED AREA–

(See SPECIAL USE AIRSPACE.)

(See ICAO term PROHIBITED AREA.)

PROHIBITED AREA [ICAO]– An airspace of defined dimensions, above the land areas or territorial waters of a State, within which the flight of aircraft is prohibited.

PROMINENT OBSTACLE– An obstacle that meets one or more of the following conditions:

a. An obstacle which stands out beyond the adjacent surface of surrounding terrain and immediately projects a noticeable hazard to aircraft in flight.

b. An obstacle, not characterized as low and close in, whose height is no less than 300 feet above the departure end of takeoff runway (DER) elevation, is within 10 NM from the DER, and that penetrates that airport/heliport's diverse departure obstacle clearance surface (OCS).

c. An obstacle beyond 10 NM from an airport/heliport that requires an obstacle departure procedure (ODP) to ensure obstacle avoidance.

(See OBSTACLE.)

(See OBSTRUCTION.)

PROPELLER (PROP) WASH (PROP BLAST)– The disturbed mass of air generated by the motion of a propeller.

PROPOSED BOUNDARY CROSSING TIME– Each center has a PBCT parameter for each internal airport. Proposed internal flight plans are transmitted to the adjacent center if the flight time along the proposed route from the departure airport to the center boundary is less than or equal to the value of PBCT or if airport adaptation specifies transmission regardless of PBCT.

PROPOSED DEPARTURE TIME– The time that the aircraft expects to become airborne.

PROTECTED AIRSPACE– The airspace on either side of an oceanic route/track that is equal to one-half the lateral separation minimum except where reduction of protected airspace has been authorized.

PROTECTED SEGMENT– The protected segment is a segment on the amended TFM route that is to be inhibited from automatic adapted route alteration by ERAM.

PT–

(See PROCEDURE TURN.)

PTP–

(See POINT-TO-POINT.)

PTS–

(See POLAR TRACK STRUCTURE.)

PUBLIC AIRCRAFT OPERATION (PAO)– A UAS operation meeting the qualifications and conditions required for the operation of a public aircraft.

(See AC-1.1)

(See AIM)

PUBLISHED INSTRUMENT APPROACH PROCEDURE VISUAL SEGMENT– A segment on an IAP chart annotated as "Fly Visual to Airport" or "Fly Visual." A dashed arrow will indicate the visual flight path on the profile and plan view with an associated note on the approximate heading and distance. The visual segment should be flown as a dead reckoning course while maintaining visual conditions.

PUBLISHED ROUTE– A route for which an IFR altitude has been established and published; e.g., Federal Airways, Jet Routes, Area Navigation Routes, Specified Direct Routes.

PWS–

(See PREDICTIVE WIND SHEAR ALERT SYSTEM.)

S

SAA–

(See SENSE AND AVOID.)

SAA–

(See SPECIAL ACTIVITY AIRSPACE.)

SAFETY ALERT– A safety alert issued by ATC to aircraft under their control if ATC is aware the aircraft is at an altitude which, in the controller’s judgment, places the aircraft in unsafe proximity to terrain, obstructions, or other aircraft. The controller may discontinue the issuance of further alerts if the pilot advises he/she is taking action to correct the situation or has the other aircraft in sight.

a. Terrain/Obstruction Alert– A safety alert issued by ATC to aircraft under their control if ATC is aware the aircraft is at an altitude which, in the controller’s judgment, places the aircraft in unsafe proximity to terrain/obstructions; e.g., “Low Altitude Alert, check your altitude immediately.”

b. Aircraft Conflict Alert– A safety alert issued by ATC to aircraft under their control if ATC is aware of an aircraft that is not under their control at an altitude which, in the controller’s judgment, places both aircraft in unsafe proximity to each other. With the alert, ATC will offer the pilot an alternate course of action when feasible; e.g., “Traffic Alert, advise you turn right heading zero niner zero or climb to eight thousand immediately.”

Note: The issuance of a safety alert is contingent upon the capability of the controller to have an awareness of an unsafe condition. The course of action provided will be predicated on other traffic under ATC control.

Once the alert is issued, it is solely the pilot’s prerogative to determine what course of action, if any, he/she will take.

SAFETY LOGIC SYSTEM– A software enhancement to ASDE–3, ASDE–X, and ASSC, that predicts the path of aircraft landing and/or departing, and/or vehicular movements on runways. Visual and aural alarms are activated when the safety logic projects a potential collision. The Airport Movement Area Safety System (AMASS) is a safety logic system enhancement to the ASDE–3. The Safety Logic System for ASDE–X and ASSC is an integral part of the software program.

SAFETY LOGIC SYSTEM ALERTS–

a. ALERT– An actual situation involving two real safety logic tracks (aircraft/aircraft, aircraft/vehicle, or aircraft/other tangible object) that safety logic has predicted will result in an imminent collision, based upon the current set of Safety Logic parameters.

b. FALSE ALERT–

1. Alerts generated by one or more false surface–radar targets that the system has interpreted as real tracks and placed into safety logic.

2. Alerts in which the safety logic software did not perform correctly, based upon the design specifications and the current set of Safety Logic parameters.

3. The alert is generated by surface radar targets caused by moderate or greater precipitation.

c. NUISANCE ALERT– An alert in which one or more of the following is true:

1. The alert is generated by a known situation that is not considered an unsafe operation, such as LAHSO or other approved operations.

2. The alert is generated by inaccurate secondary radar data received by the Safety Logic System.

3. One or more of the aircraft involved in the alert is not intending to use a runway (for example, helicopter, pipeline patrol, non–Mode C overflight, etc.).

d. VALID NON–ALERT– A situation in which the safety logic software correctly determines that an alert is not required, based upon the design specifications and the current set of Safety Logic parameters.

e. INVALID NON–ALERT– A situation in which the safety logic software did not issue an alert when an alert was required, based upon the design specifications.

SAIL BACK– A maneuver during high wind conditions (usually with power off) where float plane movement is controlled by water rudders/opening and closing cabin doors.

SAME DIRECTION AIRCRAFT– Aircraft are operating in the same direction when:

- a. They are following the same track in the same direction; or
- b. Their tracks are parallel and the aircraft are flying in the same direction; or
- c. Their tracks intersect at an angle of less than 45 degrees.

SAR–

(See **SEARCH AND RESCUE**.)

SATELLITE-BASED AUGMENTATION SYSTEM (SBAS) – A wide coverage augmentation system in which the user receives augmentation information from a satellite-based transmitter.

(See **WIDE-AREA AUGMENTATION SYSTEM (WAAS)**.)

SAW–

(See **AVIATION WATCH NOTIFICATION MESSAGE**.)

SAY AGAIN– Used to request a repeat of the last transmission. Usually specifies transmission or portion thereof not understood or received; e.g., “Say again all after **ABRAM VOR**.”

SAY ALTITUDE– Used by ATC to ascertain an aircraft’s specific altitude/flight level. When the aircraft is climbing or descending, the pilot should state the indicated altitude rounded to the nearest 100 feet.

SAY HEADING– Used by ATC to request an aircraft heading. The pilot should state the actual heading of the aircraft.

SCHEDULED TIME OF ARRIVAL (STA)– A STA is the desired time that an aircraft should cross a certain point (landing or metering fix). It takes other traffic and airspace configuration into account. A STA time shows the results of the TBFM scheduler that has calculated an arrival time according to parameters such as optimized spacing, aircraft performance, and weather.

SDF–

(See **SIMPLIFIED DIRECTIONAL FACILITY**.)

SE SAR–

(See **SURVEILLANCE ENHANCED SEARCH AND RESCUE**.)

SEA LANE– A designated portion of water outlined by visual surface markers for and intended to be used by aircraft designed to operate on water.

SEARCH AND RESCUE– A service which seeks missing aircraft and assists those found to be in need of assistance. It is a cooperative effort using the facilities and services of available Federal, state and local agencies. The U.S. Coast Guard is responsible for coordination of search and rescue for the Maritime Region, and the U.S. Air Force is responsible for search and rescue for the Inland Region. Information pertinent to search and rescue should be passed through any air traffic facility or be transmitted directly to the Rescue Coordination Center by telephone.

(See **FLIGHT SERVICE STATION**.)

(See **RESCUE COORDINATION CENTER**.)

(Refer to **AIM**.)

SEARCH AND RESCUE FACILITY– A facility responsible for maintaining and operating a search and rescue (SAR) service to render aid to persons and property in distress. It is any SAR unit, station, NET, or other operational activity which can be usefully employed during an SAR Mission; e.g., a Civil Air Patrol Wing, or a Coast Guard Station.

(See **SEARCH AND RESCUE**.)

SECNOT–

(See **SECURITY NOTICE**.)

SECONDARY RADAR TARGET– A target derived from a transponder return presented on a radar display.

SECTIONAL AERONAUTICAL CHARTS–

(See AERONAUTICAL CHART.)

SECTOR LIST DROP INTERVAL– A parameter number of minutes after the meter fix time when arrival aircraft will be deleted from the arrival sector list.

SECURITY NOTICE (SECNOT) – A SECNOT is a request originated by the Air Traffic Security Coordinator (ATSC) for an extensive communications search for aircraft involved, or suspected of being involved, in a security violation, or are considered a security risk. A SECNOT will include the aircraft identification, search area, and expiration time. The search area, as defined by the ATSC, could be a single airport, multiple airports, a radius of an airport or fix, or a route of flight. Once the expiration time has been reached, the SECNOT is considered to be canceled.

SECURITY SERVICES AIRSPACE – Areas established through the regulatory process or by NOTAM, issued by the Administrator under title 14, CFR, sections 99.7, 91.141, and 91.139, which specify that ATC security services are required; i.e., ADIZ or temporary flight rules areas.

SEE AND AVOID– When weather conditions permit, pilots operating IFR or VFR are required to observe and maneuver to avoid other aircraft. Right-of-way rules are contained in 14 CFR Part 91.

SEGMENTED CIRCLE– A system of visual indicators designed to provide traffic pattern information at airports without operating control towers.

(Refer to AIM.)

SEGMENTS OF A SID/STAR–

a. En Route Transition– The segment(s) of a SID/STAR that connect to/from en route flight. Not all SIDs/STARs will contain an en route transition.

b. En Route Transition Waypoint– The NAVAID/fix/waypoint that defines the beginning of the SID/STAR en route transition.

c. Common Route– The segment(s) of a SID/STAR procedure that provides a single route serving an airport/runway or multiple airports/runways. The common route may consist of a single point. Not all conventional SIDs will contain a common route.

d. Runway Transition– The segment(s) of a SID/STAR between the common route/point and the runway(s). Not all SIDs/STARs will contain a runway transition.

e. Runway Transition Waypoint (RTW)– On a STAR, the NAVAID/fix/waypoint that defines the end of the common route or en route transition and the beginning of a runway transition (In the arrival route description found on the STAR chart, the last fix of the common route and the first fix of the runway transition(s)).

SEGMENTS OF AN INSTRUMENT APPROACH PROCEDURE– An instrument approach procedure may have as many as four separate segments depending on how the approach procedure is structured.

a. Initial Approach– The segment between the initial approach fix and the intermediate fix or the point where the aircraft is established on the intermediate course or final approach course.

(See ICAO term INITIAL APPROACH SEGMENT.)

b. Intermediate Approach– The segment between the intermediate fix or point and the final approach fix.

(See ICAO term INTERMEDIATE APPROACH SEGMENT.)

c. Final Approach– The segment between the final approach fix or point and the runway, airport, or missed approach point.

(See ICAO term FINAL APPROACH SEGMENT.)

d. Missed Approach– The segment between the missed approach point or the point of arrival at decision height and the missed approach fix at the prescribed altitude.

(Refer to 14 CFR Part 97.)

(See ICAO term MISSED APPROACH PROCEDURE.)

SELF-BRIEFING– A self-briefing is a review, using automated tools, of all meteorological and aeronautical information that may influence the pilot in planning, altering, or canceling a proposed route of flight.

SENSE AND AVOID (SAA) – The capability of an unmanned aircraft to detect (sense) and avoid collisions with other aircraft and all obstacles, whether airborne or on the ground while operating in the NAS.

SEPARATION– In air traffic control, the spacing of aircraft to achieve their safe and orderly movement in flight and while landing and taking off.

(See SEPARATION MINIMA.)

(See ICAO term SEPARATION.)

SEPARATION [ICAO]– Spacing between aircraft, levels or tracks.

SEPARATION MINIMA– The minimum longitudinal, lateral, or vertical distances by which aircraft are spaced through the application of air traffic control procedures.

(See SEPARATION.)

SERVICE– A generic term that designates functions or assistance available from or rendered by air traffic control. For example, Class C service would denote the ATC services provided within a Class C airspace area.

SEVERE WEATHER AVOIDANCE PLAN (SWAP)– An approved plan to minimize the affect of severe weather on traffic flows in impacted terminal and/or ARTCC areas. A SWAP is normally implemented to provide the least disruption to the ATC system when flight through portions of airspace is difficult or impossible due to severe weather.

SEVERE WEATHER FORECAST ALERTS– Preliminary messages issued in order to alert users that a Severe Weather Watch Bulletin (WW) is being issued. These messages define areas of possible severe thunderstorms or tornado activity. The messages are unscheduled and issued as required by the Storm Prediction Center (SPC) at Norman, Oklahoma.

(See AIRMET.)

(See CONVECTIVE SIGMET.)

(See CWA.)

(See GRAPHICAL AIRMEN'S METEOROLOGICAL INFORMATION.)

(See SIGMET.)

SFA–

(See SINGLE FREQUENCY APPROACH.)

SFO–

(See SIMULATED FLAMEOUT.)

SFI

(See SPECIAL GOVERNMENT INTEREST.)

SHF–

(See SUPER HIGH FREQUENCY.)

SHORT RANGE CLEARANCE– A clearance issued to a departing IFR flight which authorizes IFR flight to a specific fix short of the destination while air traffic control facilities are coordinating and obtaining the complete clearance.

SHORT TAKEOFF AND LANDING AIRCRAFT (STOL)– An aircraft which, at some weight within its approved operating weight, is capable of operating from a runway in compliance with the applicable STOL characteristics, airworthiness, operations, noise, and pollution standards.

(See VERTICAL TAKEOFF AND LANDING AIRCRAFT.)

SIAP–

(See STANDARD INSTRUMENT APPROACH PROCEDURE.)

SID–

(See STANDARD INSTRUMENT DEPARTURE.)

SIDESTEP MANEUVER– A visual maneuver accomplished by a pilot at the completion of an instrument approach to permit a straight-in landing on a parallel runway not more than 1,200 feet to either side of the runway to which the instrument approach was conducted.

(Refer to AIM.)

SIGMET– A weather advisory issued concerning weather significant to the safety of all aircraft. SIGMET advisories cover severe and extreme turbulence, severe icing, and widespread dust or sandstorms that reduce visibility to less than 3 miles.

(See AIRMET.)

(See CONVECTIVE SIGMET.)

(See CWA.)

(See GRAPHICAL ARMEN'S METEOROLOGICAL INFORMATION.)

(See ICAO term SIGMET INFORMATION.)

(See SAW.)

(Refer to AIM.)

SIGMET INFORMATION [ICAO]– Information issued by a meteorological watch office concerning the occurrence or expected occurrence of specified en-route weather phenomena which may affect the safety of aircraft operations.

SIGNIFICANT METEOROLOGICAL INFORMATION–

(See SIGMET.)

SIGNIFICANT POINT– A point, whether a named intersection, a NAVAID, a fix derived from a NAVAID(s), or geographical coordinate expressed in degrees of latitude and longitude, which is established for the purpose of providing separation, as a reporting point, or to delineate a route of flight.

SIMPLIFIED DIRECTIONAL FACILITY (SDF)– A NAVAID used for nonprecision instrument approaches. The final approach course is similar to that of an ILS localizer except that the SDF course may be offset from the runway, generally not more than 3 degrees, and the course may be wider than the localizer, resulting in a lower degree of accuracy.

(Refer to AIM.)

SIMULATED FLAMEOUT– A practice approach by a jet aircraft (normally military) at idle thrust to a runway. The approach may start at a runway (high key) and may continue on a relatively high and wide downwind leg with a continuous turn to final. It terminates in landing or low approach. The purpose of this approach is to simulate a flameout.

(See FLAMEOUT.)

SIMULTANEOUS CLOSE PARALLEL APPROACHES– A simultaneous, independent approach operation permitting ILS/RNAV/GLS approaches to airports having parallel runways separated by at least 3,000 feet and less than 4,300–feet between centerlines. Aircraft are permitted to pass each other during these simultaneous operations. Integral parts of a total system are radar, NTZ monitoring with enhanced FMA color displays that include aural and visual alerts and predictive aircraft position software, communications override, ATC procedures, an Attention All Users Page (AAUP), PRM in the approach name, and appropriate ground based and airborne equipment. High update rate surveillance sensor required for certain runway or approach course separations.

SIMULTANEOUS (CONVERGING) DEPENDENT APPROACHES- An approach operation permitting ILS/RNAV/GLS approaches to runways or missed approach courses that intersect where required minimum spacing between the aircraft on each final approach course is required.

SIMULTANEOUS (CONVERGING) INDEPENDENT APPROACHES- An approach operation permitting ILS/RNAV/GLS approaches to non-parallel runways where approach procedure design maintains the required aircraft spacing throughout the approach and missed approach and hence the operations may be conducted independently.

SIMULTANEOUS ILS APPROACHES– An approach system permitting simultaneous ILS approaches to airports having parallel runways separated by at least 4,300 feet between centerlines. Integral parts of a total system are ILS, radar, communications, ATC procedures, and appropriate airborne equipment.

(See PARALLEL RUNWAYS.)

(Refer to AIM.)

SIMULTANEOUS OFFSET INSTRUMENT APPROACH (SOIA)– An instrument landing system comprised of an ILS PRM, RNAV PRM or GLS PRM approach to one runway and an offset LDA PRM with glideslope or an RNAV PRM or GLS PRM approach utilizing vertical guidance to another where parallel runway spaced less than 3,000 feet and at least 750 feet apart. The approach courses converge by 2.5 to 3 degrees. Simultaneous close parallel PRM approach procedures apply up to the point where the approach course separation becomes 3,000 feet, at the offset MAP. From the offset MAP to the runway threshold, visual separation by the aircraft conducting the offset approach is utilized.

(Refer to AIM)

SIMULTANEOUS (PARALLEL) DEPENDENT APPROACHES- An approach operation permitting ILS/RNAV/GLS approaches to adjacent parallel runways where prescribed diagonal spacing must be maintained. Aircraft are not permitted to pass each other during simultaneous dependent operations. Integral parts of a total system ATC procedures, and appropriate airborne and ground based equipment.

SINGLE DIRECTION ROUTES– Preferred IFR Routes which are sometimes depicted on high altitude en route charts and which are normally flown in one direction only.

(See PREFERRED IFR ROUTES.)

(Refer to CHART SUPPLEMENT U.S.)

SINGLE FREQUENCY APPROACH– A service provided under a letter of agreement to military single-piloted turbojet aircraft which permits use of a single UHF frequency during approach for landing. Pilots will not normally be required to change frequency from the beginning of the approach to touchdown except that pilots conducting an en route descent are required to change frequency when control is transferred from the air route traffic control center to the terminal facility. The abbreviation “SFA” in the DoD FLIP IFR Supplement under “Communications” indicates this service is available at an aerodrome.

SINGLE-PILOTED AIRCRAFT– A military turbojet aircraft possessing one set of flight controls, tandem cockpits, or two sets of flight controls but operated by one pilot is considered single-piloted by ATC when determining the appropriate air traffic service to be applied.

(See SINGLE FREQUENCY APPROACH.)

SKYSPOTTER– A pilot who has received specialized training in observing and reporting inflight weather phenomena.

SLASH– A radar beacon reply displayed as an elongated target.

SLDI–

(See SECTOR LIST DROP INTERVAL.)

SLOW TAXI– To taxi a float plane at low power or low RPM.

SMALL UNMANNED AIRCRAFT SYSTEM (sUAS)– An unmanned aircraft weighing less than 55 pounds on takeoff, including everything that is on board or otherwise attached to the aircraft.

SN–

(See SYSTEM STRATEGIC NAVIGATION.)

SPACE-BASED ADS-B (SBA)– A constellation of satellites that receives ADS-B Out broadcasts and relays that information to the appropriate surveillance facility. The currently deployed SBA system is only capable of receiving broadcasts from 1090ES-equipped aircraft, and not from those equipped with only a universal access transceiver (UAT). Also, aircraft with a top-of-fuselage-mounted transponder antenna (required for TCAS II installations) will be better received by SBA, especially at latitudes below 45 degrees.

(See AUTOMATIC DEPENDENT SURVEILLANCE-BROADCAST.)

(See AUTOMATIC DEPENDENT SURVEILLANCE-BROADCAST OUT.)

SPACE LAUNCH AND REENTRY AREA– Locations where commercial space launch and/or reentry operations occur. For pilot awareness, a rocket-shaped symbol is used to depict space launch and reentry areas on sectional aeronautical charts.

SPEAK SLOWER– Used in verbal communications as a request to reduce speech rate.

SPECIAL GOVERNMENT INTEREST (SGI)– A near real-time airspace authorization for Part 91 or Part 107 UAS, which supports activities that answer significant and urgent governmental interests. These include: national defense, homeland security, law enforcement, and emergency operations objectives.

SPECIAL ACTIVITY AIRSPACE (SAA)– Airspace with defined dimensions within the National Airspace System wherein limitations may be imposed upon operations for national defense, homeland security, public interest, or public safety. Special activity airspace includes but is not limited to the following: Air Traffic Control Assigned Airspace (ATCAA), Altitude Reservations (ALTRV), Military Training Routes (MTR), Air Refueling Tracks and Anchors, Temporary Flight Restrictions (TFR), Special Security Instructions (SSI), etc. Special Use Airspace (SUA) is a subset of Special Activity Airspace.

(See SPECIAL USE AIRSPACE.)

SPECIAL AIR TRAFFIC RULES (SATR)– Rules that govern procedures for conducting flights in certain areas listed in 14 CFR Part 93. The term “SATR” is used in the United States to describe the rules for operations in specific areas designated in the Code of Federal Regulations.

(Refer to 14 CFR Part 93.)

SPECIAL EMERGENCY– A condition of air piracy or other hostile act by a person(s) aboard an aircraft which threatens the safety of the aircraft or its passengers.

SPECIAL FLIGHT RULES AREA (SFRA)– An area in the NAS, described in 14 CFR Part 93, wherein the flight of aircraft is subject to special traffic rules, unless otherwise authorized by air traffic control. Not all areas listed in 14 CFR Part 93 are designated SFRA, but special air traffic rules apply to all areas described in 14 CFR Part 93.

SPECIAL INSTRUMENT APPROACH PROCEDURE–

(See INSTRUMENT APPROACH PROCEDURE.)

SPECIAL USE AIRSPACE– Airspace of defined dimensions identified by an area on the surface of the earth wherein activities must be confined because of their nature and/or wherein limitations may be imposed upon aircraft operations that are not a part of those activities. Types of special use airspace are:

a. Alert Area– Airspace which may contain a high volume of pilot training activities or an unusual type of aerial activity, neither of which is hazardous to aircraft. Alert Areas are depicted on aeronautical charts for the information of nonparticipating pilots. All activities within an Alert Area are conducted in accordance with Federal Aviation Regulations, and pilots of participating aircraft as well as pilots transiting the area are equally responsible for collision avoidance.

b. Controlled Firing Area– Airspace wherein activities are conducted under conditions so controlled as to eliminate hazards to nonparticipating aircraft and to ensure the safety of persons and property on the ground.

c. Military Operations Area (MOA)– Permanent and temporary MOAs are airspace established outside of Class A airspace area to separate or segregate certain nonhazardous military activities from IFR traffic and to identify for VFR traffic where these activities are conducted. Permanent MOAs are depicted on Sectional Aeronautical, VFR Terminal Area, and applicable En Route Low Altitude Charts.

Note: Temporary MOAs are not charted.

(Refer to AIM.)

d. National Security Area (NSA)– Airspace of defined vertical and lateral dimensions established at locations where there is a requirement for increased security of ground facilities. Pilots are requested to voluntarily avoid flying through the depicted NSA. When a greater level of security is required, flight through an NSA may be temporarily prohibited by establishing a TFR under the provisions of 14 CFR Section 99.7. Such prohibitions will be issued by FAA Headquarters and disseminated via the U.S. NOTAM System.

(Refer to AIM)

e. Prohibited Area– Airspace designated under 14 CFR Part 73 within which no person may operate an aircraft without the permission of the using agency.

(Refer to AIM.)

(Refer to En Route Charts.)

f. Restricted Area– Permanent and temporary restricted areas are airspace designated under 14 CFR Part 73, within which the flight of aircraft, while not wholly prohibited, is subject to restriction. Most restricted areas are designated joint use and IFR/VFR operations in the area may be authorized by the controlling ATC facility when it is not being utilized by the using agency. Permanent restricted areas are depicted on Sectional Aeronautical, VFR Terminal Area, and applicable En Route charts. Where joint use is authorized, the name of the ATC controlling facility is also shown.

Note: Temporary restricted areas are not charted.

(Refer to 14 CFR Part 73.)

(Refer to AIM.)

g. Warning Area– A warning area is airspace of defined dimensions extending from 3 nautical miles outward from the coast of the United States, that contains activity that may be hazardous to nonparticipating aircraft. The purpose of such warning area is to warn nonparticipating pilots of the potential danger. A warning area may be located over domestic or international waters or both.

SPECIAL VFR CONDITIONS– Meteorological conditions that are less than those required for basic VFR flight in Class B, C, D, or E surface areas and in which some aircraft are permitted flight under visual flight rules.

(See SPECIAL VFR OPERATIONS.)

(Refer to 14 CFR Part 91.)

SPECIAL VFR FLIGHT [ICAO]– A VFR flight cleared by air traffic control to operate within Class B, C, D, and E surface areas in meteorological conditions below VMC.

SPECIAL VFR OPERATIONS– Aircraft operating in accordance with clearances within Class B, C, D, and E surface areas in weather conditions less than the basic VFR weather minima. Such operations must be requested by the pilot and approved by ATC.

(See SPECIAL VFR CONDITIONS.)

(See ICAO term SPECIAL VFR FLIGHT.)

SPECIALIST–PROVIDED SERVICES–

Services delivered directly by a flight service specialist via ground/ground communication, air/ground communication, in-person, or technology (for example, speech-to-text, email, or short message service).

SPEED–

(See AIRSPEED.)

(See GROUND SPEED.)

SPEED ADJUSTMENT– An ATC procedure used to request pilots to adjust aircraft speed to a specific value for the purpose of providing desired spacing. Pilots are expected to maintain a speed of plus or minus 10 knots or 0.02 Mach number of the specified speed. Examples of speed adjustments are:

a. “Increase/reduce speed to Mach point (number).”

b. “Increase/reduce speed to (speed in knots)” or “Increase/reduce speed (number of knots) knots.”

SPEED BRAKES– Moveable aerodynamic devices on aircraft that reduce airspeed during descent and landing.

SPEED SEGMENTS– Portions of the arrival route between the transition point and the vertex along the optimum flight path for which speeds and altitudes are specified. There is one set of arrival speed segments adapted from each transition point to each vertex. Each set may contain up to six segments.

SPOOFING– Denotes emissions of GNSS-like signals that may be acquired and tracked in combination with or instead of the intended signals by civil receivers. The onset of spoofing effects can be instantaneous or delayed, and effects can persist after the spoofing has ended. Spoofing can result in false and potentially confusing, or hazardingly misleading, position, navigation, and/or date/time information in addition to loss of GNSS use.

SPEED ADVISORY– Speed advisories that are generated within Time-Based Flow Management to assist controllers to meet the Scheduled Time of Arrival (STA) at the meter fix/meter arc. See also Ground-Based Interval Management–Spacing (GIM–S) Speed Advisory.

SQUAWK (Mode, Code, Function)– Used by ATC to instruct a pilot to activate the aircraft transponder and ADS–B Out with altitude reporting enabled, or (military) to activate only specific modes, codes, or functions. Examples: “Squawk five seven zero seven;” “Squawk three/alpha, two one zero five.”

(See TRANSPONDER.)

STA–

(See SCHEDULED TIME OF ARRIVAL.)

STAGING/QUEUING– The placement, integration, and segregation of departure aircraft in designated movement areas of an airport by departure fix, EDCT, and/or restriction.

STAND BY– Means the controller or pilot must pause for a few seconds, usually to attend to other duties of a higher priority. Also means to wait as in “stand by for clearance.” The caller should reestablish contact if a delay is lengthy. “Stand by” is not an approval or denial.

STANDARD INSTRUMENT APPROACH PROCEDURE (SIAP)–

(See INSTRUMENT APPROACH PROCEDURE.)

STANDARD INSTRUMENT DEPARTURE (SID)– A preplanned instrument flight rule (IFR) air traffic control (ATC) departure procedure printed for pilot/controller use in graphic form to provide obstacle clearance and a transition from the terminal area to the appropriate en route structure. SIDs are primarily designed for system enhancement to expedite traffic flow and to reduce pilot/controller workload. ATC clearance must always be received prior to flying a SID.

(See IFR TAKEOFF MINIMUMS AND DEPARTURE PROCEDURES.)

(See OBSTACLE DEPARTURE PROCEDURE.)

(Refer to AIM.)

STANDARD RATE TURN– A turn of three degrees per second.

STANDARD TERMINAL ARRIVAL (STAR)– A preplanned instrument flight rule (IFR) air traffic control arrival procedure published for pilot use in graphic and/or textual form. STARS provide transition from the en route structure to an outer fix or an instrument approach fix/arrival waypoint in the terminal area.

STANDARD TERMINAL ARRIVAL CHARTS–

(See AERONAUTICAL CHART.)

STANDARD TERMINAL AUTOMATION REPLACEMENT SYSTEM (STARS)–

(See DTAS.)

STAR–

(See STANDARD TERMINAL ARRIVAL.)

STATE AIRCRAFT– Aircraft used in military, customs and police service, in the exclusive service of any government or of any political subdivision thereof, including the government of any state, territory, or possession of the United States or the District of Columbia, but not including any government-owned aircraft engaged in carrying persons or property for commercial purposes.

STATIC RESTRICTIONS– Those restrictions that are usually not subject to change, fixed, in place, and/or published.

STATIONARY AIRSPACE RESERVATION– The term used in oceanic ATC for airspace that encompasses activities in a fixed volume of airspace to be occupied for a specified time period. Stationary Airspace Reservations may include activities such as special tests of weapons systems or equipment; certain U.S. Navy carrier, fleet, and anti–submarine operations; rocket, missile, and drone operations; and certain aerial refueling or similar operations.

(See STATIONARY ALTITUDE RESERVATION.)

STATIONARY ALTITUDE RESERVATION (STATIONARY ALTRV)– An altitude reservation which encompasses activities in a fixed volume of airspace to be occupied for a specified time period. Stationary ALTRVs may include activities such as special tests of weapons systems or equipment; certain U.S. Navy carrier, fleet, and anti–submarine operations; rocket, missile, and drone operations; and certain aerial refueling or similar operations.

STEP TAXI– To taxi a float plane at full power or high RPM.

STEP TURN– A maneuver used to put a float plane in a planing configuration prior to entering an active sea lane for takeoff. The STEP TURN maneuver should only be used upon pilot request.

STEPDOWN FIX– A fix permitting additional descent within a segment of an instrument approach procedure by identifying a point at which a controlling obstacle has been safely overflown.

STEREO ROUTE– A routinely used route of flight established by users and ARTCCs identified by a coded name; e.g., ALPHA 2. These routes minimize flight plan handling and communications.

STNR ALT RESERVATION– An abbreviation for Stationary Altitude Reservation commonly used in NOTAMs.

(See STATIONARY ALTITUDE RESERVATION.)

STOL AIRCRAFT–

(See SHORT TAKEOFF AND LANDING AIRCRAFT.)

STOP ALTITUDE SQUAWK– Used by ATC to instruct a pilot to turn off the automatic altitude reporting feature of the aircraft transponder and ADS–B Out. It is issued when a verbally reported altitude varies by 300 feet or more from the automatic altitude report.

(See ALTITUDE READOUT.)

(See TRANSPONDER.)

STOP AND GO– A procedure wherein an aircraft will land, make a complete stop on the runway, and then commence a takeoff from that point.

(See LOW APPROACH.)

(See OPTION APPROACH.)

STOP BURST–

(See STOP STREAM.)

STOP BUZZER–

(See STOP STREAM.)

STOP SQUAWK (Mode or Code)– Used by ATC to instruct a pilot to stop transponder and ADS–B transmissions, or to turn off only specified functions of the aircraft transponder (military).

(See STOP ALTITUDE SQUAWK.)

(See TRANSPONDER.)

STOP STREAM– Used by ATC to request a pilot to suspend electronic attack activity.

(See JAMMING.)

STOPOVER FLIGHT PLAN– A flight plan format which permits in a single submission the filing of a sequence of flight plans through interim full-stop destinations to a final destination.

STOPWAY– An area beyond the takeoff runway no less wide than the runway and centered upon the extended centerline of the runway, able to support the airplane during an aborted takeoff, without causing structural damage to the airplane, and designated by the airport authorities for use in decelerating the airplane during an aborted takeoff.

STRAIGHT-IN APPROACH IFR– An instrument approach wherein final approach is begun without first having executed a procedure turn, not necessarily completed with a straight-in landing or made to straight-in landing minimums.

(See **LANDING MINIMUMS**.)

(See **STRAIGHT-IN APPROACH VFR**.)

(See **STRAIGHT-IN LANDING**.)

STRAIGHT-IN APPROACH VFR– Entry into the traffic pattern by interception of the extended runway centerline (final approach course) without executing any other portion of the traffic pattern.

(See **TRAFFIC PATTERN**.)

STRAIGHT-IN LANDING– A landing made on a runway aligned within 30° of the final approach course following completion of an instrument approach.

(See **STRAIGHT-IN APPROACH IFR**.)

STRAIGHT-IN LANDING MINIMUMS–

(See **LANDING MINIMUMS**.)

STRAIGHT-IN MINIMUMS–

(See **STRAIGHT-IN LANDING MINIMUMS**.)

STRATEGIC PLANNING– Planning whereby solutions are sought to resolve potential conflicts.

sUAS–

(See **SMALL UNMANNED AIRCRAFT SYSTEM**.)

SUBSTITUTE ROUTE– A route assigned to pilots when any part of an airway or route is unusable because of NAVAID status. These routes consist of:

- a. Substitute routes which are shown on U.S. Government charts.
- b. Routes defined by ATC as specific NAVAID radials or courses.
- c. Routes defined by ATC as direct to or between NAVAIDs.

SUNSET AND SUNRISE– The mean solar times of sunset and sunrise as published in the Nautical Almanac, converted to local standard time for the locality concerned. Within Alaska, the end of evening civil twilight and the beginning of morning civil twilight, as defined for each locality.

SUPPLEMENTAL WEATHER SERVICE LOCATION– Airport facilities staffed with contract personnel who take weather observations and provide current local weather to pilots via telephone or radio. (All other services are provided by the parent FSS.)

SUPPS– Refers to ICAO Document 7030 Regional Supplementary Procedures. SUPPS contain procedures for each ICAO Region which are unique to that Region and are not covered in the worldwide provisions identified in the ICAO Air Navigation Plan. Procedures contained in Chapter 8 are based in part on those published in SUPPS.

SURFACE AREA– The airspace contained by the lateral boundary of the Class B, C, D, or E airspace designated for an airport that begins at the surface and extends upward.

SURFACE METERING PROGRAM– A capability within Terminal Flight Data Manager that provides the user with the ability to tactically manage surface traffic flows through adjusting desired minimum and maximum departure queue lengths to balance surface demand with capacity. When a demand/capacity imbalance for a surface resource is predicted, a metering procedure is recommended.

SURFACE VIEWER– A capability within the Traffic Flow Management System that provides situational awareness for a user-selected airport. The Surface Viewer displays a top-down view of an airport depicting runways, taxiways, gate areas, ramps, and buildings. The display also includes icons representing aircraft and vehicles currently on the surface, with identifying information. In addition, the display includes current airport configuration information such as departure/arrival runways and airport departure/arrival rates.

SURPIC– A description of surface vessels in the area of a Search and Rescue incident including their predicted positions and their characteristics.

(Refer to FAA Order JO 7110.65, Para 10–6–4, INFLIGHT CONTINGENCIES.)

SURVEILLANCE APPROACH– An instrument approach wherein the air traffic controller issues instructions, for pilot compliance, based on aircraft position in relation to the final approach course (azimuth), and the distance (range) from the end of the runway as displayed on the controller’s radar scope. The controller will provide recommended altitudes on final approach if requested by the pilot.

(Refer to AIM.)

SURVEILLANCE ENHANCED SEARCH AND RESCUE (SE SAR)– An automated service used to enhance search and rescue operations that provides federal contract flight service specialists direct information from the aircraft’s registered tracking device.

SUSPICIOUS UAS– Suspicious UAS operations may include operating without authorization, loitering in the vicinity of sensitive locations, (e.g., national security, law enforcement facilities, and critical infrastructure), or disrupting normal air traffic operations resulting in runway changes, ground stops, pilot evasive action, etc. The report of a UAS operation alone does not constitute suspicious activity. Development of a comprehensive list of suspicious activities is not possible due to the vast number of situations that could be considered suspicious. ATC must exercise sound judgment when identifying situations that could constitute or indicate a suspicious activity.

SWAP–

(See SEVERE WEATHER AVOIDANCE PLAN.)

SWSL–

(See SUPPLEMENTAL WEATHER SERVICE LOCATION.)

SYSTEM STRATEGIC NAVIGATION– Military activity accomplished by navigating along a preplanned route using internal aircraft systems to maintain a desired track. This activity normally requires a lateral route width of 10 NM and altitude range of 1,000 feet to 6,000 feet AGL with some route segments that permit terrain following.

ground-based air traffic surveillance sensors, typically from radar targets. TIS-B service will be available throughout the NAS where there are both adequate surveillance coverage (radar) and adequate broadcast coverage from ADS-B ground stations. Loss of TIS-B will occur when an aircraft enters an area not covered by the GBT network. If this occurs in an area with adequate surveillance coverage (radar), nearby aircraft that remain within the adequate broadcast coverage (ADS-B) area will view the first aircraft. TIS-B may continue when an aircraft enters an area with inadequate surveillance coverage (radar); nearby aircraft that remain within the adequate broadcast coverage (ADS-B) area will not view the first aircraft.

TRAFFIC IN SIGHT– Used by pilots to inform a controller that previously issued traffic is in sight.

(See NEGATIVE CONTACT.)

(See TRAFFIC ADVISORIES.)

TRAFFIC MANAGEMENT INITIATIVE (TMI)– Tools used to manage demand with capacity in the National Airspace System (NAS.) TMIs can be used to manage NAS resources (e.g., airports, sectors, airspace) or to increase the efficiency of the operation. TMIs can be either tactical (i.e., short term) or strategic (i.e., long term), depending on the type of TMI and the operational need.

TRAFFIC MANAGEMENT PROGRAM ALERT– A term used in a Notice to Air Missions (NOTAM) issued in conjunction with a special traffic management program to alert pilots to the existence of the program and to refer them to a special traffic management program advisory message for program details. The contraction TMPA is used in NOTAM text.

TRAFFIC MANAGEMENT UNIT– The entity in ARTCCs and designated terminals directly involved in the active management of facility traffic. Usually under the direct supervision of an assistant manager for traffic management.

TRAFFIC NO FACTOR– Indicates that the traffic described in a previously issued traffic advisory is no factor.

TRAFFIC NO LONGER OBSERVED– Indicates that the traffic described in a previously issued traffic advisory is no longer depicted on radar, but may still be a factor.

TRAFFIC PATTERN– The traffic flow that is prescribed for aircraft landing at, taxiing on, or taking off from an airport. The components of a typical traffic pattern are upwind leg, crosswind leg, downwind leg, base leg, and final approach.

- a. Upwind Leg– A flight path parallel to the landing runway in the direction of landing.
- b. Crosswind Leg– A flight path at right angles to the landing runway off its upwind end.
- c. Downwind Leg– A flight path parallel to the landing runway in the direction opposite to landing. The downwind leg normally extends between the crosswind leg and the base leg.
- d. Base Leg– A flight path at right angles to the landing runway off its approach end. The base leg normally extends from the downwind leg to the intersection of the extended runway centerline.

NOTE–

ATC may instruct a pilot to report a “2-mile left base” to Runway 22. This instruction means that the pilot is expected to maneuver their aircraft into a left base leg that will intercept a straight-in final 2 miles from the approach end of Runway 22 and advise ATC.

REFERENCE–

Pilot's Handbook of Aeronautical Knowledge, FAA-H-8083-25, Chapter 14, Airport Operations, Traffic Patterns.

- e. Final Approach– A flight path in the direction of landing along the extended runway centerline. The final approach normally extends from the base leg to the runway. An aircraft making a straight-in approach VFR is also considered to be on final approach.

NOTE–

ATC may instruct a pilot to report “5-mile final” to Runway 22. This instruction means that the pilot should maneuver their aircraft onto a straight-in final and advise ATC when they are five miles from the approach end of Runway 22.

REFERENCE-

■ *Pilot's Handbook of Aeronautical Knowledge, FAA-H-8083-25, Chapter 14, Airport Operations, Traffic Patterns.*

(See STRAIGHT-IN APPROACH VFR.)

(See TAXI PATTERNS.)

(See ICAO term AERODROME TRAFFIC CIRCUIT.)

(Refer to 14 CFR Part 91.)

(Refer to AIM.)

TRAFFIC SITUATION DISPLAY (TSD)– TSD is a computer system that receives radar track data from all 20 CONUS ARTCCs, organizes this data into a mosaic display, and presents it on a computer screen. The display allows the traffic management coordinator multiple methods of selection and highlighting of individual aircraft or groups of aircraft. The user has the option of superimposing these aircraft positions over any number of background displays. These background options include ARTCC boundaries, any stratum of en route sector boundaries, fixes, airways, military and other special use airspace, airports, and geopolitical boundaries. By using the TSD, a coordinator can monitor any number of traffic situations or the entire systemwide traffic flows.

TRAJECTORY– A EDST representation of the path an aircraft is predicted to fly based upon a Current Plan or Trial Plan.

(See EN ROUTE DECISION SUPPORT TOOL.)

TRAJECTORY-BASED OPERATIONS (TBO)– An Air Traffic Management method for strategically planning and managing flights throughout the operation by using Time-Based Management (TBM), information exchange between air and ground systems, and the aircraft's ability to fly trajectories in time and space. Aircraft trajectory is defined in four dimensions – latitude, longitude, altitude, and time.

TRAJECTORY MODELING– The automated process of calculating a trajectory.

TRAJECTORY OPTIONS SET (TOS)– A TOS is an electronic message, submitted by the operator, that is used by the Collaborative Trajectory Options Program (CTOP) to manage the airspace captured in the traffic management program. The TOS will allow the operator to express the route and delay trade-off options that they are willing to accept.

TRANSFER OF CONTROL– That action whereby the responsibility for the separation of an aircraft is transferred from one controller to another.

(See ICAO term TRANSFER OF CONTROL.)

TRANSFER OF CONTROL [ICAO]– Transfer of responsibility for providing air traffic control service.

TRANSFERRING CONTROLLER– A controller/facility transferring control of an aircraft to another controller/facility.

(See ICAO term TRANSFERRING UNIT/CONTROLLER.)

TRANSFERRING FACILITY–

(See TRANSFERRING CONTROLLER.)

TRANSFERRING UNIT/CONTROLLER [ICAO]– Air traffic control unit/air traffic controller in the process of transferring the responsibility for providing air traffic control service to an aircraft to the next air traffic control unit/air traffic controller along the route of flight.

Note: See definition of accepting unit/controller.

TRANSITION– The general term that describes the change from one phase of flight or flight condition to another; e.g., transition from en route flight to the approach or transition from instrument flight to visual flight.

TRANSITION POINT– A point at an adapted number of miles from the vertex at which an arrival aircraft would normally commence descent from its en route altitude. This is the first fix adapted on the arrival speed segments.

TRANSITIONAL AIRSPACE– That portion of controlled airspace wherein aircraft change from one phase of flight or flight condition to another.

TRANSITIONAL HAZARD AREA (THA)– Used by ATC. Airspace normally associated with an Aircraft Hazard Area within which the flight of aircraft is subject to restrictions.

(See AIRCRAFT HAZARD AREA.)

(See CONTINGENCY HAZARD AREA.)

(See REFINED HAZARD AREA.)

TRANSMISSOMETER– An apparatus used to determine visibility by measuring the transmission of light through the atmosphere. It is the measurement source for determining runway visual range (RVR).

(See VISIBILITY.)

TRANSMITTING IN THE BLIND– A transmission from one station to other stations in circumstances where two-way communication cannot be established, but where it is believed that the called stations may be able to receive the transmission.

TRANSPONDER– The airborne radar beacon receiver/transmitter portion of the Air Traffic Control Radar Beacon System (ATCRBS) which automatically receives radio signals from interrogators on the ground, and selectively replies with a specific reply pulse or pulse group only to those interrogations being received on the mode to which it is set to respond.

(See INTERROGATOR.)

(See ICAO term TRANSPONDER.)

(Refer to AIM.)

TRANSPONDER [ICAO]– A receiver/transmitter which will generate a reply signal upon proper interrogation; the interrogation and reply being on different frequencies.

TRANSPONDER CODES–

(See CODES.)

TRANSPONDER OBSERVED – Phraseology used to inform a VFR pilot the aircraft's assigned beacon code and position have been observed. Specifically, this term conveys to a VFR pilot the transponder reply has been observed and its position correlated for transit through the designated area.

TRIAL PLAN– A proposed amendment which utilizes automation to analyze and display potential conflicts along the predicted trajectory of the selected aircraft.

TRSA–

(See TERMINAL RADAR SERVICE AREA.)

TRUST–

(See THE RECREATIONAL UAS SAFETY TEST.)

TSAS–

(See TERMINAL SEQUENCING AND SPACING.)

TSD–

(See TRAFFIC SITUATION DISPLAY.)

TURBOJET AIRCRAFT– An aircraft having a jet engine in which the energy of the jet operates a turbine which in turn operates the air compressor.

TURBOPROP AIRCRAFT– An aircraft having a jet engine in which the energy of the jet operates a turbine which drives the propeller.

TURBULENCE– An atmospheric phenomenon that causes changes in aircraft altitude, attitude, and or airspeed with aircraft reaction depending on intensity. Pilots report turbulence intensity according to aircraft's reaction as follows:

- a. Light – Causes slight, erratic changes in altitude and or attitude (pitch, roll, or yaw).
- b. Moderate– Similar to Light but of greater intensity. Changes in altitude and or attitude occur but the aircraft remains in positive control at all times. It usually causes variations in indicated airspeed.

c. Severe– Causes large, abrupt changes in altitude and or attitude. It usually causes large variations in indicated airspeed. Aircraft may be momentarily out of control.

d. Extreme– The aircraft is violently tossed about and is practically impossible to control. It may cause structural damage.

(See CHOP.)

(Refer to AIM.)

TURN ANTICIPATION– (maneuver anticipation).

TVOR–

(See TERMINAL-VERY HIGH FREQUENCY OMNIDIRECTIONAL RANGE STATION.)

TWO-WAY RADIO COMMUNICATIONS FAILURE–

(See LOST COMMUNICATIONS.)

INDEX

[References are to page numbers]

A

- ABANDONED APPROACH, 7-6-2
- ABBREVIATED DEPARTURE CLEARANCE, 4-3-5
- ABBREVIATED TRANSMISSIONS, 2-4-3
- ABBREVIATIONS, 1-2-4
- ACKNOWLEDGEMENT OF AUTOMATED NOTIFICATION, 13-1-6
- ACL, 13-1-2
- ADDITIONAL SEPARATION FOR FORMATION FLIGHTS, 5-5-8
- ADJACENT AIRPORT OPERATION, 6-1-1
- ADJACENT AIRPORT OPERATIONS, 7-8-2
- ADJACENT AIRSPACE, 5-5-8
- ADJUSTED MINIMUM FLIGHT LEVEL, 4-5-2
- ADS-B Alerts, 5-2-10
- ADS-B OUT OFF OPERATIONS, 5-2-11
- ADS-B Systems, 5-2-1
- ADVANCE DESCENT CLEARANCE, 4-7-2
- AIDC, 8-2-1
- AIR DEFENSE EXERCISE BEACON CODE ASSIGNMENT, 5-2-4
- AIR TRAFFIC SERVICE (ATS) ROUTES, 2-5-1
- AIR TRAFFIC SERVICES INTERFACILITY DATA COMMUNICATIONS, 8-2-1
- AIRBORNE MILITARY FLIGHTS, 2-2-5
- AIRCRAFT BOMB THREATS, 10-2-5
- AIRCRAFT CARRYING DANGEROUS MATERIALS, 9-2-1
- Aircraft Equipment Suffix (Strips), 2-3-10
- AIRCRAFT IDENTIFICATION, 2-4-12
- Aircraft Identity (Strips), 2-3-9
- Aircraft Orientation, 10-2-1
- Aircraft Type (Strips), 2-3-10
- AIRCRAFT TYPES, 2-4-16
- AIRPORT CONDITIONS, 3-3-1, 4-7-7
- AIRPORT GROUND EMERGENCY, 10-1-2
- Airport Lighting, 3-4-1
- Airport Surface Detection Procedures, 3-6-1
 - Radar-Only Mode, 3-6-2
- Airport Traffic Control- Terminal, 3-1-1
- AIRSPACE CLASSES, 2-4-16
- AIRSPACE CLASSIFICATION, 12-1-1
- AIT, 5-4-5
- ALERTING SERVICE AND SPECIAL ASSISTANCE, 10-6-1
- ALNOT, 10-3-2
- ALNOT CANCELLATION, 10-3-3
- ALS INTENSITY SETTINGS, 3-4-3
- ALSF-2/SSALR, 3-4-4
- ALTERNATIVE ROUTES, 4-4-5
- Altimeter Setting (Oceanic), 8-1-1
- ALTIMETER SETTING ISSUANCE BELOW LOWEST USABLE FL, 2-7-1
- Altimeter Settings, 2-7-1
- ALTITUDE AMENDMENTS, 4-2-2
- ALTITUDE AND DISTANCE LIMITATIONS, 4-1-1
- ALTITUDE ASSIGNMENT, 7-5-3
- Altitude Assignment and Verification, 4-5-1
- ALTITUDE ASSIGNMENT FOR MILITARY HIGH ALTITUDE INSTRUMENT APPROACHES, 4-8-9
- ALTITUDE ASSIGNMENTS, 7-7-1
- ALTITUDE CHANGE FOR IMPROVED RECEPTION, 10-2-2
- ALTITUDE CONFIRMATION- MODE C, 5-2-7
- ALTITUDE CONFIRMATION- NON-MODE C, 5-2-8
- ALTITUDE CONFIRMATION- NONRADAR, 4-5-11
- ALTITUDE FILTERS, 5-2-9
- ALTITUDE FOR DIRECTION OF FLIGHT, 7-3-2
- ALTITUDE INFORMATION, 4-5-4, 5-11-1
- ALTITUDE RESTRICTED LOW APPROACH, 3-10-12
- ALTITUDE/FLIGHT LEVEL TRANSITION, 8-5-1
- ALTRV CLEARANCE, 4-2-3
- ALTRV INFORMATION, 2-2-3
- ANNOTATIONS, 1-2-3

[References are to page numbers]

ANTICIPATED ALTITUDE CHANGES, 4-5-11

ANTICIPATING SEPARATION
 Arrival Procedures, 3-10-11
 Departure Procedures, 3-9-5

Approach Clearance Procedures, 4-8-1

APPROACH CONTROL SERVICE FOR VFR
 ARRIVING AIRCRAFT, 7-1-1

APPROACH GUIDANCE TERMINATION, 5-11-2,
 5-12-2

APPROACH INFORMATION, 4-7-5, 4-8-10, 5-10-1

APPROACH INTERVAL, 7-7-2

APPROACH LIGHTS, 3-4-2

APPROACH SEPARATION RESPONSIBILITY, 5-9-6

APPROACH SEQUENCE, 6-7-1

APPROACHES TO MULTIPLE RUNWAYS, 7-4-3

Arctic CTA, 8-10-1

ARRESTING SYSTEM OPERATION, 3-3-4

ARRIVAL INFORMATION, 4-7-4

ARRIVAL INFORMATION BY APPROACH
 CONTROL FACILITIES, 4-7-6

ARRIVAL INSTRUCTIONS, 5-9-2

ARRIVAL MINIMA, 6-1-2

Arrival Procedures, 4-7-1

Arrival Procedures and Separation (ATCT), 3-10-1

ARRIVAL SEPARATION, 3-12-2

ARRIVAL/DEPARTURE RUNWAY VISIBILITY,
 2-8-1

ATC Assigned Airspace, 9-3-1

ATC SECURITY SERVICES FOR THE
 WASHINGTON, DC, SPECIAL FLIGHT RULES
 AREA (DC SFRA), 9-2-5

ATC SERVICE, 2-1-1

ATC SURVEILLANCE SOURCE USE, 5-1-1

ATIS Application, 2-9-1

ATIS Content, 2-9-2

ATIS Procedures, 2-9-1

ATOP – Oceanic, 13-2-1

AUTHORIZED INTERRUPTIONS, 2-4-2

AUTHORIZED RELAYS, 2-4-2

AUTHORIZED TRANSMISSIONS, 2-4-2

AUTOMATED INFORMATION TRANSFER, 5-4-5

AUTOMATIC ALTITUDE REPORTING, 5-2-8

Automation – En Route, 5-13-1

AVOIDANCE OF AREAS OF NUCLEAR
 RADIATION, 9-2-10

AWACS SPECIAL FLIGHTS, 9-2-10

B

Balloons, Unmanned Free, 9-6-1

BEACON CODES FOR PRESSURE SUIT FLIGHTS
 AND FLIGHTS ABOVE FL 600, 5-2-4

Beacon Systems, 5-2-1

BEACON TARGET DISPLACEMENT, 5-5-9

BEACON TERMINATION, 5-2-9

BEACON/ADS-B IDENTIFICATION METHODS,
 5-3-1

Beacon/ADS-B Systems, 5-2-1

BELOW MINIMA REPORT BY PILOT, 4-7-5

BIRD ACTIVITY INFORMATION, 2-1-16

BLUE LIGHTNING EVENTS, 2-1-19

BRAKING ACTION, 3-3-2

BRAKING ACTION ADVISORIES, 3-3-3

C

Canadian Airspace Procedures, 12-1-1

CANCELLATION OF IFR FLIGHT PLAN, 4-2-5

CANCELLATION OF TAKEOFF CLEARANCE,
 3-9-19

Caribbean ICAO Region, 8-8-1

CELESTIAL NAVIGATION TRAINING, 9-2-1

CHARTED VISUAL FLIGHT PROCEDURES
 (CVFP). USA/USN NOT APPLICABLE, 7-4-5

CIRCLING APPROACH, 4-8-9

CLASS A AIRSPACE, 9-7-1

CLASS A AIRSPACE RESTRICTIONS, 7-1-1

CLASS B AIRSPACE, 9-7-1

CLASS B SEPARATION, 7-9-2

Class B Service Area (Terminal), 7-9-1

CLASS C AIRSPACE, 9-7-1

[References are to page numbers]

CLASS C SEPARATION, 7-8-1
 Class C Service (Terminal), 7-8-1
 CLASS C SERVICES, 7-8-1
 CLASS D AIRSPACE, 9-7-1
 CLASS G AIRSPACE, 4-4-5
 CLEARANCE BEYOND FIX, 4-6-2
 CLEARANCE FOR VISUAL APPROACH, 7-4-2
 CLEARANCE INFORMATION (ARRIVALS), 4-7-1
 CLEARANCE ITEMS, 4-2-1, 4-2-4
 CLEARANCE LIMIT, 4-8-9
 CLEARANCE PREFIX, 4-2-1
 CLEARANCE RELAY, 4-2-2
 Clearance Status (Strips), 2-3-11
 CLEARANCE TO HOLDING FIX, 4-6-1
 CLEARANCE VOID TIMES, 4-3-9
 Clearances, 4-2-1
 CLIMB TO VFR, 7-5-4
 CLOSED RUNWAY INFORMATION, 3-3-2
 CLOSED TRAFFIC, 3-10-13
 COAST TRACKS, 5-13-3
 CODE MONITOR, 5-2-5
 COMMUNICATION TRANSFER, 5-12-3
 COMMUNICATIONS CHECK, 5-10-5
 COMMUNICATIONS FAILURE, 10-4-1
 COMMUNICATIONS RELEASE, 4-8-10
 COMPUTER ENTRY OF FLIGHT PLAN INFORMATION, 5-13-2
 COMPUTER MESSAGE VERIFICATION, 2-2-3
 CONFLICT ALERT (CA), 5-13-1
 CONFLICT ALERT/MODE C INTRUDER (MCI) (STARS), 5-14-2
 CONFLICT DETECTION AND RESOLUTION, 13-1-1, 13-2-1
 CONFLICT PROBE-BASED CLEARANCES, 13-1-2
 CONSTRAINTS GOVERNING SUPPLEMENTS AND PROCEDURAL DEVIATIONS, 1-1-3
 CONTINGENCIES IN OCEANIC CONTROLLED AIRSPACE, 8-9-3
 CONTROL ESTIMATES, 8-1-2
 Control Symbology (Strip), 2-3-12
 CONTROL TRANSFER, 2-1-10, 7-6-2
 CONTROLLER INITIATED COAST TRACKS, 5-13-3
 CONTROLLER PILOT DATA LINK COMMUNICATIONS, 13-2-3
 Controller Pilot Data Link Communications (CPDLC), 2-4-5, 4-5-5
 COORDINATE USE OF AIRSPACE, 2-1-9
 COORDINATION BETWEEN LOCAL AND GROUND CONTROLLERS, 3-1-2
 COORDINATION WITH RECEIVING FACILITY, 4-3-11
 COURSE DEFINITIONS, 1-2-2
 COURSE DIVERGENCE, 8-5-1
 CPDLC, 13-2-3
 CROSSING ALTITUDE, 4-1-3
 CURRENCY OF TRAJECTORY INFORMATION, 13-1-6
 CURRENT SETTINGS, 2-7-1
 CVFP, 7-4-5

D

DC SFRA, 9-2-5
 Debris Response Area, 10-5-1
 DEBRIS-GENERATING SPACE LAUNCH, 10-5-1
 DECISION HEIGHT, 5-12-2
 DECISION HEIGHT (DH) NOTIFICATION, 5-12-1
 Decision Support Tools, 13-1-1
 DEGREE-DISTANCE ROUTE DEFINITION FOR MILITARY OPERATIONS, 4-4-4
 DELAY SEQUENCING, 4-3-11
 DELAYS, 4-6-3
 DELIVERY INSTRUCTIONS, 4-2-2
 DEPARTURE AND ARRIVAL, 5-8-6
 DEPARTURE CLEARANCE/COMMUNICATION FAILURE, 12-1-2
 DEPARTURE CLEARANCES, 4-3-1
 DEPARTURE CONTROL INSTRUCTIONS, 3-9-2
 DEPARTURE DELAY INFORMATION, 3-9-2

[References are to page numbers]

DEPARTURE INFORMATION, 3-9-1
 Departure Procedures, 4-3-1
 Departure Procedures and Separation (ATCT), 3-9-1
 DEPARTURE RELEASE, 4-3-9
 DEPARTURE RESTRICTIONS, 4-3-9
 DEPARTURE SEPARATION, 3-12-1
 DEPARTURE TERMINOLOGY, 4-3-1
 DEPARTURES AND ARRIVALS ON PARALLEL OR
 NONINTERSECTING DIVERGING RUNWAYS,
 5-8-6
 DERELICT BALLOONS, 9-6-2
 DESCENT INSTRUCTION, 5-12-1
 DESCENT INSTRUCTIONS, 5-11-1
 DESCENT NOTIFICATION, 5-11-1
 DEVIATION ADVISORIES, 5-1-3
 DIRECT CLEARANCES, 4-4-5
 DISSEMINATING OFFICIAL WEATHER
 INFORMATION, 2-6-7
 DISTANCE FROM TOUCHDOWN, 5-12-2
 DL, 13-1-2
 DME ARC MINIMA, 6-5-2
 DRA, 10-5-1
 DUPLICATE POSITION REPORTS, 6-1-1
 DUTY PRIORITY, 2-1-2

E

E-MSAW, 5-13-1
 EDGE OF SCOPE, 5-5-9
 ELECTRONIC ATTACK (EA) ACTIVITY, 5-1-2
 ELEVATION FAILURE, 5-12-3
 ELT, 10-2-4
 Emergencies, 10-1-1
 EMERGENCY AIRPORT RECOMMENDATION,
 10-2-7
 Emergency Assistance, 10-2-1
 Emergency Autoland, 10-1-1, 10-2-1, 10-2-8
 EMERGENCY CODE ASSIGNMENT, 5-2-2
 Emergency Control Actions, 10-4-1
 EMERGENCY DETERMINATIONS, 10-1-1

EMERGENCY LANDING PATTERN (ELP)
 OPERATIONS, 3-10-14
 EMERGENCY LIGHTING, 3-4-1
 EMERGENCY LOCATOR TRANSMITTER (ELT)
 SIGNALS, 10-2-4
 EMERGENCY OBSTRUCTION VIDEO MAP
 (EOVM), 10-2-8
 Emergency Procedures (Oceanic), 10-6-1
 EMERGENCY SITUATIONS, 10-2-2
 EMPHASIS FOR CLARITY, 2-4-6
 EN ROUTE – DATA BLOCKS, 5-3-3
 En Route Data Entries (Strips), 2-3-3
 EN ROUTE FOURTH LINE DATA BLOCK USAGE,
 5-4-6
 EN ROUTE MINIMUM SAFE ALTITUDE WARNING
 (E-MSAW), 5-13-1
 EN ROUTE OR OCEANIC SECTOR TEAM
 POSITION RESPONSIBILITIES, 2-10-1
 ENTRY OF REPORTED ALTITUDE, 5-13-2
 EOVM, 10-2-8
 EQUIPMENT USAGE, 3-6-1
 ERAM – En Route, 13-1-1
 ERAM COMPUTER ENTRY OF HOLD
 INFORMATION, 5-13-3
 ERAM VISUAL INDICATOR OF SPECIAL
 ACTIVITY AIRSPACE (SAA) STATUS, 5-13-4
 ESTABLISHING TWO-WAY COMMUNICATIONS,
 3-1-8
 ESTABLISHING TWO-WAY COMMUNICATIONS,
 7-8-2
 EVASIVE ACTION MANEUVER, 9-2-11
 EXCEPTIONS, 4-1-2
 EXPEDITIOUS COMPLIANCE, 2-1-4
 EXPERIMENTAL AIRCRAFT OPERATIONS, 9-2-1
 EXPLOSIVE CARGO, 10-5-1
 EXPLOSIVE DETECTION K-9 TEAMS, 10-2-6
 EXTENDED NOTIFICATION, 10-7-1

F

FACILITY IDENTIFICATION, 2-4-11

[References are to page numbers]

FAILED TRANSPONDER OR ADS-B OUT
 TRANSMITTER, 5-2-5
 FAILURE TO DISPLAY ASSIGNED BEACON
 CODE, 5-2-5
 FALSE OR DECEPTIVE COMMUNICATIONS, 2-4-2
 FAMILIARIZATION, 2-6-1
 FAR FIELD MONITOR (FFM) REMOTE STATUS
 UNIT, 3-3-5
 FFM, 3-3-5
 FINAL APPROACH ABNORMALITIES, 5-10-6
 Final Approach Course Interception, 5-9-1
 FINAL APPROACH GUIDANCE, 5-11-2
 FINAL APPROACH OBSTACLE CLEARANCE
 SURFACES, 3-7-8
 FINAL CONTROLLER CHANGEOVER, 5-10-5
 FIX USE, 4-1-3
 FLIGHT CHECK AIRCRAFT, 9-1-1
 FLIGHT DIRECTION, 4-5-1
 Flight Direction Exceptions, 4-5-2
 Flight Plans and Control Information, 2-2-1
 Flight Progress Strips, 2-3-1
 FLIGHT VISIBILITY BELOW ONE MILE, 7-5-5
 FLYNET, 9-2-2
 FORECAST WINDS, 13-1-7
 FORMATION FLIGHTS, 2-1-8
 FORWARD DEPARTURE DELAY INFORMATION,
 4-3-11
 FORWARDING AMENDED AND UTM DATA, 2-2-4
 FORWARDING APPROACH INFORMATION BY
 NONAPPROACH CONTROL FACILITIES,
 3-10-2
 FORWARDING DEPARTURE TIMES, 4-3-12
 FORWARDING FLIGHT PLAN DATA BETWEEN
 U.S. ARTCCs AND CANADIAN ACCs, 2-2-5
 FORWARDING INFORMATION, 2-2-1
 FORWARDING VFR DATA, 2-2-1
 FREQUENCY CHANGES, 10-2-1
 Fuel Dumping, 9-4-1
 FUNCTIONAL USE, 5-14-1
 FURNISH RVR VALUES, 2-8-1

G

General Control, 2-1-1
 GLIDEPATH AND COURSE INFORMATION, 5-12-1
 GLIDEPATH NOTIFICATION, 5-12-1
 GPD, 13-1-7
 Ground Missile Emergencies, 10-7-1
 GROUND OPERATIONS, 3-7-6
 GROUND OPERATIONS RELATED TO
 THREE/FOUR-HOUR TARMAC RULE, 3-1-8
 GROUND OPERATIONS WHEN VOLCANIC ASH IS
 PRESENT, 3-1-8
 GROUND STOP, 4-3-11
 GROUND TRAFFIC MOVEMENT, 3-7-1
 GROUND VISIBILITY BELOW ONE MILE, 7-5-4
 GUIDANCE TO EMERGENCY AIRPORT, 10-2-8

H

HAZARDOUS INFLIGHT WEATHER ADVISORY,
 2-6-7
 Helicopter Arrival Separation, 3-11-3
 HELICOPTER DEPARTURE SEPARATION, 3-11-2
 Helicopter Landing Clearance, 3-11-5
 Helicopter Operations, 3-11-1
 HELICOPTER TAKEOFF CLEARANCE, 3-11-2
 HELICOPTER TRAFFIC, 7-7-1, 7-9-3
 HIGH INTENSITY RUNWAY LIGHTS, 3-4-5
 HIGH SPEED TURNOFF LIGHTS, 3-4-6
 HIJACK, 5-2-2
 HIJACKED AIRCRAFT, 10-2-2
 HIRL, 3-4-5
 HIRL ASSOCIATED WITH MALSR, 3-4-6
 HIRL Changes Affecting RVR, 3-4-6
 HOLD FOR RELEASE, 4-3-9
 HOLDING, 7-6-1, 13-1-2
 Holding Aircraft, 4-6-1
 HOLDING FLIGHT PATH DEVIATION, 4-6-4
 HOLDING INSTRUCTIONS, 4-6-3
 HOLDING PATTERN SURVEILLANCE, 5-1-3

[References are to page numbers]**I**

ICAO PHONETICS, 2-4-6
 IDENTIFICATION, 3-6-1
 IDENTIFICATION STATUS, 5-3-3
 IFR, 4-1-1
 IFR – VFR FLIGHTS, 4-2-4
 IFR AND SVFR MINIMA, 10-7-1
 IFR FLIGHT PROGRESS DATA, 2-2-2
 IFR MILITARY TRAINING ROUTES, 9-2-2
 IFR to VFR Flight Plan Change, 2-2-1
 ILS PROTECTION/CRITICAL AREAS, 4-6-4
 INFLIGHT CONTINGENCIES, 10-6-3
 INFLIGHT DEVIATIONS FROM
 TRANSPONDER/MODE C REQUIREMENTS
 BETWEEN 10,000 FEET AND 18,000 FEET,
 5-2-8
 INFLIGHT EMERGENCIES INVOLVING MILITARY
 FIGHTER-TYPE AIRCRAFT, 10-1-3
 INFLIGHT EQUIPMENT MALFUNCTIONS, 2-1-6
 INFORMATION TO BE FORWARDED TO ARTCC,
 10-3-1
 INFORMATION TO BE FORWARDED TO RCC,
 10-3-2
 INFORMATION USAGE, 3-6-1
 INHIBITING MINIMUM SAFE ALTITUDE
 WARNING (MSAW), 5-14-2
 INITIAL CONTACT, 7-6-1
 Initial Heading, 5-8-1
 INOPERATIVE INTERRAGATOR, 5-2-5
 INOPERATIVE OR MALFUNCTIONING ADS-B
 TRANSMITTER, 5-2-10
 INTERCEPTOR OPERATIONS, 9-2-4
 INTERFACILITY CONNECTIVITY, 13-1-7
 INTERPHONE MESSAGE FORMAT, 2-4-4
 INTERPHONE MESSAGE TERMINATION, 2-4-5
 INTERPHONE TRANSMISSION PRIORITIES, 2-4-3
 INTERPRETATIONS, 1-1-2
 INTERSECTING RUNWAY SEPARATION
 (ARRIVAL), 3-10-4

INTERSECTING RUNWAY/INTERSECTING
 FLIGHT PATH OPERATIONS, 3-9-11

INTERVAL MINIMA, 6-7-3

ISSUANCE OF EFC, 7-7-1

ISSUING WEATHER AND CHAFF AREAS, 2-6-3

J

Jettisoning of External Stores, 9-5-1

K

K-9 Teams, 10-2-6

L

LANDING AREA CONDITION, 3-3-1

LANDING CHECK, 5-10-4

LANDING CLEARANCE, 3-10-9

LANDING CLEARANCE WITHOUT VISUAL
 OBSERVATION, 3-10-11

LANDING INFORMATION, 3-10-1

LAST KNOWN POSITION DETERMINATION,
 10-3-3

Lateral Separation (Nonradar), 6-5-1

Lateral Separation (Oceanic), 8-4-1

LAW ENFORCEMENT MISSIONS, 9-2-6

LEVEL FLIGHT RESTRICTION, 6-7-3

Light Signals (ATCT), 3-2-1

LIGHTING REQUIREMENTS, 10-4-1

LINE UP AND WAIT, 3-9-2

LOA, 1-1-3

LOCAL OPERATIONS, 7-5-3

Longitudinal Separation (Nonradar), 6-4-1

Longitudinal Separation (Oceanic), 8-3-1

LOST COMMUNICATIONS, 5-10-3

LOW APPROACH, 4-8-12

LOW APPROACH AND TOUCH-AND-GO, 5-10-5

Low Level Wind Shear/Microburst Advisories, 3-1-3

LOWEST USABLE FLIGHT LEVEL, 4-5-2

[References are to page numbers]

LUAW, 3-9-2

M

MACH NUMBER TECHNIQUE, 8-3-3
 MALFUNCTIONING INTERROGATOR, 5-2-5
 MALFUNCTIONING TRANSPONDER, 5-2-5
 MALS/ODALS, 3-4-4
 Man-Portable Air Defense Systems (MANPADS) Alert,
 10-2-7
 MANPADS ALERT, 10-2-7
 MANUAL COORDINATION AND THE URET
 COORDINATION MENU, 13-1-2
 MANUAL FIX POSTING, 5-1-4
 MANUAL INPUT OF COMPUTER-ASSIGNED
 BEACON CODES, 2-2-3
 MARSA, 2-1-7
 MEA, 4-5-3
 MEDIUM INTENSITY RUNWAY LIGHTS, 3-4-6
 MERGING TARGET PROCEDURES, 5-1-3
 MILITARY AERIAL REFUELING, 9-2-7
 MILITARY DVFR DEPARTURES, 2-2-1
 MILITARY OPERATIONS ABOVE FL 600, 9-2-8
 MILITARY PROCEDURES, 2-1-8
 MILITARY SINGLE FREQUENCY APPROACHES,
 5-10-7
 MILITARY SPECIAL USE FREQUENCIES, 9-2-9
 MILITARY TURBOJET EN ROUTE DESCENT,
 4-7-3
 MINIMA ALONG OTHER THAN ESTABLISHED
 AIRWAYS OR ROUTES, 6-5-3
 MINIMA ON DIVERGING COURSES, 6-2-1
 MINIMA ON DIVERGING RADIALS, 6-5-1
 MINIMA ON OPPOSITE COURSES, 6-4-8
 MINIMA ON SAME COURSE, 6-2-4
 MINIMA ON SAME, CONVERGING, OR CROSSING
 COURSES, 6-4-1
 MINIMUM EN ROUTE ALTITUDES, 4-5-3
 MINIMUM FUEL, 2-1-6
 MIREL, 3-4-6
 Miscellaneous Operations, 10-5-1

MISSED APPROACH, 4-8-10, 5-10-5
 MISSED APPROACHES, 6-7-3
 MODE C INTRUDER (MCI) ALERT, 5-13-1
 MONITORING RADIOS, 2-4-1
 MSAW, 5-14-2

N

NAT, 8-7-4
 NAVAID FIXES, 2-5-2
 NAVAID MALFUNCTIONS, 2-1-6
 NAVAID TERMS, 2-5-1
 NAVAID Use Limitations, 4-1-1
 NO-GYRO APPROACH, 5-10-2
 NONINTERSECTING CONVERGING RUNWAY
 OPERATIONS, 3-9-13
 Nonradar, 6-1-1
 Nonradar Initial Separation of Departing and Arriving
 Aircraft, 6-3-1
 Nonradar Initial Separation of Successive Departing
 Aircraft, 6-2-1
 Nonradar Timed Approaches, 6-7-1
 NONRECEIPT OF POSITION REPORT, 6-1-1
 NONSTANDARD FORMATION/CELL
 OPERATIONS, 9-2-12
 NORAD SPECIAL FLIGHTS, 9-2-10
 North American ICAO Region, 8-10-1
 NORTH AMERICAN ROUTE PROGRAM (NRP)
 INFORMATION, 2-2-6
 North Atlantic ICAO Region, 8-7-1
 NOTES, 1-2-3
 NRP, 2-2-6
 NUMBER CLARIFICATION, 2-4-11
 NUMBERS USAGE, 2-4-7

O

OBSERVED ABNORMALITIES, 3-1-7
 OBSTRUCTION LIGHTS, 3-4-7
 Oceanic Coordination, 8-2-1

[References are to page numbers]

Oceanic Data Entries, 2-3-4
 OCEANIC ERROR REPORT PROCEDURES, 8-1-1
 Oceanic Procedures, 8-1-1
 Oceanic Transition Procedures, 8-5-1
 OCS, 3-7-8
 Offshore Procedures, 8-1-1
 Offshore Transition Procedures, 8-5-1
 ONE THOUSAND-ON-TOP, 12-1-1
 OPERATIONAL PRIORITY, 2-1-2
 OPERATIONAL REQUESTS, 2-1-12
 OPERATIONS IN OFFSHORE AIRSPACE AREAS,
 8-1-1
 OPPOSITE DIRECTION, 8-5-1
 OTHER CONTROL AIRSPACE, 9-7-1
 OVERDUE AIRCRAFT, 10-3-1, 13-1-6
 OVERDUE AIRCRAFT/OTHER SITUATIONS,
 10-3-1
 OVERHEAD MANEUVER, 3-10-13

P

Pacific ICAO Region, 8-9-1
 PAPI, 3-4-2
 PAR Approaches – Terminal, 5-12-1
 PARACHUTE JUMPING, 12-1-2
 Parachute Operations, 9-7-1
 PASSING OR DIVERGING, 5-5-7
 PHASES OF EMERGENCY, 10-6-1
 PILOT ACKNOWLEDGMENT/READ BACK, 2-4-1
 PILOT DEVIATION NOTIFICATION, 2-1-17
 PIREP SOLICITATION AND DISSEMINATION,
 2-6-1
 POFZ, 3-7-8
 POINT OUT, 5-4-5
 POSITION ADVISORIES, 5-12-2
 Position Determination (Airports), 3-1-3
 POSITION INFORMATION, 5-3-3, 5-10-4
 Position Report (Oceanic), 8-1-1
 POSITION REPORTING (RADAR), 5-1-4

Position Responsibilities, 2-10-1
 PRACTICE APPROACHES, 4-8-11
 PRACTICE PRECAUTIONARY APPROACHES,
 3-10-14
 PREARRANGED COORDINATION, 5-4-6
 PRECISION APPROACH CRITICAL AREA, 3-7-7
 PRECISION APPROACH PATH INDICATORS (PAPI),
 3-4-2
 PRECISION OBSTACLE FREE ZONE, 3-7-8
 PRESENTATION AND EQUIPMENT
 PERFORMANCE, 5-1-1
 PREVENTIVE CONTROL, 3-1-1
 PRIMARY HOST OUTAGES, 13-1-7
 PRIMARY RADAR IDENTIFICATION METHODS,
 5-3-1
 PRIORITY INTERRUPTION, 2-4-3
 PROCEDURAL LETTERS OF AGREEMENT (LOA),
 1-1-3
 PROCEDURAL PREFERENCE, 2-1-2
 PROCEDURES FOR WEATHER DEVIATIONS IN
 NORTH ATLANTIC (NAT) AIRSPACE, 8-7-4
 PROVIDE SERVICE, 3-1-1

Q

QUESTIONABLE IDENTIFICATION, 5-3-2

R

Radar, 5-1-1
 Radar Approaches – Terminal, 5-10-1
 Radar Arrivals, 5-9-1
 RADAR ASSISTANCE TECHNIQUES, 10-2-4
 RADAR ASSISTANCE TO VFR AIRCRAFT IN
 WEATHER DIFFICULTY, 10-2-3
 RADAR BEACON CHANGES FOR MILITARY
 AIRCRAFT, 4-7-2
 RADAR BEACON CODE CHANGES, 5-2-1
 RADAR CONTACT LOST, 5-10-4
 Radar Departures, 5-8-1
 Radar Identification, 5-3-1
 RADAR IDENTIFICATION APPLICATION, 8-5-3

[References are to page numbers]

Radar Separation, 5-5-1
 Radar Separation Application, 5-5-1
 RADAR SEPARATION MINIMA, 5-5-2
 RADAR SEPARATION VERTICAL APPLICATION,
 5-5-6
 RADAR SERVICE TERMINATION, 5-1-4
 RADAR-ONLY MODE, 3-6-2
 Radio and Interphone Communications, 2-4-1
 RADIO COMMUNICATIONS, 2-1-11, 2-4-1
 RADIO FAILURE, 5-2-2
 RADIO FREQUENCY FOR MILITARY AIRCRAFT,
 4-7-2
 RADIO MESSAGE FORMAT, 2-4-2
 RCC, 10-3-3
 Receiver-Only Acknowledgment (ATCT), 3-2-1
 RECEIVING CONTROLLER HANDOFF, 5-4-4
 RECORDING INFORMATION, 2-2-1
 RECORDING OF CONTROL DATA, 13-1-2
 REDUCED VERTICAL SEPARATION MINIMUM
 (RVSM), 2-1-18
 REDUCTION OF ROUTE PROTECTED AIRSPACE,
 8-4-5
 REENTRY VEHICLE MISHAPS, 10-5-1
 REFERENCES, 1-2-3
 REFUSAL OF AVOIDANCE CLEARANCE, 8-6-1
 REIL, 3-4-1
 RELAYED APPROACH CLEARANCE, 4-8-9
 RELEASE TIMES, 4-3-9
 REPORTING DEATH, ILLNESS, OR OTHER
 PUBLIC HEALTH RISK ON BOARD
 AIRCRAFT, 10-2-9
 REPORTING ESSENTIAL FLIGHT INFORMATION,
 2-1-6
 REPORTING WEATHER CONDITIONS, 2-6-3
 RESEARCH AND DEVELOPMENT FLIGHTS, 9-2-2
 RESPONSIBILITY TRANSFER TO RCC, 10-3-3
 RNAV AIRCRAFT ALONG VOR
 AIRWAYS/ROUTES, 6-4-9
 RNAV MINIMA- DIVERGING/CROSSING
 COURSES, 6-5-6
 RNAV VISUAL FLIGHT PROCEDURES (RVFP),
 7-4-5

ROTATING BEACON, 3-4-7
 ROUTE AMENDMENTS, 4-2-2
 Route and NAVAID Description, 2-5-1
 Route Assignment, 4-4-1
 ROUTE STRUCTURE TRANSITIONS, 4-4-3
 ROUTE USE, 4-4-1
 RUNWAY EDGE LIGHTS, 3-4-4
 RUNWAY END IDENTIFIER LIGHTS, 3-4-1
 RUNWAY EXITING, 3-10-11
 RUNWAY PROXIMITY, 3-7-6
 Runway Selection, 3-5-1
 RUNWAY STATUS LIGHTS (RWSL), 3-4-7
 RVFP. *See* RNAV VISUAL FLIGHT PROCEDURES
 (RVFP)
 RVR, 2-8-1
 RVR/RVV, 2-8-1
 RVSM, 2-1-18
 RVSM OPERATIONS, 8-1-2
 RWSL, 3-4-7

S

SAA, 5-13-4
 SAFETY ALERT, 2-1-5
 SAFETY LOGIC ALERT RESPONSES, 3-6-2
 SAFETY MANAGEMENT SYSTEM (SMS), 1-1-4
 SAME DIRECTION, 8-5-2
 SAME RUNWAY SEPARATION, 3-9-5
 SAME RUNWAY SEPARATION (ARRIVAL), 3-10-2
 SAMP Flights, 9-2-10
 SAR, 10-3-1
 SATR, 9-2-4
 Sea Lane Operations, 3-12-1
 Search and Rescue, 10-3-1
 SECNOT, 9-2-6
 SECTOR ELIGIBILITY, 5-13-3
 SECURITY NOTICE (SECNOT), 9-2-6
 SELECTED ALTITUDE LIMITS, 5-13-2

[References are to page numbers]

- SELECTION, 3-5-1
- SENSITIVE GOVERNMENT MISSIONS, 9-2-6
- SEPARATION BY PILOTS, 6-4-9, 6-6-2
- Separation from Airspace Reservations, 8-6-1
- SEPARATION FROM OBSTRUCTIONS, 5-5-8
- SEPARATION METHODS, 6-5-1, 8-4-1
- SEPARATION MINIMA, 6-3-1
- SEQUENCE INTERRUPTION, 6-7-3
- Sequence/Spacing Application, 3-8-1
- SEQUENCED FLASHING LIGHTS (SFL), 3-4-3
- SERVICE PROVIDED WHEN TOWER IS INOPERATIVE, 7-6-3
- SERVICES TO RESCUE AIRCRAFT, 10-6-4
- SFA, 4-7-2
- SFL, 3-4-3
- SFRA, 9-2-5
- SIDE-STEP MANEUVER, 4-8-10
- SIMULATED FLAMEOUT (SFO) APPROACHES, 3-10-14
- SIMULTANEOUS DEPARTURES, 5-8-2
- SIMULTANEOUS DEPENDENT APPROACHES, 5-9-7
- SIMULTANEOUS INDEPENDENT APPROACHES TO WIDELY-SPACED PARALLEL RUNWAYS WITHOUT FINAL MONITORS, 5-9-15
- SIMULTANEOUS INDEPENDENT APPROACHES-DUAL & TRIPLE, 5-9-9
- SIMULTANEOUS INDEPENDENT CLOSE PARALLEL APPROACHES -PRECISION RUNWAY MONITOR (PRM) APPROACHES, 5-9-12
- Simultaneous Landings or Takeoffs (Helicopter), 3-11-5
- SIMULTANEOUS OFFSET INSTRUMENT APPROACHES (SOIA), 5-9-12
- SIMULTANEOUS OPPOSITE DIRECTION OPERATION, 3-8-2
- Simultaneous Same Direction Operation, 3-8-2
- SINGLE FREQUENCY APPROACHES, 4-7-2
- SMOKE COLUMN AVOIDANCE, 10-7-1
- SMS, 1-1-4
- Spacing and Sequencing (ATCT), 3-8-1
- SPECIAL ACTIVITY AIRSPACE, 5-13-4
- SPECIAL AIR TRAFFIC RULES (SATR) AND SPECIAL FLIGHT RULES AREA (SFRA), 9-2-4
- Special Flights, 9-1-1
- SPECIAL HANDLING, 9-1-1
- SPECIAL INTEREST SITES, 9-2-4
- Special Operations, 9-2-1
- Special Use Airspace, 9-3-1
- Special VFR, 7-5-1
- SPECIAL VFR (SVFR), 12-1-2
- SPECIFYING ALTITUDE, 4-8-9
- Speed Adjustment, 5-7-1
- APPLICATION, 5-7-1
- METHODS, 5-7-2
- SPEED ASSIGNMENTS, 5-7-5
- TERMINATION, 5-7-6
- SPEED ASSIGNMENTS, 5-7-5
- Standard Operating Practice (SOP) for Aircraft Deviating for Weather Near Active Special Activity Airspace (SAA), Appendix B-1
- Standard Terminal Automation Replacement System (STARS), 5-14-1
- STANDBY OPERATION, 5-2-4
- STARS, 5-14-1
- STOL RUNWAYS, 3-5-1
- Stop-and-Go Low Approach, 3-8-2
- SUCCESSIVE DEPARTURES, 5-8-2
- SUPERVISORY NOTIFICATION, 2-1-17
- SURFACE AREA RESTRICTIONS, 3-1-7
- SURFACE AREAS, 2-1-10
- Surveillance Approaches - Terminal, 5-11-1
- SURVEILLANCE UNUSABLE, 5-12-3
- SVFR, 7-5-1, 12-1-2
- SWITCHING ILS RUNWAYS, 4-7-8

T

- TAILWIND COMPONENTS, 3-5-1
- TAKEOFF CLEARANCE, 3-9-16
- TARGET RESOLUTION, 5-5-2

[References are to page numbers]

TARGET SEPARATION, 5-5-2

TAWS, 2-1-19

TAXI AND GROUND MOVEMENT OPERATION, 3-11-1

TAXI AND GROUND MOVEMENT OPERATIONS, 3-7-2

Taxi and Ground Movement Procedures, 3-7-1

TAXIWAY LIGHTS, 3-4-7

TBFM, 11-1-2

TCAS RESOLUTION ADVISORIES, 2-1-17

TEAM RESPONSIBILITIES – MULTIPLE PERSON OPERATION, 13-2-4

TELETYPE FLIGHT DATA FORMAT- U.S. ARTCCs – CANADIAN ACCs, 2-2-5

TEMPORARY MOVING AIRSPACE RESERVATIONS, 8-6-2

TEMPORARY STATIONARY AIRSPACE RESERVATIONS, 8-6-1

TERMINAL – DATA BLOCKS, 5-3-3

TERMINAL AUTOMATION SYSTEMS IDENTIFICATION METHODS, 5-3-2

Terminal Data Entries (Strips), 2-3-5

Terminal Radar Service Area, 7-7-1

TERMINAL RADAR/NONRADAR TEAM POSITION RESPONSIBILITIES, 2-10-3

TERMINOLOGY, 2-8-1

TERMS – TRANSFER OF RADAR IDENTIFICATION, 5-4-1

Terms of Reference, 1-2-1

TERRAIN AWARENESS WARNING SYSTEM (TAWS) ALERTS, 2-1-19

THE AIRCRAFT LIST (ACL), DEPARTURE LIST (DL) AND FLIGHT DATA MANAGEMENT, 13-1-2

THROUGH CLEARANCES, 4-2-3

TIME BASED FLOW MANAGEMENT (TBFM), 11-1-2

TIME CHECK, 6-7-3

TIMELY INFORMATION, 3-3-2

Touch-and-Go Low Approach, 3-8-2

TOUCH-AND-GO, 4-8-12

TOUCHDOWN ZONE LIGHTS, 3-4-5

TOWER CLEARANCE, 5-10-6

TOWER TEAM POSITION RESPONSIBILITIES, 2-10-5

TRACK SEPARATION, 8-4-6

TRACK SUSPEND FUNCTION, 5-14-2

TRAFFIC ADVISORIES, 2-1-14

TRAFFIC INFORMATION, 3-1-3

Traffic Management Procedures, 11-1-1

TRAFFIC RESTRICTIONS, 10-4-1

TRAFFIC RESUMPTION, 10-4-1

TRAFFIC – TRANSFER OF RADAR IDENTIFICATION, 5-4-3

TRANSFER OF CONTROL AND COMMUNICATIONS, 8-2-1

TRANSFER OF JURISDICTION, 4-7-5

Transfer of Position (SOP), Appendix A-1

TRANSFER OF POSITION RESPONSIBILITY, 2-1-16

Transfer of Radar Identification, 5-4-1

TRANSFER OR RADAR IDENTIFICATION – METHODS, 5-4-1

TRANSFERRING CONTROLLER HANDOFF, 5-4-3

TRANSITING ACTIVE SUA/ATCAA, 9-3-3

TRANSITIONAL PROCEDURE, 5-9-16

TRANSMISSION ACKNOWLEDGMENT, 5-10-5

TRANSMIT PROPOSED FLIGHT PLAN, 2-2-3

TRIAL PLANNING, 13-1-1

TRSA, 7-7-1

TRSA DEPARTURE INFORMATION, 7-7-2

TRSA SEPARATION, 7-7-1

TYPES OF SEPARATION, 8-1-1

U

UAS, 2-1-16

UFO, 9-8-1

UNAUTHORIZED LASER ILLUMINATION OF AIRCRAFT, 2-9-3, 10-2-7

Unidentified Flying Object (UFO) Reports, 9-8-1

UNLAWFUL INTERFERENCE, 5-2-2

UNMANNED AIRCRAFT SYSTEM (UAS) ACTIVITY INFORMATION., 2-1-16

[References are to page numbers]

UNMANNED AIRCRAFT SYSTEMS (UAS) LOST LINK, 5-2-2
 Unmanned Free Balloons, 9-6-1
 UNMONITORED NAVAIDS, 4-6-4
 UNSAFE RUNWAY INFORMATION, 3-3-2
 URET AIRSPACE CONFIGURATION ELEMENTS, 13-1-7
 USAF/USN Undergraduate Pilots (Strips), 2-3-10
 USE OF ACTIVE RUNWAYS, 3-1-1
 USE OF GRAPHICS PLAN DISPLAY (GPD), 13-1-7
 USE OF MARSAs, 2-1-7
 USE OF TOWER RADAR DISPLAYS, 3-1-6

V

VALIDATION OF MODE C ALTITUDE READOUT, 5-2-6
 VASI, 3-4-1
 Vectoring, 5-6-1
 VECTORS ACROSS FINAL APPROACH COURSE, 5-9-2
 VECTORS BELOW MINIMUM ALTITUDE, 5-6-3
 VECTORS FOR VISUAL APPROACH, 7-4-1
 VECTORS TO FINAL APPROACH COURSE, 5-9-1
 VEHICLES/EQUIPMENT/PERSONNEL NEAR/ON RUNWAYS, 3-1-2
 VERTICAL APPLICATION EXCEPTIONS, 5-5-6
 Vertical Separation (Nonradar), 6-6-1
 VERTICAL SEPARATION MINIMA, 4-5-1
 VFR – IFR FLIGHTS, 4-2-4
 VFR AIRCRAFT IN CLASS B AIRSPACE, 7-9-1
 VFR AIRCRAFT IN WEATHER DIFFICULTY, 10-2-3
 VFR Basic Radar Service (Terminal), 7-6-1
 VFR CLIMB AND DESCENT, 8-8-4
 VFR CODE ASSIGNMENTS, 5-2-3
 VFR CONDITIONS, 7-1-1

VFR DEPARTURE INFORMATION, 7-6-2
 VFR FLIGHT PLANS, 8-1-1
 VFR MINIMA, 10-7-1
 VFR RELEASE OF IFR DEPARTURE, 4-3-11
 VFR-ON-TOP, 7-3-1
 VFR-ON-TOP (NAVAID), 4-1-3
 Visual, 7-1-1
 VISUAL APPROACH SLOPE INDICATORS, 3-4-1
 Visual Approaches, 7-4-1
 VISUAL HOLDING OF VFR AIRCRAFT, 7-1-2
 VISUAL HOLDING POINTS, 4-6-4
 VISUAL REFERENCE REPORT, 5-11-1
 VISUAL SEPARATION, 7-2-1
 Visual Signals (ATCT), 3-2-1
 VISUALLY SCANNING RUNWAYS, 3-1-7
 VOLCANIC ASH, 10-2-9

W

WAKE TURBULENCE, 2-1-13
 WAKE TURBULENCE CAUTIONARY ADVISORIES, 2-1-13
 WAKE TURBULENCE SEPARATION FOR INTERSECTION DEPARTURES, 3-9-10
 Warning Signal (ATCT), 3-2-1
 WEATHER DEVIATIONS, 8-9-3
 Weather Deviations in North Atlantic (NAT) Airspace, 8-7-4
 Weather Information, 2-6-1
 WEATHER INFORMATION (ARRIVALS), 4-7-4
 WEATHER RECONNAISSANCE FLIGHTS, 9-2-10
 WHEELS DOWN CHECK, 2-1-16
 WITHHOLDING LANDING CLEARANCE, 3-10-11
 WORD MEANINGS, 1-2-1
 Words and Phrases (Communications), 2-4-5

BRIEFING GUIDE

**U.S. DEPARTMENT OF TRANSPORTATION
FEDERAL AVIATION ADMINISTRATION**

Table of Contents

Paragraph Number	Title	Page
2-1-4	OPERATIONAL PRIORITY	BG-3
5-2-15	VALIDATION OF MODE C READOUT	BG-3
5-5-4	MINIMA	BG-4
5-5-9	SEPARATION FROM OBSTRUCTIONS	BG-4
5-9-7	SIMULTANEOUS INDEPENDENT APPROACHES- DUAL & TRIPLE ...	BG-6
7-4-6	RNAV VISUAL FLIGHT PROCEDURES (RVFP)	BG-7

1. PARAGRAPH NUMBER AND TITLE: 2-1-4. OPERATIONAL PRIORITY

2. BACKGROUND: The Department of Defense (DoD) has requested modifications to National Airborne Operations Center (NAOC) and Special Air Missions (SCOOT) mission procedures and information in FAA Orders JO 7610.4, Sensitive Procedures and Requirements for Special Operations; and JO 7110.65, Air Traffic Control.

3. CHANGE:

OLD

2-1-4. OPERATIONAL PRIORITY

Title through e

f. Provide priority handling to NIGHT WATCH aircraft when NAOC (pronounced NA-YOCK) is indicated in the remarks section of the flight plan or in air/ground communications.

NOTE-

The term “NAOC” will not be a part of the call sign but may be used when the aircraft is airborne to indicate a request for special handling.

REFERENCE-

FAA Order JO 7610.4, Para 12-1-1, Applications.

g through i REFERENCE

j. Provide priority handling to Special Air Mission aircraft when SCOOT is indicated in the remarks section of the flight plan or used in air/ground communications.

NOTE-

The term “SCOOT” will not be part of the call sign but may be used when the aircraft is airborne to indicate a request for special handling.

REFERENCE-

FAA Order JO 7610.4, Para 12-6-1, Applications.

NEW

2-1-4. OPERATIONAL PRIORITY

No Change

f. Provide priority handling to NIGHT WATCH **“NAOC” (pronounced NAY-OCK) aircraft when notified via landline or when “NAOC” is used** in air/ground communications. **When the term “NAOC” is used, approve any request(s) as soon as practicable.**

NOTE-

The term “NAOC” will not be a part of the Flight ID in the flight plan or used in conjunction with the call sign but may otherwise be used when the aircraft is airborne.

No Change

No Change

j. Provide priority handling to Special Air Mission **“SCOOT”** aircraft when **notified via landline or when “SCOOT” is used** in air/ground communications. **When the term “SCOOT” is used, approve any request(s) as soon as practicable.**

NOTE-

The term “SCOOT” will not be a part of the Flight ID in the flight plan but may be used during radio communications in conjunction with the call sign.

No Change

1. PARAGRAPH NUMBER AND TITLE: 5-2-15. VALIDATION OF MODE C READOUT

2. BACKGROUND: FAA Order JO 7110.65, paragraph 5-2-15, Validation of Mode C Readout, makes reference to a “Coast/Suspend Tabular List” that is no longer used in ERAM. The reference will be modified/updated accordingly to reflect the current environment.

3. CHANGE:

OLD

5-2-15. VALIDATION OF MODE C READOUT

Ensure that Mode C altitude readouts are valid after accepting an interfacility handoff, initial track start, track start from coast/suspend tabular list, or during and after an unreliable Mode C readout, except as follows:

NEW

5-2-15. VALIDATION OF MODE C ALTITUDE READOUT

a. Ensure that Mode C altitude readouts are valid after:

NOTE-

Consider a Mode C readout unreliable when any condition, not just those that display an indicator in the Data Block, exists that indicates that the Mode C may be in error.

Delete

Add

Add

Add

Add

a. CTRD-equipped tower cabs are not required to validate Mode C altitude readouts after accepting interfacility handoffs from TRACONS according to the procedures in paragraph 5-4-3, Methods, subparagraph a4.

b. ERAM facilities are not required to validate Mode C altitude readouts after accepting interfacility handoffs from other ERAM facilities, except:

1. After initial track start or track start from coast is required, or

2. During and after the display of a missing, unreasonable, exceptional, or otherwise unreliable Mode C readout indicator.

Add

c through **g**

1. Initial track start.

2. Track start from coast/frozen status.

3. During and after an unreliable Mode C readout.

4. Accepting an interfacility handoff, except:

(a) CTRD-equipped tower cabs are not required to validate Mode C altitude readouts after accepting interfacility handoffs from TRACONS according to the procedures in paragraph 5-4-3, Methods, subparagraph a4.

(b) ERAM facilities are not required to validate Mode C altitude readouts after accepting interfacility handoffs from other ERAM facilities, except:

(1) After initial track start or track start from coast is required, or

(2) During and after the display of a missing, unreasonable, exceptional, or otherwise unreliable Mode C readout indicator.

NOTE-

Consider a Mode C readout unreliable when any condition exists that indicates the Mode C may be in error, not just those that display an indicator in the Data Block.

Re-letter as **b** through **f**

1. PARAGRAPH NUMBER AND TITLE:

5-5-4. MINIMA

5-5-9. SEPARATION FROM OBSTRUCTIONS

2. BACKGROUND: The Surveillance Acquisition and Sustainment Group of the Program Management Office (PMO) is undertaking the Mode S Beacon Replacement System (MSBRS) beginning in 2023. This secondary radar refresh seeks the replacement of all legacy Mode S and Condor MK2 beacon systems associated with ASR-8/9 and ASR-11 terminal airport surveillance radar (ASR) systems. The impending replacement requires the relevant provisions in JO 7110.65 to reflect the new system infrastructure. There will be no changes in separation standards as a result of this system replacement.

3. CHANGE:

OLD

5-5-4. MINIMA

Separate aircraft by the following minima:

a. TERMINAL. Single Sensor ASR or Digital Terminal Automation System (DTAS):

NEW

5-5-4. MINIMA

No Change

No Change

NOTE-

1. Includes single sensor long range radar mode.
2. ADS-B and WAM are not selectable sources when in Single Sensor Mode.

No Change

No Change

1. When less than 40 miles from the antenna- 3 miles.

No Change

2. When 40 miles or more from the antenna- 5 miles.

No Change

3. For single sensor ASR-9 with Mode S, when less than 60 miles from the antenna- 3 miles.

3. For single sensor **monopulse secondary surveillance radar (MSSR)**, when less than 60 miles from the antenna- 3 miles.

4. For single sensor ASR-11 MSSR Beacon, when less than 60 miles from the antenna- 3 miles.

Delete

NOTE-

Wake turbulence procedures specify increased separation minima required for certain classes of aircraft because of the possible effects of wake turbulence.

No Change

5. If TRK appears in the data block, handle in accordance with paragraph 5-3-7, Identification Status, subparagraph b, and take appropriate steps to establish nonradar separation.

4. If TRK appears in the data block, handle in accordance with paragraph 5-3-7, Identification Status, subparagraph b, and take appropriate steps to establish nonradar separation.

No Change

NOTE-

TRK appears in the data block whenever the aircraft is being tracked by a radar site other than the radar currently selected. Current equipment limitations preclude a target from being displayed in the single sensor mode; however, a position symbol and data block, including altitude information, will still be displayed. Therefore, low altitude alerts must be provided in accordance with paragraph 2-1-6, Safety Alert.

b through **d3(a)(1)**

No Change

(2) Within 60 NM of the preferred radar when using ASR-9 with Mode S or ASR-11 MSSR Beacon; or

(2) Within 60 NM of the preferred radar when using **an** MSSR; or

d3(a)(1) through **e3(b)**

No Change

(c) Within 40 NM of the sensor or within 60 NM of the sensor when using ASR-9 with Mode S or ASR-11 MSSR Beacon and within the 3 NM separation area.

(c) Within 40 NM of the sensor or within 60 NM of the sensor when using **an** MSSR and within the 3 NM separation area.

e3(d) through **e4**

No Change

(a) Up to and including FL230 within 40 miles from the antenna or within 60 NM when using ASR-9 with Mode S or ASR-11 MSSR Beacon and targets are from the adapted sensor.

(a) Up to and including FL230 within 40 miles from the antenna or within 60 NM when using **an** MSSR and targets are from the adapted sensor.

OLD

5-5-9. SEPARATION FROM OBSTRUCTIONS

a. TERMINAL. Separate aircraft from prominent obstructions depicted on the radar display by the following minima:

1. When less than 40 miles from the antenna- 3 miles.
2. When 40 miles or more from the antenna- 5 miles.
3. For single sensor ASR-9 with Mode S, when less than 60 miles from the antenna - 3 miles.
4. For single sensor ASR-11 MSSR Beacon, when less than 60 miles from the antenna - 3 miles.
5. FUSION:
 - (a) Fusion target symbol - 3 miles.
 - (b) When ISR is displayed - 5 miles.

NOTE-
When operating in FUSION, distances from the antenna listed in paragraph 5-5-9, a1 through a4, do not apply.

a6

NEW

5-5-9. SEPARATION FROM OBSTRUCTIONS

No Change

No Change

No Change

3. For single sensor MSSR, when less than 60 miles from the antenna - 3 miles.

Delete

4. FUSION:
 - No Change
 - No Change

NOTE-
When operating in FUSION, distances from the antenna listed in paragraph 5-5-9, a1 through a3, do not apply.

Renumber as **a5**

1. PARAGRAPH NUMBER AND TITLE: 5-9-7. SIMULTANEOUS INDEPENDENT APPROACHES

2. BACKGROUND: In May 2021, Flight Standards Flight Research and Analysis Branch, AFS-430, completed a supplemental analysis of DOT/FAA/AFS-400/2018/R/22 which provided the foundational analysis for implementation of the revised High Update Rate (HUR) surveillance procedures now published in JO 7110.65 and JO 7210.3. This supplemental analysis was requested after a 2020 safety risk management panel on the subject. It was found that through additional review of ADS-B surveillance accuracy that was not known at the time of the first report, that runway centerline spacing (RCLS) could be further reduced.

3. CHANGE:

OLD

5-9-7. SIMULTANEOUS INDEPENDENT APPROACHES- DUAL & TRIPLE

Title through HIGH UPDATE RATE SURVEILLANCE

b. At locations with high update rate surveillance, simultaneous independent approaches may be conducted where the surveillance update rate is 1 second or faster, the system processing time is 3 seconds or faster, and under the following conditions:

1. Dual parallel runway centerlines are at least 3,200 feet apart, or dual parallel runway centerlines are at least 2,500 feet apart with a 2.5° to 3.0° offset approach to either runway.

NEW

5-9-7. SIMULTANEOUS INDEPENDENT APPROACHES- DUAL & TRIPLE

No Change

b. At locations with high update rate surveillance **capable of update rates of 1.2 seconds or faster, and where fusion display mode is utilized,** simultaneous independent approaches may be conducted under the following conditions:

1. Dual parallel runway centerlines are at least 3,100 feet apart, or dual parallel runway centerlines are at least 2,500 feet apart with a 2.5° to 3.0° offset approach to either runway.

2. Triple parallel runway centerlines are at least 3,400 feet apart, or triple parallel runway centerlines are at least 2,500 feet apart with a 2.5° to 3.0° offset approach to both outside runways, or triple parallel runway centerlines are at least 2,500 feet apart, a single 2.5° to 3.0° offset approach to either outside runway while parallel approaches to the remaining two runways are separated by at least 3,400 feet.

NOTE-
Aircraft without functioning ADS-B Out are restricted from utilizing these high update rate (HUR) procedures unless an alternative HUR surveillance source providing one-second or faster target report updating is utilized.

3. A surveillance update rate of at least 1 second is required for monitoring the no transgression zone (NTZ) when conducting simultaneous independent approaches to the runway centerline spacing (RCLS) provided in this paragraph.

NOTE-
1. HUR procedures cannot be conducted if notified that a one second update rate is not being provided.
2. Where RCLS is ≤ 3400 feet, the normal operating zone (NOZ) is constant at 700 feet; and for RCLS ≥ 3400 feet, the no transgression zone (NTZ) remains constant at 2000 feet.

b4 through c

1. Dual parallel runway centerlines are at least 3,000 and less than 4,300 feet apart.
2. Triple parallel runway centerlines are at least 3,000 but less than 5,000 feet apart.

2. Triple parallel runway centerlines are at least 3,100 feet apart, or triple parallel runway centerlines are at least 2,500 feet apart with a 2.5° to 3.0° offset approach to both outside runways, or triple parallel runway centerlines are at least 2,500 feet apart, **and** a single 2.5° to 3.0° offset approach to either outside runway while parallel approaches to the remaining two runways are separated by at least 3,100 feet.

No Change

3. A surveillance update rate of at least 1.2 seconds is required for monitoring the no transgression zone (NTZ) when conducting simultaneous independent approaches to the runway centerline spacing (RCLS) provided in this paragraph.

NOTE-
1. HUR procedures cannot be conducted if notified that a 1.2-second update rate is not being provided.

No Change

No Change

1. Dual parallel runway centerlines are at least 2,500 and less than 4,300 feet apart.
2. Triple parallel runway centerlines are at least 2,500 but less than 5,000 feet apart.

1. PARAGRAPH NUMBER AND TITLE: 7-4-6. RNAV VISUAL FLIGHT PROCEDURES (RVFP)

2. BACKGROUND: RNAV Visual Flight Procedures (RVFP) have been approved for use in the National Airspace System (NAS) as special procedures by the Flight Standards Service since 2010. These special procedures leverage the navigation data base and automation on board many modern aircraft. Facility personnel are made aware of RVFPs during the design and implementation process. Due to the nature of these procedures, RVFPs can only be issued to authorized operators.

3. CHANGE:

OLD

Add

Add

NEW

7-4-6. RNAV VISUAL FLIGHT PROCEDURES (RVFP)

RNAV Visual Flight Procedures (RVFPs) are special procedures flown in VMC and clear of clouds and used by authorized operators only. Clear an aircraft for an RVFP when:

- Add **a. Requested by the pilot, or if necessary, as addressed in a Letter of Agreement (LOA).**
 - Add **b. The pilot reports the airport in sight or, at locations with an operating control tower, the preceding aircraft in sight.**
 - Add **c. An altitude is assigned at or above the MVA/MIA, before issuing an approach clearance when conducting an RVFP. The pilot should join the RVFP at the beginning of the charted procedure, or if necessary, may join at another waypoint along the path of the charted procedure, except for waypoints beginning or within an RF leg.**
 - Add **d. The official weather at the airport of intended landing indicates VFR and should meet or exceed the ceiling and visibility specified on the RVFP.**
 - Add **e. The published name of the RVFP and the landing runway are specified in the approach clearance.**
 - Add **PHRASEOLOGY-**
(Ident) CLEARED RNAV VISUAL RUNWAY (number) APPROACH
 - Add **NOTE-**
Refer to the facility RVFP LOAs, if applicable, to determine the authorized operators.
 - Add **REFERENCE-**
FAA Order 8260.60, Special Procedures.
 - 7-4-6** Renumber as **7-4-7**
-